



3Com[®] Switch 5500 Family Command Reference Guide

Switch 5500-SI
Switch 5500-EI
Switch 5500G-EI

3Com Corporation
350 Campus Drive
Marlborough, MA
USA 01752-3064

Copyright © 2006, 3Com Corporation. All rights reserved. No part of this documentation may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from 3Com Corporation.

3Com Corporation reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of 3Com Corporation to provide notification of such revision or change.

3Com Corporation provides this documentation without warranty, term, or condition of any kind, either implied or expressed, including, but not limited to, the implied warranties, terms or conditions of merchantability, satisfactory quality, and fitness for a particular purpose. 3Com may make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

If there is any software on removable media described in this documentation, it is furnished under a license agreement included with the product as a separate document, in the hard copy documentation, or on the removable media in a directory file named LICENSE.TXT or !LICENSE.TXT. If you are unable to locate a copy, please contact 3Com and a copy will be provided to you.

UNITED STATES GOVERNMENT LEGEND

If you are a United States government agency, then this documentation and the software described herein are provided to you subject to the following:

All technical data and computer software are commercial in nature and developed solely at private expense. Software is delivered as "Commercial Computer Software" as defined in DFARS 252.227-7014 (June 1995) or as a "commercial item" as defined in FAR 2.101(a) and as such is provided with only such rights as are provided in 3Com's standard commercial license for the Software. Technical data is provided with limited rights only as provided in DFAR 252.227-7015 (Nov 1995) or FAR 52.227-14 (June 1987), whichever is applicable. You agree not to remove or deface any portion of any legend provided on any licensed program or documentation contained in, or delivered to you in conjunction with, this User Guide.

Unless otherwise indicated, 3Com registered trademarks are registered in the United States and may or may not be registered in other countries.

3Com and the 3Com logo are registered trademarks of 3Com Corporation.

Intel and Pentium are registered trademarks of Intel Corporation. Microsoft, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation. Novell and NetWare are registered trademarks of Novell, Inc. UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company, Ltd.

IEEE and 802 are registered trademarks of the Institute of Electrical and Electronics Engineers, Inc.

All other company and product names may be trademarks of the respective companies with which they are associated.

ENVIRONMENTAL STATEMENT

It is the policy of 3Com Corporation to be environmentally friendly in all operations. To uphold our policy, we are committed to:

Establishing environmental performance standards that comply with national legislation and regulations.

Conserving energy, materials and natural resources in all operations.

Reducing the waste generated by all operations. Ensuring that all waste conforms to recognized environmental standards. Maximizing the recyclable and reusable content of all products.

Ensuring that all products can be recycled, reused and disposed of safely.

Ensuring that all products are labelled according to recognized environmental standards.

Improving our environmental record on a continual basis.

End of Life Statement

3Com processes allow for the recovery, reclamation and safe disposal of all end-of-life electronic components.

Regulated Materials Statement

3Com products do not contain any hazardous or ozone-depleting material.

Environmental Statement about the Documentation

The documentation for this product is printed on paper that comes from sustainable, managed forests; it is fully biodegradable and recyclable, and is completely chlorine-free. The varnish is environmentally friendly, and the inks are vegetable-based with a low heavy-metal content.

CONTENTS

ABOUT THIS GUIDE

About This Software Version	5
Organization of the Manual	5
Intended Readership	5
Conventions	5
Related Manuals	6

ALPHABETICAL LISTING OF COMMANDS

COMMANDS

COMMANDS BY FUNCTION

ABOUT THIS GUIDE

This guide provides all the information you need to use the configuration commands supported by version 3.2 software on the 3Com Switch 5500 Family.

About This Software Version

The software in the 3Com Switch 5500 Family is a subset of that used in some other 3Com products. Depending on the capabilities of your hardware platform, some commands described in this guide may not be available on your Switch, although the unavailable commands may still display on the command line interface (CLI). If you try to use an unavailable command, an error message displays.



CAUTION: Any command that displays on the CLI, but is not described in this guide, is not supported in version 3.2 software. 3Com only supports the commands described in this guide. Other commands may result in the loss of data, and are entered at the user's risk.

Organization of the Manual

The Switch 5500 Command Reference list all commands in alphabetical order. A index of commands organized by function is provided at the end of this document.

Intended Readership

The manual is intended for the following readers:

- Network administrators
- Network engineers
- Users who are familiar with the basics of networking

Conventions

This manual uses the following conventions:

Table 1 Icons

Icon	Notice Type	Description
	Information note	Information that describes important features or instructions.
	Caution	Information that alerts you to potential loss of data or potential damage to an application, system, or device.
	Warning	Information that alerts you to potential personal injury.

Table 2 Text conventions

Convention	Description
Screen displays	This typeface represents text as it appears on the screen.
Keyboard key names	If you must press two or more keys simultaneously, the key names are linked with a plus sign (+), for example: Press Ctrl+Alt+Del
The words "enter" and "type"	When you see the word "enter" in this guide, you must type something, and then press Return or Enter. Do not press Return or Enter when an instruction simply says "type."
Fixed command text	This typeface indicates the fixed part of a command text. You must type the command, or this part of the command, exactly as shown, and press <i>Return</i> or <i>Enter</i> when you are ready to enter the command. Example: The command display history-command must be entered exactly as shown.
Variable command text	This typeface indicates the variable part of a command text. You must type a value here, and press <i>Return</i> or <i>Enter</i> when you are ready to enter the command. Example: in the command super level , a value in the range 0 to 3 must be entered in the position indicated by level
{ x y ... }	Alternative items, one of which must be entered, are grouped in braces and separated by vertical bars. You must select and enter one of the items. Example: in the command flow-control {hardware none software} , the braces and the vertical bars combined indicate that you must enter one of the parameters. Enter either hardware , or none , or software .
[]	Items shown in square brackets [] are optional. Example 1: in the command display users [all] , the square brackets indicate that the parameter all is optional. You can enter the command with or without this parameter. Example 2: in the command user-interface [type] first-number [last-number] the square brackets indicate that the parameters [type] and [last-number] are both optional. You can enter a value in place of one, both or neither of these parameters. Alternative items, one of which can optionally be entered, are grouped in square brackets and separated by vertical bars. Example 3: in the command header [shell incoming login] text , the square brackets indicate that the parameters shell , incoming and login are all optional. The vertical bars indicate that only one of the parameters is allowed.

Related Manuals

The *3Com 3Com Switch 5500 Family Getting Started Guide* provides information about installation.

The *3Com 3Com Switch 5500 Family Configuration Guide* provides information about configuring your network using the commands described in this guide.

ALPHABETICAL LISTING OF COMMANDS

abr-summary 28
access-limit 29
accounting domain 32
accounting optional 35
accounting 30
accounting-on enable 33
acl 37
acl 36
active region-configuration 39
add-member 40
address-check 41
administrator-address 42
am enable 43
am ip-pool 44
am trap enable 46
am user-bind 47
apply cost 49
apply poe-profile 50
apply qos-profile interface 53
apply qos-profile 52
apply tag 54
area 55
arp check enable 56
arp static 57
arp static 58
arp timer 60
asbr-summary 61
ascii 62
attribute 63
authentication 65
authentication-mode 67
authentication-mode 68
authorization 69
auto-build 70
auto-execute command 71
backup current-configuration to 72
binary 74
boot attribute-switch 75
boot boot-loader backup-attribute 77
boot boot-loader 76
boot bootrom 78
boot web-package 79
broadcast-suppression 80
broadcast-suppression 81
bsr-policy 82

build 84
bye 85
cache-sa-enable 86
c-bsr 87
cd 89
cdup 90
change self-unit 91
change unit-id 92
check region-configuration 93
checkzero 95
clock datetime 96
clock summer-time 97
clock timezone 99
close 100
cluster enable 102
cluster switch-to 105
cluster 101
cluster-mac syn-interval 104
cluster-mac 103
command-privilege level 106
copy configuration 109
copy 108
count 110
crp-policy 111
c-rp 88
cut connection 113
databits 116
data-flow-format 115
debugging arp packet 119
debugging dhcp client 121
debugging dhcp server 124
debugging dhcp xrn xha 126
debugging dhcp xrn xha 127
debugging dhcp-relay 122
debugging DLDP 128
debugging hwtacacs 129
debugging igmp 130
debugging lacp packet 131
debugging lacp state 132
debugging link-aggregation error 133
debugging link-aggregation event 134
debugging mac-authentication event 135
debugging msdp 136
debugging multicast forwarding 137
debugging multicast kernel-routing 138
debugging multicast status-forwarding 139
debugging ntp-service 140
debugging pim common 141
debugging pim dm 142
debugging pim sm 143
debugging resilient-arp 144

- debugging ssh server 145
- debugging udp-helper 146
- debugging vrrp 147
- debugging webcache 148
- debugging 117
- default cost 149
- default cost 151
- default interval 152
- default limit 153
- default tag 156
- default type 157
- default-cost 150
- default-route-advertise 154
- delete static-routes all 162
- delete 159
- delete 160
- delete-member 161
- delete 158
- description 163
- description 164
- destination-ip 165
- detect-group 166
- detect-list 167
- dhcp enable 168
- dhcp relay information enable 169
- dhcp relay information strategy 170
- dhcp select global 171
- dhcp select interface 173
- dhcp server detect 176
- dhcp server dns-list 177
- dhcp server domain-name 179
- dhcp server expired 181
- dhcp server forbidden-ip 183
- dhcp server ip-pool 186
- dhcp server nbns-list 187
- dhcp server netbios-type 189
- dhcp server option 191
- dhcp server ping 193
- dhcp server static-bind 194
- dhcp server voice-config interface 197
- dhcp server voice-config 195
- dhcp-security static 199
- dhcp-security tracker 200
- dhcp-server ip 185
- dhcp-server 175
- dhcp-snooping trust 202
- dhcp-snooping 201
- dir 205
- dir 203
- disconnect 206
- display acl 207

display am user-bind 209
display am 208
display arp timer aging 212
display arp 210
display boot-loader 213
display bootp client 214
display brief interface 215
display channel 217
display clock 218
display cluster candidates 221
display cluster members 223
display cluster 219
display config-agent 225
display connection 226
display cpu 228
display current-configuration 229
display debugging fabric by-module 235
display debugging ospf 236
display debugging 233
display debugging 234
display detect-group 237
display device 238
display dhcp client 239
display dhcp server conflict 243
display dhcp server expired 244
display dhcp server free-ip 246
display dhcp server ip-in-use 248
display dhcp server statistics 250
display dhcp server tree 252
display dhcp-security 240
display dhcp-server interface vlan-interface 247
display dhcp-server 241
display dhcp-snooping trust 255
display dhcp-snooping 254
display diagnostic-information 256
display dldp 257
display domain 259
display dot1x 260
display drv 262
display fan 263
display fib acl 266
display fib ip-prefix 268
display fib ip_address 267
display fib statistics 269
display fib 264
display fib 265
display ftm 270
display ftp source-ip 273
display ftp-server source-ip 272
display ftp-server 271
display ftp-user 274

- display garp statistics 275
- display garp timer 276
- display gvrp statistics 277
- display gvrp status 278
- display history-command 279
- display hwtacacs 280
- display icmp statistics 281
- display igmp group 283
- display igmp interface 284
- display igmp-snooping configuration 285
- display igmp-snooping group 286
- display igmp-snooping statistics 287
- display info-center 288
- display interface VLAN-interface 292
- display interface 289
- display ip host 293
- display ip interface vlan-interface 294
- display ip ip-prefix 295
- display ip routing-table acl 297
- display ip routing-table ip-prefix 303
- display ip routing-table ip_address1 ip_address2 302
- display ip routing-table ip_address 300
- display ip routing-table protocol 305
- display ip routing-table radix 307
- display ip routing-table statistics 308
- display ip routing-table verbose 309
- display ip routing-table 296
- display ip socket 311
- display ip statistics 313
- display isolate port 315
- display lacp system-id 316
- display link-aggregation interface 317
- display link-aggregation summary 319
- display link-aggregation verbose 320
- display local-server statistics 321
- display local-user 322
- display logbuffer 324
- display loopback-detection 326
- display mac-address aging-time 329
- display mac-address multicast static 330
- display mac-address 327
- display mac-authentication 331
- display memory limit 335
- display memory 333
- display memory 334
- display mirror 336
- display mirroring-group 337
- display mpm 339
- display msdp brief 340
- display msdp peer-status 341
- display msdp sa-cache 342

- display msdp sa-count 344
- display multicast forwarding-table 345
- display multicast routing-table 347
- display multicast-source-deny 349
- display ndp 350
- display ntdp device-list 353
- display ntdp 352
- display ntp-service sessions 355
- display ntp-service status 356
- display ntp-service trace 357
- display ospf abr-asbr 358
- display ospf asbr-summary 359
- display ospf brief 361
- display ospf cumulative 363
- display ospf error 365
- display ospf interface 367
- display ospf lsdb 369
- display ospf nexthop 371
- display ospf peer brief 374
- display ospf peer statistics 375
- display ospf peer 372
- display ospf request-queue 377
- display ospf retrans-queue 378
- display ospf routing 379
- display ospf vlink 380
- display packet-filter 381
- display password-control blacklist 383
- display password-control super 384
- display password-control 382
- display pim bsr-info 385
- display pim interface 386
- display pim neighbor 387
- display pim routing-table 388
- display pim rp-info 390
- display poe interface 391
- display poe power supply 395
- display poe power 393
- display poe-profile 396
- display port vlan-vpn 400
- display port 397
- display port-security 398
- display power 401
- display protocol-priority 402
- display protocol-vlan interface 403
- display protocol-vlan vlan 404
- display qos cos-local-precedence-map 405
- display qos-interface all 406
- display qos-interface line-rate 408
- display qos-interface mirrored-to 409
- display qos-interface traffic-limit 410
- display qos-interface traffic-priority 411

display qos-interface traffic-statistic 412
display qos-profile 413
display queue-scheduler 414
display radius statistics 416
display radius 415
display remote-ping 417
display resilient-arp 420
display rip interface 422
display rip 421
display rmon alarm 423
display rmon event 424
display rmon eventlog 425
display rmon history unit 428
display rmon history 426
display rmon prialarm 429
display rmon statistics unit 432
display rmon statistics 430
display route-policy 433
display rsa local-key-pair public 434
display rsa peer-public-key 435
display saved-configuration 436
display schedule reboot 439
display sftp source-ip 440
display snmp-agent community 442
display snmp-agent group 443
display snmp-agent mib-view 444
display snmp-agent statistics 445
display snmp-agent sys-info 447
display snmp-agent trap-list 448
display snmp-agent usm-user 449
display snmp-agent 441
display snmp-proxy unit 450
display ssh server 451
display ssh server-info 452
display ssh user-information 454
display ssh-server source-ip 453
display ssh2 source-ip 455
display startup 456
display stop-accounting buffer 457
display stp ignored-vlan 460
display stp region-configuration 461
display stp tc 462
display stp 458
display tcp statistics 463
display tcp status 465
display telnet-server source-ip 466
display tftp source-ip 467
display this 468
display time-range 469
display transceiver-information interface 470
display trapbuffer 471

display udp statistics 473
display udp-helper server 472
display unit 474
display user-interface 475
display users 477
display version 478
display vlan 479
display vlan 480
display voice vlan oui 482
display voice vlan status 483
display vrrp 484
display webcache 486
display xrn-fabric 487
lldp authentication-mode 490
lldp interval 491
lldp reset 492
lldp unidirectional-shutdown 493
lldp work-mode 494
lldp 488
dns-list 495
domain 496
domain-name 498
dot1x authentication-method 501
dot1x authentication-method 502
dot1x dhcp-launch 503
dot1x guest-vlan 504
dot1x max-user 506
dot1x port-control 507
dot1x port-method 509
dot1x quiet-period 511
dot1x retry 512
dot1x retry-version-max 513
dot1x supp-proxy-check 514
dot1x timer ver-period 518
dot1x timer 516
dot1x version-check 519
dot1x 499
duplex 520
enable snmp trap updown 521
end-station polling ip-address 522
execute 523
exit 524
expired 525
fabric port enable 526
file prompt 527
filter-policy export 528
filter-policy export 529
filter-policy export 531
filter-policy import 532
filter-policy import 534
filter-policy import 536

fixdisk 538
flow-control 539
flow-control 540
format 541
free user-interface 542
free web-users 543
frequency 544
ftm stacking-vlan 545
ftp cluster 547
ftp dir 550
ftp disconnect 551
ftp server enable 553
ftp source-interface 556
ftp source-ip 557
ftp timeout 558
ftp { cluster | remote-server } source-interface 548
ftp { cluster | remote-server } source-ip 549
ftp 546
ftp-server source-interface 554
ftp-server source-ip 555
ftp-server 552
garp timer leaveall 561
garp timer 559
gateway-list 562
get 563
gratuitous-arp learning enable 564
gvrp registration 566
gvrp 565
header 567
help 570
history-command max-size 571
holdtime 572
host-route 573
hwtacacs nas-ip 574
hwtacacs scheme 575
icmp 576
idle-cut 577
idle-timeout 578
if-match cost 580
if-match interface 581
if-match ip next-hop 582
if-match tag 583
if-match { acl | ip-prefix } 579
igmp enable 584
igmp group-limit 585
igmp group-policy 586
igmp host-join 588
igmp lastmember-queryinterval 589
igmp max-response-time 591
igmp proxy 592
igmp robust-count 593

- igmp timer other-querier-present 603
- igmp timer query 604
- igmp version 605
- igmp-snooping fast-leave 596
- igmp-snooping group-limit 597
- igmp-snooping group-policy 598
- igmp-snooping host-aging-time 600
- igmp-snooping max-response-time 601
- igmp-snooping router-aging-time 602
- igmp-snooping 595
- import-route 607
- import-route 606
- import-source 609
- info-center channel name 610
- info-center console channel 611
- info-center enable 612
- info-center logbuffer 613
- info-center loghost source 616
- info-center loghost 614
- info-center monitor channel 617
- info-center snmp channel 618
- info-center source 619
- info-center switch-on 623
- info-center synchronous 625
- info-center timestamp loghost 627
- info-center timestamp 626
- info-center trapbuffer 628
- instance 629
- interface VLAN-interface 632
- interface 631
- ip address bootp-alloc 635
- ip address dhcp-alloc 636
- ip address 633
- ip host 637
- ip http acl 638
- ip ip-prefix 639
- ip route-static 642
- ip-pool 641
- jumboframe enable 643
- key 644
- lacp enable 645
- lacp port-priority 646
- lacp system-priority 647
- language-mode 648
- lcd 649
- level 650
- line-rate 651
- link-aggregation group agg-id description 652
- link-aggregation group agg-id mode 653
- local-server 654
- local-user password-display mode 656

- local-user 655
- lock 657
- logging-host 658
- loopback 659
- loopback-detection control enable 660
- loopback-detection enable 661
- loopback-detection interval-time 663
- loopback-detection per-vlan enable 664
- ls 665
- mac-address max-mac-count 667
- mac-address multicast interface vlan 668
- mac-address multicast vlan 669
- mac-address timer 670
- mac-address 666
- mac-authentication authmode 673
- mac-authentication authpassword 674
- mac-authentication authusername 675
- mac-authentication domain 676
- mac-authentication timer 677
- mac-authentication 671
- management-vlan 678
- mdi 679
- memory auto-establish disable 680
- memory auto-establish enable 681
- memory { safety | limit } 682
- messenger 684
- mirrored-to 685
- mirroring group 687
- mirroring-group mirroring-port 688
- mirroring-group monitor-port 689
- mirroring-group reflector-port 690
- mirroring-group remote-probe vlan 691
- mirroring-port 692
- mkdir 693
- monitor-port 694
- more 695
- move 696
- msdp 697
- msdp-tracert 698
- multicast route-limit 700
- multicast routing-enable 701
- multicast-source-deny 702
- multicast-suppression 704
- name 705
- nas-ip 706
- nbns-list 707
- ndp enable 708
- ndp timer aging 709
- ndp timer hello 710
- netbios-type 711
- network 712

- nm-interface vlan-interface 714
- nssa 715
- ntdp enable 716
- ntdp explore 717
- ntdp hop 718
- ntdp timer hop-delay 720
- ntdp timer port-delay 721
- ntdp timer 719
- ntp-service access 722
- ntp-service authentication enable 723
- ntp-service authentication-keyid 724
- ntp-service broadcast-client 725
- ntp-service broadcast-server 726
- ntp-service in-interface disable 727
- ntp-service max-dynamic sessions 728
- ntp-service multicast-client 729
- ntp-service multicast-server 730
- ntp-service reliable authentication-keyid 731
- ntp-service source-interface 732
- ntp-service unicast-peer 733
- ntp-service unicast-server 735
- option 737
- originating-rp 738
- ospf authentication-mode 740
- ospf cost 742
- ospf dr-priority 743
- ospf mib-binding 744
- ospf mtu-enable 745
- ospf network-type 746
- ospf timer dead 748
- ospf timer hello 749
- ospf timer poll 750
- ospf timer retransmit 751
- ospf trans-delay 752
- ospf 739
- packet-filter 753
- packet-filter 754
- parity 755
- passive 756
- password 757
- password 758
- password-control enable 762
- password-control super 764
- password-control 759
- peer connect-interface 767
- peer description 768
- peer mesh-group 769
- peer minimum-ttl 770
- peer request-sa-enable 772
- peer sa-cache-maximum 773
- peer sa-policy 774

- peer sa-request-policy 775
- peer-public-key end 771
- peer 765
- peer 766
- pim bsr-boundary 777
- pim dm 778
- pim neighbor-limit 779
- pim neighbor-policy 780
- pim sm 781
- pim timer hello 782
- pim 776
- ping 783
- pki 786
- poe enable 787
- poe legacy enable 788
- poe max power 789
- poe mode 790
- poe power-management 791
- poe priority 792
- poe update 794
- poe-profile 793
- port access vlan 796
- port hybrid protocol-vlan vlan 797
- port hybrid pvid vlan 798
- port hybrid vlan 799
- port isolate 800
- port link-aggregation group 801
- port link-type 802
- port trunk permit vlan 817
- port trunk pvid vlan 818
- port 795
- port-security enable 803
- port-security intrusion-mode 804
- port-security max-mac-count 806
- port-security ntk-mode 807
- port-security OUI 809
- port-security port-mode 810
- port-security timer disableport 813
- port-security trap 814
- port-tagged 816
- preference 819
- preference 820
- primary accounting 821
- primary authentication 822
- primary authorization 823
- priority trust 825
- priority 824
- protocol inbound 826
- protocol-priority protocol-type 827
- protocol-vlan 828
- public-key-code begin 830

public-key-code begin 831
public-key-code end 832
put 833
pwd 834
qos cos-local-precedence-map 839
qos-profile 841
queue-scheduler 835
quit 837
quit 838
radius nas-ip 842
radius scheme 844
radius-scheme 843
reboot member 847
reboot 846
region-name 848
register-policy 849
remotehelp 854
remote-ping 850
remote-ping-agent enable 852
remote-probe vlan 853
remove 855
rename 856
reset acl counter 858
reset arp 859
reset counters interface 860
reset dhcp server conflict 861
reset dhcp server ip-in-use 862
reset dhcp server statistics 863
reset dot1x statistics 864
reset garp statistics 865
reset hwtacacs statistics 866
reset igmp group 867
reset igmp-snooping statistics 868
reset ip statistics 869
reset lacp statistics 870
reset logbuffer 871
reset msdp peer 872
reset msdp sa-cache 873
reset msdp statistics 874
reset multicast forwarding-table 875
reset multicast routing-table 877
reset ndp statistics 878
reset ospf all 879
reset password-control blacklist 880
reset password-control history-record super 882
reset password-control history-record 881
reset pim neighbor 883
reset pim routing-table 884
reset radius statistics 886
reset recycle-bin 887
reset saved-configuration 888

- reset stop-accounting-buffer 890
- reset stp 891
- reset tcp statistics 892
- reset traffic-statistic 893
- reset trapbuffer 895
- reset udp statistics 896
- reset vrrp statistics 897
- reset 857
- resilient-arp enable 898
- resilient-arp interface vlan-interface 899
- restore startup-configuration from 900
- retry realtime-accounting 902
- retry stop-accounting 903
- retry 901
- return 904
- revision-level 905
- rip authentication-mode 907
- rip input 909
- rip metricin 910
- rip metricout 911
- rip output 912
- rip split-horizon 913
- rip version 914
- rip work 915
- rip 906
- rmdir 916
- rmon alarm 917
- rmon event 918
- rmon history 919
- rmon prialarm 920
- rmon statistics 922
- route-policy 923
- router id 925
- rsa local-key-pair create 926
- rsa local-key-pair destroy 928
- rsa peer-public-key 929
- rule 930
- save 934
- schedule reboot at 936
- schedule reboot delay 938
- scheme 940
- screen-length 941
- secondary accounting 942
- secondary authentication 943
- secondary authorization 944
- security-policy-server 945
- self-service-url 946
- send 947
- server-type 948
- service-type multicast 953
- service-type 949

- service-type 951
- set authentication password 954
- set unit name 955
- sftp server enable 958
- sftp source-interface 959
- sftp source-ip 960
- sftp time-out 961
- sftp 956
- shell 962
- shutdown 963
- silent-interface 964
- snmp-agent community 965
- snmp-agent group 968
- snmp-agent group 966
- snmp-agent local-engineid 970
- snmp-agent log 971
- snmp-agent mib-view 972
- snmp-agent packet max-size 973
- snmp-agent sys-info 974
- snmp-agent target-host 975
- snmp-agent trap enable ospf 979
- snmp-agent trap enable 977
- snmp-agent trap life 981
- snmp-agent trap queue-size 982
- snmp-agent trap source 983
- snmp-agent usm-user 986
- snmp-agent usm-user 984
- snmp-host 988
- source-policy 989
- speed 990
- speed 991
- spf-schedule-interval 992
- ssh client assign rsa-key 993
- ssh client first-time enable 994
- ssh server authentication-retries 995
- ssh server rekey-interval 997
- ssh server timeout 999
- ssh user assign rsa-key 1000
- ssh user authentication-type 1001
- ssh user service-type 1003
- ssh user username authentication-type 1004
- ssh-server source-interface 996
- ssh-server source-ip 998
- ssh2 source-interface 1007
- ssh2 source-ip 1008
- ssh2 1005
- standby detect-group 1009
- startup bootrom-access enable 1019
- startup saved-configuration 1020
- state 1010
- state 1011

static-bind ip-address 1013
static-bind mac-address 1015
static-rp 1016
static-rpf-peer 1017
stop-accounting-buffer enable 1022
stopbits 1023
stp bpd protection 1025
stp bridge-diameter 1026
stp cost 1027
stp edged-port 1028
stp ignored vlan 1030
stp interface cost 1032
stp interface edged-port 1034
stp interface loop protection 1036
stp interface mcheck 1037
stp interface point-to-point 1038
stp interface port priority 1040
stp interface root-protection 1041
stp interface transmit-limit 1043
stp interface 1031
stp loop-protection 1044
stp max-hops 1045
stp mcheck 1046
stp mode 1047
stp pathcost-standard 1048
stp point-to-point 1050
stp port priority 1052
stp priority 1053
stp region-configuration 1054
stp root primary 1055
stp root secondary 1058
stp root-protection 1057
stp tc-protection 1060
stp timeout-factor 1061
stp timer forward-delay 1063
stp timer hello 1065
stp timer max-age 1066
stp timer-factor 1062
stp transmit-limit 1067
stp 1024
stub 1068
summary 1069
super password 1071
super 1070
sysname 1072
sysname 1073
sysname 1074
system-view 1075
tcp timer fin-timeout 1076
tcp timer syn-timeout 1077
tcp window 1078

telnet source-interface 1082
telnet source-ip 1083
telnet 1079
telnet-server source-interface 1080
telnet-server source-ip 1081
terminal debugging 1084
terminal logging 1085
terminal monitor 1086
terminal trapping 1087
test-enable 1088
test-type 1089
tftp cluster get 1090
tftp cluster put 1091
tftp get 1092
tftp put 1093
tftp source-interface 1095
tftp source-ip 1096
tftp tftp-server source-interface 1097
tftp tftp-server source-ip 1098
tftp-server 1094
timeout 1101
timer loop 1103
timer quiet 1104
timer realtime-accounting 1105
timer response-timeout 1106
timer retry 1107
timer wait 1108
timer 1102
time-range 1099
timers 1109
tracert 1110
traffic-limit 1114
traffic-limit 1112
traffic-priority 1118
traffic-priority 1116
traffic-redirect 1120
traffic-share-across-interface 1122
traffic-statistic 1123
udp-helper enable 1125
udp-helper port 1126
udp-helper server 1127
undelete 1128
undo snmp-agent 1129
unicast-suppression 1130
update fabric 1131
user privilege level 1136
user 1133
user-interface 1134
user-name-format 1135
verbose 1137
virtual-cable-test 1138

vlan to 1145
vlan-assignment-mode 1141
vlan-mapping modulo 1143
vlan-vpn enable 1146
vlan-vpn inner-cos-trust 1147
vlan-vpn tpid 1148
vlan-vpn tunnel 1149
vlan-vpn uplink enable 1150
vlan 1140
vlink-peer 1151
voice vlan aging 1156
voice vlan enable 1157
voice vlan mac-address 1159
voice vlan mode 1158
voice vlan security enable 1160
voice vlan 1155
voice-config 1153
vrrp authentication-mode 1161
vrrp method 1163
vrrp ping-enable 1164
vrrp vlan-interface vrid track 1165
vrrp vrid preempt-mode 1166
vrrp vrid priority 1167
vrrp vrid timer advertise 1168
vrrp vrid track detect-group 1171
vrrp vrid track 1169
vrrp vrid virtual-ip 1172
wred 1173
xmodem 1174
xrn-fabric authentication-mode 1175

COMMANDS

abr-summary

Purpose	<p>Use the abr-summary command to configure route aggregation on the area border router.</p> <p>Use the undo abr-summary command to disable route aggregation on the area border router. This is the default.</p>								
Syntax	<pre>abr-summary ip_address mask [advertise not-advertise] undo abr-summary ip_address mask</pre>								
Parameters	<table><tr><td><i>ip_address</i></td><td>Specifies a network segment IP address.</td></tr><tr><td><i>mask</i></td><td>Specifies the subnet mask.</td></tr><tr><td>advertise</td><td>Specifies to advertise only the summarized route.</td></tr><tr><td>not advertise</td><td>Specifies to not advertise routes matching the specified IP address and mask.</td></tr></table>	<i>ip_address</i>	Specifies a network segment IP address.	<i>mask</i>	Specifies the subnet mask.	advertise	Specifies to advertise only the summarized route.	not advertise	Specifies to not advertise routes matching the specified IP address and mask.
<i>ip_address</i>	Specifies a network segment IP address.								
<i>mask</i>	Specifies the subnet mask.								
advertise	Specifies to advertise only the summarized route.								
not advertise	Specifies to not advertise routes matching the specified IP address and mask.								
Example	<p>To enter area 1, and then aggregate the network segments, 66.48.10.0 and 66.48.120.0 into the summary route 66.48.0.0, enter the following:</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]router id 1.1.1.1 [SW5500]ospf [SW5500-ospf-1]area 1 [SW5500-ospf-1-area-0.0.0.1]network 66.48.10.0 0.0.0.255 [SW5500-ospf-1-area-0.0.0.1]network 66.48.120.0 0.0.0.255 [SW5500-ospf-1-area-0.0.0.1]abr-summary 66.48.0.0 255.255.0.0</pre>								
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ OSPF Area view								
Description	<p>This command is applicable only to an area border router (ABR) and is used for the route aggregation in an area. The ABR only transmits an aggregated route to other areas. Route aggregation refers to the routing information that is processed in the ABR. For each network segment configured with route aggregation, there is only one route transmitted to other areas.</p>								

access-limit

Purpose Use the `access-limit` command to configure a limit to the amount of supplicants in the current ISP domain.

Syntax `access-limit { disable | enable max-user-number }`

Parameters

<code>disable</code>	No limit to the supplicant number in the current ISP domain. If not specified, disable is selected by default.
<code>enable <i>max-user-number</i></code>	Specifies the maximum supplicant number in the current ISP domain. Valid values are 1 to 1048.

Example Sets a limit of 500 supplicants for the ISP domain, marlboro.net.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]domain marlboro.net
New domain added.
[SW5500-isp-marlboro.net]access-limit enable 500
```

View This command can be used in the following views:

- ISP Domain view

Description This command limits the amount of supplicants contained in the current ISP domain. The supplicants may contend with each other for the network resources. So setting a suitable limit to the amount will guarantee the reliable performance for the existing supplicants.

accounting

Purpose

Use the **accounting** command to configure an accounting scheme for the current ISP domain.

Use the **undo accounting** command to cancel the accounting scheme configuration of the current ISP domain.

Syntax

```
accounting { none | radius-scheme radius-scheme-name }  
undo accounting
```

Parameters

none	Specifies not to perform accounting.
radius-scheme-name	Name of a RADIUS scheme, consisting of a character string no more than 32 characters long.

Default

By default, no accounting scheme is configured for the ISP domain.

Example

Enter system view.

```
<S5500> system-view
```

Create an ISP domain named aabbcc.net.

```
[S5500] domain aabbcc.net  
New Domain added.
```

Specify the scheme radius as the RADIUS accounting scheme that will be referenced by the current ISP domain aabbcc.net.

```
[S5500-isp-aabbcc.net] accounting radius-scheme radius
```

View

This command can be used in the following views:

- ISP Domain view

Description

When you use the **accounting** command to specify a RADIUS scheme to be referenced by the current ISP domain, the RADIUS scheme must have already been defined.

If the **accounting** command is executed in an ISP domain view, the system uses the accounting scheme specified in this command to charge the users in the domain. Otherwise, the system uses the scheme specified in the **scheme** command to charge the users.

Related Command

- `scheme`
- `radius scheme`

accounting domain

Purpose Use the **accounting domain** command to enable the DHCP accounting function.

Use the **undo accounting domain** command to disable the DHCP accounting function.

Syntax

```
accounting domain domain-name  
undo accounting domain
```

Parameters

<i>domain-name</i>	Name of a domain, consisting of a string from 1 to 24 characters long. (You can use the domain command to create a domain.)
--------------------	---

Example

Enter system view.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.
```

Enter DHCP address pool view.

```
[S5500] dhcp server ip-pool test
```

Enable the DHCP accounting function (assuming that domain 123 already exists).

```
[S5500-dhcp-pool-test] accounting domain 123
```

View

This command can be used in the following views:

- DHCP Address Pool view

accounting-on enable

Purpose

Use the **accounting-on enable** command to enable user re-authentication at reboot.

Use the **undo accounting-on enable** command to disable user re-authentication at reboot and restore the default interval and maximum times to transmit Accounting-On packet.

Use the **undo accounting-on send** command to restore the default maximum times to transmit Accounting-On packet.

Use the **undo accounting-on interval** command to restore the default interval to transmit Accounting-On packet.

Syntax

```
accounting-on enable [ send times | interval interval ]
```

```
undo accounting-on { enable | send | interval }
```

Parameters

<i>times</i>	Maximum times to send Accounting-On packet, ranging from 1 to 256. If not specified, the default is 15 times.
<i>interval</i>	Interval to send Accounting-On packet, ranging from 1 to 30. If not specified, the default is 3 (in seconds).

Default

By default, this feature is disabled.

Example

Enter system view.

```
<S5500> system-view
```

Enter the view of the RADIUS scheme named CAMS (supposing this scheme has already existed).

```
[S5500] radius scheme CAMS
```

Enable user re-authentication at reboot.

```
[S5500-radius-CAMS] accounting-on enable
```

View

This command can be used in the following views:

- RADIUS Scheme view

Description

The purpose of this feature is to resolve the following problem: users cannot re-log onto the network after the switch reboots because they are already online. After this feature is enabled, every time the switch reboots:

- The switch generates an Accounting-On packet, which mainly contains the following information: NAS-ID, NAS-IP (source IP address), and session ID.
- The switch sends the Accounting-On packet to the CAMS at regular intervals.
- Once the CAMS receives the Accounting-On packet, it sends a response to the switch. At the same time it finds and deletes the existing online information of the user who was accessing the network through the switch before the reboot based on the NAS-ID, NAS-IP and session ID contained in the Accounting-On packet, and ends the charging of the user according to the last accounting update packet.
- Once the switch receives the response from the CAMS, it stops sending other Accounting-On packets.
- If the switch has tried the set maximum times to transmit the Accounting-On packet but still does not receive any response from the CAMS, it stops the sending of the Accounting-On packet.



*Note: The switch can automatically generate the main attributes (NAS-ID, NAS-IP and session ID) of the Accounting-On packets. However, you can also manually configure the NAS-IP attribute with the **nas-ip** command. When doing this, be sure to configure a correct and valid IP address. If this attribute is not configured manually, the switch will automatically select the IP address of the VLAN interface as the NAS-IP address.*

Related Command

nas-ip

accounting optional

Purpose

Use the **accounting optional** command to enable the selection of the RADIUS accounting option.

Use the **undo accounting optional** command to disable the selection of RADIUS accounting option.

Syntax

```
accounting optional
```

```
undo accounting optional
```

Parameters

None

Default

By default, selection of the RADIUS accounting option is disabled.

Example

Enable the selection of RADIUS accounting of the RADIUS scheme named as CAMS.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]radius scheme cams  
New Radius scheme  
[SW5500-radius-cams]accounting optional
```

View

This command can be used in the following views:

- ISP Domain view

Description

If no RADIUS server is available or if RADIUS accounting server fails when the accounting optional is configured, the user can still use the network resource, otherwise, the user will be disconnected.

The user configured with **accounting optional** command in RADIUS scheme will no longer send real-time accounting update packet or stop accounting packet.

The **accounting optional** command in RADIUS Scheme View is only effective on the accounting that uses this RADIUS scheme.

acl

Purpose

Use the **acl** command to reference ACL and implement the ACL control to the TELNET users.

Use the **undo acl** command to remove the control from the TELNET users.

Syntax

```
acl acl-number { inbound | outbound }
```

```
undo acl { inbound | outbound }
```

Parameters

<i>acl-number</i>	The number identifier of basic and advanced number-based ACLs. Valid values are 2000 to 3999.
<i>inbound</i>	Performs ACL control to the users who access the local Switch using TELNET.
<i>outbound</i>	Performs ACL control to the users who access other Switches from the local Switch using TELNET.

Example

Perform ACL control to the users who access the local Switch using TELNET (basic ACL 2000 has been defined).

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]user-interface vty 0 4  
[SW5500-ui-vty0-4]acl 2000 inbound  
[SW5500-ui-vty0-4]
```

View

This command can be used in the following views:

- User Interface view

acl

Purpose

Use the **acl** command to define an ACL identified by a number, and enter the corresponding ACL View.

Use the **undo acl** command to cancel all sub-items of an ACL identified by a number, or cancel the entire ACL.

Syntax

```
acl number acl-number [ match-order { config | auto } ]
```

```
undo acl { number acl-number | all }
```

Parameters

number <i>acl-number</i>	the sequence number of an Access Control List (ACL), the range is: 2000~2999: Basic ACL. 3000~3999: Advanced ACL. 4000~4999: Layer 2 ACL. 5000~5999: User-defined ACL.
config	Follow the user configuration order to match ACL rules.
auto	Follow the depth-first order to match ACL rules.
all (for the undo command)	Cancel all the ACLs.

Default

By default, the ACLs are matched in **config** order.

Example

Specify depth first order as the match order of number 2000 ACL.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]acl number 2000 match-order auto  
[SW5500-acl-basic-2000]
```

View

This command can be used in the following views:

- System view

Description

After entering a corresponding ACL View, you can use the **rule** command to create sub-items of this ACL (you can exit the ACL View by using the **quit** command).

Using the **match-order**, you can specify whether the match order is the user's configuration order or depth first order (it first matches the rules with a small range); if not specified, then the user's configuration order will be chosen by default. Once the matching order of the ACL is specified, you cannot change the order unless you have cancelled all the sub-items. Note that the ACL matching order is in effect only

when the ACL is employed by the software as a means of data filtering and classification.

Related Command`rule`

active region-configuration

Purpose Use the **active region-configuration** command to activate the settings of an MST (multiple spanning tree) region.

Syntax `active region-configuration`

Parameters None

Example Activate the MST region settings.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500s5500] stp region-configuration
[S5500-mst-region] active region-configuration
```

View This command can be used in the following views:

- MST Region view

Description This command causes the switch to operate with the new MST region settings, when spanning trees are regenerated.

Changes of MST region parameters, especially those of the VLAN mapping tables, can cause MSTP to recalculate the spanning trees, creating network topology jitters across the network. To reduce network topology jitters caused by configuration changes, MSTP does not recalculate the spanning trees immediately in response to region configuration changes. Rather, MSTP brings the configurations into effect only after you activate the new MST region settings or enable MSTP.

Related Commands

- `check region-configuration`
- `instance`
- `region-name`
- `revision-level`
- `vlan-mapping modulo`

add-member

Purpose Use the **add-member** command to add a candidate device to a cluster.

Syntax `add-member [member-number] mac-address H-H-H [password password]`

Parameters	<i>member-number</i>	Number of a member device. Valid values are 1 to 255.
	<i>H-H-H</i>	Hexadecimal MAC address of a member device.
	<i>password</i>	Password of a candidate device. Valid values are 1 to 256. Before joining a cluster, the candidate device needs to be authenticated. A candidate without password does not need this setting.

Example Add a candidate device with MAC address 00E0-fc00-35e7 and user password 123456 to the cluster, and specify member number 6 for it.

```
<aaa_0.S5500>system-view
System View: return to User View with Ctrl+Z.
[aaa_0.S5500]cluster
[aaa_0.S5500-cluster] add-member 6 mac-address 00E0-fc00-35e7 password
123456
```

View This command can be used in the following views:

- Cluster view

Description This command can be executed on the management device only, otherwise an error message appears.

If you do not specify the member number when adding a cluster member, the management device will assign the next available number for it.

After the candidate device is added into the cluster, its device password will become the management device password.

address-check

Purpose Use the **address-check** command to enable or disable DHCP relay security on a VLAN interface, so as to start the validity check on user addresses under the VLAN interface.

Syntax

```
address-check enable  
address-check disable
```

Parameters None

Default By default, DHCP relay security is disabled on a VLAN interface.

Example To enter system view and enter the VLAN 1 interface view, enter the following:

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] interface vlan-interface 1
```

To enable DHCP relay security on VLAN 1 interface, enter the following:

```
[S5500-Vlan-interface1] address-check enable
```

View This command can be used in the following views:

- VLAN Interface view

Description



Among Switch 5500-series switches, only Switch 5500 E1-series switches support the two commands.

administrator-address

Purpose

Use the **administrator-address** command to store the MAC address of the management device on a member device.

Use the **undo administrator-address** command to remove a member from the cluster, usually for debugging or restoration.

Syntax

```
administrator-address mac-address name name
```

```
undo administrator-address
```

Parameters

mac-address

MAC address of the management device.

name

Name of an existing cluster consisting of no more than 8 characters, including only alphanumeric characters, subtraction sign "-" and/or underline "_"

Default

By default, a switch is not in any cluster.

Example

Remove the current member device from the cluster.

```
<aaa_1.S5500>system-view  
System View: return to User View with Ctrl+Z  
[aaa_1.S5500] cluster  
[aaa_1.S5500] undo administrator-address
```

View

This command can be used in the following views:

- Cluster view

Description

Only one management device exists in a cluster. When the system reboots, member devices can recognize the administrator device by its MAC address.

The recommended way to remove a cluster member is to execute the **delete-member** command.

am enable

Purpose

Use the **am enable** command to enable address management IP address pool.

Use the **undo am enable** command to disable address management IP address pool.

Syntax

```
am enable  
undo am enable
```

Parameters

None

Default

By default, address management IP address pool is disabled on the switch.

Example

Enable address management IP address pool.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] am enable
```

View

This command can be used in the following views:

- System view

Description



Notice:

- *3Com recommends you remove static ARP configuration before enabling address management IP address pool. This ensures that the binding of an IP address to the Ethernet switch takes effect.*
- *If you have configured on another port to implement static ARP on an IP address within the IP address pool on the current port, the system will prompt you to remove that ARP setting.*

am ip-pool

Purpose

Use the **am ip-pool** command to set an address management IP address pool for a port, permitting the packets in this IP address pool whose IP addresses are the source IP addresses to pass the port for layer 3 forwarding.

Use the **undo am ip-pool** command to remove part or all of the IP addresses in the address management IP address pool on a port.

Syntax

```
am ip-pool address-list

undo am ip-pool { all | address-list }
```

Parameters

all	Carries out the operation on all IP addresses (pools).
ip-pool	Configures an address management IP address pool.
address-list	Lists IP address ranges. This list is a combination of IP address segments and specific IP addresses. An IP address segment is in the form of start_ip_address [ip_address_num] & < 1-10 > , where start_ip_address is the starting IP address of an IP address range in the IP address pool, ip_address_num indicates the number of consecutive IP addresses starting from start_ip_address , and & < 1-10 > means that up to 10 address segments can be specified.

Default

By default, address management IP address pools on all ports are null and the switch permits all packets to pass.

Example

Configure an address management IP address pool on Ethernet1/0/1, allowing the IP addresses ranging from 202.112.66.2 to 202.112.66.20 and the specified IP address 202.112.65.1 to access the network through the port.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface ethernet1/0/1
[S5500-Ethernet1/0/1] am ip-pool 202.112.66.2 19 202.112.65.1
```

View

This command can be used in the following views:

- Ethernet Port view

Description



Notice:

When you are configuring an address management IP address pool on a port, if the IP addresses in this IP address pool are those configured in the static ARP on another

port, the system will prompt you to delete the corresponding static ARP to ensure that the binding takes effect.

Note that when you are configuring an address management IP address pool on a port, if the IP addresses in this IP address pool are those configured in the static ARP on another port, the system will prompt you to delete the corresponding static ARP to ensure that the binding takes effect.

am trap enable

Purpose	<p>Use the <code>am trap enable</code> command to enable the access management trap function.</p> <p>Use the <code>undo am trap enable</code> command to disable the access management trap function.</p>
Syntax	<pre>am trap enable undo am trap enable</pre>
Parameters	None
Default	By default, the access management trap is disabled.
Example	<p>To enable the access management trap, enter the following:</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]am trap enable</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view

am user-bind

Purpose

Use the **am user-bind** command to bind the MAC address and IP address of a legal user to the specified port.

Use the **undo am user-bind** command to remove the binding of the MAC address and IP address to the specified port.

Syntax

In system view:

```
am user-bind mac-addr mac-address ip-addr ip-address interface  
interface-type interface-number
```

```
undo am user-bind mac-addr mac-address ip-addr ip-address interface  
interface-type interface-number
```

In Ethernet port view:

```
am user-bind mac-addr mac-address ip-addr ip-address
```

```
undo am user-bind mac-addr mac-address ip-addr ip-address
```

Parameters

<i>mac-address</i>	Specifies the MAC address to be bound.
<i>ip-address</i>	Specifies the IP address to be bound.
<i>interface-type</i>	Specifies the type of interface to be bound.
<i>interface-number</i>	Specifies the number of the interface to be bound.

Example

Bind a legal user whose MAC address is 00e0-fc00-5500 and whose IP address is 10.153.1.1 to Ethernet1/0/2.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] am user-bind mac-addr 00e0-fc00-5500 ip-addr 10.153.1.1  
interface Ethernet1/0/2
```



CAUTION:

The **am user-bind** command is related to none of the following commands:

- The **am enable** command, which enables address management in system view
- The **am ip-pool { address-list }** command, which sets an address management IP address pool on a port in Ethernet port view

For detailed descriptions on the **am enable** command and the **am ip-pool { address-list }** command, see the "Network Protocol" module in **S5500 Series Ethernet Switches Command Manual**.

View

This command can be used in the following views:

- System view
- Ethernet Port view

Description

After the binding, only packets from a legal user can pass the port.

A legal user

- Has a MAC address that is bound by using the **am user-bind** command.
- Has an IP address that is bound by using the **am user-bind** command.



Notice:

- *You can bind up to 128 MAC addresses and IP addresses to one port.*
- *The system allows you to bind the same MAC address only once.*
- *The system allows you to bind the same IP address only once.*

apply cost

Purpose

Use the **apply cost** command to configure the route cost value of route information.

Use the **undo apply cost** command to cancel the apply sub-statement.

Syntax

```
apply cost value
```

```
undo apply cost
```

Parameters

value Enter the route cost value of route information.

Example

Define one **apply** sub-statement. When it is used for setting route information attribute, it sets the route metric value of route information to 120.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]route-policy permit node 1
    % New sequence of this list
[SW5500-route-policy]apply cost 120
```

View

This command can be used in the following views:

- Route Policy view

Description

This command is one of the **apply** sub-statements of the Route-policy attribute set.

Related Commands

- **if-match interface**
- **if-match { acl | ip-prefix }**
- **if-match ip next-hop**
- **if-match cost**
- **if-match tag**
- **route-policy**
- **apply tag**

apply poe-profile

Purpose

Use the **apply poe-profile** command to apply the existing PoE Profile configuration to the specified Ethernet port.

Use the **undo apply poe-profile** command to delete the PoE Profile configuration for the specified Ethernet port.

Syntax

Under system view use the following commands:

```
apply poe-profile profilename interface interface-type interface-number
[ to interface-type interface-number ]
```

```
undo apply poe-profile profilename interface interface-type
interface-number [ to interface-type interface-number ]
```

Under Ethernet port view use the following commands:

```
apply poe-profile profilename
```

```
undo apply poe-profile profilename
```

Parameters

<i>profilename</i>	Name of PoE Profile, consisting of a string 1 to 15 characters long, and cannot be reserved keywords like all, interface, user, undo, and mode.
<i>interface-type</i>	interface-type indicates type of the interface.
<i>interface-number</i>	interface-number specifies the port ID.

Example

Apply the existing PoE Profile (profile-test) configuration to Ethernet1/0/1 through Ethernet1/0/9 ports of the switch.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] apply poe-profile profile-test interface ethernet1/0/1 to
ethernet1/0/9
```

View

This command can be used in the following views:

- System view

Description

Only one PoE Profile can be in use at any time for each Ethernet port.



Various PoE features can be configured within one PoE Profile. The following holds while using the **apply poe-profile** command to apply a PoE Profile to a group of ports.

- The **display current-configuration** command can be used to indicate that the PoE Profile is being used properly, so long as one PoE feature in the PoE Profile is in proper use for a given port.

- If one or more features of the PoE Profile are not used properly in a given port, the terminal will show clearly exactly which feature on what port is not used properly.

apply qos-profile

Purpose

Use the **apply qos-profile** command to apply the QoS profile to the current port.

Use the **undo apply qos-profile** command to remove the QoS profile from a port.

Syntax

```
apply qos-profile profile-name
```

```
undo apply qos-profile profile-name
```

Parameters

profile-name

QoS profile name, consisting of a string 1 to 32 characters long, starting with letters [a-z, A-Z] and excluding all, interface, and user which are reserved as keywords.

Example

To apply the qos-profile student to the current port, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]interface Ethernet 1/0/1  
[SW5500-Ethernet1/0/1] apply qos-profile student  
[SW5500-Ethernet1/0/1]
```

View

This command can be used in the following views:

- Ethernet Port view

Description

You cannot delete a QoS profile which has been applied to a port. Likewise a profile has to be created before it can be assigned to a port.

apply qos-profile interface

Purpose

Use the `apply qos-profile interface` command to apply a QoS profile to one or more consecutive ports.

Use the `undo apply qos-profile` command to remove the configuration.

Syntax

```
apply qos-profile profile-name interface { interface-name /  
interface-type interface-num } [ to interface { interface-name /  
interface-type interface-num } ]
```

```
undo apply qos-profile profile-name interface { interface-name /  
interface-type interface-num } [ to interface { interface-name /  
interface-type interface-num } ]
```

Parameters

profile-name

QoS profile name, a string of one to 32 characters, starting with English letters [a-z, A-Z] and excluding all, interface, user and others that are reserved as keywords.

```
interface { interface-name  
/ interface-type  
interface-num } [ to  
interface { interface-name  
/ interface-type  
interface-num } ]
```

A group of consecutive ports. The first interface { *interface-name* | *interface-type* *interface-num* } is the starting port and the second one is the end port.

Example

To apply the qos-profile student to the ports Ethernet1/0/1 through Ethernet1/0/4, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]apply qos-profile qos-profile student interface e1/0/1 to  
e1/0/4  
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

You cannot delete the specific QoS profile that has been applied to the port.

apply tag

Purpose

Use the **apply tag** command to configure to set the tag area of OSPF route information.

Use the **undo apply tag** command to cancel the **apply** sub-statement.

Syntax

```
apply tag value
```

```
undo apply tag
```

Parameters

value Specifies the tag value of route information.

Example

Define one **apply** sub-statement. When it is used for setting route information attribute, it sets the tag area of route information to 100.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]route-policy permit node 1  
    % New sequence of this list  
[SW5500-route-policy]apply tag 100
```

View

This command can be used in the following views:

- Route Policy view

Description

This command is one of the **apply** sub-statements of the Route-policy attribute set.

Related Commands

- **if-match interface**
- **if-match { acl | ip-prefix }**
- **if-match ip next-hop**
- **if-match cost**
- **if-match tag**
- **route-policy**
- **apply cost**

area

Purpose

Use the **area** command to enter an OSPF area view.

Use the **undo area** command to exit from the OSPF area view.

Syntax

```
area area_id
```

```
undo area area_id
```

Parameters

area_id

Specifies the ID of the OSPF area. The ID can either be in IP address format, or as a number between 0 and 4294967295.

Example

To enter the OSPF area view 0, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]router id 1.1.1.1  
[SW5500]ospf  
[SW5500-ospf]area 0  
[SW5500-ospf-area-0.0.0.0]
```

View

This command can be used in the following views:

- OSPF view

arp check enable

Purpose

Use the `arp check enable` command to enable the checking of an ARP entry so the device does not learn the ARP entry where the MAC address is a multicast MAC address.

Use the `undo arp check enable` command to disable the checking of ARP entry so the device learns the ARP entry where the MAC address is a multicast MAC address.

Syntax

```
arp check enable
```

```
undo arp check enable
```

Parameters

None

Default

By default, the checking of ARP entry is enabled and the device does not learn the ARP entry where the MAC address is a multicast MAC address.

Example

Configure that the device learns the ARP entry where the MAC address is multicast MAC address.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]undo arp check enable
```

View

This command can be used in the following views:

- System view

arp static

Purpose

Use the **arp static** command to manually configure the static ARP mapping entries in the ARP mapping table.

Use the **undo arp static** command to remove a static ARP mapping entry from the ARP table.

Syntax

```
arp static ip_address mac_address vlan_id
```

```
undo arp static ip_address
```

Parameters

<i>ip_address</i>	Specifies the IP address of the ARP mapping entry.
<i>mac_address</i>	Specifies the MAC address of the ARP mapping entry, in the format H-H-H (H indicates a four digit hexadecimal number, for example 00e0-fc01-0000).
<i>vlan_id</i>	Specifies the ID number of the VLAN that you want to use to associate with the ARP mapping entry. Valid values for the VLAN ID are 1 to 4094. Optional.

Example

To establish a mapping between IP address 129.102.0.1 and MAC address 00e0-fc01-0000, and to send frames to this address through VLAN 1, Ethernet port 1/0/1, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]arp static 202.38.0.10 00e0-fc01-0000 1 arp timer aging
```

View

This command can be used in the following views:

- Ethernet Port view

Description

You must enter an IP address and MAC address with this command. You can optionally enter a VLAN ID.



*To remove all static ARP entries, use the **reset arp static** command. Note that the **reset arp static** command removes all static ARP entries permanently.*

By default, the ARP mapping table is empty, and the Switch uses dynamic ARP to maintain its address mapping.

Related Commands

- **reset arp**
- **display arp**

arp static

Purpose

Use the `arp static` command to manually configure the static ARP mapping entries in the ARP mapping table.

Use the `undo arp ip_address` command to remove a static ARP mapping entry from the ARP table.

Syntax

```
arp static ip_address mac_address [ vlan_id { interface_type |  
interface_number }]
```

```
undo arp static ip_address
```

Parameters

<i>ip_address</i>	Specifies the IP address of the ARP mapping entry.
<i>mac_address</i>	Specifies the MAC address of the ARP mapping entry, in the format H-H-H (H indicates a four digit hexadecimal number, for example 00e0-fc01-0000).
<i>vlan_id</i>	Specifies the ID number of the local VLAN that you want to use to associate with the ARP mapping entry. Valid values for the VLAN ID are 1 to 4094. This parameter is optional.
<i>interface_type</i>	Specifies the type of the port that you want to use to send frames to this address. This parameter is optional, but must be entered if a VLAN ID is specified.
<i>interface_number</i>	Specifies the number of the port that you want to use to send frames to this address. This parameter is optional, but must be entered if a VLAN ID is specified.

Default

By default, the ARP mapping table is empty, and the Switch uses dynamic ARP to maintain its address mapping.

Example

To associate the IP address 202.38.10.2 with the MAC address 00e0-fc01-0000, and the ARP mapping entry to Ethernet1/0/1 on VLAN1, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]arp static 202.38.0.10 00e0-fc01-0000 1 Ethernet1/0/1
```

View

This command can be used in the following views:

- System view

Description

You must enter an IP address and MAC address with this command. You can optionally enter a VLAN ID, which also requires entry of an interface type and

interface number. An aggregation port or port with LACP enabled cannot be set as the egress port of static ARP.



*To remove all static ARP entries, use the **reset arp static** command. Note that the **reset arp static** command removes all static ARP entries permanently.*

Related Commands

- **reset arp**
- **display arp**

arp timer

Purpose

Use the `arp timer aging` command to configure the dynamic ARP aging timer.

Use the `undo arp timer aging` command to restore the default time of 20 minutes.

Syntax

```
arp timer aging aging_time
```

```
undo arp timer aging
```

Parameters

aging_time

Specifies the aging time of dynamic ARP aging timer.
Valid values are 1 to 1440 minutes.
If not specified, the default is 20 minutes.

Example

To configure the dynamic ARP aging timer to 10 minutes, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]arp timer aging 10
```

View

This command can be used in the following views:

- System view

Related Command

```
display arp timer aging
```


asbr-summary

Purpose

Use the **asbr-summary** command to configure a summary of imported routes for OSPF.

Use the **undo asbr-summary** command to cancel the summary. This is the default.

Syntax

```
asbr-summary ip_address mask [ not-advertise | tag value ]
```

```
undo asbr-summary ip-address mask
```

Parameters

<i>ip_address</i>	Specifies the matched IP address.
<i>mask</i>	Specifies the IP subnet mask.
<i>not-advertise</i>	Designates that you do not want to advertise routes matching the specified IP address and mask.
<i>tag value</i>	Specifies a tag value, which is mainly used to control advertisement of routes via route-policy. Valid values are 0 to 4294967295. If not specified, the default is 1.

Example

To summarize the OSPF imported routes, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]router id 1.1.1.1  
[SW5500]ospf  
[SW5500-ospf]asbr-summary 10.2.0.0 255.255.0.0 not-advertise
```

View

This command can be used in the following views:

- OSPF view

Description

After the summarization of imported routes is configured, if the local router is an autonomous system border router (ASBR), this command summarizes the imported Type-5 LSAs in the summary address range. When NSSA is configured, this command will also summarize the imported Type-7 LSAs in the summary address range.

If the local router acts as both an ABR and an ASBR in the NSSA, this command summarizes Type-5 LSAs translated from Type-7 LSAs. If the router is not the ASBR in the NSSA, the summarization is disabled.

Related Command

```
display ospf asbr-summary
```

ascii

Purpose Use the **ascii** command to configure data transmission mode as ASCII mode.

Syntax **ascii**

Parameters None

Default By default, the file transmission mode is ASCII mode.

Example Configure to transmit data in the ASCII mode.

```
<SW5500>ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in.
[ftp]ascii
200 Type set to A.
[ftp]
```

View This command can be used in the following views:

- FTP Client view

Description Perform this command if the user needs to change the file transmission mode to default mode.

attribute

Purpose

Use the **attribute** command to configure some attributes for specified local user.

Use the **undo attribute** command to cancel the attributes that have been defined for this local user.

Syntax

```
attribute { ip ip-address | mac mac-address | idle-cut second |  
access-limit max-user-number | vlan vlanid | location { nas-ip  
ip-address port portnum | port portnum }  
undo attribute { ip | mac | idle-cut | access-limit | vlan | location }
```

Parameters

idle-cut <i>second</i>	Allows/disallows the local users to enable the idle-cut function. (The specific data for this function depends on the configuration of the ISP domain where the users are located.) The argument <i>minute</i> defines the idle-cut time. Valid values are 60 to 7200 seconds.
access-limit max-user-number	Specifies the maximum number of users who access the device using the current user name. Valid values for the <i>max-user-number</i> argument are 1 to 1024.
ip	Specifies the IP address of a user.
mac <i>mac-address</i>	Specifies the MAC address of a user. Where, <i>mac-address</i> takes on the hexadecimal format of <i>HHHH-HHHH-HHHH-HHHH</i> .
vlan <i>vlanid</i>	Sets the VLAN attribute of user, in other words, the VLAN to which a user belongs. Valid values for the <i>vlanid</i> argument are 1 to 4094.
location	Sets the port binding attribute of user.
nas-ip <i>ip-address</i>	The IP address of the access server in the event of binding a remote port with a user. The argument <i>ip-address</i> is an IP address in dotted decimal format and defaults to 127.0.0.1. The argument <i>nas-ip</i> must be defined for a user bound with a remote port.
port <i>portnum</i>	Sets the port to which a user is bound. The argument <i>portnum</i> is represented by "SlotNumber SubSlotNumber PortNumber". If any of these three items is absent, the value 0 will be used to replace it.

Example

To configure the IP address 10.110.50.1 to the user JohnQ, enter the following:

```
<SW5500> system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]local-user JohnQ  
New local user added.  
[SW5500-luser-JohnQ]ip 10.110.50.1
```

View

This command can be used in the following views:

- Local User view

Related Command

`display local-user`

authentication

Purpose

Use the **authentication** command to configure an authentication scheme for the current ISP domain.

Use the **undo authentication** command to restore the default authentication scheme of the current ISP domain.

Syntax

```
authentication { radius-scheme radius-scheme-name [ local ] | local | none }
```

```
undo authentication
```

Parameters

radius-scheme	
radius-scheme-name	Specifies a RADIUS authentication scheme.
local	Specifies to use local authentication scheme.
none	Specifies not to perform authentication.

Example

To create an ISP domain named aabbcc.net and # specify the scheme radius as the RADIUS authentication scheme to be referenced by the current ISP domain aabbcc.net, enter the following:

```
<S5500> system-view  
[S5500] domain aabbcc.net  
New Domain added.  
[S5500-isp-aabbcc.net] authentication radius-scheme radius
```

View

This command can be used in the following views:

- ISP Domain view

Description

By default, no separate authentication scheme is configured.

Before you use the **authentication** command to specify a RADIUS scheme to be referenced by the current ISP domain, the specified RADIUS scheme must have already been defined.

- After the **authentication radius-scheme radius-scheme-name local** command is executed, the **local** scheme is used as the secondary authentication scheme in case the RADIUS server does not respond normally. That is, if the communication between the switch and the RADIUS server is normal, no local authentication is performed; otherwise, local authentication is performed.
- After the **authentication local** command is executed, the **local** scheme is used as the primary scheme. In this case, only local authentication is performed. After the **authentication none** command is executed, no authentication is performed.

- After the **authentication** command is executed in an ISP domain view, the system uses the authentication scheme specified in the command to authenticate the users in the domain. Otherwise the system uses the scheme specified in the **scheme** command to authenticate the users.

Related Command

- **scheme**
- **radius scheme**

authentication-mode

Purpose

Use the command `authentication-mode` to configure login authentication.

Use the command `authentication-mode password` to prompt a user for local password authentication at login.

To set the password, use `set authentication password`.

Use the command `authentication-mode scheme` to prompt a user to provide local or remote user name and password authentication at login.

Use the command `authentication-mode none` to allow a user to log in without username or password authentication.

Syntax

```
authentication-mode { password | scheme | none }
```

Parameters

<code>password</code>	Requires local authentication of password at login.
<code>scheme</code>	Requires local or remote authentication of username and password at log in.
<code>none</code>	Allows users to log in without username or password.

Default

By default, users logging in using the console port do not need to pass any terminal authentication. Users logging in via modem or Telnet are required to provide password authentication when they log in.

Example

To configure local password authentication, enter the following command:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]user-interface aux 0
[SW5500-ui-aux0]authentication-mode password
```

View

This command can be used in the following views:

- User Interface view

Description

This command configures the authentication method for a user at log in.

The type of the authentication depends on your network configuration. For further information, see "AAA and RADIUS".

authentication-mode

Purpose

Use the **authentication-mode** command to configure an OSPF area to use a specified authentication mode.

Use the **undo authentication-mode** command to cancel the authentication mode for this area. By default, an area does not support an authentication mode.

Syntax

```
authentication-mode { simple | md5 }
```

```
undo authentication-mode
```

Parameters

simple Specifies to configure simple text authentication mode.

md5 Specifies to configure MD5 cipher text authentication mode.

Example

To set the OSPF area 0 to support MD5 cipher text authentication, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]area 0
[SW5500-ospf-1-area-0.0.0.0]authentication-mode md5
```

View

This command can be used in the following views:

- OSPF Area view

Description

All the routers in one area must use the same authentication mode (no authentication, simple text authentication or MD5 cipher text authentication). In addition, all routers on the same segment must use the same authentication key.

To configure a simple text authentication key, use the **ospf authentication-mode simple** command.

To configure an MD5 cipher text key, use the **ospf authentication-mode md5** command.

Related Command

```
ospf authentication-mode
```


authorization

Purpose

Use the **authorization none** command to allow users in the current ISP domain to use network services without being authorized.

Use the **undo authorization** command to restore the default authorization scheme of the ISP domain.

Syntax

```
authorization none
```

```
undo authorization
```

Parameters

None

Default

By default, no separate authorization scheme is configured.

Example

To create an ISP domain named aabbcc.net and allow users in the current ISP domain aabbcc.net to use network services without being authorized, enter the following:

```
<S5500> system-view
[S5500] domain aabbcc.net
New Domain added.
[S5500-isp-aabbcc.net] authorization none
```

View


This command can be used in the following views:

- ISP Domain view

Description

For related configuration, refer to the **scheme** and **radius scheme** commands in the security module of the *Switch 5500 Series Ethernet Switches Command manual*.

auto-build

Purpose	Use the auto-build command to configure a cluster automatically.
Syntax	auto-build [<i>recover</i>]
Parameters	recover Automatically gets back the members of a cluster for the management device when it reboots.
Example	To set up a cluster automatically, enter the following: <pre><S5500>system-view System View: return to User View with Ctrl+Z [S5500] cluster [S5500-cluster] auto-build</pre>
View	This command can be used in the following views: <ul style="list-style-type: none">■ Cluster view
Description	<p>This command can be executed on a candidate device or a management device.</p> <p>When you use this command on a candidate device, you are required to input a cluster name to create a cluster. Then the cluster collects candidates through NTDP and adds them to the cluster upon your confirmation.</p> <p>When you use this command on a management device, the system will collect candidates directly.</p> <p>Argument <i>recover</i> is used to recover a cluster. Using the auto-build recover command, you can find the members that left the member list and add them to the cluster again.</p> <p> <i>Note:</i></p> <p>Ensure that NTDP is enabled, because it is the basis of candidate and member collection. The collection range is also decided through NTDP. You can use the hop command to modify the collection range in System view.</p> <p><i>If a member is configured with an enable-password different from the password of the management device, it cannot be added to a cluster automatically.</i></p>

auto-execute command

Purpose Enter `auto-execute command text` to configure the Switch to automatically run a specified command.

Enter `undo auto-execute command` to cancel the auto-execute command so the command is not run automatically.

Syntax

```
auto-execute command text  
undo auto-execute command
```

Parameters `text` Specifies the command to be run automatically.

Default By default, auto-execute is disabled.

Example To configure the Switch to automatically Telnet to device 10.110.100.1 after the user logs in via VTY 0, enter the following command:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]user-interface vty 0  
[SW5500-ui-vty0]auto-execute command telnet 10.110.100.1
```

View This command can be used in the following views:

- User Interface view

Description When the user logs in, the command will be executed automatically. This command is usually used to configure the `telnet` command on the terminal, which will connect the user to a designated device automatically.



CAUTION:

If you execute this command, the user-interface can no longer be used to perform routine configurations on the local system. Ensure that you can log in to the system in some other way to cancel the configuration, before you configure the `auto-execute command` and save the configuration.

backup current-configuration to

Purpose

Use the **backup current-configuration to** command to back up either all configurations or the current configuration of a specified switch to a file on a TFTP server.

Use the **backup unit current-configuration to** command to back up the current configuration of a specified switch to a file on a TFTP server.

Use the **backup fabric current-configuration to** command to back up the current configurations of all the switches in the fabric to a file on a TFTP server.

Syntax

```
backup { unit unit-id | fabric } current-configuration to dest-addr
filename.cfg
```

Parameters

<i>unit-id</i>	Unit ID of a switch.
<i>fabric</i>	Specifies the whole fabric system.
<i>dest-addr</i>	Host name or IP address of a TFTP server.
<i>filename.cfg</i>	Name of the configuration file to which the current configurations will be backed up, a character string of 5 to 56 characters (including the extension name .cfg.)

Example

To back up the current configurations of 8 to the file aaa.cfg on the TFTP server with IP address 1.1.1.253, enter the following:

```
<S5500> backup unit 8 current-configuration to 1.1.1.253 aaa.cfg
Backup current configuration to 1.1.1.253. Please wait...
File will be transferred in binary mode.
Copying file to remote tftp server. Please wait...
TFTP:      1958 bytes sent in 0 second(s).

File uploaded successfully.

Unit 8: Backup current configuration finished!
```

To Back up the current configuration of the whole fabric to the file aaa.cfg on the TFTP server with IP address 1.1.1.253, enter the following:

```
<S5500> backup fabric current-configuration to 1.1.1.253 aaa.cfg
Backup current configuration to 1.1.1.253. Please wait...
File will be transferred in binary mode.
Copying file to remote tftp server. Please wait...
TFTP:      2029 bytes sent in 0 second(s).

File uploaded successfully.

Unit 7: Backup current configuration finished!
Unit 8: Backup current configuration finished!
```

View

This command can be used in the following views:

- User view

binary

Purpose Use the `binary` command to configure file transmission type as binary mode.

Syntax `binary`

Parameters None

Example Configure to transmit data in the binary mode.

```
<SW5500>ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in.
[ftp]binary
200 Type set to I.
[ftp]
```

View This command can be used in the following views:

- FTP Client view

boot attribute-switch

Purpose Use the **boot attribute-switch** command to toggle between the main and backup attributes of file.

Syntax `boot attribute-switch { all | app | configuration | web } fabric`

Parameters

all	Specifies all files, including App, configuration and Web files.
app	Specifies App files.
configuration	Specifies configuration files.
web	Specifies Web files.
fabric	Operates on the whole fabric.

Example To toggle between the main and backup attributes of all files in the fabric system, enter the following:

```
<S5500> boot attribute-switch all fabric
The boot, web and configuration file's backup-attribute and
main-attribute will exchange.
Are you sure? [Y/N] y
The boot, web and configuration file's backup-attribute and
main-attribute successfully exchanged on unit 1!
The boot, web and configuration file's backup-attribute and
main-attribute successfully exchanged on unit 2!
```

View This command can be used in the following views:

- User view

boot boot-loader

Purpose Use the **boot boot-loader** command to assign the main attribute to an App file on one switch or all switches in the fabric, so as to use this App file as the preferred boot file upon next startup of switch.

Syntax `boot boot-loader file-url [fabric]`

Parameters

<code>file-url</code>	Path name or file name of an App file in the flash memory, consisting of a character string from 1 to 64 characters long.
<code>fabric</code>	Operates on the whole fabric.

Example To set the file boot.bin as the main boot file of the whole fabric, enter the following:

```
<S5500> boot boot-loader boot.bin fabric
The specified file will be booted next time on unit 1!
The specified file will be booted next time on unit 2!
```

View This command can be used in the following views:

- User view

Description If you execute the **boot boot-loader** command without the **fabric** keyword, the command takes effect only on the local unit.



CAUTION:

You can assign the main attribute to an App file on the whole fabric only when the App file exists in all the switches of the fabric. For this series of Ethernet switches, you are not allowed to specify an App file in the flash memory of another unit as the App boot file of the local unit.

boot boot-loader backup-attribute

Purpose

Use the **boot boot-loader backup-attribute** command to assign the backup attribute to an App file on one switch or all switches in the fabric, so as to use this App file as the backup boot file upon next startup of switch.

When the file with main attribute does not exist or is unavailable, the switch(es) will use the file with backup attribute to start up.

Syntax

```
boot boot-loader backup-attribute file-url [ fabric ]
```

Parameters

file-url	Path name or file name of an App file in the flash memory, consisting of a character string from 1 to 64 characters long.
fabric	Operates on the whole fabric.

Example

To set the file backup.bin as the backup boot file of the whole fabric, enter the following:

```
<S5500> boot boot-loader backup-attribute backup.bin fabric
Set boot file backup-attribute successfully on unit 1!
Set boot file backup-attribute successfully on unit 2!
```

View

This command can be used in the following views:

- User view

Description

If you execute the **boot boot-loader backup-attribute** command without the **fabric** keyword, the command takes effect only on the local unit.



CAUTION:

You can assign the backup attribute to an App file on the whole fabric only when the App file exists in all the switches of the fabric. For this series of Ethernet switches, you are not allowed to specify an App file in the flash memory of another unit as the App boot file of the local unit.

boot bootrom

- Purpose** Use the `boot bootrom` command to upgrade bootrom.
- Syntax** `boot bootrom file-path`
- Parameters** *file-path* File path and file name of Bootrom.
- Example** To upgrade bootrom of the switch, enter the following:
`<SW5500>boot bootrom PLATV100R002B09D002.btm`
- View** This command can be used in the following views:
- User view

boot web-package

Purpose

Use the **boot web-package** command to assign the main or backup attribute to a Web file on the fabric, so as to use this file as the main or backup Web file upon next startup.

Syntax

```
boot web-package webfile { backup | main }
```

Parameters

<i>webfile</i>	Name of a Web file, consisting of a character string from 5 to 127 characters long.
<i>main</i>	Assigns the main attribute to the file.
<i>backup</i>	Assigns the backup attribute to the file.

Example

To set the file boot.web as the main Web file, enter the following:

```
<S5500> boot web-package http.web main
```

View

This command can be used in the following views:

- User view

Description



CAUTION:

- You can assign the main or backup attribute to a Web file only when the Web file exists in all the switches of the fabric.
- The assignment of the main or backup attribute to a Web file takes effect immediately without the need of restarting the switches.

broadcast-suppression

Purpose

Use the **broadcast-suppression** command to globally set the size of the broadcast traffic allowed to pass through each Ethernet port.

Use the **undo broadcast-suppression** command to restore the default size.

Syntax

```
broadcast-suppression { ratio | pps max-pps }
```

```
undo broadcast-suppression
```

Parameters

ratio Percentage of the total network bandwidth, that is, the ratio of network bandwidth allowed to be occupied by the broadcast traffic on each Ethernet port to the total network bandwidth. Valid values for this argument are 1 to 100 (in increments of 1). The smaller the value of this argument, the smaller the allowed-to-pass broadcast traffic is. If not specified, the default is 100.

max-pps Maximum number of broadcast packets allowed to pass through each Ethernet port per second. Valid values are 1 to 262,143 in pps.

Default

By default, the system allows broadcast traffic to occupy 100% network bandwidth. That is, it does not limit broadcast traffic.

Example

To globally set the maximum number of broadcast packets allowed to pass through each Ethernet port per second to 1000, enter the following:

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] broadcast-suppression pps 1000
```

View

This command can be used in the following views:

- System view

Description

After the broadcast traffic exceeds the threshold you set here, the system will discard all the broadcast packets beyond the traffic limit to decrease the ratio of the broadcast traffic into a reasonable range. This guarantees the normal operation of network services.



*The broadcast suppression configured globally with the **broadcast-suppression** command will take effect on all the Ethernet ports in a stack system.*

broadcast-suppression

Purpose Use **broadcast-suppression** to configure the amount of broadcast traffic that will be accepted on a port.

Syntax

```
broadcast-suppression { ratio | pps pps }  
undo broadcast-suppression
```

Parameters

ratio	Specifies the bandwidth ratio of broadcast traffic allowed on an Ethernet port. Valid ratio values are 1 to 100. The incremental step is 1. The smaller the ratio, the less bandwidth is allocated to broadcast traffic and therefore less broadcast traffic is accepted on the Ethernet port. If not specified, the default ratio of 100 is used, meaning that all broadcast traffic is accepted.
pps pps	Specifies the maximum number of broadcast packets per second accepted on an Ethernet port. Valid values are 1 to 148810 pps.

Example Enable a limit of 20% of the available bandwidth on a port to be allocated to broadcast traffic. Broadcast traffic exceeding 20% of the ports bandwidth will be discarded

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface ethernet 1/0/1  
[SW5500-Ethernet1/0/1]broadcast-suppression 20  
[SW5500-Ethernet1/0/1]
```

To specify the maximum packets per second of broadcast traffic on Ethernet1/0/1 to be 1000., enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface ethernet 1/0/1  
[SW5500-Ethernet1/0/1]broadcast-suppression pps 1000  
[SW5500-Ethernet1/0/1]
```

View This command can be used in the following views:

- Ethernet Port view

Description Once the broadcast traffic exceeds the value set by the user, the excess broadcast traffic will be discarded. This feature can be used to ensure network service and prevent broadcast storms.

bsr-policy

Purpose

Use the **bsr-policy** command to limit the range of legal BSRs to prevent BSR spoofing.

Use the **undo bsr-policy** command to restore the default setting so that no range limit is set and all received messages are taken as legal.

Syntax

```
bsr-policy acl-number
```

```
undo bsr-policy
```

Parameters

acl-number

ACL number imported in BSR filtering policy. Valid values are 2000 to 2999.

Example

Configure BSR filtering policy on routers, only 1.1.1.1/32 can be a BSR.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]multicast routing-enable
[SW5500]pim
[SW5500-pim]bsr-policy 2000
[SW5500-pim]quit
[SW5500]acl number 2000
[SW5500-acl-basic-2000]rule 0 permit source 1.1.1.1 0
```

View

This command can be used in the following views:

- PIM view

Description

In a PIM SM network using the BSR (bootstrap router) mechanism, every router can set itself as a C-BSR (candidate BSR) and have the authority to advertise RP information in the network once it wins the election. To prevent malicious BSR spoofing in the network, the following two measures need to be taken:

- Prevent the router from being spoofed by hosts though faking legal BSR messages to modify RP mapping. BSR messages are of multicast type and their TTL is 1, so this type of attacks often hits edge routers. Fortunately, BSRs are inside the network, while the assaulting hosts are outside, therefore neighbor and RPF checks can be used to stop this type of attacks.
- If a router in the network is manipulated by an attacker, or an illegal router is placed on the network, the attacking router may set itself as a C-BSR and try to win the election and gain the authority to advertise RP information throughout the network. Since the router configured as a C-BSR propagates BSR messages, as multicast with a TTL of 1. Then the network cannot be affected as long as the peer routers do not receive these BSR messages. This is done by configuring bsr-policy on each router to limit the legal BSR range, for example, only 1.1.1.1/32 and 1.1.1.2/32 can be BSRs, thus the routers cannot receive or forward BSR messages

received from any other source other than these two. Even legal BSRs cannot contest with them.

Problems may still exist if a legal BSR is attacked, though these two measures can effectively guarantee high BSR security.

The *source* parameter in the **rule** command is translated as a BSR address in the **bsr-policy** command.

Related Commands

- **acl**
- **rule**

build

Purpose

Use the **build** command to configure a cluster with the current switch as the management device. Argument *name* specifies the name of the cluster.

Use the **undo build** command to configure the current management device as a candidate.

Syntax

```
build name
```

```
undo build
```

Parameters

name

Cluster name with no more than 8 characters, including only alphanumeric characters, subtraction sign "-" and/or underline "_".

Default

By default, all the devices supporting cluster are candidate devices.

Example

Configure the current switch as the management device and specifies HUAWEL as the cluster name.

```
<S5500>system-view
System View: return to User View with Ctrl+Z
[S5500] cluster
[S5500-cluster] build 3Com
```

View

This command can be used in the following views:

- Cluster view

Description

After a cluster is created, the device on which the command is executed becomes the management device and will be assigned with a fixed member number of 0.

This command can be executed on a management-capable device that is not a cluster member. Running this command on a cluster member will fail. If the current switch is a management device for a cluster, whose name is different with that specified in the command, the command will only set the name of the cluster as the new one.

The member number for a management device is 0.

bye

Purpose	Use the bye command to terminate the connection to the remote SFTP server and return to system view.
Syntax	bye
Parameters	None
Example	<p>Terminate the connection to the remote SFTP server (assume that the server IP address is 10.1.1.2).</p> <pre><S5500> system-view [S5500] sftp 10.1.1.2 sftp-client> bye [S5500]</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ SFTP Client view
Description	This command has the same function as the exit and quit commands.

cache-sa-enable

Purpose	Use the cache-sa-enable command to enable the SA message cache mechanism. Use the undo cache-sa-enable command to disable the cache mechanism.
Syntax	cache-sa-enable undo cache-sa-enable
Parameters	None
Default	By default, a router caches (S, G) entries after it receives an SA message.
Example	Enable the router to cache all SA states. <pre><S5500> system-view [S5500] msdp [S5500-msdp] cache-sa-enable</pre>
View	This command can be used in the following views: <ul style="list-style-type: none">■ MSDP view
Description	If the router is in the cache state, it does not send an SA request message to the specified MSDP peer when it receives a Join message.

c-bsr

Purpose

Use the `c-bsr` to configure a candidate BSR.

Use the `undo c-bsr` to remove the candidate BSR configured.

Syntax

```
c-bsr interface-type interface-number hash-mask-len [ priority ]
```

```
undo c-bsr
```

Parameters

interface-type
interface-number

Interface type and interface number of a router. The candidate BSR is configured on the interface. PIM-SM must be enabled on the interface first.

hash-mask-len

Length of the mask. Valid values are 0 to 32.

priority

Priority of the candidate BSR. The larger the value of the priority, the higher the priority of the BSR. Valid values are 0 to 255.

If not specified, the default value is 0.

Default

By default, no candidate BSR is set.

Example

Configure the Ethernet Switch as C-BSR with priority 2 (and the C-BSR address is designated as the IP address of VLAN-interface10).

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]multicast routing-enable
[SW5500] pim
[SW5500-pim]c-bsr vlan-interface 10 24 2
```

View

This command can be used in the following views:

- PIM view

Related Command

`pim sm`

c-rp

Purpose

Use the **c-rp** to configure the router to advertise itself as a candidate RP.

Use the **undo c-rp** to remove the configuration.

Syntax

```
c-rp interface-type interface-number [ group-policy acl-number |
priority priority-value ]*
```

```
undo c-rp { interface-type interface-number | all }
```

Parameters

interface-type

interface-number

Specified interface with the IP address advertised as a candidate RP address.

acl-number

Number of the basic ACL that defines a group range, which is the service range of the advertised RP. Valid values are 2000 to 2999.

priority-value

Priority value of candidate RP. Valid values are 0 to 255. The greatest value corresponds to the lowest priority level.

If no priority value is specified, the default is 0.

all

Removes all candidate RP configurations.

Default

By default, no candidate RP is configured.

Example

Configure the Ethernet Switch to advertise the BSR that it is the C-RP in the PIM domain. The standard access list 2000 defines the groups related to the RP. The address of C-RP is designated as the IP address of VLAN-interface10.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]multicast routing-enable
[SW5500]acl number 2000
[SW5500-acl-basic-2000]rule permit source 225.0.0.0 0.255.255.255
[SW5500-acl-basic-2000]quit
[SW5500]pim
[SW5500-pim]c-rp vlan-interface 10 group-list 2000
```

View

This command can be used in the following views:

- PIM view

Related Command

c-bsr

cd

Purpose Use the **cd** command to change the current path on the remote SFTP server. If you did not specify the **remote-path** argument, the current path is displayed.

Syntax `cd [remote-path]`

Parameters *remote-path* Name of a path on the server. If you did not specify the **remote-path** argument, the current path is displayed.

Example Change current path to d:/temp.

```
sftp-client> cd d:/temp
```

View This command can be used in the following views:

- SFTP Client view

cdup

Purpose Use the **cdup** command to return to the upper directory.

Syntax `cdup`

Parameters None

Example Return to the upper directory.

```
sftp-client> cdup
```

View This command can be used in the following views:

- SFTP Client view

change self-unit

Purpose Use the `change unit` command to change the unit ID of the current Switch.

Syntax `change self-unit to { <1-8> | auto-numbering }`

Parameters

<code><1-8></code>	New unit ID of the device. A unit ID can be set to a value in the range from 1 to the maximum number of devices supported in XRN. If not specified, the unit ID of a Switch is set to 1 by default.
<code>auto-numbering</code>	Changes the unit ID automatically.

Example To change the unit ID of the current Switch to 3, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500] change self-unit to 3
Unit %d saved unit ID successfully.
```

View This command can be used in the following views:

- System view

change unit-id

Purpose Use the `change unit-id` command to change the unit ID of a Switch in the Fabric.

Syntax `change unit-id to { <1-8> | auto-numbering }`

Parameters

<code><1-8></code>	Old unit ID of the device. A unit ID can be set to a value in the range from 1 to the maximum number of devices supported in XRN. If not specified, the unit ID of a Switch is set to 1 by default.
<code>auto-numbering</code>	Changes the unit ID automatically.

Example To change the unit ID from 2 to 3, enter the following:

```
<SW5500>display xrn-fabric
Fabric name is SW5500, system mode is L3.
Fabric authentication : no authentication, unit number : 2.
Unit Name      Unit ID
First          1
Second         2(*)
[SW5500]change unit-id 2 to 3
Unit %d saved unit ID successfully.
<SW5500>display xrn-fabric
Fabric name is SW5500, system mode is L3.
Fabric authentication: no authentication, unit number: 3.
Unit Name      Unit ID
First          1
Second         3(*)
```

View This command can be used in the following views:

- System view

check region-configuration

Purpose Use the **check region-configuration** command to display the configurations of the MST regions that are not activated, including region name, revision level, and VLAN mapping table.

Syntax `check region-configuration`

Parameters None

Example Display the configuration of an MST region.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] stp region-configuration
[S5500-mst-region] check region-configuration
Admin Configuration
  Format selector :0
  Region name    :00e0fc005500
  Revision level :0

  Instance  Vlans Mapped
    0       1 to 9, 11 to 4094
    16      10
```

Table 1 Description on the fields of the check region-configuration command

Field	Description
Format selector	Selector specified by MSTP
Region name	Name of the MST region
Revision level	Revision level of the MST region
Instance Vlans Mapped	Spanning tree instance-to-VLAN mappings in the MST region

View This command can be used in the following views:

- MST Region view

Description MSTP-enabled switches are in the same region only when they are configured with the exact region name, revision level, and VLAN mapping table.

You can use this command to find in what MST region a deactivated switch is or check whether or not the MST region configuration is correct.

- Related Commands**
- `instance`
 - `region-name`
 - `revision-level`
 - `vlan-mapping modulo`

■ **active region-configuration**

checkzero

Purpose

Use the **checkzero** command to check the zero field of RIP-1 packets. By default, RIP-1 performs zero field checking.

Use the **undo checkzero** command to disable the checking of the zero fields

Use the **checkzero** command to enable or disable the zero check operation on RIP-1.

Syntax

checkzero

undo checkzero

Parameters

None

Example

To configure the Switch not to perform zero checking for RIP-1 packet, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]rip
[SW5500-rip]undo checkzero
```

View

This command can be used in the following views:

- RIP view

Description



According to the RFC1058 protocol specifications, some fields in RIP-1 packets must be set to zero. These are called zero fields. During the zero check operation, if a RIP-1 packet is received in which the zero fields are not zeros, it will be rejected. This command does not work with RIP-2 packets, since RIP-2 packets have no zero fields.

clock datetime

Purpose Use the `clock datetime` command to set the current system time and date.

Syntax `clock datetime time date`

Parameters

<code>time</code>	Specifies the current time in <i>HH:MM:SS</i> format. Valid values for <i>HH</i> are 0 to 23. Valid values for <i>MM</i> and <i>SS</i> are 0 to 59. If not specified, the default is 23:55:52.
<code>date</code>	Specifies the current year in <i>MM/DD/YYYY</i> or <i>YYYY/MM/DD</i> format. Valid values for <i>YYYY</i> are 2000 to 2099. Valid values for <i>MM</i> are 1 to 12. Valid values for <i>DD</i> are 1 to 31. If not specified, the default is 2000/4/1.

Example To set the system time and date to 09:30:00, 2004/1/1, enter the following:

```
<SW5500>clock datetime 09:30:00 2004/01/01
```

View This command can be used in the following views:

- User view

Related Command `display clock`

clock summer-time

Purpose

Use the **clock summer-time** command to set the name, time range and offset of the daylight saving time.

Use the **undo clock summer-time** command to cancel the setting.

Syntax

```
clock summer-time zone-name { one-off | repeating } start-time  
start-date end-time end-date add-time  
  
undo clock summer-time
```

Parameters

zone-name	Name of the daylight saving time, consisting of a character string 1 to 32 characters long.
one-off	Sets the daylight saving time for only one year (the specified year).
repeating	Sets the daylight saving time for every year starting from the specified year.
start-time	Start time of the daylight saving time, in the format of HH:MM:SS.
start-date	Start date of the daylight saving time, in the format of YYYY/MM/DD or MM/DD/YYYY.
end-time	End time of the daylight saving time, in the format of HH:MM:SS.
end-date	End date of the daylight saving time, in the format of YYYY/MM/DD or MM/DD/YYYY.
add-time	Offset of the daylight saving time relative to (ahead of) the standard time, in the format of HH:MM:SS.

Example

Set the daylight saving time named abc1, so that it begins at 06:00:00 08/01/2005, ends at 06:00:00 09/01/2005, and is one hour earlier than the standard time.

```
<S5500> clock summer-time abc1 one-off 06:00:00 08/01/2005 06:00:00  
09/01/2005 01:00:00
```

Set the daylight saving time named abc2, so that every year from 2005 on, it begins at 06:00:00 08/01, ends at 06:00:00 09/01, and is one hour earlier than the standard time.

```
<S5500> clock summer-time abc2 repeating 06:00:00 08/01/2005 06:00:00  
09/01/2005 01:00:00
```

View

This command can be used in the following views:

- User view

Description

After the setting, you can use the **display clock** command to check the result.

clock timezone

Purpose

Use the **clock timezone** command to set local time zone information.

Use the **undo clock timezone** command to return to the default, which is Universal Time Coordinated (UTC).

Syntax

```
clock timezone zone_name { add | minus } HH:MM:SS  
undo clock timezone
```

Parameters

zone_name	Specifies the name of the time zone, which may be up to 32 characters long.
add	Specifies that time is ahead of UTC.
minus	Specifies that time is behind UTC.
HH:MM:SS	Specifies the time difference between the time zone and UTC.

Example

To set the local time zone as zone 5, and configure the local time to be 5 hours ahead of UTC, enter the following:

```
<SW5500>clock timezone z5 add 05:00:00
```

View

This command can be used in the following views:

- User view

Description

Use the **display clock** command to check the summer time settings.

Related Command

```
clock summer-time
```

close

Purpose Use the `close` command to disconnect FTP client side from FTP server side without exiting FTP client side view so that you terminate the control connection and data connection with the remote FTP server at the same time.

Syntax `close`

Parameters None

Example Terminate connection with the remote FTP Server and stay in FTP Client view.

```
<SW5500>ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in.
[ftp]close
221 Server closing.
[ftp]
```

View This command can be used in the following views:

- FTP Client view

cluster

Purpose Use the **cluster** command to enter cluster view.

Syntax **cluster**

Parameters None

Example Enter cluster view.

```
<S5500>system-view  
System View: return to User View with Ctrl+Z  
[S5500] cluster  
[S5500-cluster]
```

View This command can be used in the following views:

- System view

cluster enable

Purpose Use the **cluster enable** command to enable the cluster function on a switch.

Use the **undo cluster enable** command to disable the cluster function on a switch.

Syntax

```
cluster enable
undo cluster enable
```

Parameters None

Default By default, the cluster function is enabled on all the devices supporting cluster.

Example Enable the cluster function on a switch.

```
<S5500>system-view
System View: return to User View with Ctrl+Z
[S5500] cluster enable
```

View This command can be used in the following views:

- System view

Description You need to first using the **cluster enable** command create a cluster before using the **build** command on the management device.

Above commands can be used on any device supporting the cluster function. When you use the **undo cluster enable** command on a management device, the system will delete the cluster and disable the cluster function and administering function of the device. When you use it on a member device, the system will disable the cluster function on it.

cluster-mac

Purpose Use the **cluster-mac** command to configure a multicast MAC address for cluster management. Run this command only on the management device.

Syntax `cluster-mac H-H-H`

Parameters `H-H-H` Hexadecimal multicast MAC address, ranging 0180-C200-0000, 0180-C200-000A and 0180-C200-0020 to 0180-C200-002F.

Default By default, the cluster multicast MAC address is 0180-C200-000A.

Example Configure the multicast MAC address of the management device as 0180-C200-0028.

```
<aaa_0.S5500>system-view
System View: return to User View with Ctrl+Z.
[aaa_0.S5500]cluster
[aaa_0.S5500-cluster] cluster-mac 0180-C200-0028
```

View This command can be used in the following views:

- Cluster view

Description Multicast MAC addresses enable the member devices of a cluster to receive multicast information delivered by the management device, and thus multicast information sending function is implemented on the management device.

If the multicast packet interval on the management device is 0 after the command execution, you will be prompted to set an interval for it.

cluster-mac syn-interval

- Purpose** Use the **cluster-mac syn-interval** command to set the interval for the management device to send multicast packets. This command can be executed on the management device only.
- Syntax** `cluster-mac syn-interval time-interval`
- Parameters** *time-interval* Multicast packet interval in minutes on the management device.
- Example** Set the multicast packet interval as 1.
- ```
<aaa_0.S5500>system-view
System View: return to User View with Ctrl+Z.
[aaa_0.S5500]cluster
[aaa_0.S5500-cluster] cluster-mac syn-interval 1
```
- View** This command can be used in the following views:
- Cluster view
- Description** When the interval is set as 0, the management device does not send multicast packets to cluster members.

# cluster switch-to

---

## Purpose

Use the **cluster switch-to** command to switch between the management device and member devices for configuration and management.

## Syntax

```
cluster switch-to { member-number | mac-address H-H-H | administrator }
```

## Parameters

|                          |                                                         |
|--------------------------|---------------------------------------------------------|
| <b>member-number</b>     | Number of a member device. Valid values are 1 to 255.   |
| <b>mac-address H-H-H</b> | MAC address of a member device.                         |
| <b>administrator</b>     | Redirect from a member device to the management device. |

## Example

Switch from the management device to member device 6 and then switches back to the management device.

```
<aaa_0.S5500> cluster switch-to 6
<aaa_6.S5500> quit
<aaa_0.S5500>
```

## View

This command can be used in the following views:

- User view

## Description

You can manage member devices in a cluster through the management device, on which you can switch to member view to configure or manage specified member devices, and then switch back to the management device.

Authentication is required when you switch from the management device to a member device. Upon passing the member device authentication, the switchover is allowed. If the password of the member device is different from that of the management device, the switchover will be rejected.

The view will be inherited from the management device when you switch to a member device from the management device. For example, user view remains unchanged after you switch from the management device to a member device.

Authentication is also required when you switch from a member device to the management device. After passing the authentication, the system will enter user view automatically.

When you execute this command on the management device, if the specified member number *n* does not exist, an error message appears. Enter **quit** to stop the switchover operation.

# command-privilege level

---

## Purpose

Use the `command-privilege level` command to configure the priority level assigned to any command within a selected view.

Use the `undo command-privilege view` command to restore the default priority to a command.

## Syntax

```
command-privilege level level view view command
```

```
undo command-privilege view view command
```

## Parameters

*level*

Specifies the command level you want to assign to this command. Valid values are 0 to 3, as defined below:

- 0 – Visit
- 1 – Monitoring
- 2 – System
- 3 – Management

Unless otherwise specified, the following settings occur by default:

- ping, tracer, and telnet are at level 0
- display and debugging are at level 1
- all configuration commands are at system level 2
- FTP, XMODEM, TFTP and commands for file system operations are at level 3

*view*

Specifies the name of the view that contains the command. This can be any of the views supported by the Switch.

*command*

Specifies the command to be configured.

## Example

To configure the precedence of the command 'interface' as 0, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]command-privilege level 0 view system interface
```

## View

This command can be used in the following views:

- System view

## Description

You can assign a priority level depending on user requirements. The commands that a user can access depend first on the access level assigned to the command and second

on the access level assigned to the user interface. If the two levels are different, the access level assigned to the command has priority. For example, if the access level of a user interface is 1, but a specific user can access commands at level 3, the user can log in from this user interface, but can access commands up to and including level 3.

# copy

---

**Purpose** Use the `copy` command to copy a file.

**Syntax** `copy filepath-source filepath-dest`

**Parameters**

|                              |                        |
|------------------------------|------------------------|
| <code>filepath-source</code> | Source file name.      |
| <code>filepath-dest</code>   | Destination file name. |

**Example** Display current directory information.

```
<SW5500>dir
Directory of unit1>flash:/
0 -rw- 595 Jul 12 2001 19:41:50 test.txt
16125952 bytes total (13975552 bytes free)
```

Copy the file test.txt and save it as test.bak.

```
<SW5500>copy test.txt test.bak
%Copy file unit1>flash:/test.txt to unit1>flash:/test.bak
...Done
```

Display current directory information.

```
<SW5500>dir
Directory of unit1>flash:/
 0 -rw- 595 Jul 12 2001 19:41:50 test.txt
 1 -rw- 595 Jul 12 2001 19:46:50 test.bak
16125952 bytes total (13974528 bytes free)
```

**View** This command can be used in the following views:

- User view

**Description** When the destination filename is the same as that of an existing file, the system will ask whether to overwrite it.



# copy configuration

---

**Purpose** Use the `copy configuration` command to copy the configuration of a specific port to other ports, to ensure consistent configuration.

**Syntax**

```
copy configuration source { interface-type interface_number |
interface_name | aggregation-group agg-id } destination {
interface_list [aggregation-group agg-id] | aggregation-group agg-id
}
```

**Parameters**

|                       |                                                                                                                                                                                                                                                                                       |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>interface_type</i> | Source port type.                                                                                                                                                                                                                                                                     |
| <i>interface_num</i>  | Source port number.                                                                                                                                                                                                                                                                   |
| <i>interface_name</i> | Source port name, in the format of <code>interface_name = interface_type interface_num</code> . For more information, see the parameter item for the interface command.                                                                                                               |
| <i>interface_list</i> | Destination port list, <i>interface_list1</i> = { <i>interface_type interface_num</i>   <i>interface_name</i> } [ to { <i>interface_type interface_num</i>   <i>interface_name</i> } ] &<1-10>. &<1-10> indicates that the former parameter can be input 10 times repeatedly at most. |
| <i>agg-id</i>         | Source or destination aggregation group ID. If it is a source aggregation group, the port with minimum port number is the source port; if it is a destination aggregation group, the configurations of all its member ports change to be consistent with that of the source.          |

**Example** Copy the configuration of aggregation group 1 to aggregation group 2.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]copy configuration source ethernet 1/0/1 destination ethernet
1/0/2
Copying VLAN configuration...
Copying LACP configuration...
Copying QOS configuration...
Copying STP configuration...
Copying speed/duplex configuration...
[SW5500]
```

**View** This command can be used in the following views:

- System view

# count

---

**Purpose** Use the **count** command to configure the packet sending times in each test.

Use the **undo count** command to restore the default times.

**Syntax** `count times`

`undo count`

**Parameters** `times` Packet sending times. Valid values are 1 to 15. If not specified the default is 1.

**Example** Set the packet sending times in each of the test to 10.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] remote-ping administrator icmp
[S5500-remote-ping-administrator-icmp] count 10
```

**View** This command can be used in the following views:

- Remote-Ping Test Group view

**Description** If the `times` argument set in this command is greater than one, the system sends the second test packet once it receives a response to the first one, or when the test timer times out if it receives no response after sending the first one, and so forth until the last test packet is sent out.

**Related Command** `frequency`

# crp-policy

---

## Purpose

Use the `crp-policy` command to limit the range of legal C-RP, as well as target service group range of each C-RP, prevent C-RP spoofing.

Use the `undo crp-policy` command to restore the default setting so that no range limit is set and all received messages are taken as legal.

## Syntax

```
crp-policy acl-number
```

```
undo crp-policy
```

## Parameters

`acl-number`

ACL number imported in C-RP filtering policy. Valid values are 3000 to 3999.

## Example

Configure C-RP filtering policy on the C-BSR routers, allowing only 1.1.1.1/32 as C-RP and to serve only for the groups 225.1.0.0/16.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]multicast routing-enable
[SW5500]pim
[SW5500-pim]crp-policy 3000
[SW5500-pim]quit
[SW5500]acl number 3000
[SW5500-acl-adv-3000]rule 0 permit ip source 1.1.1.1 0 destination
225.1.0.0 0.0.255.255
```

## View

This command can be used in the following views:

- PIM view

## Description

In a PIM SM network, every router can set itself as a C-RP (candidate rendezvous point) servicing particular groups. If elected, a C-RP becomes the RP servicing the current group.

A C-RP router unicasts C-RP messages to the BSR, which then propagates the C-RP messages among the network using BSR messages. To prevent C-RP spoofing, you need to configure a `crp-policy` on the BSR to limit legal C-RP range and their service group range. Since each C-BSR has the chance to become the BSR, you must configure the same filtering policy on each C-BSR router.

This command uses the ACLs numbered between 3000 and 3999. The `source` parameter in the `rule` command is translated as C-RP address in the `crp-policy` command, and the destination parameter as the service group range of this C-RP address. For the C-RP messages received, only when their C-RP addresses match the source address and their server group addresses are subset of those in ACL, can the be considered as matched.

**Related Commands**

- **acl**
- **rule**

# cut connection

---

|                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>                                                | Use the <code>cut connection</code> command to disconnect a user or a category of users by force.                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Syntax</b>                                                 | <pre>cut connection { all   access-type { dot1x   gcm   mac-authentication }   domain <i>domain-name</i>   interface <i>interface-type interface-number</i>   ip <i>ip-address</i>   mac <i>mac-address</i>   radius-scheme <i>radius-scheme-name</i>   vlan <i>vlanid</i>   ucibindex <i>ucib-index</i>   user-name <i>user-name</i> }</pre>                                                                                                                             |
| <b>Parameters</b>                                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <code>all</code>                                              | Configures to disconnect all connection.                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <code>access-type { dot1x   gcm   mac authentication }</code> | Configures to cut a category of connections according to logon type. dot1x means the 802.1x users. gcm means gcm user. mac authentication means the centralized MAC address authentication users.                                                                                                                                                                                                                                                                         |
| <code>domain <i>domain-name</i></code>                        | Configures to cut the connection according to ISP domain. <i>domain-name</i> specifies the ISP domain name with a character string not exceeding 24 characters. The specified ISP domain shall have been created.                                                                                                                                                                                                                                                         |
| <code>mac <i>mac-address</i></code>                           | Configures to cut the connection of the supplicant whose MAC address is <i>mac-address</i> . The argument <i>mac-address</i> is in the hexadecimal format (H-H-H).                                                                                                                                                                                                                                                                                                        |
| <code>radius-scheme <i>radius-scheme-name</i></code>          | Configures to cut the connection according to RADIUS server name. <i>radius-scheme-name</i> specifies the RADIUS server name with a character string not exceeding 32 characters.                                                                                                                                                                                                                                                                                         |
| <code>interface <i>interface-type interface-number</i></code> | Configures to cut the connection according to the port.                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <code>ip <i>ip-address</i></code>                             | Configures to cut the connection according to IP address. The argument <i>ip-address</i> is in the hexadecimal format (ip-address).                                                                                                                                                                                                                                                                                                                                       |
| <code>vlan <i>vlanid</i></code>                               | Configures to cut the connection according to VLAN ID. Here, <i>vlanid</i> ranges from 1 to 4094.                                                                                                                                                                                                                                                                                                                                                                         |
| <code>ucibindex <i>ucib-index</i></code>                      | Configures to cut the connection according to <i>ucib-index</i> . Here, <i>ucib-index</i> ranges from 0 to 4095.                                                                                                                                                                                                                                                                                                                                                          |
| <code>user-name <i>user-name</i></code>                       | Configures to cut the connection according to user name. <i>user-name</i> is the argument specifying the username. It is a character string not exceeding 80 characters, excluding <code>/</code> , <code>:</code> , <code>*</code> , <code>?</code> , <code>&lt;</code> and <code>&gt;</code> . The <code>@</code> character can only be used once in one username. The pure username (the part before <code>@</code> , namely the user ID) cannot exceed 55 characters. |

**Example**

To cut all the connections in the ISP domain, marlboro.net, enter the following:

```
<SW5500> system-view
System View: return to User View with Ctrl+Z.
[SW5500]cut connection domain marlboro.net
```

**View**

This command can be used in the following views:

- System view

**Related Command**

**display connection**

# data-flow-format

---

## Purpose

Use the `data-flow-format` command to configure the unit of data flow sent to TACACS Server.

Use the `undo data-flow-format` command to restore the unit to the default setting.

## Syntax

```
data-flow-format data { byte | giga-byte | kilo-byte | mega-byte }
data-flow-format packet { giga-packet | kilo-packet | mega-packet |
one-packet }
undo data-flow-format { data | packet }
```

## Parameters

|                          |                                                |
|--------------------------|------------------------------------------------|
| <code>data</code>        | Sets data unit.                                |
| <code>byte</code>        | Sets 'byte' as the unit of data flow.          |
| <code>giga-byte</code>   | Sets 'giga-byte' as the unit of data flow.     |
| <code>kilo-byte</code>   | Sets 'kilo-byte' as the unit of data flow.     |
| <code>mega-byte</code>   | Sets 'mega-byte' as the unit of data flow.     |
| <code>packet</code>      | Sets data packet unit.                         |
| <code>giga-packet</code> | Sets 'giga-packet' as the unit of packet flow. |
| <code>kilo-packet</code> | Sets 'kilo-packet' as the unit of packet flow. |
| <code>mega-packet</code> | Sets 'mega-packet' as the unit of packet flow. |
| <code>one-packet</code>  | Sets 'one-packet' as the unit of packet flow.  |

## Default

By default, the data unit is byte and the data packet unit is one-packet.

## Example

Set the unit of data flow sent to TACACS Server 3Com to kilo-byte and the data packet unit to kilo-packet.

```
[S5500-hwtacacs-3Com] data-flow-format data kilo-byte packet
kilo-packet
```

## View

This command can be used in the following views:

- HWTACACS view

## Related Command

`display hwtacacs`

# databits

---

## Purpose

Use the **databits** command to configure the data bits for the AUX (Console) port to either 7 or 8.

Use the **undo databits** command to restore the default value.

## Syntax

```
databits { 7 | 8 }
```

```
undo databits
```

## Parameters

|   |                                                                         |
|---|-------------------------------------------------------------------------|
| 7 | Sets the data bits to 7.                                                |
| 8 | Sets the data bits to 8.<br>If no value is specified, 8 is the default. |

## Example

To configure the data bits of the AUX (Console) port to 7 bits, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]user-interface aux 0
[SW5500-ui-aux0]databits 7
```

## View

This command can be used in the following views:

- User Interface view

## Description

This command can only be performed in the AUX User Interface view.



# debugging

---

## Purpose

Use the **debugging** command to enable the system debugging.

Use the **undo debugging** command to disable the system debugging.

## Syntax

```
debugging module-name [debugging-option]
```

```
undo debugging { all | module-name [debugging-option] }
```

## Parameters

**all** Disables all the debugging.

**timeout interval** The interval during which the debugging command is valid. Valid *interval* values are 1 to 1440 minutes.

**module-name** Specifies the module name.

**debugging-option** Debugging option.

## Default

By default, all the debugging processes are disabled.

## Example

Enable IP Packet debugging.

```
<SW5500>debugging ip packet
IP packet debugging switch is on.
```

## View

This command can be used in the following views:

- User view

## Description

The Switch provides various kinds of debugging functions for technical support personnel and experienced maintenance staff to troubleshoot the network.

Enabling the debugging will generate a large amount of debugging information and decrease the system efficiency. If the **debugging all** command is used, it will adversely affect the operational performance of the network. Use the **undo debugging all** command to disable all debugging.

By default, if multiple devices form a fabric, the debugging information of the master is broadcasted within the fabric and the debugging information of the slave is only displayed on the slave device. You can view the debugging information including that of the master and the device in which the login port resides.

You can enable the logging, debugging and trap information switches within the fabric by executing the **info-center switch-on all** command. Synchronization is a process that each switch sends its own information to the other switches in the fabric,

and meantime receives information from others to update local information, ensuring the consistency of logging, debugging and trap information in a fabric.



*After the synchronization of the whole fabric, a great deal of terminal display is generated. You are recommended not to enable the information synchronization switch of the whole fabric. If you enabled the information synchronization switch, after the synchronization information statistics and detection, you must execute the **undo info-center switch-on** command to disable the switch in time.*

## Related Command

**display debugging**

# debugging arp packet

---

## Purpose

Use the `debugging arp` command to enable ARP debugging.

Use the `undo debugging arp` command to disable the corresponding ARP debugging.

## Syntax

```
debugging arp [packet | error | info packet]
```

```
undo debugging arp packet
```

## Parameters

|                     |                                                                             |
|---------------------|-----------------------------------------------------------------------------|
| <code>error</code>  | Specifies to enable ARP error debugging.                                    |
| <code>info</code>   | Specifies to enable ARP mapping table and information management debugging. |
| <code>packet</code> | Specifies to enable ARP packet debugging.                                   |

## Description

By default, undo ARP debugging is enabled.

## Example

To enable ARP packet debugging, enter the following:

```
<SW5500>debugging arp packet
*0.771346-ARP-8-S1-arp_send:Send an ARP Packet, operation : 1,
sender_eth_addr :
 00e0-fc00-3500,sender_ip_addr : 10.110.91.159, target_eth_addr :
0000-0000-0000
, target_ip_addr : 10.110.91.193
*0.771584-ARP-8-S1-arp_rcv:Receive an ARP Packet, operation : 2,
sender_eth_addr
: 0050-ba22-6fd7, sender_ip_addr : 10.110.91.193, target_eth_addr :
00e0-fc00-3500, target_ip_addr : 10.110.91.159
```

**Table 2** Output Description of the debugging arp packet command

| Field           | Description                                                                                   |
|-----------------|-----------------------------------------------------------------------------------------------|
| operation       | Type of ARP packets: 1 ARP request packet; 2 ARP reply packet                                 |
| sender_eth_addr | Ethernet address of the sender                                                                |
| sender_ip_addr  | IP address of the sender                                                                      |
| target_eth_addr | Target Ethernet address. If the packet is ARP request packet, the target IP address will be 0 |
| target_ip_addr  | Target IP address                                                                             |

## View

This command can be used in the following views:

- User view

## **Related Commands**

- `arp static`
- `display arp`

# debugging dhcp client

---

**Purpose** Use the `debugging dhcp client` command to enable DHCP client debugging.  
Use the `undo debugging dhcp client` command to disable DHCP client debugging.

**Syntax**

```
debugging dhcp client { all | error | event | packet }
undo debugging dhcp client { all | error | event | packet }
```

**Parameters**

|                     |                                                                                                 |
|---------------------|-------------------------------------------------------------------------------------------------|
| <code>all</code>    | Specifies to enable all DHCP client debugging.                                                  |
| <code>error</code>  | Specifies to enable DHCP client error (including packet unrecognizable) debugging.              |
| <code>event</code>  | Specifies to enable DHCP client event (including address allocation and data update) debugging. |
| <code>packet</code> | Specifies to enable DHCP client packet debugging.                                               |

**Default** By default, all DHCP client debugging is disabled.

**Example** To enable DHCP client event debugging, enter the following:

```
<SW5500>debugging dhcp client event
```

**View** This command can be used in the following views:

- User view

# debugging dhcp-relay

---

**Purpose** Use the `debugging dhcp-relay` command to enable DHCP relay debugging.

Use the `undo debugging dhcp-relay` command to disable DHCP relay debugging.

**Syntax**

```
debugging dhcp-relay
undo debugging dhcp-relay
```

**Parameters** None

**Default** By default, DHCP relay debugging is disabled.

**Example** Enable DHCP relay debugging.

```
<S5500> debugging dhcp-relay
*0.7200205-DHCP-8-dhcp_debug:
From client to server:
Interface: VLAN-Interface 1
ServerGroupNo: 0
Type: dhcp-request
ClientHardAddress: 0010-dc19-695d
 ServerIpAddress: 192.168.1.2

*0.7200230-DHCP-8-dhcp_debug:
From server to client:
Interface: VLAN-Interface 1
ServerGroupNo: 0
Type: dhcp-ack
ClientHardAddress: 0010-dc19-695d
 AllocatedIpAddress: 10.1.1.1

*0.7200580-DHCP-8-largehop:
Discard DHCP request packet because of too large hop count!

*0.7200725-DHCP-8-invalidpkt:
Wrong DHCP packet!
```

**Table 3** Description on the fields of the debugging dhcp-relay command

| Field              | Description                                     |
|--------------------|-------------------------------------------------|
| Interface          | VLAN interface carrying the DHCP relay function |
| ServerGroupNo      | DHCP server group number of the DHCP relay      |
| Type               | DHCP packet type of the DHCP relay              |
| ClientHardAddress  | MAC address of the DHCP client                  |
| ServerIpAddress    | IP address of the DHCP server                   |
| AllocatedIpAddress | IP address assigned to the DHCP client          |

## View

This command can be used in the following views:

- User view

## Related Commands

- `dhcp-server ip`
- `dhcp-server`
- `display dhcp-server`
- `display dhcp-server interface vlan-interface`

# debugging dhcp server

---

## Purpose

Use the **debugging dhcp server** command to enable a specified type or all types of debugging on a DHCP server.

Use the **undo debugging dhcp server** command to disable a specified type or or all types of debugging on a DHCP server.

## Syntax

```
debugging dhcp server { all | error | event | packet | irf
synchronization }
```

```
undo debugging dhcp server { all | error | event | packet | irf
synchronization }
```

## Parameters

|                            |                                                                                                                                                                        |
|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>all</b>                 | Enables/disables all types of debugging on a DHCP server.                                                                                                              |
| <b>error</b>               | Enables/disables error debugging on a DHCP server, for the errors that occur when a DHCP server processes DHCP packets and assigns IP addresses.                       |
| <b>event</b>               | Enables/disables event debugging on a DHCP server, for the events such as IP address assigning and ping timeout.                                                       |
| <b>packet</b>              | Enables/disables DHCP packet debugging on a DHCP server, for the packets received/sent by the DHCP server and the ping packets.                                        |
| <b>irf synchronization</b> | Enables/disables IRF (intelligent resilient framework) debugging on a DHCP server, for the sending/receiving situation of batch backup data and real-time backup data. |

## Description

By default, no debugging is enabled on a DHCP server.

## Example

Enable event debugging on a DHCP server.

```
<S5500> debugging dhcp server events
*0.62496500-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: ICMP Timeout
*0.62496583-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: Still Need to ICMP detect for 1 times
*0.62497000-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: ICMP Timeout
*0.62497083-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: All Try finished
*0.62497166-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: Ack User's Lease
```



Enable packet debugging on a DHCP server.

```
<S5500> debugging dhcp server packet
*0.62080906-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: receive DHCPRELEASE from 00.05.5D.85.D5.45.
*0.62081016-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: Release Lease for MAC 00.05.5D.85.D5.45. IP is 5.5.5.2
*0.62082240-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: receive DHCPDISCOVER from 00.05.5D.85.D5.45.
*0.62082350-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: Sending ICMP ECHO to Target IP: 5.5.5.2
*0.62082733-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: Sending ICMP ECHO to Target IP: 5.5.5.2
*0.62083233-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: Send DHCP OFFER to MAC=> 00.05.5D.85.D5.45. Offer IP=>
5.5.5.2
*0.62083366-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: receive DHCPREQUEST from 00.05.5D.85.D5.45.
*0.62083483-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: Send DHCPACK to MAC=> 00.05.5D.85.D5.45. Offer IP=> 5.5.5.2
```

Enable error debugging on a DHCP server.

```
<S5500> debugging dhcp server error
*0.63269475-DHCP SER-8-DHCPS_DEBUG_COMMON:
DhcpServer: Icmp Packet is not EHHOREPLY!
```

Enable IRF debugging on a DHCP server.

```
<S5500> debugging dhcp server irf synchronization
*0.89790713 5500-EI DHCPS/8/DHCPS_DEBUG_COMMON:- 1 -
 DHCP Server begin to send XRN One RealTime Lease Backup Data !
*0.89790832 5500-EI DHCPS/8/DHCPS_DEBUG_COMMON:- 1 -
 DHCP Server : Send Lease to slave
 Ip Address: 2.2.1.6
 Mac Address: 0010-5CE8-8803
 Start Time : Apr 3 2000 00:46:31 AM
 Expired Time: Apr 4 2000 00:51:31 AM
 Lease State: DHCP_LEASE_COMMITTED
*0.89791149 5500-EI DHCPS/8/DHCPS_DEBUG_COMMON:- 1 -
 DHCP Server finished sending XRN One RealTime Lease Backup Data !
*0.89791299 5500-EI DHCPS/8/DHCPS_DEBUG_COMMON:Slot=2;- 2 -
 DHCP Server begin to Receive a RealTime Batchup Data
*0.89791433 5500-EI DHCPS/8/DHCPS_DEBUG_COMMON:Slot=2;- 2 -
 DHCP Server : Receive Lease from master
 Ip Address: 2.2.1.6
 Mac Address: 0010-5CE8-8803
 Start Time : Apr 3 2000 00:46:31 AM
 Expired Time: Apr 4 2000 00:51:31 AM
 Lease State: DHCP_LEASE_COMMITTED
*0.89791749 5500-EI DHCPS/8/DHCPS_DEBUG_COMMON:Slot=2;- 2 -
 DHCP Server finished Receiving a RealTime Batchup Data
```

## View

This command can be used in the following views:

- User view

## Description



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

# debugging dhcp xrn xha

---

|                   |                                                                                                                                                                                                                       |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | <p>Use the <code>debugging dhcp xrn xha</code> command to enable BOOTP client hot backup debugging.</p> <p>Use the <code>undo debugging dhcp xrn xha</code> command to disable BOOTP client hot backup debugging.</p> |
| <b>Syntax</b>     | <pre>debugging dhcp xrn xha undo debugging dhcp xrn xha</pre>                                                                                                                                                         |
| <b>Parameters</b> | None                                                                                                                                                                                                                  |
| <b>Default</b>    | By default, BOOTP client hot backup debugging is disabled.                                                                                                                                                            |
| <b>Example</b>    | <p>To enable BOOTP client hot backup debugging, enter the following:</p> <pre>&lt;SW5500&gt;debugging dhcp xrn xha</pre>                                                                                              |
| <b>View</b>       | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ User view</li></ul>                                                                                                   |

# debugging dhcp xrn xha

---

## Purpose

Use the `debugging dhcp xrn xha` command to enable DHCP client hot backup debugging.

Use the `undo debugging dhcp xrn xha` command to disable DHCP client hot backup debugging.

## Syntax

```
debugging dhcp xrn xha
```

```
undo debugging dhcp xrn xha
```

## Parameters

None

## Default

By default, DHCP client hot backup debugging is disabled.

## Example

To enable DHCP client hot backup debugging, enter the following:

```
<SW5500>debugging dhcp xrn xha
```

## View

This command can be used in the following views:

- User view

# debugging DLDP

---

## Purpose

Use the **debugging dldp** command to enable specific debugging for DLDP on all ports with DLDP enabled.

Use the **undo debugging dldp** command to disable debugging for DLDP on all ports with DLDP enabled.

## Syntax

```
debugging dldp { error | neighbor | packet | state } | all }
```

```
undo debugging dldp { error | neighbor | packet | state | all }
```

## Parameters

|                 |                                        |
|-----------------|----------------------------------------|
| <b>error</b>    | Debugging for DLDP error.              |
| <b>neighbor</b> | Debugging for DLDP neighbor.           |
| <b>packet</b>   | Debugging for DLDP packets.            |
| <b>state</b>    | Debugging for the DLDP status on ports |
| <b>all</b>      | All DLDP debuggings.                   |

## Default

By default, DLDP debugging is disabled.

## Example

Enable debugging for DLDP error.

```
<S5500> debugging dldp error
```

## View

This command can be used in the following views:

- User view

## Related Command

```
display dldp
```

# debugging hwtacacs

---

**Purpose** Use the `debugging hwtacacs` command to enable HWTACACS debugging.

Use the `undo debugging hwtacacs` command to disable HWTACACS debugging.

**Syntax**

```
debugging hwtacacs { all | error | event | message | receive-packet | send-packet }
```

```
undo debugging hwtacacs { all | error | event | message | receive-packet | send-packet }
```

|                   |                             |                                    |
|-------------------|-----------------------------|------------------------------------|
| <b>Parameters</b> | <code>all</code>            | Enables all HWTACACS debugging.    |
|                   | <code>error</code>          | Enables error debugging.           |
|                   | <code>event</code>          | Enables event debugging.           |
|                   | <code>message</code>        | Enables message debugging.         |
|                   | <code>receive-packet</code> | Enables incoming packet debugging. |
|                   | <code>send-packet</code>    | Enables outgoing packet debugging. |

**Default** By default, HWTACACS debugging is disabled.

**Example** Enable the event debugging of HWTACACS.

```
<S5500> debugging hwtacacs event
```

**View** This command can be used in the following views:

- User view

# debugging igmp

---

## Purpose

Use the `debugging igmp` command to enable IGMP debugging functions.

Use the `undo debugging igmp` command to disable the debugging functions.

## Syntax

```
debugging igmp { all | event | host | packet | timer }
```

```
undo debugging igmp { all | event | host | packet | timer }
```

## Parameters

|                     |                                                           |
|---------------------|-----------------------------------------------------------|
| <code>all</code>    | Enables all the debugging information for IGMP functions. |
| <code>event</code>  | Enables debugging information for IGMP events.            |
| <code>host</code>   | Enables debugging information for IGMP hosts              |
| <code>packet</code> | Enables debugging information for IGMP packets.           |
| <code>timer</code>  | Enables debugging information for IGMP timers.            |

## Default

By default, IGMP debugging functions are disabled.

## Example

Enable all IGMP debugging functions

```
<SW5500>debugging igmp all
```

## View

This command can be used in the following views:

- User view

# debugging lacp packet

---

## Purpose

Use the `debugging lacp packet` command to enable LACP packets debugging at a designated port or ports.

Use the `undo debugging lacp packet` command to disable LACP packets debugging at a designated port or ports.

## Syntax

```
debugging lacp packet [interface { interface_type interface_number |
interface_name } [to { interface_type interface_num | interface_name }
]]
```

```
undo debugging lacp packet [interface { interface_type
interface_number | interface_name } [to { interface_type interface_num
| interface_name }]]
```

## Parameters

```
interface { interface_type
interface_num |
interface_name } [to {
interface_type interface_
num | interface_name }]
```

Specifies ports. You can specify multiple sequential ports with the `to` parameter, instead of specifying only one port.

*interface\_name*

Specifies port name, in the format of `interface_name = interface_type interface_num`.

*interface\_type*

Specifies port type and *interface\_num* port number.

For more information, see the parameter item for the `interface` command.

## Example

To enable LACP packets debugging at Ethernet1/0/1, enter the following:

```
<SW5500>debugging lacp packet interface ethernet1/0/1
```

## View

This command can be used in the following views:

- User view

# debugging lacp state

---

## Purpose

Use the `debugging lacp state` command to enable LACP state machines debugging on a designated port or ports.

Use the `undo debugging lacp state` command to disable LACP state machines debugging on a designated port or ports.

## Syntax

```
debugging lacp state [interface { interface_type interface_number |
interface_name } [to { interface_type interface_num | interface_name }
]] { { actor-churn | mux | partner-churn | ptx | rx }* | all }
```

```
undo debugging lacp state [interface { interface_type interface_number |
interface_name } [to { interface_type interface_num | interface_name }
]] { { actor-churn | mux | partner-churn | ptx | rx }* | all }
```

## Parameters

```
interface { interface_type
interface_num |
interface_name } [to {
interface_type
interface_num |
interface_name }]
```

Specifies ports. You can specify multiple sequential ports with the `to` parameter, instead of specifying only one port.

*interface\_name* Specifies port name, in the format of ***interface\_name* = *interface\_type* *interface\_num***.

*interface\_type* Specifies port type and *interface\_num* port number.

For more information, see the parameter item for the `interface` command.

**actor-churn** Debugging actor-churn state machine.

**mux** Debugging MUX state machine.

**partner-churn** Debugging partner-churn state machine.

**ptx** Debugging PTX state machine.

**rx** Debugging RX state machine.

**all** Debugging all state machines.

## Example

To enable all LACP state machines debugging.

```
<SW5500>debugging lacp state all
```

## View

This command can be used in the following views:

- User view



# debugging link-aggregation error

---

## Purpose

Use the `debugging link-aggregation error` command to enable link aggregation error debugging.

Use the `undo debugging link-aggregation error` command to disable link aggregation error debugging.

## Syntax

```
debugging link-aggregation error
```

```
undo debugging link-aggregation error
```

## Parameters

None

## Example

To enable link aggregation error debugging, enter the following:

```
<SW5500>debugging link-aggregation error
```

## View

This command can be used in the following views:

- User view

# debugging link-aggregation event

---

## Purpose

Use the `debugging link-aggregation event` command to enable link aggregation events debugging.

Use the `undo debugging link-aggregation event` command to disable link aggregation events debugging.

## Syntax

```
debugging link-aggregation event
```

```
undo debugging link-aggregation event
```

## Parameters

None

## Example

To enable link aggregation events debugging, enter the following:

```
<SW5500>debugging link-aggregation event
```

## View

This command can be used in the following views:

- User view

# debugging mac-authentication event

---

## Purpose

Use the **debugging mac-authentication event** command to enable debugging for centralized MAC address authentication events.

Use the **undo debugging mac-authentication event** command to disable debugging for centralized MAC address authentication events.

## Syntax

```
debugging mac-authentication event
```

```
undo debugging mac-authentication event
```

## Parameters

None

## Example

Enable debugging for centralized MAC address authentication events.

```
<S5500> debugging mac-authentication event
```

## View

This command can be used in the following views:

- User view

# debugging msdp

---

## Purpose

Use the `debugging msdp` command to enable debugging for MSDP.

Use the `undo debugging msdp` command to disable debugging for MSDP.

## Syntax

```
debugging msdp { all | connect | event | packet | source-active }
undo debugging msdp { all | connect | event | packet | source-active }
```

## Parameters

|                            |                                                            |
|----------------------------|------------------------------------------------------------|
| <code>all</code>           | Enables/disables all types of debugging for MSDP.          |
| <code>connect</code>       | Enables/disables debugging for MSDP peer connection reset. |
| <code>event</code>         | Enables/disables debugging for MSDP events.                |
| <code>packet</code>        | Enables/disables debugging for MSDP packets.               |
| <code>source-active</code> | Enables/disables debugging for MSDP SA messages.           |

## Default

By default, no debugging for MSDP is enabled.

If you enable debugging for all the instances, debugging will be automatically enabled for new instances.

## Example

Enable all types of debugging for MSDP.

```
<S5500> debugging msdp all
```

## View

This command can be used in the following views:

- User view

# debugging multicast forwarding

---

|                   |                                                                                                                                                                                                                           |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | <p>Use the <code>debugging multicast forwarding</code> to enable multicast packet forwarding debugging functions.</p> <p>Use the <code>undo debugging multicast forwarding</code> to disable the debugging functions.</p> |
| <b>Syntax</b>     | <pre>debugging multicast forwarding undo debugging multicast forwarding</pre>                                                                                                                                             |
| <b>Parameters</b> | None                                                                                                                                                                                                                      |
| <b>Default</b>    | By default, the debugging function is disabled.                                                                                                                                                                           |
| <b>Example</b>    | <p>Enable multicast packet forwarding debugging functions.</p> <pre>&lt;SW5500&gt;debugging multicast forwarding</pre>                                                                                                    |
| <b>View</b>       | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ User view</li></ul>                                                                                                       |

# debugging multicast kernel-routing

---

|                   |                                                                                                                                                                                                                                |
|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | <p>Use the <code>debugging multicast kernel-routing</code> to enable multicast kernel routing debugging functions.</p> <p>Use the <code>undo debugging multicast kernel-routing</code> to disable the debugging functions.</p> |
| <b>Syntax</b>     | <pre>debugging multicast kernel-routing undo debugging multicast kernel-routing</pre>                                                                                                                                          |
| <b>Parameters</b> | None                                                                                                                                                                                                                           |
| <b>Example</b>    | <p>Enable multicast kernel routing debugging functions.</p> <pre>&lt;SW5500&gt;debugging multicast kernel-routing</pre>                                                                                                        |
| <b>View</b>       | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ User view</li></ul>                                                                                                            |

# debugging multicast status-forwarding

---

## Purpose

Use the `debugging multicast status-forwarding` to enable multicast forwarding status debugging functions.

Use the `undo debugging multicast status-forwarding` to disable the debugging functions.

## Syntax

```
debugging multicast status-forwarding
```

```
undo debugging multicast status-forwarding
```

## Parameters

None

## Example

Enable multicast forwarding status debugging functions.

```
<SW5500>debugging multicast status-forwarding
```

## View

This command can be used in the following views:

- User view

# debugging ntp-service

---

**Purpose** Use the `debugging ntp-service` command to debug different NTP services.

Use the `undo debugging ntp-service` command to disable corresponding debugging function.

**Syntax**

```
debugging ntp-service { access | adjustment | authentication | event |
filter | packet | parameter | refclock | selection | synchronization |
validity | all }
```

```
undo debugging ntp-service { access | adjustment | authentication |
event | filter | packet | parameter | refclock | selection |
synchronization | validity | all }
```

|                   |                        |                                                  |
|-------------------|------------------------|--------------------------------------------------|
| <b>Parameters</b> | <b>access</b>          | NTP access control debugging.                    |
|                   | <b>adjustment</b>      | NTP clock adjustment debugging.                  |
|                   | <b>all</b>             | All NTP debugging functions.                     |
|                   | <b>authentication</b>  | NTP authentication debugging.                    |
|                   | <b>event</b>           | NTP event debugging.                             |
|                   | <b>filter</b>          | NTP filter information debugging.                |
|                   | <b>packet</b>          | NTP packet debugging.                            |
|                   | <b>parameter</b>       | NTP clock parameter debugging.                   |
|                   | <b>refclock</b>        | NTP reference clock debugging.                   |
|                   | <b>selection</b>       | NTP clock selection information debugging.       |
|                   | <b>synchronization</b> | NTP clock synchronization information debugging. |
|                   | <b>validity</b>        | NTP remote host validity debugging.              |

**Default** By default, no debugging function is enabled.

**Example** Enable NTP access control debugging.

```
<SW5500>debugging ntp-service access
```

**View** This command can be used in the following views:

- User view



# debugging pim common

---

**Purpose** Use the `debugging pim common` to enable common PIM debugging functions.

Use the `undo debugging pim common` to disable the debugging functions.

## Syntax

```
debugging pim common { all | event | packet | timer }
```

```
undo debugging pim common { all | event | packet | timer }
```

## Parameters

|                     |                                              |
|---------------------|----------------------------------------------|
| <code>all</code>    | All the common debugging information of PIM. |
| <code>event</code>  | Debugging information of common PIM event.   |
| <code>packet</code> | Debugging information of PIM hello packet.   |
| <code>timer</code>  | Debugging information of common PIM timer.   |

## Default

By default, common PIM debugging functions are disabled.

## Example

Enable all common PIM debugging functions.

```
<SW5500>debugging pim common all
```

## View

This command can be used in the following views:

- User view

# debugging pim dm

---

**Purpose** Use the `debugging pim dm` to enable PIM-DM debugging functions.

Use the `undo debugging pim dm` to disable the debugging functions.

## Syntax

```
debugging pim dm { alert | all | mrt | timer | warning | { recv | send
} { all | assert | graft | graft-ack | join | prune } }
```

```
undo debugging pim dm { alert | all | mrt | timer | warning | { recv |
send } { all | assert | graft | graft-ack | join | prune } }
```

## Parameters

|                                                                      |                                                          |
|----------------------------------------------------------------------|----------------------------------------------------------|
| <code>alert</code>                                                   | Interoperation event debugging information of PIM-DM.    |
| <code>all</code>                                                     | All the debugging information of PIM-DM.                 |
| <code>mrt</code>                                                     | Debugging information of PIM-DM multicast routing table. |
| <code>timer</code>                                                   | Debugging information of PIM-DM timer.                   |
| <code>warning</code>                                                 | Debugging information of PIM-DM warning message.         |
| <code>recv</code>                                                    | Debugging information of PIM-DM receiving packets.       |
| <code>send</code>                                                    | Debugging information of PIM-DM sending packets.         |
| <code>all   assert  <br/>graft   graft-ack  <br/>join   prune</code> | Packets type.                                            |

## Default

By default, PIM-DM debugging functions are disabled.

## Example

Enable all PIM-DM debugging functions

```
<SW5500>debugging pim dm all
```

## View

This command can be used in the following views:

- User view

# debugging pim sm

---

## Purpose

Use the `debugging pim sm` to enable PIM-SM debugging functions.

Use the `undo debugging pim sm` to disable the debugging functions.

## Syntax

```
debugging pim sm { all | register-proxy | mrt | warning | mbr {alert |
fresh } | timer { assert | bsr | crpadv | jp | jpdelay | mrt | probe |
spt } | { recv | send } { assert | bootstrap | crpadv | reg | regstop |
jp } }
```

```
undo debugging pim sm { all | register-proxy | mrt | warning | mbr
{alert | fresh } | timer { assert | bsr | crpadv | jp | jpdelay | mrt |
probe | spt } | { recv | send } { assert | bootstrap | crpadv | reg |
regstop | jp } }
```

## Parameters

|                                                                               |                                                                |
|-------------------------------------------------------------------------------|----------------------------------------------------------------|
| <code>mbr</code>                                                              | Debugging information of PIM-SM multicast border router event. |
| <code>register-proxy</code>                                                   | Debugging information of PIM-SM IO registry proxy.             |
| <code>mrt</code>                                                              | Debugging information of PIM-SM multicast routing table.       |
| <code>timer</code>                                                            | Debugging information of PIM-SM timer.                         |
| <code>warning</code>                                                          | Debugging information of PIM-SM warning message.               |
| <code>recv</code>                                                             | Debugging information of PIM-SM receiving packets.             |
| <code>send</code>                                                             | Debugging information of PIM-SM sending packets.               |
| <code>alert   fresh</code>                                                    | Debugging information of PIM-SM multicast border router event. |
| <code>assert   bootstrap   crpadv<br/>  jp   reg   regstop</code>             | Packets type.                                                  |
| <code>assert   bsr   crpadv   jp<br/>  jpdelay   mrt   probe  <br/>spt</code> | Debugging information of PIM-SM timer.                         |

## Default

By default, PIM-SM debugging functions are disabled.

## Example

Enable all PIM-SM debugging functions.

```
[SW5500]debugging pim sm all
```

## View

This command can be used in the following views:

- User view

# debugging resilient-arp

---

**Purpose** Use the `debugging resilient-arp` command to enable resilient ARP debugging.

Use the `undo debugging resilient-arp` command to disable resilient ARP debugging.

**Syntax**

```
debugging resilient-arp { packet | state | error | all }
undo debugging resilient-arp { packet | state | error | all }
```

**Parameters**

|               |                                                                           |
|---------------|---------------------------------------------------------------------------|
| <i>packet</i> | Enter to enable debugging resilient ARP packets.                          |
| <i>state</i>  | Enter to enable debugging resilient ARP state machine.                    |
| <i>error</i>  | Enter to enable debugging resilient ARP errors (including packet errors). |
| <i>all</i>    | Enter to enable all resilient ARP debugging.                              |

**Default** By default, all resilient ARP debugging is disabled.

**Example** To enable debugging resilient ARP packets, enter the following:

```
<SW5500>debugging resilient-arp packet
```

**View** This command can be used in the following views:

- User view

# debugging ssh server

---

## Purpose

Use the **debugging ssh server** command to send the negotiation process and other information prescribed in SSH 2.0 to the information center as debugging information, and to enable debugging for a single user interface.

Use the **undo debugging ssh server** command to disable SSH debugging.

## Syntax

```
debugging ssh server { VTY vty-num | all }
```

```
undo debugging ssh server { VTY vty-num | all }
```

## Parameters

|                |                                                                                                                 |
|----------------|-----------------------------------------------------------------------------------------------------------------|
| <i>vty-num</i> | SSH channel to be debugged. It must be within the range of VTY user interface numbers. Valid values are 0 to 4. |
| <b>all</b>     | All SSH channels.                                                                                               |

## Default

By default, SSH debugging is not enabled.

## Example

Enable SSH debugging for the VTY 0 user interface.

```
<S5500> debugging ssh server vty 0
```

## View

This command can be used in the following views:

- User view

## Related Commands

- **ssh server authentication-retries**
- **ssh server timeout**

# debugging udp-helper

---

## Purpose

Use the `debugging udp-helper` command to enable UDP Helper debugging.

Use the `undo debugging udp-helper` command to disable UDP Helper debugging.

## Syntax

```
debugging udp-helper { event | packet [receive | send] }
undo debugging udp-helper { event | packet [receive | send] }
```

## Parameters

|                      |                                       |
|----------------------|---------------------------------------|
| <code>event</code>   | UDP Helper event debugging.           |
| <code>packet</code>  | UDP Helper packet debugging.          |
| <code>receive</code> | UDP Helper inbound packet debugging.  |
| <code>send</code>    | UDP Helper outbound packet debugging. |

## Default

By default, UDP Helper debugging is disabled.

## Example

To enable UDP Helper packet debugging, enter the following:

```
<SW5500>debugging udp-helper packet
```

## View

This command can be used in the following views:

- User view

# debugging vrrp

---

## Purpose

Use the **debugging vrrp** command to enable VRRP debugging.

Use the **undo debugging vrrp** command to disable VRRP debugging. By default, VRRP debugging is disabled.

## Syntax

```
debugging vrrp { state | packet }
```

```
undo debugging vrrp { state | packet }
```

## Parameters

**state** Debugs VRRP state.

**packet** Debugs VRRP packets.

## Example

Enable VRRP debugging.

```
<S5500> debugging vrrp state
```

## View

This command can be used in the following views:

- User view

## Description



*The VRRP feature is supported by Switch 5500-EI series switches but is not supported by Switch 5500-SI series switches.*

# debugging webcache

---

|                   |                                                                                                                                                                                                                 |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | <p>Use the <code>debugging webcache</code> command to enable the debugging for Webcache redirection.</p> <p>Use the <code>undo debugging webcache</code> to disable the debugging for Webcache redirection.</p> |
| <b>Syntax</b>     | <pre>debugging webcache undo debugging webcache</pre>                                                                                                                                                           |
| <b>Parameters</b> | None                                                                                                                                                                                                            |
| <b>Example</b>    | <p>To enable the debugging for Webcache redirection, enter the following:</p> <pre>&lt;SW5500&gt; debugging webcache</pre>                                                                                      |
| <b>View</b>       | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ User view</li></ul>                                                                                             |



# default cost

---

## Purpose

Use the **default cost** command to configure the default routing cost of an external route imported by OSPF.

Use the **undo default cost** command to restore the default value of the default routing cost configured for OSPF to import external routes.

## Syntax

```
default cost value
```

```
undo default cost
```

## Parameters

**value**

Specifies the default routing cost of the external route imported by OSPF. Valid values are 0 to 16777214. If not specified, the default value is 1.

## Example

To specify a default routing cost of 10 for an external route imported by OSPF, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]default cost 10
```

## View

This command can be used in the following views:

- OSPF view

## Description

Since OSPF can import external routing information, whose routing cost can influence routing selection and calculation, and propagate it to the entire autonomous system, it is necessary to specify the default routing cost for the protocol to import external routes.

# default-cost

---

**Purpose** Use the **default-cost** command to configure the cost of the route transmitted by OSPF to a Stub or NSSA area.

Use the **undo default-cost** command to restore the default cost of the default route transmitted by OSPF to a Stub or NSSA.

**Syntax**

```
default-cost value
undo default-cost
```

**Parameters**

|              |                                                                                                                                                                     |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>value</b> | Specifies the cost value of the default route transmitted by OSPF to a Stub or NSSA area. Valid values are 0 to 16777214. If not specified, the default value is 1. |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example** To set area 1 as a Stub area, and to set the cost of the default route transmitted to this Stub area to 60, enter the following commands:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]area 1
[SW5500-ospf-1-area-0.0.0.1]network 20.0.0.0 0.255.255.255
[SW5500-ospf-1-area-0.0.0.1]stub
[SW5500-ospf-1-area-0.0.0.1]default-cost 60
```

**View** This command can be used in the following views:

- OSPF Area view

**Related Commands**

- **nssa**
- **stub**

# default cost

---

**Purpose** Use the `default cost` command to set the default routing cost of an imported route.

Use the `undo default cost` command to restore the default value.

**Syntax** `default cost value`

`undo default cost`

**Parameters** `value` Enter the default routing cost. Valid values are 1 to 16. If not specified, the default is 1.

**Example** To set the default routing cost of the imported route of another routing protocol to 3, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]rip
[SW5500-rip]default cost 3
```

**View** This command can be used in the following views:

- RIP view

**Description** If you do not specify a routing cost when using the `import-route` command, the default cost you specify here is used.

**Related Command** `import-route`

# default interval

---

## Purpose

Use the `default interval` command to configure the default interval for OSPF to import external routes.

Use the `undo default interval` command to restore the default value of 1 second.

## Syntax

```
default interval seconds
```

```
undo default interval
```

## Parameters

*seconds*

Specifies the default interval, in seconds, for redistributing external routes. Valid values are 1 to 2147483647.

If no value is specified, the default is 1 second.

## Example

To specify a default interval of 10 seconds for OSPF to import external routes, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]default interval 10
```

## View

This command can be used in the following views:

- OSPF view

## Description

Because OSPF can import external routing information and broadcast it to the entire autonomous system, and importing routes can affect the performances of the device (depending on the number of external routes being imported), it is necessary to specify the default interval for the protocol to import external routes.

# default limit

---

## Purpose

Use the `default limit` command to configure maximum number of allowed imported routes.

Use the `undo default limit` command to restore the default value.

## Syntax

```
default limit routes
```

```
undo default limit
```

## Parameters

*routes*

Specifies a limit on the number of imported external routes. Valid values are 200 to 2147483647. If no value is specified, the default limit is 1000.

## Example

To specify a limit of 200 imported external routes, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]default limit 200
```

## View

This command can be used in the following views:

- OSPF view

## Description

OSPF can import external routing information and advertise them to the whole AS. Importing too many external routes at once can greatly affect the performance of the device.

## Related Command

`default interval`

# default-route-advertise

---

## Purpose

Use the **default-route-advertise** command to import the default route into the OSPF Autonomous System.

Use the **undo default-route-advertise** command to cancel the import of default route. This is the default.

## Syntax

```
default-route-advertise [always | cost value | type type_value | route-policy route_policy_name]*
```

```
undo default-route-advertise [always | cost | type | route-policy]*
```

## Parameters

|                                           |                                                                                                                                                                                                                                                                                                      |
|-------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>always</b>                             | Generates an ASE LSA that describes the default route and advertises it if the local router is not configured with the default route. If this parameter is not set, the local router cannot import the ASE LSA, which generates the default route only when it is configured with the default route. |
| <b>costvalue</b>                          | Specifies the cost value of the ASE LSA. Valid values are 0 to 16777214.<br>If no value is specified, the default is 1.                                                                                                                                                                              |
| <b>typetype_value</b>                     | Specifies the external type of this ASE LSA. Valid values are 1 or 2.<br>If no value is specified, the default is 2.                                                                                                                                                                                 |
| <b>route-policy<br/>route_policy_name</b> | Specifies a definition for this parameter to have the route-policy affect the value in ASE LSA if the default route matches the route-policy specified by route-policy-name. The <b>route_policy_name</b> parameter may be 1 to 16 characters long.                                                  |

## Example

If a local route has no default route, the ASE LSA of the default route will be generated.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]default-route-advertise
```

The ASE LSA of the default route will be generated and advertised to OSPF route area even if the local router has no default route.

```
[SW5500-ospf]default-route-advertise always
```

## View

This command can be used in the following views:

- OSPF view

## Description

The `import-route` command cannot import the default route. When local router is not configured with default route, the keyword `always` should be used by ASE LSA to generate default route.

## Related Command

`import-route`

# default tag

---

## Purpose

Use the **default tag** command to configure the default tag of OSPF when it redistributes an external route.

Use the **undo default tag** command to restore the default tag of OSPF when it redistributes the external route.

## Syntax

```
default tag tag
```

```
undo default tag
```

## Parameters

**tag** Specifies a tag number. Valid values are 0 to 4294967295.

## Example

To set a default tag of 10 to OSPF imported external routes, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]default tag 10
```

## View

This command can be used in the following views:

- OSPF view

## Description

OSPF requires a default tag when redistributing a route found by other routing protocols.

## Related Command

```
default type
```



# default type

---

**Purpose** Use the `default type` command to configure the default type when OSPF redistributes external routes.

Use the `undo default type` command to restore the default type.

**Syntax**

```
default type { 1 | 2 }
undo default type
```

**Parameters**

|   |                                                                                            |
|---|--------------------------------------------------------------------------------------------|
| 1 | Sets the default to external routes of type 1.                                             |
| 2 | Sets the default to external routes of type 2.<br>If not specified, the default type is 2. |

**Example** To specify the default type as type 1 when OSPF imports an external route, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]default type 1
```

**View** This command can be used in the following views:

- OSPF view

**Description** OSPF requires a default type when redistributing a route found by other routing protocols.

**Related Command** `default tag`

# delete

---

**Purpose** Use the **delete** command to delete a specified file from the storage device of the switch.

**Syntax** `delete [ / unreserved ] file-path`

**Parameters**

|                          |                                                                         |
|--------------------------|-------------------------------------------------------------------------|
| <code>/unreserved</code> | The file will be deleted permanently if the user chooses this parameter |
| <code>file-path</code>   | Path and name of the file you want to delete.                           |

**Example** Delete the file flash:/test/test.txt

```
<SW5500>delete flash:/test/test.txt
Delete unit1>flash:/test/test.txt?[Y/N]:y
%Delete file unit1>flash:/test/test.txt...Done.
<SW5500>
```

**View** This command can be used in the following views:

- User view

**Description** The deleted files are kept in the recycle bin and will not be displayed when you use the **dir** command. However they will be displayed, using the **dir /all** command. The files deleted by the **delete** command can be recovered with the **undelete** command or deleted permanently from the recycle bin, using the **reset recycle-bin** command.



If two files with the same name in a directory are deleted, only the latest deleted file will be kept in the recycle bin.

# delete

---

**Purpose** Use the **delete** command to delete the specified file.  
This command is used to delete a file.

**Syntax** `delete remotefile`

**Parameters** `remotefile` File name.

**Example** Delete the file temp.c

```
<SW5500>ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in.
[ftp]delete temp.c
250 DELE command successful
```

**View** This command can be used in the following views:

- FTP Client view

# delete

---

**Purpose** Use the **delete** command to delete the specified file from the server.

**Syntax** `delete remote-file`

**Parameters** `remote-file` Name of a file on the server.

**Example** Delete file temp from the server.  

```
sftp-client> delete temp.c
```

**View** This command can be used in the following views:

- SFTP Client view

**Description** This command has the same function as the **remove** command.

# delete-member

---

**Purpose** Use the **delete-member** command to remove a member from the cluster.

**Syntax** `delete-member member-number`

**Parameters** *member-number* Number of a member device. Valid values are 1 to 255.

**Example** Delete the member switch numbered 2 from the cluster.

```
<aaa_0.S5500>system-view
System View: return to User View with Ctrl+Z.
[aaa_0.S5500]cluster
[aaa_0.S5500-cluster] delete-member 2
```

**View** This command can be used in the following views:

- Cluster view

**Description** This command can be performed on the management device only. Otherwise, an error message will appear.

# delete static-routes all

---

**Purpose** Use the `delete static-routes all` command to delete all the static routes.

**Syntax** `delete static-routes all`

**Parameters** None

**Example** Delete all the static routes in the router.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]delete static-routes all
Are you sure to delete all the static routes? [Y/N]
```

**View** This command can be used in the following views:

- System view

**Description** The system requests your confirmation before it deletes all the configured static routes.

**Related Commands**

- `ip route-static`
- `display ip routing-table`

# description

---

**Purpose** Use the `description` command to enter a description of an Ethernet port.  
Use the `undo description` command to cancel the description.

**Syntax** `description text`  
`undo description`

**Parameters** `text` Specifies a description of the Ethernet port. The description may be up to 80 characters long.

**Default** By default, an Ethernet port does not have a description.

**Example** Set the description of port Ethernet1/0/1 to be lanswitch-interface.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]description lanswitch-interface
[SW5500-Ethernet1/0/1]
```

**View** This command can be used in the following views:

- Ethernet Port view

# description

---

|                        |                                                                                                                                                                                                                                  |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>         | Use the <b>description</b> command to set a description for the current VLAN.<br>Use the <b>undo description</b> command to cancel the description of current VLAN.                                                              |
| <b>Syntax</b>          | <b>description</b> <i>string</i><br><b>undo description</b>                                                                                                                                                                      |
| <b>Parameters</b>      | <i>string</i> Specifies a description of the current VLAN, up to a maximum of 32 characters. For a description of a VLAN interface, the maximum is 80 characters.                                                                |
| <b>Example</b>         | To give VLAN1 the description "RESEARCH", enter the following:<br><br><pre>&lt;SW5500&gt;system-view System View: return to User View with Ctrl+Z. [SW5500]vlan 1 [SW5500-vlan1]description RESEARCH [SW5500-vlan1]</pre>        |
| <b>View</b>            | This command can be used in the following views:<br><ul style="list-style-type: none"><li>■ VLAN view</li></ul>                                                                                                                  |
| <b>Description</b>     | The default description character string of the current VLAN is <code>no description!</code> . The default description character string of the VLAN interface is the interface name, for example, <code>vlan-interface1</code> . |
| <b>Related Command</b> | <b>display vlan</b>                                                                                                                                                                                                              |



# destination-ip

---

## Purpose

Use the **destination-ip** command to configure the destination IP address of the test.

Use the **undo destination-ip** command to delete the configured destination IP address.

## Syntax

```
destination-ip ip-address
```

```
undo destination-ip
```

## Parameters

*ip-address*

Destination IP address of the test.

## Default

By default, no destination IP address is configured for the test.

## Example

Set the destination IP address of the test in the test group administrator icmp to 10.10.10.10.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] remote-ping administrator icmp
[S5500-remote-ping-administrator-icmp] destination-ip 10.10.10.10
```

## View

This command can be used in the following views:

- Remote-Ping Test Group view

# detect-group

---

## Purpose

Use the **detect-group** command to create a detecting group and enter detecting group view.

Use the **undo detect-group** command to remove a detecting group.

## Syntax

```
detect-group group-number
```

```
undo detect-group group-number
```

## Parameters

*group-number*

Detecting group number. Valid values are 1 to 50.

## Example

Create detecting group 10.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] detect-group 10
[S5500-detect-group-10]
```

## View

This command can be used in the following views:

- System view

# detect-list

---

## Purpose

Use the **detect-list** command to specify the IP address to be detected in the detecting group. This command also specifies the order in which the IP addresses in a detecting group are detected.

Use the **undo detect-list** command to specify to skip a specified IP address when performing auto detect operations.

## Syntax

```
detect-list list-number ip address ip-address [nexthop ip-address]
undo detect-list list-number ip address ip-address [nexthop ip-address]
```

## Parameters

|                           |                                                                                            |
|---------------------------|--------------------------------------------------------------------------------------------|
| <i>list-number</i>        | Sequence number of the address to be detected. Valid values for this argument are 1 to 10. |
| <i>ip-address</i>         | IP address to be detected.                                                                 |
| <i>nexthop ip-address</i> | Specifies the next hop IP address.                                                         |

## Example

Add the IP address of 202.13.1.55 to detecting group 10, with **list-number** set to 1, the next hop IP address set to 1.1.1.1.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] detect-group 10
[S5500-detect-group-10] detect-list 1 ip address 202.13.1.55 nexthop
1.1.1.1
```

## View

This command can be used in the following views:

- Detecting Group view

## Description

When performing auto detect operations, a switch detects the IP addresses by their **list-number** values in an ascending order. Up to 10 IP addresses can be configured in a detecting group. You can specify how the detecting result is generated using the **option** command.

## Related Command

**option**

# dhcp enable

---

**Purpose**

Use the **dhcp enable** command to enable DHCP.

Use the **undo dhcp enable** command to disable DHCP.

**Syntax**

```
dhcp enable
```

```
undo dhcp enable
```

**Parameters**

None

**Default**

By default, DHCP is enabled.

**Example**

Enter system view and enable DHCP, enter the following:

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] dhcp enable
```

**View**

This command can be used in the following views:

- System view

**Description**

You must first enable DHCP before performing other DHCP-related configurations. This configuration is necessary for both DHCP servers and DHCP relays.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

# dhcp relay information enable

---

## Purpose

Use the **dhcp relay information enable** command to enable option 82 supporting on a DHCP relay, through which you can enable the DHCP relay to insert option 82 into DHCP request packets sent to a DHCP server.

Use the **undo dhcp relay information enable** command to disable option 82 supporting on a DHCP relay, through which you can disable the DHCP relay from inserting option 82 into DHCP request packets sent to a DHCP server.

## Syntax

```
dhcp relay information enable
undo dhcp relay information enable
```

## Parameters

None

## Default

By default, this function is disabled.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Enable option 82 supporting on a DHCP relay.

```
[S5500] dhcp relay information enable
```

Disable option 82 supporting on a DHCP relay.

```
[S5500] undo dhcp relay information enable
```

## View

This command can be used in the following views:

- System view

## Related Command

```
dhcp relay information strategy
```

# dhcp relay information strategy

---

## Purpose

Use the **dhcp relay information strategy** command to instruct a DHCP relay to perform specified operations to DHCP request packets that carry option 82.

Use the **undo dhcp relay information strategy** command to instruct a DHCP relay to perform the default operations to DHCP request packets that carry option 82.

## Syntax

```
dhcp relay information strategy { drop | keep | replace }
undo dhcp relay information strategy
```

## Parameters

|                |                                                                                                  |
|----------------|--------------------------------------------------------------------------------------------------|
| <b>drop</b>    | Specifies to discard the DHCP request packets that carry option 82.                              |
| <b>keep</b>    | Specifies to remain the DHCP request packets that carry option 82 unchanged.                     |
| <b>replace</b> | Specifies to replace the option 82 carried by a DHCP request packet with that of the DHCP relay. |

## Default

By default, the DHCP relay replaces the option 82 carried by a DHCP request packet with its own option 82.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Instruct the DHCP relay to discard the DHCP request packets that carry option 82.

```
[S5500] dhcp relay information strategy drop
```

Instruct the DHCP relay to perform the default operations to DHCP request packets that carry option 82.

```
[S5500] undo dhcp relay information strategy
```

## View

This command can be used in the following views:

- System view

## Related Command

```
dhcp relay information enable
```

# dhcp select global

---

## Purpose

Use the **dhcp select global** command to configure the specified interface(s) or all interfaces to operate in global DHCP address pool mode.

Use the **undo dhcp select global** command to restore the default DHCP packet processing mode.

## Syntax

VLAN interface view:

```
dhcp select global
```

```
undo dhcp select global
```

System view:

```
dhcp select global { interface interface-type interface-number [to
interface-type interface-number] | all }
```

```
undo dhcp select global { interface interface-type interface-number [
to interface-type interface-number] | all }
```

## Parameters

```
interface interface-type
interface-number [to
interface-type
interface-number]
```

Specifies the interface(s) to operate in global address pool mode. The *interface-type* and *interface-number* arguments are the type and number of an interface. The *to* keyword separates the start and the end of an interface range.

```
all
```

Specifies all ports to operate in global address pool mode.

## Default

By default, an interface operates in local DHCP server global address pool mode.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Configure all interfaces to operate in global DHCP address pool mode, so that when a DHCP packet is received from a DHCP client through any interface, the DHCP server assigns an IP address in local global DHCP address pools to the DHCP client.

```
[S5500] dhcp select global all
```

**View**

This command can be used in the following views:

- System view
- VLAN Interface view

**Description**

Upon receiving a DHCP packet from a DHCP client through an interface operating in global DHCP address pool mode, the DHCP server chooses an IP address from a global DHCP address pool of the local DHCP server and assigns the address to the DHCP client.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*



# dhcp select interface

---

## Purpose

Use the **dhcp select interface** command to configure the specified interface(s) to operate in DHCP interface address pool mode.

Use the **undo dhcp select interface** command to restore the default DHCP packet processing mode.

## Syntax

VLAN interface view:

```
dhcp select interface
```

```
undo dhcp select interface
```

System view:

```
dhcp select interface { interface interface-type interface-number [to
interface-type interface-number] | all }
```

```
undo dhcp select interface { interface interface-type interface-number
[to interface-type interface-number] | all }
```

## Parameters

```
interface interface-type
interface-number [to
interface-type
interface-number]
```

Specifies the interface(s) to operate in interface address pool mode.

```
all
```

Specifies all interfaces to operate in interface address pool mode.

## Default

By default, an interface operates in local DHCP server global address pool mode.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Configure all interfaces to operate in interface DHCP address pool mode, so that when a DHCP packet is received from a DHCP client through any interface, the DHCP server assigns an IP address in the local interface DHCP address pool to the DHCP client.

```
[S5500] dhcp select interface all
```

## View

This command can be used in the following views:

- System view
- VLAN Interface view

**Description**

Upon receiving a DHCP packet from a DHCP client through an interface operating in interface address pool mode, the DHCP server chooses an IP address from the interface address pool of the local DHCP server and assigns the address to the DHCP client.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

# dhcp-server

---

**Purpose** Use the **dhcp-server** command to map the current VLAN interface to a DHCP server group.

Use the **undo dhcp-server** command to cancel the mapping.

**Syntax**

```
dhcp-server groupNo
undo dhcp-server
```

**Parameters**

|                |                                                                       |
|----------------|-----------------------------------------------------------------------|
| <i>groupNo</i> | DHCP server group number. Valid values for this argument are 0 to 19. |
|----------------|-----------------------------------------------------------------------|

**Examples**

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Enter VLAN 1 interface view.

```
[S5500] interface vlan-interface 1
```

Specify that VLAN 1 interface corresponds to DHCP server group 1.

```
[S5500-Vlan-interface1] dhcp-server 1
```

**View** This command can be used in the following views:

- VLAN Interface view

**Related Commands**

- **dhcp-server ip**
- **display dhcp-server**
- **display dhcp-server interface vlan-interface**
- **debugging dhcp-relay**

# dhcp server detect

---

## Purpose

Use the **dhcp server detect** command to enable the private DHCP server detecting function.

Use the **undo dhcp server detect** command to disable the private DHCP server detecting function.

## Syntax

```
dhcp server detect
```

```
undo dhcp server detect
```

## Parameters

None

## Default

By default, the private DHCP server detecting function is disabled.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Enable the private DHCP server detecting function.

```
[S5500] dhcp server detect
```

## View

This command can be used in the following views:

- System view

## Description

With the private DHCP server detecting function enabled, a DHCP server tracks the information (such as the IP addresses and interfaces) of DHCP servers to enable the administrator to detect private DHCP servers in time and take proper measures.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

# dhcp server dns-list

---

## Purpose

Use the **dhcp server dns-list** command to configure DNS server IP address(es) for the DHCP address pool(s) of specified interface(s).

Use the **undo dhcp server dns-list** command to remove the DNS server IP address(es) configured for the DHCP address pool(s) of the specified interface(s).

## Syntax

VLAN interface view:

```
dhcp server dns-list ip-address&<1-8>
```

```
undo dhcp server dns-list { ip-address | all }
```

System view:

```
dhcp server dns-list ip-address&<1-8> { interface interface-type
interface-number [to interface-type interface-number] | all }
```

```
undo dhcp server dns-list { ip-address | all } { interface
interface-type interface-number [to interface-type interface-number]
| all }
```

## Parameters

*ip-address&<1-8>*

IP address of a DNS server. &<1-8> means you can provide up to eight DNS server IP addresses. When inputting more than one DNS server IP address, separate two neighboring IP addresses with a space.

```
interface interface-type
interface-number [to
interface-type
interface-number]
```

Specifies the interface(s), through which you can specify the corresponding interface address pools.

**all**

(In comparison with the ip-address argument) Specifies all DNS server IP addresses.

**all**

(In comparison with the interface keyword) Specifies all interface address pools.

## Default

By default, no DNS server IP address is configured for a DHCP interface address pool.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Enter VLAN 1 interface view.

```
[S5500] interface Vlan-interface 1
```

Configure the DNS server IP address 1.1.1.254 for the DHCP address pool of the VLAN 1 interface.

```
[S5500-Vlan-interface1] dhcp server dns-list 1.1.1.254
```

## View

This command can be used in the following views:

- System view
- VLAN Interface view

## Description

If you execute the dhcp server dns-list command repeatedly, the new configuration overwrites the previous one.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

## Related Command

`dns-list`

# dhcp server domain-name

---

## Purpose

Use the **dhcp server domain-name** command to configure a domain name for the DHCP clients whose IP addresses are from the specified interface address pool(s).

Use the **undo dhcp server domain-name** command to remove the configured domain name.

## Syntax

VLAN interface view:

```
dhcp server domain-name domain-name
```

```
undo dhcp server domain-name
```

System view:

```
dhcp server domain-name domain-name { interface interface-type
interface-number [to interface-type interface-number] | all }
```

```
undo dhcp server domain-name { interface interface-type
interface-number [to interface-type interface-number] | all }
```

## Parameters

*domain-name*

Domain name of the DHCP clients whose IP addresses are from the specified interface address pool(s). This argument consists of a string from 3 to 50 characters long.

```
interface interface-type
interface-number [to
interface-type
interface-number]
```

Specifies the interface(s), through which you can specify the corresponding interface address pool(s).

all

Specifies all interface address pools.

## Default

By default, no domain name is configured for the DHCP clients.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Enter VLAN 1 interface view.

```
[S5500] interface Vlan-interface 1
```

Configure the domain name aabbcc.com for the DHCP clients whose IP addresses are from the DHCP address pool of the current VLAN interface.

```
[S5500-Vlan-interface1] dhcp server domain-name aabbcc.com
```

**View**

This command can be used in the following views:

- System view
- VLAN Interface view

**Description**

*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

**Related Command**

**domain-name**



# dhcp server expired

---

## Purpose

Use the **dhcp server expired** command to configure the lease time of the IP addresses in the specified interface address pool(s).

Use the **undo dhcp server expired** command to restore the default lease time.

## Syntax

VLAN interface view:

```
dhcp server expired { day day [hour hour [minute minute]] | unlimited }
```

```
undo dhcp server expired
```

System view:

```
dhcp server expired { day day [hour hour [minute minute]] | unlimited } { interface interface-type interface-number [to interface-type interface-number] | all }
```

```
undo dhcp server expired { interface interface-type interface-number [to interface-type interface-number] | all }
```

## Parameters

|                                                                                                                     |                                                                                                                         |
|---------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| <b>day</b> <i>day</i>                                                                                               | Specifies the number of days. Valid values are 0 to 365.<br>If not specified, the default lease time is 1 day.          |
| <b>hour</b> <i>hour</i>                                                                                             | Specifies the number of hours. Valid values are 0 to 23.                                                                |
| <b>minute</b> <i>minute</i>                                                                                         | Specifies the number of minutes. Valid values are 0 to 59.                                                              |
| <b>unlimited</b>                                                                                                    | Specifies that the lease time is unlimited. (But actually, the system limits the maximum lease time to about 25 years.) |
| <b>interface</b> <i>interface-type</i> <i>interface-number</i> [ to <i>interface-type</i> <i>interface-number</i> ] | Specifies the interface(s), through which you can specify the corresponding interface address pool(s).                  |
| <b>all</b>                                                                                                          | Specifies all interface address pools.                                                                                  |

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Set the lease time of the IP addresses in all interface address pools to be 1 day, 2 hours and 3 minutes.

```
[S5500] dhcp server expired day 1 hour 2 minute 3 all
```

**View**

This command can be used in the following views:

- System view
- VLAN Interface view

**Description**

*An IP address is considered to be expired if its lease time is after the year 2106.*

*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

**Related Command**

**expired**

# dhcp server forbidden-ip

---

## Purpose

Use the **dhcp server forbidden-ip** command to forbid the specified IP addresses in a DHCP address pool to be automatically assigned.

Use the **undo dhcp server forbidden-ip** command to cancel the forbiddance.

## Syntax

```
dhcp server forbidden-ip low-ip-address [high-ip-address]
```

```
undo dhcp server forbidden-ip low-ip-address [high-ip-address]
```

## Parameters

*low-ip-address*

IP address that is not available for being assigned to DHCP clients automatically (An IP address of this kind is known as a forbidden IP address). This argument also marks the lower end of the range of the forbidden IP addresses.

*high-ip-address*

IP address that is not available for being assigned to DHCP clients. This argument also marks the higher end of the range of the forbidden IP addresses. Note that this argument cannot be less than the low-ip-address argument. If you do not provide this argument, only the IP address specified by the low-ip-address argument is forbidden.

## Default

By default, all IP addresses in an address pool are allowed to be automatically assigned.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Forbid the IP addresses in the range 10.110.1.1 to 10.110.1.63 to be automatically assigned.

```
[S5500] dhcp server forbidden-ip 10.110.1.1 10.110.1.63
```

## View

This command can be used in the following views:

- System view

## Description

You will fail to execute the **undo dhcp server forbidden-ip** command if the specified forbidden IP address range contains any statically bound IP address.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

**Related Commands**

- `dhcp server ip-pool`
- `dhcp server static-bind`
- `network`
- `static-bind ip-address`

# dhcp-server ip

---

## Purpose

Use the **dhcp-server ip** command to configure the DHCP server IP address(es) in a specified DHCP server group.

Use the **undo dhcp-server** command to remove all DHCP server IP addresses in a DHCP server group.

## Syntax

```
dhcp-server groupNo ip ip-address1 [ipaddress-list]
```

```
undo dhcp-server groupNo
```

## Parameters

|                       |                                                                                                                         |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------|
| <b>groupNo</b>        | DHCP server group number. Valid values are 0 to 19.                                                                     |
| <b>ipaddress-1</b>    | IP address of DHCP server 1 in the DHCP server group.                                                                   |
| <b>ipaddress-list</b> | IP addresses of other DHCP servers in the DHCP server group. You can provide up to seven other DHCP sever IP addresses. |

## Examples

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Configure three DHCP server IP addresses 1.1.1.1, 2.2.2.2, and 3.3.3.3 for DHCP server group 1, so that this group contains three DHCP servers (server 1, server 2 and server 3).

```
[S5500] dhcp-server 1 ip 1.1.1.1 2.2.2.2 3.3.3.3
```

## View

This command can be used in the following views:

- System view

## Related Commands

- **dhcp-server**
- **display dhcp-server**
- **debugging dhcp-relay**

# dhcp server ip-pool

---

## Purpose

Use the **dhcp server ip-pool** command to create a global DHCP address pool and enter DHCP address pool view.

Use the **undo dhcp server ip-pool** command to remove a specified DHCP address pool.

## Syntax

```
dhcp server ip-pool pool-name
```

```
undo dhcp server ip-pool pool-name
```

## Parameters

**pool-name**

Name of a DHCP address pool, which uniquely identifies the address pool. This argument may be 1 to 35 characters long.

## Default

By default, no global DHCP address pool is created.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Create DHCP address pool 0.

```
[S5500] dhcp server ip-pool 0
[S5500-dhcp-pool-0]
```

## View

This command can be used in the following views:

- System view

## Description

If the address pool identified by the pool-name argument already exists, this command leads you to DHCP address pool view.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

## Related Command

**dhcp enable**

# dhcp server nbns-list

---

## Purpose

Use the **dhcp server nbns-list** command to configure NetBIOS server IP address(es) for the specified DHCP interface address pool(s).

Use the **undo dhcp server nbns-list** command to remove the NetBIOS server IP address(es) configured for the specified DHCP interface address pool(s).

## Syntax

VLAN interface view:

```
dhcp server nbns-list ip-address&<1-8>
undo dhcp server nbns-list { ip-address | all }
```

System view:

```
dhcp server nbns-list ip-address&<1-8> { interface interface-type
interface-number [to interface-type interface-number] | all }
undo dhcp server nbns-list { ip-address | all } { interface
interface-type interface-number [to interface-type interface-number]
| all }
```

## Parameters

|                                                                                         |                                                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>ip-address&amp;&lt;1-8&gt;</i>                                                       | IP address of a NetBIOS server. &<1-8> means you can provide up to eight NetBIOS server IP addresses. When inputting more than one NetBIOS server IP address, separate two neighboring IP addresses with a space. |
| <i>interface interface-type interface-number [ to interface-type interface-number ]</i> | Specifies the interface(s), through which you can specify the corresponding interface address pool(s).                                                                                                            |
| <i>all</i>                                                                              | (In comparison with the ip-address argument) Specifies all NetBIOS server IP addresses.                                                                                                                           |
| <i>all</i>                                                                              | (In comparison with the interface keyword) Specifies all interface address pools.                                                                                                                                 |

## Default

By default, no NetBIOS server IP address is configured for a DHCP interface address pool.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Configure the NetBIOS server IP address 10.12.1.99 for all the DHCP interface address pools.

```
[S5500] dhcp server nbns-list 10.12.1.99 all
```

**View**

This command can be used in the following views:

- System view
- VLAN Interface view

**Description**

If you execute the **dhcp server nbns-list** command repeatedly, the new configuration overwrites the previous one.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

**Related Commands**

- **dhcp server netbios-type**
- **nbns-list**



# dhcp server netbios-type

---

## Purpose

Use the **dhcp server netbios-type** command to configure the NetBIOS node type of the DHCP clients whose IP addresses are from the specified interface address pool(s).

Use the **undo dhcp server netbios-type** command to restore the default NetBIOS node type.

## Syntax

VLAN interface view:

```
dhcp server netbios-type { b-node | h-node | m-node | p-node }
undo dhcp server netbios-type
```

System view:

```
dhcp server netbios-type { b-node | h-node | m-node | p-node } {
interface interface-type interface-number [to interface-type interface-number] | all }
undo dhcp server netbios-type { interface interface-type interface-number [to interface-type interface-number] | all }
```

## Parameters

|                                                                                                           |                                                                                                                                                 |
|-----------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>b-node</b>                                                                                             | Specifies the broadcast type. Nodes of this type acquire host name-to-IP address mapping by broadcasting.                                       |
| <b>p-node</b>                                                                                             | Specifies the peer-to-peer type. Nodes of this type acquire host name-to-IP address mapping by communicating with the NetBIOS server.           |
| <b>m-node</b>                                                                                             | Specifies the m-typed mixed type. Nodes of this type are p-nodes with some broadcasting features. (The character m here stands for mixed.)      |
| <b>h-node</b>                                                                                             | Specifies the hybrid type. Nodes of this type are b-nodes with peer-to-peer communicating features. This node is the default NetBIOS node type. |
| <pre>interface <i>interface-type interface-number</i> [ to <i>interface-type interface-number</i> ]</pre> | Specifies the interface(s), through which you can specify the corresponding interface address pools.                                            |
| <b>all</b>                                                                                                | Specifies all interface address pools.                                                                                                          |

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Specify p-node as the NetBIOS node type of the DHCP clients whose IP addresses are from the DHCP address pool of VLAN 1 interface.

```
[S5500] interface vlan-interface 1
[S5500-Vlan-interface1] dhcp server netbios-type p-node
```

## View

This command can be used in the following views:

- System view
- VLAN Interface view

## Description



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

## Related Commands

- **dhcp server nbns-list**
- **netbios-type**

# dhcp server option

---

## Purpose

Use the **dhcp server option** command to customize DHCP options for the specified DHCP interface address pool(s).

Use the **undo dhcp server option** command to remove the customized DHCP options.

## Syntax

VLAN interface view:

```
dhcp server option code { ascii ascii-string | hex hex-string&<1-10> |
ip-address ip-address&<1-8> }
```

```
undo dhcp server option code
```

System view:

```
dhcp server option code { ascii ascii-string | hex hex-string&<1-10> |
ip-address ip-address&<1-8> } { interface interface-type
interface-number [to interface-type interface-number] | all }
```

```
undo dhcp server option code { interface interface-type
interface-number [to interface-type interface-number] | all }
```

## Parameters

|                                                                                                                                 |                                                                                                                                                                                                                                                                                                             |
|---------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>code</b>                                                                                                                     | Customized option number ranging from 2 to 254. Note that this argument cannot be 3, 6, 15, 44, 46, 50 through 55, 57 through 61, 82, or 217.                                                                                                                                                               |
| <b>ascii <i>ascii-string</i></b>                                                                                                | Specifies a string that is of 1 to 63 characters. Note that each character of the string must be an ASCII character.                                                                                                                                                                                        |
| <b>hex <i>hex-string</i>&amp;&lt;1-10&gt;</b>                                                                                   | Specifies strings, each of which comprises 1 to 8 hexadecimal digits. &<1-10> means you can provide up to 10 such strings. When inputting more than one string, separate two neighboring strings with a space. Note that the total number of the hexadecimal digits (spaces not included) cannot exceed 64. |
| <b>ip-address<br/><i>ip-address</i>&amp;&lt;1-8&gt;</b>                                                                         | Specifies IP addresses. &<1-8> means you can provide up to eight IP addresses. When inputting more than one IP address, separate two neighboring IP addresses with a space.                                                                                                                                 |
| <b>interface <i>interface-type</i><br/><i>interface-number</i> [ to<br/><i>interface-type</i><br/><i>interface-number</i> ]</b> | Specifies the interface(s), through which you can specify the corresponding interface address pools.                                                                                                                                                                                                        |
| <b>all</b>                                                                                                                      | Specifies all interface address pools.                                                                                                                                                                                                                                                                      |

**Example**

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Configure option 100 to be 0x11 and 0x22 for all DHCP interface address pools.

```
[S5500] dhcp server option 100 hex 11 22 all
```

**View**

This command can be used in the following views:

- System view
- VLAN Interface view

**Description**

If you execute the dhcp server option command repeatedly, the new configuration overwrites the previous one.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

**Related Command**

`option`

# dhcp server ping

---

## Purpose

Use the **dhcp server ping** command to set the maximum number of the ICMP packets a DHCP server sends in a ping test and the maximum response timeout time of each ICMP packet.

Use the **undo dhcp server ping** command to restore the default settings.

## Syntax

```
dhcp server ping { packets number | timeout milliseconds }
```

```
undo dhcp server ping { packets | timeout }
```

## Parameters

|                             |                                                                                                                                                                                                     |
|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>packets number</b>       | Specifies the number of the packets to be sent in a ping test. The number argument ranges from 0 to 10. A value of 0 means that no packet will be sent. If no value is specified, the default is 2. |
| <b>timeout milliseconds</b> | Specifies the timeout time (in milliseconds) of each packet. The milliseconds argument ranges from 0 to 10,000. If no value is specified, the default is 500.                                       |

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Set the maximum number of the packets the DHCP server sends in a ping test to 10, and the timeout time of each packet to 500 milliseconds.

```
[S5500] dhcp server ping packets 10
```

## View

This command can be used in the following views:

- System view

## Description



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

# dhcp server static-bind

---

**Purpose** Use the **dhcp server static-bind** command to statically bind an IP address of the current address pool to a MAC address.

Use the **undo dhcp server static-bind** command to cancel an IP-MAC address binding.

**Syntax**

```
dhcp server static-bind ip-address ip-address mac-address mac-address

undo dhcp server static-bind { ip-address ip-address | mac-address mac-address }
```

**Parameters**

|                    |                                                                                                                                              |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| <i>ip-address</i>  | IP address to be statically bound. Note that the specified IP address must belong to the same network segment as that of the VLAN interface. |
| <i>mac-address</i> | MAC address to which the IP address is statically bound, in the format of H-H-H.                                                             |

**Default** By default, no IP address in an address pool is statically bound.

**Example** Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Enter VLAN 1 interface view.


```
[S5500] interface vlan-interface 1
```

Statically bind the IP address 10.1.1.1 to the MAC address 0000-e03f-0305. (Assume that the interface address pool of VLAN 1 interface already exists and the IP address belongs to the address pool.)

```
[S5500-Vlan-interface1] dhcp server static-bind 10.1.1.1 0000-e03f-0305
```

**View** This command can be used in the following views:

- VLAN Interface view

**Description**  This command applies only to the S5500-EI series among Switch 5500-Series Switches.

# dhcp server voice-config

---

## Purpose

Use the **dhcp server voice-config** command to configure option 184 and its sub-options, which will be sent to DHCP clients by a DHCP server as well when the DHCP server assigns IP addresses of the current address pool to DHCP clients.

Use the **undo dhcp server voice-config** command to disable a DHCP server from sending option 184 and the specified sub-option to DHCP clients when the DHCP server assigns IP addresses to DHCP clients.

## Syntax

```
dhcp server voice-config { ncp-ip ip-address | as-ip ip-address |
voice-vlan vlan-id { enable | disable } | fail-over ip-address
dialer-string }
```

```
undo dhcp server voice-config [ncp-ip | as-ip | voice-vlan | fail-over
]
```

## Parameters

|                      |                                                                                                                 |
|----------------------|-----------------------------------------------------------------------------------------------------------------|
| <b>ncp-ip</b>        | Specifies the IP address of the NCP.                                                                            |
| <b>as-ip</b>         | Specifies the IP address of the alternate server (AS).                                                          |
| <b>voice-vlan</b>    | Specifies the voice VLAN.                                                                                       |
| <b>fail-over</b>     | Specifies the Fail-over call routing.                                                                           |
| <b>ip-address</b>    | IP address of the NCP, alternate server, or Fail-over.                                                          |
| <b>vlan-id</b>       | ID of the voice VLAN. Valid values are 1 to 4094.                                                               |
| <b>enable</b>        | Enables the voice VLAN.                                                                                         |
| <b>disable</b>       | Disables the voice VLAN.                                                                                        |
| <b>dialer-string</b> | Dial number string. This argument comprises of number 0 through 9 and the * character (acting as the wildcard). |

## Default

By default, option 184 and its sub-options are not supported by a DHCP server.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Enter Ethernet1/0/1 port view.

```
[S5500] interface Ethernet 1/0/1
```

Configure the DHCP server to support option 184 and all its sub-options, with the sub-options being set as follows:

```
NCP-IP: 1.1.1.1
AS-IP: 2.2.2.2
Voice VLAN: Enabled
Voice VLAN ID: 1
```

```
IP address of Fail-over: 3.3.3.3
Dialer-string: 99*
[S5500-Ethernet1/0/1] dhcp select interface
[S5500-Ethernet1/0/1] dhcp server voice-config ncp-ip 1.1.1.1
[S5500-Ethernet1/0/1] dhcp server voice-config as-ip 2.2.2.2
[S5500-Ethernet1/0/1] dhcp server voice-config voice-vlan 1 enable
[S5500-Ethernet1/0/1] dhcp server voice-config fail-over 3.3.3.3 99*
```

**View**

This command can be used in the following views:

- VLAN Interface view

**Description**

A DHCP server sends Option 184 and the corresponding sub-options to a DHCP client only when the latter requests for option 184.

The NCP-IP sub-option is necessary for all other sub-options. You need to configure the NCP-IP sub-option first to enable other sub-options.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

**Related Command**

**voice-config**



# dhcp server voice-config interface

---

## Purpose

Use the **dhcp server voice-config interface** command to configure option 184 and its sub-options, which will be sent to DHCP clients by a DHCP server as well when the DHCP server assigns IP addresses of specified address pools to DHCP clients.

Use the **undo dhcp server voice-config interface** command to disable a DHCP server from sending option 184 and the specified sub-option to DHCP clients when the DHCP server assigns IP addresses to DHCP clients.

## Syntax

```
dhcp server voice-config { ncp-ip ip-address | as-ip ip-address |
voice-vlan vlan-id { enable | disable } | fail-over ip-address
dialer-string } { all | interface interface-type interface-number [to
interface-type interface-number] }
```

```
undo dhcp server voice-config [ncp-ip | as-ip | voice-vlan | fail-over
] { all | interface interface-type interface-number [to interface-type
interface-number] }
```

## Parameters

|                                                                                           |                                                                                                                                                                                                                                                                                                                     |
|-------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>ncp-ip</b>                                                                             | Specifies the IP address of the network call processor (NCP).                                                                                                                                                                                                                                                       |
| <b>as-ip</b>                                                                              | Specifies the IP address of the alternate server (AS).                                                                                                                                                                                                                                                              |
| <b>voice-vlan</b>                                                                         | Specifies the voice VLAN.                                                                                                                                                                                                                                                                                           |
| <b>fail-over</b>                                                                          | Specifies the Fail-over call routing.                                                                                                                                                                                                                                                                               |
| <b>ip-address</b>                                                                         | IP address of the NCP, alternate server, or Fail-over.                                                                                                                                                                                                                                                              |
| <b>vlan-id</b>                                                                            | ID of the voice VLAN. Valid values are 1 to 4094.                                                                                                                                                                                                                                                                   |
| <b>enable</b>                                                                             | Enables the voice VLAN.                                                                                                                                                                                                                                                                                             |
| <b>disable</b>                                                                            | Disables the voice VLAN.                                                                                                                                                                                                                                                                                            |
| <b>dialer-string</b>                                                                      | Dial number string. This argument is comprised of number 0 through 9 and the * character (acting as the wildcard).                                                                                                                                                                                                  |
| <b>all</b>                                                                                | Specifies that the sub-options apply to all VLAN interfaces.                                                                                                                                                                                                                                                        |
| <b>interface-type<br/>interface-number [ to<br/>interface-type<br/>interface-number ]</b> | Specifies all ports in the port range identified by the two port indexes separated by the to keyword (including the end ports). Note that the ports must be Ethernet ports, sub-Ethernet ports, or virtual Ethernet ports. (The combination of the interface-type and interface-number arguments forms port index.) |

## Default

By default, option 184 and its sub-options are not supported by a DHCP server.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Configure the DHCP server to support option 184 and all its sub-options when the DHCP server assigns IP addresses to DHCP clients through Ethernet1/0/1 port, with the sub-options being set as follows:

```
NCP-IP: 1.1.1.1
AS-IP: 2.2.2.2
Voice VLAN: Enabled
Voice VLAN ID: 1
IP address of Fail-over: 3.3.3.3
Dialer-string: 99*
[S5500] dhcp select interface Ethernet 1/0/1
[S5500] dhcp server voice-config ncp-ip 1.1.1.1 interface Ethernet
1/0/1
[S5500] dhcp server voice-config as-ip 2.2.2.2 interface Ethernet 1/0/1
[S5500] dhcp server voice-config voice-vlan 1 enable interface Ethernet
1/0/1
[S5500] dhcp server voice-config fail-over 3.3.3.3 99* interface
Ethernet 1/0/1
```

## View

This command can be used in the following views:

- System view

## Description

A DHCP server sends Option 184 and the corresponding sub-options to a DHCP client only when the latter requests for option 184.

The NCP-IP sub-option is necessary for all other sub-options. You need to configure the NCP-IP sub-option first to enable other sub-options.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

## Related Command

**voice-config**

# dhcp-security static

---

## Purpose

Use the **dhcp-security static** command to configure a static user address entry.

Use the **undo dhcp-security** command to remove one or all user address entries, or all user address entries of a specified type.

## Syntax

```
dhcp-security static ip-address mac-address
```

```
undo dhcp-security { ip-address | all | dynamic | static }
```

## Parameters

|                    |                                       |
|--------------------|---------------------------------------|
| <i>ip-address</i>  | User IP address.                      |
| <i>mac-address</i> | User MAC address.                     |
| <b>all</b>         | Removes all user address entries.     |
| <b>dynamic</b>     | Removes dynamic user address entries. |
| <b>static</b>      | Removes static user address entries.  |

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z
```

Configure a user address entry for the DHCP server group, with the user IP address being 1.1.1.1 and the user MAC address being 0005-5D02-F2B3.

```
[S5500] dhcp-security static 1.1.1.1 0005-5D02-F2B3
```

## View

This command can be used in the following views:

- System view

## Description



*Note: Among 3Com Switch 5500 Family switches, only S5500-EI series switches support the two commands.*

## Related Command

```
display dhcp-security
```

# dhcp-security tracker

---

## Purpose

Use the **dhcp-security tracker** command to set the interval to update DHCP security entries.

Use the **undo dhcp-security tracker** command to cancel the configuration.

## Syntax

```
dhcp-security tracker { interval | auto }
```

```
undo dhcp-security tracker [interval]
```

## Parameters

|                 |                                                                                                                                                                                       |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>interval</b> | Interval (in seconds) to update DHCP security entries. Valid values are 1 to 120 seconds.                                                                                             |
| <b>auto</b>     | Specifies that the interval to update DHCP security entries is automatically determined by the number of the DHCP security entries. A larger number corresponds to a longer interval. |

## Default

By default, the update interval is determined by the number of the DHCP security entries.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Set the interval to update dynamic address entries to 60 seconds.

```
[S5500] dhcp-security tracker 60
```

## View

This command can be used in the following views:

- System view

## Description



*Note:*

*Switch 5500 S1-series switches do not support these two commands.*

# dhcp-snooping

---

|                        |                                                                                                                                                                                                                                              |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>         | <p>Use the <b>dhcp-snooping</b> command to enable the DHCP snooping function, so as to allow the switch to listen to the DHCP broadcast packets.</p> <p>Use the <b>undo dhcp-snooping</b> command to disable the DHCP snooping function.</p> |
| <b>Syntax</b>          | <pre>dhcp-snooping undo dhcp-snooping</pre>                                                                                                                                                                                                  |
| <b>Parameters</b>      | None                                                                                                                                                                                                                                         |
| <b>Default</b>         | By default, the DHCP snooping function is disabled.                                                                                                                                                                                          |
| <b>Example</b>         | <p>Enter system view.</p> <pre>&lt;S5500&gt; system-view System View: return to User View with Ctrl+Z.</pre> <p>Enable the DHCP snooping function.</p> <pre>[S5500] dhcp-snooping</pre>                                                      |
| <b>View</b>            | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ System view</li></ul>                                                                                                                        |
| <b>Related Command</b> | <pre>display dhcp-snooping</pre>                                                                                                                                                                                                             |

# dhcp-snooping trust

---

|                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>         | <p>Use the <b>dhcp-snooping trust</b> command to set an Ethernet port to a trusted port.</p> <p>Use the <b>undo dhcp-snooping trust</b> command to restore an Ethernet port to an untrusted port.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Syntax</b>          | <pre>dhcp-snooping trust undo dhcp-snooping trust</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Parameters</b>      | None                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Example</b>         | <p>Enter system view.</p> <pre>&lt;S5500&gt; system-view System View: return to User View with Ctrl+Z.</pre> <p>Set the Ethernet1/0/1 port to a trusted port.</p> <pre>[S5500-Ethernet1/0/1] dhcp-snooping trust</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>View</b>            | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ Ethernet Port view</li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Description</b>     | <p>DHCP snooping security allow you to set a port to a trusted port or an untrusted port, so that DHCP clients can obtain IP addresses from only valid DHCP servers.</p> <ul style="list-style-type: none"><li>■ Trusted ports can be used to connect DHCP servers or ports of other switches. Untrusted ports can be used to connect DHCP clients or networks.</li><li>■ Trusted ports forward any received DHCP packets to ensure that DHCP clients can obtain IP addresses from valid DHCP servers. Untrusted ports discard the DHCP-ACK and DHCP-OFF responses received from DHCP servers.</li><li>■ By default, all the ports of a switch are untrusted ports.</li></ul> |
| <b>Related Command</b> | <pre>display dhcp-snooping trust</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

# dir

---

**Purpose** Use the `dir` command to display the information about the specified file or directory in the storage device of the Switch.

**Syntax** `dir [ /all ] [ file-path ]`

**Parameters**

|                               |                                                                                                                                                                                                                                               |
|-------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>/all</code>             | Display all the files (including the deleted ones).                                                                                                                                                                                           |
| <code><i>file-path</i></code> | File or directory name to be displayed. The <code><i>file-path</i></code> parameter supports "*" matching. For example, using <code>dir *.txt</code> will display all the files with the extension <code>txt</code> in the current directory. |

`dir` without any parameters will display the file information in the current directory.

**Example** Display the information for file `flash:/test/test.txt`

```
<SW5500>dir flash:/test/test.txt
Directory of unit1>flash:/test/test.txt
1 -rw- 248 Aug 29 2000 17:49:36 test.txt
20578304 bytes total (3104544 bytes free)
```

Display information for directory `flash:/test/`

```
<SW5500>dir flash:/test/
Directory of unit1>flash:/test/

1 -rw- 248 Aug 29 2000 17:49:36 test.txt
20578304 bytes total (3104544 bytes free)
```

Display all of the files with names starting with "t" in directory `flash:/test/`

```
<SW5500>dir flash:/test/t*
Directory of unit1>flash:/test/t*
1 -rw- 248 Aug 29 2000 17:49:36 test.txt
20578304 bytes total (3104544 bytes free)
```

Display information about all of the files (including the deleted files) in directory `flash:/test/`

```
<SW5500>dir /all flash:/test/
Directory of unit1>flash:/test/
1 -rw- 248 Aug 29 2000 17:49:36 test.txt
20578304 bytes total (3104544 bytes free)
```

Display information about all of the files (including the deleted files) with names starting with "t" in flash:/test/

```
<SW5500>dir /all flash:/test/t*
Directory of unit1>flash:/test/t*
1 -rw- 248 Aug 29 2000 17:49:36 text.txt
20578304 bytes total (3104544 bytes free)
```

## View

This command can be used in the following views:

- User view



# dir

---

**Purpose** Use the **dir** command to display the files in the specified directory.

**Syntax** `dir [ remote-path ]`

**Parameters** *remote-path* Name of the intended directory.  
If the *remote-path* argument is not specified, the files in the current directory are displayed.

**Example** Display the files in directory flash:/.

```
sftp-client> dir flash:/
-rwxrwxrwx 1 noone nogroup 1759 Aug 23 06:52 vrpcfg.cfg
-rwxrwxrwx 1 noone nogroup 225 Aug 24 08:01 pubkey2
-rwxrwxrwx 1 noone nogroup 283 Aug 24 07:39 pubkey1
-rwxrwxrwx 1 noone nogroup 225 Sep 28 08:28 pub1
drwxrwxrwx 1 noone nogroup 0 Sep 28 08:24 new1
drwxrwxrwx 1 noone nogroup 0 Sep 28 08:18 new2
-rwxrwxrwx 1 noone nogroup 225 Sep 28 08:30 pub2
```

**View** This command can be used in the following views:

- SFTP Client view

**Description** This command has the same function as the **ls** command.

# disconnect

---

## Purpose

The **disconnect** command terminates the control connection and data connection with the remote FTP Server at the same time.

Using the **disconnect** command, subscribers can disconnect FTP client side from FTP server side without exiting FTP client side view.

## Syntax

**disconnect**

## Parameters

None

## Example

Terminate connection with the remote FTP Server and stay in FTP Client view.

```
<SW5500>ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in.
[ftp]disconnect
221 Server closing
[ftp]
```

## View

This command can be used in the following views:

- FTP Client view

# display acl

---

**Purpose** Use the `display acl` command to view the detailed configuration information about the ACL, including every rule, sequence number and the number and byte number of the packets matched with this rule.

**Syntax** `display acl { all | acl-number }`

**Parameters**

|                                |                                                                                          |
|--------------------------------|------------------------------------------------------------------------------------------|
| <code>all</code>               | Displays all ACLs.                                                                       |
| <code><i>acl-number</i></code> | Specifies the sequence number of the ACL to be displayed. Valid values are 2000 to 5999. |

**Example** Display the content of all the ACLs.

```
<SW5500>display acl all
Basic acl 2000, 0 rule,match-order is auto
Acl's step is 1

Advanced ACL 3000, 1 rule
Acl's step is 1
rule 1 permit ip (0 times matched)
```

**View** This command can be used in the following views:

- Any view

**Description** The matched times displayed by this command are software matched times, namely, the matched times of the ACL to be processed by the Switch CPU. You can use the `traffic-statistic` command to calculate the matched times of hardware during packet-forwarding

# display am

**Purpose** Use the `display am` command to view whether address management is enabled and to display IP address pool configuration.

**Syntax** `display am [ interface-list ]`

**Parameters** *interface-list* Displays the address management information of the specified port. It is expressed as { { *interface-type interface-number* / *interface-name* } [ to { *interface-type interface-number* / *interface-name* } ] } &<1-10>, where *interface-type* indicates the port type, *interface-number* the port number, and *interface-name* the port name. For detailed parameter settings, refer to the interface commands described in the port command manual. &<1-10> indicates that you can enter the preceding arguments for up to ten times.

**Example** Display the address management configurations on ports Ethernet1/0/1 and Ethernet1/0/2.

```
<S5500> display am ethernet1/0/1 ethernet1/0/2
Ethernet1/0/1
 Status : enabled
 IP Pools : (NULL)
Ethernet1/0/2
 Status : enabled
IP
```

**Table 4** Description on the fields of the display am command

| Field    | Description                                                                                                                                                                                                                                                                                                      |
|----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Status   | Indicates whether AM is enabled on the port. "enabled" means it is enabled and "disabled" means it is disabled.                                                                                                                                                                                                  |
| IP Pools | IP addresses (pools); NULL indicates that no IP address (pool) is configured. Each IP address segment is expressed as X.X.X.X(number), where X.X.X.X represents the starting IP address and number means that the consecutive "number" of IP addresses starting from this IP address are in the IP address pool. |

**View** This command can be used in the following views:

- Any view

**Description** If no port is specified, this command displays the current address management configurations on all ports.

# display am user-bind

---

**Purpose** Use the **display am** command to view whether address management is enabled and to display IP address pool configuration.

**Syntax** `display am user-bind [ interface interface-type interface-number ] [ ip-addr ip-address ] [mac-addr mac-address]`

**Parameters**

|                    |                                        |
|--------------------|----------------------------------------|
| <i>ip-address</i>  | Specifies the IP address to be bound.  |
| <i>mac-address</i> | Specifies the MAC address to be bound. |

**Example** Display address management configuration.

```
<S5500> display am user-bind
Following User address bind have been configured:
 Mac IP Port
 000a-000a-000a 1.1.1.1 Ethernet1/0/1
Unit 1:Total 1 found, 1 listed.

Total: 1 found.
```

**View** This command can be used in the following views:

- Any view

**Description** If no port is specified, this command displays the current address management configurations on all ports.

# display arp

---

**Purpose** Use the **display arp** command to display the ARP mapping table entries by entry type, or by a specified IP address.

**Syntax** `display arp [ ip-address | [ dynamic | static ] [ | { begin | include | exclude } text ]]`

|                   |                |                                                                                                             |
|-------------------|----------------|-------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | <b>dynamic</b> | Displays the dynamic ARP entries in the ARP mapping table.                                                  |
|                   | <b>static</b>  | Displays the static ARP entries in the ARP mapping table.                                                   |
|                   | <b>begin</b>   | Specifies to start displaying from the first ARP entry that contains the specified character string "text". |
|                   | <b>include</b> | Displays only the ARP entries that contain the specified character string "text".                           |
|                   | <b>exclude</b> | Displays only the ARP entries that do not contain the specified character string "text".                    |
|                   | <b>text</b>    | Displays the ARP entries that contain this user-defined character string.                                   |

**Example** To display all ARP entries in the mapping table, enter the following:

```
<SW5500>display arp
Type: S-Static D-Dynamic
IP Address MAC Address VLAN ID Port Name / AL ID Aging Type
161.71.61.20 0020-9c08-e774 1 Ethernet2/0/6 20 D

--- 1 entry found ---
<SW5500>
```

**Table 5** Output Description of the display arp command

| Field       | Description                                |
|-------------|--------------------------------------------|
| IP Address  | IP address of the ARP mapping entry        |
| MAC Address | MAC address of the ARP mapping entry       |
| VLAN ID     | VLAN to which the static ARP entry belongs |
| Port Name   | Port to which the static ARP entry belongs |
| Aging       | Aging time of dynamic ARP entry in minutes |
| Type        | Type of ARP entry                          |

**View** This command can be used in the following views:

- Any view

**Related Commands** ■ `arp static`

■ **reset arp**

# display arp timer aging

---

**Purpose** Use the `display arp timer aging` command to view the current setting of the dynamic ARP aging timer.

**Syntax** `display arp timer aging`

**Parameters** None

**Example** To display the current setting of the dynamic ARP aging timer, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500] display arp timer aging
```

```
The information displays in the following format:
Current ARP aging time is 20 minute(s) (default)
[SW5500]
```

**View** This command can be used in the following views:

- Any view



# display boot-loader

---

**Purpose** Use the **display boot-loader** command to display the information about the App boot files on one switch or all switches in the fabric, including the names of the currently used, the to-be-used main and the backup App boot files.

**Syntax** `display boot-loader [ unit unit-id ]`

**Parameters** `unit unit-id` Unit ID of a switch.

**Example** Display the information about the App boot files on unit 1.

```
<S5500> display boot-loader unit 1
Unit 1
 The current boot app is: Switch 5500.bin
 The main boot app is: Switch 5500.bin
 The backup boot app is: Switch 5500bak.bin
```

**View** This command can be used in the following views:

- Any view

**Description** Executing the **display boot-loader** command without **unit *unit-id*** will display the settings in the whole fabric.

# display bootp client

---

**Purpose** Use the **display bootp client** command to display BOOTP client-related information, including the MAC address of the BOOTP client and the IP address obtained.

**Syntax** `display bootp client [ interface vlan-interface vlan-id ]`

**Parameters** `vlan-id` VLAN interface ID.

**Example** Display the BOOTP client-related information.

```
<S5500> display bootp client interface vlan-interface 1
Vlan-interface1:
Allocated IP: 169.254.0.2 255.255.0.0
Transaction ID = 0x3d8a7431
Mac Address 00e0-fc0a-c3ef
```

**Table 6** Description on the fields of the display bootp client command

| Field           | Description                                                           |
|-----------------|-----------------------------------------------------------------------|
| Vlan-interface1 | VLAN interface 1 is configured to obtain an IP address through BOOTP. |
| Allocated IP    | IP address allocated to VLAN interface 1                              |
| Transaction ID  | Value of the XID field in BOOTP packets                               |
| Mac Address     | MAC address of the BOOTP client                                       |

**View** This command can be used in the following views:

- Any view

**Related Command** `ip address bootp-alloc`

# display brief interface

---

## Purpose

Use the **display brief interface** command to display the configuration information about one specific or all ports in brief, including the port type, connection state, connection rate, duplex attribute, link type and default VLAN ID.

## Syntax

```
display brief interface [interface-type interface-number] [| { begin
| include | exclude } regular-expression]
```

## Parameters

|                           |                                                                                                                                                                 |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>interface-type</i>     | Port type.                                                                                                                                                      |
| <i>interface-number</i>   | Port number.                                                                                                                                                    |
|                           | Uses regular expression to specify the details in the port configuration information fields, so as to specify which port information entries will be displayed. |
| <b>begin</b>              | There is a port information field beginning with the specified character (string).                                                                              |
| <b>include</b>            | There is a port information field containing the specified character (string).                                                                                  |
| <b>exclude</b>            | There is no port information field containing the specified character (string).                                                                                 |
| <i>regular-expression</i> | Regular expression; a character string from 1 to 256 characters long.                                                                                           |

## Example

Display the configuration information about Ethernet1/0/3 port in brief.

```
<S5500> display brief interface ethernet 1/0/3
Interface Link Speed Duplex Link-type PVID
Ethernet1/0/3 DOWN auto auto access 1
```

**Table 7** Description on the fields of the display brief interface command

| Field     | Description                       |
|-----------|-----------------------------------|
| Interface | Port type                         |
| Link      | Link state UP or DOWN             |
| Speed     | Link rate                         |
| Duplex    | Duplex attribute                  |
| Link-type | Link type access, hybrid or trunk |
| PVID      | Default VLAN ID                   |

## View

This command can be used in the following views:

- Any view

**Description**

This command functions similarly to the **display interface** command but displays the port information in brief.



*Currently, for a non-Ethernet port, the system only displays its connection state and displays "--" in other configuration information fields.*

**Related Command**

**display interface**

# display channel

---

**Purpose** Use the `display channel` command to display the details about the information channel.

**Syntax** `display channel [ channel-number | channel-name ]`

**Parameters**

|                       |                                                                                                                                                                                                                                                                                                      |
|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>channel-number</i> | Channel number. Valid values are 0 to 9, meaning that the system has ten channels.                                                                                                                                                                                                                   |
| <i>channel-name</i>   | Specifies the channel name, the name can be console, monitor, loghost, trapbuffer, logbuffer, snmpagent, channel6, channel7, channel8, channel9. Where console is channel 0, monitor is channel 1, loghost is channel 2, trapbuffer is channel 3, logbuffer is channel 4 and snmpagent is channel 5. |

**Example** Show details about the information channel 0.

```
<SW5500>display channel 0
channel number:0, channel name:console
MODU_ID NAME ENABLE LOG_LEVEL ENABLE TRAP_LEVEL ENABLE
DEBUG_LEVEL
ffff0000 Y warning Y debugging Y debugging
```

**View** This command can be used in the following views:

- Any view

**Description** Without a parameter, the `display channel` command shows the configurations of all the channels.

# display clock

---

|                        |                                                                                                                                                              |
|------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>         | Use the <code>display clock</code> command to obtain information about system data and time from the terminal display.                                       |
| <b>Syntax</b>          | <code>display clock</code>                                                                                                                                   |
| <b>Parameters</b>      | None                                                                                                                                                         |
| <b>Example</b>         | View the current system date and clock.<br><br><pre>&lt;SW5500&gt;display clock<br/>15:50:45 UTC Mon 01/01/2001</pre>                                        |
| <b>View</b>            | This command can be used in the following views: <ul style="list-style-type: none"><li>■ Any view</li></ul>                                                  |
| <b>Related Command</b> | <ul style="list-style-type: none"><li>■ <code>clock datetime</code></li><li>■ <code>clock summer-time</code></li><li>■ <code>clock timezone</code></li></ul> |

# display cluster

---

**Purpose** Use the **display cluster** command to display the state and basic configuration information of the cluster that contains the current switch.

**Syntax** `display cluster`

**Parameters** None

**Example** Display cluster information on the management device.

```
<aaa_0.S5500-cluster> display cluster
Cluster name:"aaa"
Role:Administrator
Management-vlan:100
```

```
Handshake timer:10 sec
Handshake hold-time:60 sec
IP-Pool:20.1.1.1/24
cluster-mac:0180-c200-000a
No logging host configured
No SNMP host configured
No FTP server configured
No TFTP server configured
```

```
3 member(s) in the cluster, and 0 of them down.
```

Display cluster information on the member device.

```
[aaa_2.5500-3] display cluster
Cluster name:"aaa"
Role:Member
Member number:2
Management-vlan:100
```

```
cluster-mac:0180-c200-000a
Handshake timer:10 sec
Handshake hold-time:60 sec
```

```
Administrator device mac address:00e0-fc00-3901
Administrator status:Up
```

**Table 1 Description of cluster status and statistics**

| Field                            | Description                      |
|----------------------------------|----------------------------------|
| Cluster name                     | Name of the cluster              |
| Role                             | Role of the cluster member       |
| Member number                    | Number of the cluster member     |
| Handshake timer                  | Value of handshake timer         |
| Handshake hold-time              | Value of handshake hold-time     |
| Administrator device mac address | MAC address of management device |
| Administrator status             | Status of the management device  |

**View**

This command can be used in the following views:

- Any view

**Description**

This command can be performed on both the management device and member device, but the displays are different.

On the member device, displayed information includes the cluster name, member serial number and management device information, including the MAC address, state, holdtime and packet interval.

On the management device, displayed information includes the cluster name, total member number and management device information, including the state, holdtime and packet interval.

Using this command on a device that is not in any cluster will result in error message.



# display cluster candidates

**Purpose** Use the **display cluster candidates** command to display candidate devices of a cluster.

**Syntax** `display cluster candidates [ mac-address H-H-H | verbose ]`

**Parameters**

|                          |                                                               |
|--------------------------|---------------------------------------------------------------|
| <b>mac-address H-H-H</b> | MAC address of the candidate device.                          |
| <b>verbose</b>           | Displays the detailed information about the candidate device. |

**Example** Display a list of all candidate devices.

```
<aaa_0.S5500-cluster> display cluster candidates
MAC HOP IP PLATFORM
5500-0000-3334 2 16.1.1.11/24 S5500
00e0-fc00-3190 1 16.1.1.1/24 S5500
```

**Table 8** Description of candidate list information

| Field    | Description                      |
|----------|----------------------------------|
| MAC      | MAC address                      |
| Hop      | Hops to the management device    |
| IP       | IP address                       |
| Platform | Platform of the candidate device |

Display the detailed information about the specified candidate device.

```
<aaa_0.S5500-cluster> display cluster candidates mac-address
00e0-fc00-3190
Hostname : aaa_1.S5500
MAC : 00e0-fc00-3190
Hop : 1
Platform : S5500
IP : 16.1.1.1/24
```

Display the detailed information about all the candidate devices.

```
[aaa_0.S5500-cluster]display cluster candidates verbose

Hostname : S5500
MAC : 5500-0000-3334
Hop : 2
Platform : S5500
IP : 16.1.1.11/24

Hostname : 5500-3
MAC : 00e0-fc00-3190
Hop : 1
Platform : S5500
IP : 16.1.1.1/24
```

**Table 2 Description of candidate list information**

| <b>Field</b> | <b>Description</b>               |
|--------------|----------------------------------|
| Hostname     | Name of the candidate device     |
| MAC          | MAC address                      |
| Hop          | Hops to the management device    |
| IP           | IP address                       |
| Platform     | Platform of the candidate device |

**View**

This command can be used in the following views:

- Any view

**Description**

This command can only be performed on the management device.

# display cluster members

**Purpose** Use the **display cluster members** command to display the information of cluster members.

**Syntax** `display cluster members [ member-number | verbose ]`

**Parameters**

**member-number:** Member number in the cluster, ranging from 0 to 255.

**verbose:** Displays the detailed information about all the member devices.

**Example** Display configurations about member devices.

```
<aaa_0.S5500-cluster> display cluster members
SN Device MAC Address Status Name
0 S5500 00e0-fc00-3901 Admin aaa_0.S5500
1 S5500 5500-0000-3334 Up aaa_1.S5500
2 S5500 00e0-fc00-3190 Up aaa_2.S5500-3
```

## View

**Table 9** Description of displayed information

| Field       | Description               |
|-------------|---------------------------|
| SN          | Device serial number      |
| Device      | Device type               |
| MAC Address | MAC address of the device |
| Status      | Status of the device      |
| Name        | Name of the device        |

Display the detailed configuration information about the management device and all member devices.

```
<aaa_0.S5500-cluster> display cluster members verbose
Member number:0
Name:aaa_0.S5500
Device:S5500
MAC Address:00e0-fc00-3901
Member status:Admin
Hops to administrator device:0
IP: 100.100.1.1/24
Version:
3Com Versatile Routing Platform Software
VRP (tm) Software, Version 3.10
Copyright (c) 1998-2006 3Com Tech. Co.,Ltd. All rights reserved.
S5500 5500-0002
```

```
Member number:1
Name:aaa_1.S5500
Device:S5500
MAC Address:5500-0000-3334
Member status:Up
```

```

Hops to administrator device:2
IP: 16.1.1.11/24
Version:
3Com Versatile Routing Platform Software
VRP (tm) Software, Version 3.10
Copyright (c) 1998-2006 3Com Corporation. All rights reserved.
S5500 5500-0002

Member number:2
Name: aaa_2.S5500
Device:S5500
MAC Address:00e0-fc00-3190
Member status:Up
Hops to administrator device:1
IP: 16.1.1.1/24
Version:
3Com Versatile Routing Platform Software
VRP (tm) Software, Version 3.10
Copyright (c) 1998-2006 3Com Corporation. All rights reserved.
S5500 5500-0002

```

**Table 10** Description of displayed information

| Field                        | Description                                                  |
|------------------------------|--------------------------------------------------------------|
| Member number                | Device member number                                         |
| Name                         | Name of the device                                           |
| Device                       | Device type                                                  |
| MAC Address                  | MAC address of the device                                    |
| Member status                | Status of the device                                         |
| Hops to administrator device | Hops from the current member device to the management device |
| IP                           | IP address of the current member device                      |
| Version                      | Software version of the current device                       |

**View**

This command can be used in the following views:

- Any view

**Description**

This command can only be performed on the management device.

# display config-agent

---

**Purpose** Use the `display config-agent unit-id` command to view statistics of the configuration agent.

**Syntax** `display config-agent unit-id unit-id`

**Parameters** `unit-id` Unit ID of current switch, in the range of 1 to 8.

**Example** To display statistics of the configuration agent on switch 1, enter the following:

```
<SW5500>display config-agent unit-id 1
Config-agent statistic information on Unit1
Message type Successful Failed on
Config message rcv: 0 0
Config message send: 0 0
Notification message rcv: 0 0
Notification message send: 0 0
Information message rcv: 0 0
Information message send: 0 0
```

**View** This command can be used in the following views:

- Any view

**Description** Configuration agent is one of the XRN features. You can log into one switch of the fabric to configure and manage the fabric by the configuration agent. The functions of the configuration agent include;

- Distributing configuration commands to the right destination switches or processing modules based on the resolution result of the commands input.
- Sending output information of the commands from the switch you have logged into to your terminal.
- Supporting simultaneous configuration of multiple users.

You cannot configure the configuration agent, but can view the statistics of the configuration agent.

# display connection

---

## Purpose

Use the `display connection` command to view the relevant information of all the supplicants or the specified one(s).

## Syntax

```
display connection [access-type { dot1x | mac-authentication } |
domain domain-name | interface interface-type interface-number | ip
ip-address | mac mac-address | radius-scheme radius-scheme-name | vlan
vlanid | ucibindex ucib-index | user-name user-name]
```

## Parameters

`access-type { dot1x | mac-authentication }`

Configures to display the supplicants according to their logon type. dot1x means the 802.1x users. mac-authentication means the centralized mac address authentication users.

`domain domain-name`

Configures to display all the users in an ISP domain. ***domain-name*** specifies the ISP domain name with a character string not exceeding 24 characters. The specified ISP domain shall have been created.

`mac mac-address`

Configures to display the supplicant whose MAC address is ***mac-address***. The argument ***mac-address*** is in the hexadecimal format (*H-H-H*).

`radius-scheme  
radius-scheme-name`

Configures to display the supplicant according to RADIUS server name. ***radius-scheme-name*** specifies the RADIUS server name with a character string not exceeding 32 characters.

`interface interface-type  
interface-number`

Configures to display the supplicant according the port.

`ip ip-address`

Configures to display the user specified with IP address. The argument ***ipt-address*** is in the hexadecimal format (*ip-address*).

`vlan vlanid`

Configures to display the user specified with VLAN ID. Here, ***vlanid*** ranges from 1 to 4094.

`ucibindex ucib-index`

Configures to display the user specified with ***ucib-index***. Here, ***ucib-index*** ranges from 0 to 4095.

`user-name user-name`

Configures to display a user specifies with ***user-name***. ***user-name*** is the argument specifying the username. It is a character string not exceeding 32 characters, excluding `/`, `:`, `*`, `?`, `<` and `>`. The `@` character can only be used once in one username. The pure username (the part before `@`, namely the user ID) cannot exceed 24 characters.

## Example

To display the relevant information of all the users, enter the following:

```
<SW5500>display connection
Total 0 connections matched ,0 listed.
```

## View

This command can be used in the following views:

- Any view

## Description

The output can help you with the user connection diagnosis and troubleshooting.

If no parameter is specified, this command displays the related information about all connected users

## Related Command

`cut connection`

# display cpu

---

**Purpose** Use the `display cpu` command to display CPU occupancy.

**Syntax** `display cpu [ unit unit-id ]`

**Parameters** `unit unit-id:` Specify the Unit ID of the switch.

**Example** To display CPU occupancy, enter the following:

```
<SW5500>display cpu
```

The information displays in the following format:

```
Unit 1
Board 0 CPU busy status:
 11% in last 5 seconds
 12% in last 1 minute
 14% in last 5 minutes
```

**Table 11** Display information

| Field                   | Description                                     |
|-------------------------|-------------------------------------------------|
| Board 0 CPU busy status | The busy status of the Switch                   |
| 11% in last 5 seconds   | The CPU occupancy rate is 11% at last 5 seconds |
| 12% in last 1 minute    | The CPU occupancy rate is 12% at last 1 minute  |
| 14% in last 5 minutes   | The CPU occupancy rate is 14% at last 5 minutes |

**View** This command can be used in the following views:

- Any view



# display current-configuration

---

## Purpose

Use the **display current-configuration** command to display the current configurations of the switch.

## Syntax

```
display current-configuration [configuration [configuration-type] |
interface [interface-type] [interface-number] | vlan [vlan-id]]
[by-linenum] [| { begin | include | exclude } regular-expression]
```

## Parameters

|                                  |                                                                                                                                          |
|----------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| <b>configuration</b>             | Displays the specified type of configurations.                                                                                           |
| <b><i>configuration-type</i></b> | Configuration type. You can specify one of the following types: isp, post-system, topology, radius-template, system, and user-interface. |
| <b>interface</b>                 | Displays the configurations on interface.                                                                                                |
| <b><i>interface-type</i></b>     | Interface type, which can be Aux, Ethernet, GigabitEthernet, NULL, or VLAN.                                                              |
| <b><i>interface-number</i></b>   | Interface number.                                                                                                                        |
| <b>vlan</b>                      | Displays the VLAN configuration.                                                                                                         |
| <b><i>vlan-id</i></b>            | VLAN ID.                                                                                                                                 |
| <b>by-linenum</b>                | Displays the number of each line.                                                                                                        |
| <b> </b>                         | Uses a regular expression to filter the configurations of the switch to be displayed.                                                    |
| <b>begin</b>                     | Displays the configurations starting with the specified text ( <i>regular-expression</i> ).                                              |
| <b>include</b>                   | Displays the configurations that contain the specified text ( <i>regular-expression</i> ).                                               |
| <b>exclude</b>                   | Displays the configurations that do not contain the specified text ( <i>regular-expression</i> ).                                        |
| <b><i>regular-expression</i></b> | A regular expression.                                                                                                                    |

**Table 12** Special characters in regular expression

| Special Character | Meaning                                                                                                                                 | Use                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| _                 | Underline. It is similar to a wildcard and can represent the following characters: (^ \$_ [,(){}]), space, start symbol and end symbol. | <p>If the first character of the expression is not underline, the number of the underlines is not limited in theory (but is limited by the length of the command line in practice).</p> <p>If the first character of the expression is underline, there can be four successive underlines at most at the beginning of the expression.</p> <p>If the underlines are not successive, only the first group of successive underlines is matched. The subsequent groups of underlines are ignored.</p> |
| (                 | Left parenthesis. It represents the in-stack flag in programs.                                                                          | It is recommended not to use this character in regular expression.                                                                                                                                                                                                                                                                                                                                                                                                                                |
| .                 | Period. It is a wildcard which matches any character, including space.                                                                  | -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| *                 | Asterisk. It means that the preceding sub-expression can be matched for zero or multiple times.                                         | zo* can be matched by "z" and "zoo".                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| +                 | Plus sign. It means that the preceding sub-expression can be matched for one or multiple times.                                         | zo+ can be matched by "zo" and "zoo" but not "z".                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

## Example

Display the currently valid configuration parameters on the Ethernet switch.

```
<S5500> display current-configuration
#
sysname S5500
#
radius scheme system
#
domain system
#
vlan 1
#
vlan 2
#
interface Vlan-interface2
#
interface Aux1/0/0
#
interface GigabitEthernet1/0/1
#
interface GigabitEthernet1/0/2
#
interface GigabitEthernet1/0/3
```

```
#
interface GigabitEthernet1/0/4
#
interface GigabitEthernet1/0/5
#
interface GigabitEthernet1/0/6
#
interface GigabitEthernet1/0/7
#
interface GigabitEthernet1/0/8
#
interface GigabitEthernet1/0/9
#
interface GigabitEthernet1/0/10
#
interface GigabitEthernet1/0/11
#
interface GigabitEthernet1/0/12
#
interface GigabitEthernet1/0/13
#
interface GigabitEthernet1/0/14
#
interface GigabitEthernet1/0/15
#
interface GigabitEthernet1/0/16
#
interface GigabitEthernet1/0/17
#
interface GigabitEthernet1/0/18
#
interface GigabitEthernet1/0/19
#
interface GigabitEthernet1/0/20
#
interface GigabitEthernet1/0/21
#
interface GigabitEthernet1/0/22
#
interface GigabitEthernet1/0/23
#
interface GigabitEthernet1/0/24
#
interface NULL0
#
management-vlan 2
#
user-interface aux 0 7
user-interface vty 0 4
#
return
```

Display the lines that include 10\* in the configuration information. "\*" means that the zero before it may not appear or appear multiple times continuously.

```
<S5500> display current-configuration | include 10*
primary authentication 127.0.0.1 1645
 primary accounting 127.0.0.1 1646
 local-server nas-ip 127.0.0.1 key easyKey
vlan 1
interface Vlan-interface1
 ip address 10.1.1.2 255.255.255.0
```

```
interface GigabitEthernet1/0/1
 speed 1000
interface GigabitEthernet1/0/2
interface GigabitEthernet1/0/3
interface GigabitEthernet1/0/4
 network 10.1.1.0 0.0.0.255
```

Display the configuration information starting with “user”.

```
<S5500> display current-configuration | include ^user
user-interface aux 0
user-interface vty 0 4
```

## View

This command can be used in the following views:

- Any view

## Description

This command will not display those configuration parameters which have the same values with the corresponding default parameters.

After performing a group of configurations, you can use the **display current-configuration** command to verify the configuration results by checking the currently valid parameters in the display output. This command will not display the parameters whose corresponding functions do not take effect even though these parameters have been configured.

## Related Commands

- **display saved-configuration**
- **reset saved-configuration**
- **save**

# display debugging

---

**Purpose** Use the `display debugging` command to display the enabled debugging process.

**Syntax**

```
display debugging [[interface { interface_name | interface_type
interface_num }] [module-name]
```

**Parameters**

|                       |                                     |
|-----------------------|-------------------------------------|
| <i>interface-name</i> | Specifies the Ethernet port name.   |
| <i>interface-type</i> | Specifies the Ethernet port type.   |
| <i>interface-num</i>  | Specifies the Ethernet port number. |
| <i>module-name</i>    | Specifies the module name.          |

**Example** Show all the enabled debugging.

```
<SW5500>display debugging
IP packet debugging switch is on.
```

**View** This command can be used in the following views:

- Any view

**Description** Shows all the enabled debugging when there is no parameter.

**Related Command** `debugging`

# display debugging

---

**Purpose** Use the **display debugging** command to display the debugging switches opened on a specified switch or in the whole fabric.

**Syntax** `display debugging { fabric | unit unit-id } [ interface interface-type interface-number | module-name ]`

|                   |                         |                              |
|-------------------|-------------------------|------------------------------|
| <b>Parameters</b> | <b>fabric</b>           | Represents the whole fabric. |
|                   | <b>unit-id</b>          | Unit ID of a switch.         |
|                   | <b>interface-type</b>   | Interface type.              |
|                   | <b>interface-number</b> | Interface number.            |
|                   | <b>module-name</b>      | Name of a functional module. |

**Example** Display the debugging switches opened on device unit 1.

```
<S5500> display debugging unit 1
IP icmp debugging is on
Rip packet debugging switch is on
Rip receive debugging switch is on
Rip send debugging switch is on
```

Display the debugging switches of IP functional module opened in the fabric.

```
<S5500> display debugging fabric ip
UNIT1:
=====
IP icmp debugging is on
=====
UNIT2:
=====
IP icmp debugging is on
=====
```

**View** This command can be used in the following views:

- Any view

# display debugging fabric by-module

---

**Purpose** Use the **display debugging fabric by-module** command to display the debugging switches opened in the fabric by module names.

**Syntax** `display debugging fabric by-module`

**Parameters** None

**Example** Display the debugging switches opened in the fabric by module names.

```
<S5500> display debugging fabric by-module
IP icmp debugging is on : unit1
LACP packet debugging switch is on interface Ethernet1/0/23 : unit1
Rip packet debugging switch is on
Rip receive debugging switch is on
Rip send debugging switch is on : unit1
```

**View** This command can be used in the following views:

- Any view

# display debugging ospf

---

**Purpose** Use the `display debugging ospf` command to view the debugging states of global OSPF and all processes.

**Syntax** `display debugging ospf`

**Example** To display the debugging states of global OSPF and all processes, enter the following.

```
<SW5500>display debugging ospf
OSPF global debugging state:
OSPF SPF debugging is on
OSPF LSA debugging is on
OSPF process 100 debugging state:
OSPF SPF debugging is on

OSPF process 200 debugging state:
OSPF SPF debugging is on
OSPF LSA debugging is on
```

**View** This command can be used in the following views:

- Any view



# display detect-group

---

**Purpose** Use the **display detect-group** command to display the configuration of a specified detecting group or all detecting groups.

**Syntax** `display detect-group [ group-number ]`

**Parameters** *group-number* Detecting group number ranging from 1 to 50.

**Example** Display the configuration of detecting group 1.

```
<S5500> display detect-group 1
detect-group 1 :
 detect loop time(s) : 20
 ping wait time(s) : 2
 detect retry times : 2
 detect ip option : and
 group state : not detecting
 register module num : 0
 detect ip count : 1
detect-list ip address next hop
1 1.1.1.1 2.2.2.2
```

**View** This command can be used in the following views:

- Any view

## Description

**Table 13** Description on the field of the display detect-group command

| Field               | Description                                                                                                                                                                                                                                                                                                                    |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| detect-group        | Detecting group number                                                                                                                                                                                                                                                                                                         |
| detect loop time(s) | Detecting interval                                                                                                                                                                                                                                                                                                             |
| ping wait time(s)   | Timeout time of a ping operation                                                                                                                                                                                                                                                                                               |
| detect retry times  | Number of retries of an auto detect operation                                                                                                                                                                                                                                                                                  |
| detect ip option    | The way in which the result of an auto detect operation is generated. The word <b>and</b> indicates a detecting group is reachable only when all the IP addresses contained in it are reachable. And the word <b>or</b> indicates a detecting group is reachable if only one of the IP addresses contained in it is reachable. |
| group state         | Current state of a detecting group                                                                                                                                                                                                                                                                                             |
| register module num | Number of registered modules (that is, the number of the modules utilizing the detecting group)                                                                                                                                                                                                                                |
| detect ip count     | Number of the IP addresses contained in a detecting group                                                                                                                                                                                                                                                                      |
| detect-list         | Sequence number of an IP address contained in a detecting group                                                                                                                                                                                                                                                                |
| ip address          | IP address to be detected                                                                                                                                                                                                                                                                                                      |
| next-hop            | Next hop IP address                                                                                                                                                                                                                                                                                                            |

# display device

---

## Purpose

Use the **display device** command to display the module type and working status information of a card, including physical card number, physical daughter card number, number of ports, hardware version number, FPGA version number, version number of BOOTROM software, application version number, address learning mode, interface card type and interface card type description.

## Syntax

```
display device [unit unit-id]
```

## Parameters

**unit** *unit-id* Specifies the Unit ID of the switch.

## Example

Show device information.

```
<SW5500>display device
```

```
Unit 1
SlotNo SubSNo PortNum PCBVer FPGAVer CPLDVer BootRomVer AddrLM Type State
0 0 24 REV.A NULL 000 200 IVLMAIN Norma
```

## View

This command can be used in the following views:

- Any view

# display dhcp client

---

**Purpose** Use the `display dhcp client` command to view detailed information about address allocation at DHCP client.

**Syntax** `display dhcp client [ verbose ]`

**Parameters** `verbose` Displays detailed information about address allocation at DHCP client.

**Example** To display detailed information about address allocation at DHCP client, enter the following:

```
<SW5500>display dhcp client verbose
DHCP client statistic information:
Vlan-interface1:
Current machine state: BOUND
Alloced IP: 169.254.0.2 255.255.0.0
Alloced lease: 86400 seconds, T1: 43200 seconds, T2: 75600 seconds
Lease from 2002.09.20 01:05:03 to 2002.09.21 01:05:03
Server IP: 169.254.0.1
Transaction ID = 0x3d8a7431
Default router: 2.2.2.2
DNS server: 1.1.1.1
Domain name: 3Com.com
Client ID: 3com-00e0.fc0a.c3ef-Ethernet0/0
Next timeout will happen after 0 days 11 hours 56 minutes 1 seconds.
```

**View** This command can be used in the following views:

- Any view

# display dhcp-security

---

**Purpose** Use the **display dhcp-security** command to display one or all user address entries, or a specified type of user address entries in the valid user address table of a DHCP server group.

**Syntax** `display dhcp-security [ ip-address | dynamic | static | tracker ]`

**Parameters**

|                         |                                                                                                    |
|-------------------------|----------------------------------------------------------------------------------------------------|
| <code>ip-address</code> | IP address. This argument is used to display the user address entry with the specified IP address. |
| <code>dynamic</code>    | Displays the dynamic user address entries.                                                         |
| <code>static</code>     | Displays the static user address entries.                                                          |
| <code>tracker</code>    | Displays the interval to update the user address entries of a DHCP-security table.                 |

**Example** Display all user address entries contained in the valid user address table of the DHCP server group.

```
<S5500> display dhcp-security
IP Address MAC Address IP Address Type
2.2.2.3 0005-5d02-f2b2 Static
3.3.3.3 0005-5d02-f2b3 Dynamic
--- 2 dhcp-security item(s) found ---
```

**Table 14** Description on the fields of the display dhcp-security command

| Field           | Description                                      |
|-----------------|--------------------------------------------------|
| IP Address      | IP address of a user of the DHCP server group    |
| MAC Address     | MAC address of the user of the DHCP server group |
| IP Address Type | Type of the user address entry (static/dynamic)  |

**View** This command can be used in the following views:

- Any view

## Description



*Among Switch 5500-series switches, only Switch 5500 E1-series switches support this command.*

# display dhcp-server

**Purpose** Use the **display dhcp-server** command to display information about a specified DHCP server group.

**Syntax** `display dhcp-server groupNo`

**Parameters** `groupNo` DHCP server group number. Valid values are 0 to 19.

**Example** Display information about DHCP server group 0.

```
<S5500> display dhcp-server 0
IP address of DHCP server group 0: 1.1.1.1
IP address of DHCP server group 0: 2.2.2.2
IP address of DHCP server group 0: 3.3.3.3
IP address of DHCP server group 0: 4.4.4.4
IP address of DHCP server group 0: 5.5.5.5
IP address of DHCP server group 0: 6.6.6.6
IP address of DHCP server group 0: 7.7.7.7
IP address of DHCP server group 0: 8.8.8.8
Messages from this server group: 0
Messages to this server group: 0
Messages from clients to this server group: 0
Messages from this server group to clients: 0
DHCP_OFFER messages: 0
DHCP_ACK messages: 0
DHCP_NAK messages: 0
DHCP_DECLINE messages: 0
DHCP_DISCOVER messages: 0
DHCP_REQUEST messages: 0
DHCP_INFORM messages: 0
DHCP_RELEASE messages: 0
BOOTP_REQUEST messages: 0
BOOTP_REPLY messages: 0
```

**Table 15** Description on the fields of the display dhcp-server command

| Field                                      | Description                                               |
|--------------------------------------------|-----------------------------------------------------------|
| IP address of DHCP server group 0:         | DHCP server IP addresses of DHCP server group 0           |
| Messages from this server group            | Number of the packets received from the DHCP server group |
| Messages to this server group              | Number of the packets sent to the DHCP server group       |
| Messages from clients to this server group | Number of the packets received from the DHCP clients      |
| Messages from this server group to clients | Number of the packets sent to the DHCP clients            |
| DHCP_OFFER messages                        | Number of the received DHCP-OFFER packets                 |
| DHCP_ACK messages                          | Number of the received DHCP-ACK packets                   |
| DHCP_NAK messages                          | Number of the received DHCP-NAK packets                   |
| DHCP_DECLINE messages                      | Number of the received DHCP-DECLINE packets               |
| DHCP_DISCOVER messages                     | Number of the received DHCP-DISCOVER packets              |
| DHCP_REQUEST messages                      | Number of the received DHCP-REQUEST packets               |

**Table 15** Description on the fields of the display dhcp-server command (continued)

| <b>Field</b>           | <b>Description</b>                          |
|------------------------|---------------------------------------------|
| DHCP_INFORM messages   | Number of the received DHCP-INFORM packets  |
| DHCP_RELEASE messages  | Number of the received DHCP-RELEASE packets |
| BOOTP_REQUEST messages | Number of the BOOTP request packets         |
| BOOTP_REPLY messages   | Number of the BOOTP response packets        |

**View**

This command can be used in the following views:

- Any view

**Related Commands**

- `debugging dhcp-relay`
- `dhcp-server`
- `dhcp-server ip`
- `display dhcp-server interface vlan-interface`

# display dhcp server conflict

---

**Purpose** Use the `display dhcp server conflict` command to display the statistics of IP address conflicts on the DHCP server.

**Syntax** `display dhcp server conflict { all | ip ip-address }`

**Parameters**

|                         |                             |
|-------------------------|-----------------------------|
| <code>all</code>        | Specifies all IP addresses. |
| <code>ip-address</code> | Specifies one IP address.   |

**Example** Display the statistics of IP address conflicts.


```
<S5500> display dhcp server conflict all
Address Discover Time
10.110.1.2 Jan 11 2003 11:57: 7 PM
```

**Table 16** Description on the fields of the display dhcp server conflict command

| Field         | Description                        |
|---------------|------------------------------------|
| Address       | Conflicting IP address             |
| Discover Time | Time when the conflict is detected |

**View** This command can be used in the following views:

- Any view

**Description**  *This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

**Related Command** `reset dhcp server conflict`

# display dhcp server expired

---

## Purpose

Use the `display dhcp server expired` command to display the lease expiration information about one IP address, or the lease expiration information about all IP addresses in one or all DHCP address pools.

## Syntax

```
display dhcp server expired { ip ip-address | pool [pool-name] |
interface [interface-type interface-number] all }
```

## Parameters

|                                                                   |                                                                                                                                                                                                                        |
|-------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>ip <i>ip-address</i></code>                                 | Specifies an IP address.                                                                                                                                                                                               |
| <code>pool [ <i>pool-name</i> ]</code>                            | Specifies a global address pool. The <i>pool-name</i> argument, a string of 1 to 35 characters, is the name of an address pool. If you do not provide this argument, this command applies to all global address pools. |
| <code>interface [ <i>interface-type interface-number</i> ]</code> | Specifies a VLAN interface. If you do not specify a VLAN interface, this command applies to all VLAN interfaces.                                                                                                       |
| <code>all</code>                                                  | Specifies all DHCP address pools.                                                                                                                                                                                      |

## Example

Display the lease expiration information about the IP addresses in all DHCP address pools.

```
<S5500> display dhcp server expired all
Global pool:
IP address Client-identifier/ Lease expiration Type
 Hardware address

Interface pool:
IP address Client-identifier/ Lease expiration Type
 Hardware address

--- total 0 entry ---
```

**Table 17** Description on the fields of the display dhcp server expired command

| Field                              | Description                                                               |
|------------------------------------|---------------------------------------------------------------------------|
| Global pool                        | The information about the expired IP addresses of global address pools    |
| Interface pool                     | The information about the expired IP addresses of interface address pools |
| IP address                         | Bound IP addresses                                                        |
| Client-identifier/Hardware address | User ID or MAC addresses to which IP addresses are bound                  |
| Lease expiration                   | The time when a lease time expires                                        |
| Type                               | Address binding type                                                      |



## View

This command can be used in the following views:

- Any view

## Description

When all the IP addresses in an address pool are assigned, the DHCP server assigns the IP addresses that are expired to DHCP clients.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

# display dhcp server free-ip

---

**Purpose** Use the `display dhcp server free-ip` command to display the free (that is, unassigned) IP addresses.

**Syntax** `display dhcp server free-ip`

**Parameters** None

**Example** Display the free IP addresses.

```
<S5500> display dhcp server free-ip
IP Range from 1.0.0.0 to 2.2.2.1
IP Range from 2.2.2.3 to 2.255.255.255
IP Range from 4.0.0.0 to 4.255.255.255
IP Range from 5.5.5.0 to 5.5.5.0
IP Range from 5.5.5.2 to 5.5.5.255
```

**View** This command can be used in the following views:

- Any view

**Description**



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

# display dhcp-server interface vlan-interface

---

|                         |                                                                                                                                                                                                                                                                                                                 |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>          | Use the <b>display dhcp-server interface vlan-interface</b> command to display information about the DHCP server group to which a VLAN interface is mapped.                                                                                                                                                     |
| <b>Syntax</b>           | <b>display dhcp-server interface vlan-interface <i>vlan-id</i></b>                                                                                                                                                                                                                                              |
| <b>Parameters</b>       | <b>vlan-id</b> VLAN ID.                                                                                                                                                                                                                                                                                         |
| <b>Examples</b>         | <p>Display information about the DHCP server group to which VLAN 2 interface is mapped.</p> <pre>&lt;S5500&gt; display dhcp-server interface vlan-interface 2 The DHCP server group of this interface is 0 The above display information indicates the VLAN 2 interface is mapped to DHCP server group 0.</pre> |
| <b>View</b>             | This command can be used in the following views: <ul style="list-style-type: none"><li>■ Any view</li></ul>                                                                                                                                                                                                     |
| <b>Related Commands</b> | <ul style="list-style-type: none"><li>■ <b>debugging dhcp-relay</b></li><li>■ <b>dhcp-server</b></li><li>■ <b>display dhcp-server</b></li></ul>                                                                                                                                                                 |

# display dhcp server ip-in-use

## Purpose

Use the **display dhcp server ip-in-use** command to display the address binding information of one IP address, the specified DHCP address pool(s) or all DHCP address pools.

## Syntax

```
display dhcp server ip-in-use { ip ip-address | pool [pool-name] |
interface [interface-type interface-number] all }
```

## Parameters

|                                                             |                                                                                                                                                                                                                 |
|-------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>ip</b> <i>ip-address</i>                                 | Specifies an IP address.                                                                                                                                                                                        |
| <b>pool</b> [ <i>pool-name</i> ]                            | Specifies a global address pool. The pool-name argument, a string of 1 to 35 characters, is the name of an address pool. If you do not provide this argument, this command applies to all global address pools. |
| <b>interface</b> [ <i>interface-type interface-number</i> ] | Specifies a VLAN interface. If you do not specify a VLAN interface, this command applies to all VLAN interfaces.                                                                                                |
| <b>all</b>                                                  | Specifies all address pools.                                                                                                                                                                                    |

## Example

Display the address binding information of all DHCP address pools.

```
<S5500> display dhcp server ip-in-use all
Global pool:
IP address Client-identifier/
 Hardware address Lease expiration Type
2.2.2.2 44444-4444-4444 NOT Used Manual

Interface pool:
IP address Client-identifier/
 Hardware address Lease expiration Type
5.5.5.1 0050-ba28-930a Jun 5 2003 10:56: 7 AM Auto:COMMITTE
--- total 0 entry ---
```

**Table 18** Description on the fields of the display dhcp server ip-in-use command

| Field                              | Description                                                 |
|------------------------------------|-------------------------------------------------------------|
| Global pool                        | Address binding information of global DHCP address pools    |
| Interface pool                     | Address binding information of interface DHCP address pools |
| IP address                         | Bound IP address                                            |
| Client-identifier/Hardware address | User ID or MAC address to which the IP address is bound     |
| Lease expiration                   | Time when the lease expires                                 |
| Type                               | Address binding type                                        |

## View

This command can be used in the following views:

- Any view

## Description



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

## Related Command

`reset dhcp server ip-in-use`

# display dhcp server statistics

---

**Purpose** Use the `display dhcp server statistics` command to display the statistics on a DHCP server.

**Syntax** `display dhcp server statistics`

**Parameters** None

**Example** Display the statistics on a DHCP server.

```
<S5500> display dhcp server statistics
Global Pool:
 Pool Number:5
 Binding
 Auto:0
 Manual:1
 Expire:0
Interface Pool:
 Pool Number:1
 Binding
 Auto:1
 Manual:0
 Expire:0
Boot Request:6
 Dhcp Discover:1
 Dhcp Request:4
 Dhcp Decline:0
 Dhcp Release:1
 Dhcp Inform:0
Boot Reply:4
 Dhcp Offer:1
 Dhcp Ack:3
 Dhcp Nak:0
Bad Messages:0
```

**Table 19** Description on the fields of the display dhcp server statistics command

| Field          | Description                                    |
|----------------|------------------------------------------------|
| Global Pool    | Statistics about global address pools          |
| Interface Pool | Statistics about interface address pools       |
| Pool Number    | Number of address pools                        |
| Auto           | Number of the automatically bound IP addresses |
| Manual         | Number of the manually bound IP addresses      |

**Table 19** Description on the fields of the display dhcp server statistics command (continued)

| Field          | Description                                                  |
|----------------|--------------------------------------------------------------|
| Expire         | Number of the expired IP addresses                           |
| Boot Request:  | 6                                                            |
| Dhcp Discover: | 1                                                            |
| Dhcp Request:  | 4                                                            |
| Dhcp Decline:  | 0                                                            |
| Dhcp Release:  | 1                                                            |
| Dhcp Inform:   | 0                                                            |
|                | Statistics about the DHCP packets received from DHCP clients |
| Boot Reply:    | 4                                                            |
| Dhcp Offer:    | 1                                                            |
| Dhcp Ack:      | 3                                                            |
| Dhcp Nak:      | 0                                                            |
|                | Statistics about the DHCP packets sent to DHCP clients       |
| Bad Messages   | Number of the error DHCP packets                             |

**View**

This command can be used in the following views:

- Any view

**Description**



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

**Related Command**

`reset dhcp server statistics`

# display dhcp server tree

---

|                   |                                                                                                                            |                                                                                                                                                                                                                 |
|-------------------|----------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | Use the <b>display dhcp server tree</b> command to display information about address pool tree.                            |                                                                                                                                                                                                                 |
| <b>Syntax</b>     | <b>display dhcp server tree</b> { pool [ <i>pool-name</i> ]   interface [ <i>interface-type interface-number</i> ]   all } |                                                                                                                                                                                                                 |
| <b>Parameters</b> | <b>pool [ <i>pool-name</i> ]</b>                                                                                           | Specifies a global address pool. The pool-name argument, a string of 1 to 35 characters, is the name of an address pool. If you do not provide this argument, this command applies to all global address pools. |
|                   | <b>interface [ <i>interface-type interface-number</i> ]</b>                                                                | Specifies a VLAN interface. If you do not specify a VLAN interface, this command applies to all VLAN interfaces.                                                                                                |
|                   | <b>all</b>                                                                                                                 | Specifies all address pools.                                                                                                                                                                                    |

**Example** Display information about address pool tree.

```
<S5500> display dhcp server tree all
Global pool:
Pool name: 5
network 10.10.1.0 mask 255.255.255.0
Child node:6
Sibling node:7
 option 1 ip-address 255.0.0.0
 expired 1 0 0
 option 58 hex 00 00 A8 C0
 option 59 hex 00 00 00 3C

Pool name: 6
 static-bind ip-address 10.10.1.2 mask 255.0.0.0
 static-bind mac-address 00e0-00fc-0001
Parent node:5
 option 1 ip-address 255.255.0.
 expired 1 0 0
 option 58 hex 00 00 A8 C0
 option 59 hex 00 00 00 3C

Pool name: 7
network 10.10.1.64 mask 255.255.255.192
PrevSibling node:5
 option 1 ip-address 255.0.0.0
 gateway-list 2.2.2.2
 dns-list 1.1.1.1
 domain-name 444444
 nbns-list 3.3.3.3
 expired 1 0 0
 option 58 hex 00 00 A8 C0
 option 59 hex 00 00 00 3C
```



**Table 20** Description on the fields of the display dhcp server tree command

| Field                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Description                                                             |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| Global pool                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | Information about global address pools                                  |
| Interface pool                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Information about interface address pools                               |
| Pool name                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | Address pool name                                                       |
| network                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Assignable IP address range                                             |
| static-bind ip-address 10.10.1.2 mask 255.0.0.0                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Statically bound IP and MAC addresses                                   |
| static-bind mac-address 00e0-00fc-0001                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                                                                         |
| Child node:6                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | The address pool 6 is the child node of this node.                      |
| <p>This field can display the information about the following types of node:</p> <p>Child node: Displays the information about an address pool that is a child of the current address pool.</p> <p>Parent node: Displays the information about the address pool that is the parent of the current address pool.</p> <p>Sibling node: Displays the information about the next sibling address pool of the current address pool. (The order of sibling address pools are determined by the time when they are configured.)</p> <p>PrevSibling node: Displays the information about the previous sibling address pool of the current address pool.</p> |                                                                         |
| option                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Customized DHCP options                                                 |
| expired                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | The address lease time (in terms of number of days, hours, and minutes) |
| gateway-list                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | List of the gateways configured for the DHCP clients                    |
| dns-list                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | List of the DNS servers configured for the DHCP clients                 |
| domain-name                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | The domain name configured for the DHCP clients                         |
| nbns-list                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | List of the NetBIOS servers configured for the DHCP clients             |

**View**

This command can be used in the following views:

- Any view

**Description**



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

# display dhcp-snooping

---

**Purpose** Use the **display dhcp-snooping** command to display the user IP-MAC address mapping entries recorded by the DHCP snooping function.

**Syntax** `display dhcp-snooping [ unit unit-id ]`

**Parameters** *unit-id* ID of a unit in a fabric.

**Example** Display the user IP-MAC address mapping entries recorded by the DHCP snooping function.

```
<S5500> display dhcp-snooping
DHCP-Snooping is enabled.
Type : D--Dynamic , S--Static
Unit ID : 1
Type IP Address MAC Address Lease VLAN Interface
==== =====
--- 0 dhcp-snooping item(s) of unit 1 found ---
```

**View** This command can be used in the following views:

- Any view

**Related Command** `dhcp-snooping`

# display dhcp-snooping trust

---

**Purpose** Use the `display dhcp-snooping trust` command to display the (enabled/disabled) state of the DHCP snooping function and the trusted ports.

**Syntax** `display dhcp-snooping trust`

**Parameters** None

**Example** Display the state of the DHCP snooping function and the trusted ports.

```
<S5500> display dhcp-snooping trust
dhcp-snooping is enabled
dhcp-snooping trust become effective
```

```
Interface Trusted
=====
Ethernet1/0/1 Trusted
```

The above display information indicates that the DHCP snooping function is enabled, and the Ethernet1/0/1 port is a trusted port.

**View** This command can be used in the following views:

- Any view

**Related Command** `dhcp-snooping trust`

# display diagnostic-information

---

**Purpose** Use the **display diagnostic-information** command to display the system diagnostic information, or save the system diagnostic information to a file (with a suffix of "diag") in the flash memory.

**Syntax** `display diagnostic-information`

**Parameters** None

**Example** Save the system diagnostic information to the default.diag file.

```
<S5500> display diagnostic-information
This operation may take a few minutes, continue? [Y/N]y
Diagnostic-information is saved to Flash or displayed(Y=save
N=display)? [Y/N]y
Please input the file name(*.diag) [flash:/default.diag]:
The file is already existing, overwrite it? [Y/N]y

% Output information to file: flash:/default.diag.
Please wait.....
```

**View** This command can be used in the following views:

- User view

# display dldp

---

**Purpose** Use the **display dldp** command to specify the configuration, status, and neighbor table information about one specific or all the ports in the specified unit with DLDP enabled.

**Syntax** `display dldp { unit-id | interface-type interface-number }`

|                   |                         |                                                              |
|-------------------|-------------------------|--------------------------------------------------------------|
| <b>Parameters</b> | <i>unitid</i>           | Unit number in intelligent resilient framework (IRF) system. |
|                   | <i>interface-type</i>   | Port type.                                                   |
|                   | <i>interface-number</i> | Port number.                                                 |

**Example** Display information about all the ports with DLDP enabled on Unit 1.

```
<S5500> display dldp 1
dldp interval 10
dldp work-mode enhance
dldp authentication-mode none
dldp unidirectional-shutdown manual
```

The port number of unit 1 with DLDP is 2.

```
interface GigabitEthernet2/0/1
 dldp port state : inactive
 dldp link state : down
 The neighbor number of the port is 0.
interface GigabitEthernet2/0/2
 dldp port state : advertisement
 dldp link state : up
 The neighbor number of the port is 1.
 neighbor mac address : 00e0-fc27-750d
 neighbor port index : 98
 neighbor state : two way
 neighbor aged time : 24
```

**View** This command can be used in the following views:

- Any view

**Description** The configuration information includes the following:

- The configuration information includes the time interval, authentication mode, password, DLDP operating mode, and handling mode when a unidirectional link is found.
- The status information includes the neighbor status, local port status and link status.

- The neighbor table includes the MAC address, port ID, neighbor status and aging time items.

# display domain

---

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                 |                                                                                                                                       |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|---------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>          | Use the <b>display domain</b> command to view the configuration of a specified ISP domain or display the summary information of all ISP domains.                                                                                                                                                                                                                                                                                                                                          |                 |                                                                                                                                       |
| <b>Syntax</b>           | <code>display domain [ <i>isp-name</i> ]</code>                                                                                                                                                                                                                                                                                                                                                                                                                                           |                 |                                                                                                                                       |
| <b>Parameters</b>       | <table><tr><td><i>isp-name</i></td><td>Specifies the ISP domain name, with a character string not exceeding 24 characters. The specified ISP domain shall have been created.</td></tr></table>                                                                                                                                                                                                                                                                                            | <i>isp-name</i> | Specifies the ISP domain name, with a character string not exceeding 24 characters. The specified ISP domain shall have been created. |
| <i>isp-name</i>         | Specifies the ISP domain name, with a character string not exceeding 24 characters. The specified ISP domain shall have been created.                                                                                                                                                                                                                                                                                                                                                     |                 |                                                                                                                                       |
| <b>Example</b>          | <p>To display the summary information of all ISP domains of the system, enter the following:</p> <pre>&lt;SW5500&gt;display domain 0 Domain = system   State = Active      Access-limit = Disable   Domain User Template:   Idle-cut = Disable   Self-service = Disable   Messenger Time = Disable</pre>                                                                                                                                                                                  |                 |                                                                                                                                       |
| <b>View</b>             | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ Any view</li></ul>                                                                                                                                                                                                                                                                                                                                                                        |                 |                                                                                                                                       |
| <b>Description</b>      | <p>This command is used to output the configuration of a specified ISP domain or display the summary information of all ISP domains. If an ISP domain is specified, the configuration information (content and format) will be displayed exactly the same as the displayed information of the <b>display domain</b> command. The output information can help with ISP domain diagnosis and troubleshooting. Note that the accounting scheme to be displayed should have been created.</p> |                 |                                                                                                                                       |
| <b>Related Commands</b> | <ul style="list-style-type: none"><li>■ <code>access-limit</code></li><li>■ <code>domain</code></li><li>■ <code>radius-scheme</code></li><li>■ <code>state</code></li></ul>                                                                                                                                                                                                                                                                                                               |                 |                                                                                                                                       |

# display dot1x

---

## Purpose

Use the `display dot1x` command to view the relevant information of 802.1x, including configuration information, running state (session connection information) and relevant statistics information.

## Syntax

```
display dot1x [sessions | statistics [interface interface-list]]
```

## Parameters

|                       |                                                                                                                                                                                                                                                                                                                          |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>interface</b>      | Displays the 802.1x information on the specified interface.                                                                                                                                                                                                                                                              |
| <b>sessions</b>       | Displays the session connection information of 802.1x.                                                                                                                                                                                                                                                                   |
| <b>statistics</b>     | Displays the relevant statistics information of 802.1x.                                                                                                                                                                                                                                                                  |
| <b>interface-list</b> | Ethernet interface list including several Ethernet interfaces, expressed in the format <b>interface-list</b> = { <b>interface-num</b> [ to <b>interface-num</b> ] } & < 1-10 >.                                                                                                                                          |
| <b>interface-num</b>  | Specifies a single Ethernet interface in the format <b>interface-num</b> = { <b>interface-type</b> <b>interface-num</b> / <b>interface-name</b> }, where <b>interface-type</b> specifies the interface type, <b>interface-num</b> specifies the interface number and <b>interface-name</b> specifies the interface name. |

For the respective meanings and value ranges, read the parameter of the Port Command Manual section.

## Default

By default, all the relevant 802.1x information about each interface will be displayed.

## Example

Display the configuration information of 802.1x.

```
<SW5500>display dot1x
Equipment 802.1X protocol is enabled
DHCP-launch is disabled
EAP-relay is enabled
Proxy trap checker is disabled
Proxy logoff checker is disabled

Configuration: Transmit Period 30 s, Handshake Period 15 s
 Quiet Period 60 s, Quiet Period Timer is disabled
 Supp Timeout 30 s, Server Timeout 100 s
 The Max-Req 3
Total maximum 802.1x user resource number is 1024

Total current used 802.1x resource number is 0

Ethernet1/0/1 is link-up
 802.1X protocol is disabled
Proxy trap checker is disabled
```



```
Proxy logoff checker is disabled
The port is a(n) authenticator
Authenticate Mode is auto
Port Control Type is Mac-based
Max on-line user number is 256
... (Omitted)
```

## View

This command can be used in the following views:

- Any view

By default, all the relevant 802.1x information about each interface will be displayed.

This command can be used to display the following information on the specified interface: 802.1x configuration, state or statistics. If no port is specified when executing this command, the system will display all 802.1x related information. For example, 802.1x configuration of all ports, 802.1x session connection information, and 802.1x data statistical information. The output information of this command can help the user to verify the current 802.1x configurations so as to troubleshoot 802.1x.

- **dot1x**
- **dot1x max-user**
- **dot1x port-control**
- **dot1x port-method**
- **dot1x retry**
- **reset dot1x statistics**
- **timer**

# display drv

---

**Purpose** Use the **display drv** command to display MNT module driver debugging information.

**Syntax**

```
display drv [chip_data | drv-route | drv-routenip | ip_table |
mac_all_address | mac_count | mac_system | ni_que | qacl_configuration
| qacl_resource | qinq | rd_table | soc_ver | sysm | vlan-port]
```

|                   |                           |                                                                                 |
|-------------------|---------------------------|---------------------------------------------------------------------------------|
| <b>Parameters</b> | <b>chip_data</b>          | MNT module: Information of Chip Data.                                           |
|                   | <b>drv-route</b>          | MNT module: Route Table from driver.                                            |
|                   | <b>drv-routenip</b>       | MNT module: Route Table from driver with next hop ip information from L3 table. |
|                   | <b>ip_table</b>           | MNT module: L3 ip_table information.                                            |
|                   | <b>mac_all_address</b>    | MNT module: all mac addresses.                                                  |
|                   | <b>mac_count</b>          | MNT module: all mac address count.                                              |
|                   | <b>mac_system</b>         | MNT module: mac address configured by driver system.                            |
|                   | <b>ni_que</b>             | MNT module: information of NI queue.                                            |
|                   | <b>qacl_configuration</b> | MNT module: QACL configuration.                                                 |
|                   | <b>qacl_resource</b>      | MNT module: QACL resource information.                                          |
|                   | <b>qinq</b>               | QINQ module: Display QINQ information.                                          |
|                   | <b>rd_table</b>           | MNT module: L3 interface information.                                           |
|                   | <b>soc_ver</b>            | MNT module: Chip(SOC) version.                                                  |
|                   | <b>sysm</b>               | SYSM module: SYSM debug information.                                            |
|                   | <b>vlan-port</b>          | MNT module: display information for port & vlan.                                |

**View** This command can be used in the following views:

- Any view

# display fan

---

**Purpose** Use the `display fan` command to display the working state of the built-in fans.

**Syntax** `display fan [ unit unit-id ]`

**Parameters** `unit unit-id` Specifies the Unit ID of the switch.

**Example** Display the working state of the fans.

```
<SW5500>display fan
Unit 1
Fan 1 State: Normal
```

The information above indicates that the fan works normally.

**View** This command can be used in the following views:

- Any view

# display fib

---

**Purpose** Use the `display fib` command to view the summary of the forwarding information base.

**Syntax** `display fib`

**Parameters** None

**Example** To display the summary of the Forwarding Information Base, enter the following:

```
<SW5500>display fib
Destination/Mask Nexthop Flag TimeStamp Interface
127.0.0.0/8 127.0.0.1 U t [0] InLoopBack0
```

**Table 21** Description of the output information of the display fib command

| Field | Description                                                                                                                                                                               |
|-------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Flag  | The flag options include:<br>B – Blackhole route<br>D – Dynamic route<br>G – Gateway route<br>H – Local host route<br>S – Static route<br>U – Route in UP status<br>R – Unreachable route |

**View** This command can be used in the following views:

- Any view

**Description** The information includes: destination address/mask length, next hop, current flag, timestamp and outbound interface.

# display fib

---

## Purpose

Use the **display fib** command to view the FIB entries which are output from the buffer according to regular expression and related to the specific character string.

## Syntax

```
display fib | { { begin | include | exclude } text }
```

## Parameters

|                |                                                                                   |
|----------------|-----------------------------------------------------------------------------------|
| <b>begin</b>   | Displays the FIB entries from the first one containing the character string text. |
| <b>include</b> | Displays only those FIB entries containing the character string text.             |
| <b>exclude</b> | Displays only those FIB entries excluding the character string text.              |
| <b>text</b>    | Displays string of specific characters.                                           |

## Example

To display the lines starting from the first one containing the string 169.254.0.0, enter the following:

```
<SW5500>display fib | begin 169.254.0.0
Destination/MaskNexthopFlagTimeStampInterface
169.254.0.0/16 2.1.1.1Ut [0]Vlan-interface1
2.0.0.0/16 2.1.1.1Ut [0]Vlan-interface1
```

## View

This command can be used in the following views:

- Any view

# display fib acl

---

**Purpose** Use the `display fib acl` command to view the FIB entries matching a specific ACL.

**Syntax** `display fib acl number`

**Parameters** *number* Enter the ACL in number form. Valid values are 2000 to 2999

**Example** To display the FIB entries matching ACL 2000, enter the following:

```
<SW5500>display fib acl 2000
Route entry matched by access-list 2000:
Summary counts: 1
Destination/MaskNextHopFlagTimeStampInterface
127.0.0.0/8 127.0.0.1Ut [0] InLoopBack0
```

**View** This command can be used in the following views:

- Any view

# display fib *ip\_address*

---

**Purpose** Use the `display fib ip_address` command to view the FIB entries matching the destination IP address (range).

**Syntax**

```
display fib ip_address1 [{ mask1 | mask-length1 } [ip_address2 {
mask2 | mask-length2 } | longer] | longer]
```

**Parameters**

*ip\_address1*, *ip\_address2* Specifies destination IP address, in dotted decimal format. *ip\_address1* and *ip\_address2* jointly define the address range. The FIB entries in this address range will be displayed.

*mask1*, *mask2*,  
*mask-length1*, *mask-length2* Specifies the IP address mask, in dotted decimal format, or an integer in the range of 0 to 32 to represent the mask length.

*longer* All FIB entries matched in the natural mask range.

**Example** To display the FIB entries whose destination addresses match 169.253.0.0 in natural mask range, enter the following:

```
<SW5500>display fib 169.253.0.0
Route Entry Count: 1
Destination/MaskNextHopFlagTimeStampInterface
169.0.0.0/16 2.1.1.1 Ut[0]Vlan-interface1
```

To display the FIB entries whose destination addresses are in the range of 169.254.0.0/16 to 169.254.0.6/16, enter the following:

```
<SW5500>display fib 169.254.0.0 255.255.0.0 169.254.0.6 255.255.0.0
Route Entry Count: 1
Destination/MaskNextHopFlagTimeStampInterface
169.254.0.1/16 2.1.1.1Ut[0]Vlan-interface1
```

**View** This command can be used in the following views:

- Any view

**Description** Each line outputs a FIB entry and the display contents for each entry include destination address/mask length, next hop, current flag, timestamp and outbound interface.

# display fib ip-prefix

---

- Purpose** Use the **display fib ip-prefix** command to view the FIB entries matching the specific prefix list.
- Syntax** `display fib ip-prefix listname`
- Parameters** *listname* Specifies prefix list name, consisting of a string from 1 to 19 characters long.
- Example** To display the FIB entries matching prefix list abc0, enter the following:
- ```
<SW5500>display fib ip-prefix abc0
Route Entry matched by prefix-list abc0:
Summary count: 3
Destination/MaskNextHopFlagTimeStampInterface
127.0.0.0/8      127.0.0.1Ut [0] InLoopBack0
127.0.0.1/32    127.0.0.1Ut [0] InLoopBack0
169.0.0.0/8     2.1.1.1SUt [0] Vlan-interface1
```
- View** This command can be used in the following views:
- Any view

display fib statistics

Purpose Use the `display fib statistics` command to view the total number of FIB entries.

Syntax `display fib statistics [{ begin | include | exclude } text]`

Parameters

<code>begin</code>	Specifies the FIB entries from the first one containing the character string <i>text</i> .
<code>include</code>	Specifies only those FIB entries containing the character string <i>text</i> .
<code>exclude</code>	Specifies only those FIB entries excluding the character string <i>text</i> .
<code>text</code>	String of specific characters.

Example To display the total number of FIB entries, enter the following:

```
<SW5500>display fib statistics  
Route Entry Count : 30
```

View

This command can be used in the following views:

- Any view

display ftm

Purpose

Use the **display ftm information** command to display FTM protocol information.

Use the **display ftm information** command to display the information about FTM protocol, including DDP status, unit ID, Fabric link status, Fabric port status and DDP packet statistics.

Use the **display ftm topology-database** command to display the information about the fabric topology information database.

Syntax

```
display ftm { information | topology-database }
```

Parameters

information	Displays FTM protocol information.
topology-database	Displays the information about the fabric topology information database.

Example

Display FTM protocol information about the switch.

```
<S5500> display ftm information  
DDP Protocol   : disabled  
Fabric VLAN   : NONE  
Fabric Auth    : NONE
```

View

This command can be used in the following views:

- Any view

display ftp-server

Purpose Use the `display ftp-server` command to display the parameters of the current FTP Server. You can perform this command to verify the configuration after setting FTP parameters.

Syntax `display ftp-server`

Parameters None

Example Display the configuration of FTP Server parameters.

```
<SW5500>display ftp-server
  Ftp server is running
  Max user number1
  User count    0
  Timeout (minute) 30
<SW5500>
```

View This command can be used in the following views:

- Any view

display ftp-server source-ip

Purpose Use the **display ftp-server source-ip** command to display the source IP address of the FTP server. If no source IP address is specified, 0.0.0.0 is displayed.

Syntax `display ftp-server source-ip`

Parameters None

Example Display the source IP address of the FTP server.

```
<S5500> display ftp-server source-ip  
The source IP you specified is 192.168.0.1
```

View This command can be used in the following views:

- Any view

display ftp source-ip

Purpose Use the **display ftp source-ip** command to display the source IP address of the FTP client. If no source IP address is specified, 0.0.0.0 is displayed.

Syntax `display ftp source-ip`

Parameters None

Example Display the source IP address of the FTP client.

```
<S5500> display ftp source-ip  
The source IP you specified is 192.168.0.1
```

View This command can be used in the following views:

- Any view

display ftp-user

Purpose	Use the display ftp-user command to display the parameters of current FTP user. You can perform this command to examine the configuration after setting FTP parameters.
Syntax	display ftp-user
Parameters	None
Example	Show the configuration of FTP user parameters. <pre><SW5500>display ftp-user % No ftp user <SW5500></pre>
View	This command can be used in the following views: <ul style="list-style-type: none">■ Any view

display garp statistics

Purpose Use the **display garp statistics** command to display the GARP statistics.

Syntax `display garp statistics [interface interface-list]`

Parameters *interface-list* Ethernet port list, in the format of *interface-list* = { *interface-type interface-number* [to *interface-type interface-number*] }&<1-10>. Where, *interface-type* is the port type, *interface-number* is the port number (refer to the parameter description of the port part in this document for the meanings and ranges of the two parameter), and &<1-10> is the repeatable times of the expression (from 1 to 10). The GARP statistics about the ports in this list will be displayed.

Example Display the GARP statistics on the port Ethernet1/0/1.

```
<S5500> display garp statistics interface ethernet1/0/1
GARP statistics on port Ethernet1/0/1
Number Of GMRP Frames Received      : 0
Number Of GVRP Frames Received      : 0
Number Of GMRP Frames Transmitted    : 0
Number Of GVRP Frames Transmitted    : 0
Number Of Frames Discarded           : 0
```

View This command can be used in the following views:

- Any view

Description The displayed information includes:

- Number of GMRP packets the port received
- Number of GVRP packets the port received
- Number of GMRP packets the port received
- Number of GVRP packets the port received
- Number of packets the port discarded

display garp timer

Purpose Use the **display garp timer** command to display the values of the GARP timers.

Syntax `display garp timer [interface interface-list]`

Parameters *interface-list* Ethernet port list, in the format of *interface-list* = { *interface-type interface-number* [to *interface-type interface-number*] } &<1-10>. Where, *interface-type* is the port type, *interface-number* is the port number (refer to the parameter description of the port part in this document for the meanings and ranges of the two parameter), and &<1-10> is the repeatable times of the expression (from 1 to 10). The timer information about the ports in this list will be displayed.

Example Display the values of GARP timers of the port Ethernet1/0/1.

```
<S5500> display garp timer interface ethernet1/0/1
GARP timers on port Ethernet1/0/1

Garp Join Time           : 20 centiseconds
Garp Leave Time          : 60 centiseconds
Garp LeaveAll Time       : 1000 centiseconds
Garp Hold Time           : 10 centiseconds
```

View This command can be used in the following views:

- Any view

Description The displayed information includes:

- Value of the Join timer
- Value of the Leave timer
- Value of the LeaveAll timer
- Value of the Hold timer

Related Commands

- `garp timer`
- `garp timer leaveall`

display gvrp statistics

Purpose Use the **display gvrp statistics** command to display the GVRP statistics about all or specified Trunk ports.

Syntax `display gvrp statistics [interface interface-list]`

Parameters *interface-list* Ethernet port list, in the format of *interface-list* = { *interface-type interface-number* [to *interface-type interface-number*] }&<1-10>. Where, *interface-type* is the port type, *interface-number* is the port number (refer to the parameter description of the port part in this document for the meanings and ranges of the two parameter), and &<1-10> is the repeatable times of the expression (from 1 to 10).

Example Display the GVRP statistics about the port Ethernet1/0/1.

```
<S5500> display gvrp statistics interface ethernet1/0/1
GVRP statistics on port Ethernet1/0/1

GVRP Status           : Enabled
GVRP Running          : YES
GVRP Failed Registrations : 0
GVRP Last Pdu Origin  : 0000-0000-0000
GVRP Registration Type : Normal
```

View This command can be used in the following views:

- Any view

Description The displayed information includes:

- GVRP status
- Whether GVRP is running
- Number of the failed GVRP registrations
- The source MAC address of the last GVRP PDU
- GVRP registration type of the port

display gvrp status

Purpose Use the **display gvrp status** command to display the enable/disable status of global GVRP.

Syntax `display gvrp status`

Parameters None

Example Display the enable/disable status of global GVRP.

```
<S5500> display gvrp status
GVRP is enabled
The above information indicates GVRP is enabled globally.
```

View This command can be used in the following views:

- Any view

display history-command

Purpose	Use the <code>display history-command</code> command to view the commands previously entered during this login session, up to a specified maximum.
Syntax	<code>display history-command</code>
Parameters	None
Example	<p>To display previously entered commands, enter the following.</p> <pre><SW5500>display history-command</pre> <p>The commands display on screen.</p>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ Any view
Description	To set the maximum number of commands to display, see <code>history-command max-size</code> .

display hwtacacs

Purpose Use the **display hwtacacs** command to view configuration information of one or all HWTACACS schemes.

Syntax `display hwtacacs [hwtacacs-scheme-name]`

Parameters *hwtacacs-scheme-name*: Scheme name of the HWTACACS server. Valid values are a string of 1 to 32 case-insensitive characters, excluding "?". If this argument is null, configuration information of all HWTACACS schemes are displayed.

Default By default, configuration information of all HWTACACS schemes is displayed.

Example Display the configuration information of the HWTACACS scheme gy.

```
<S5500> display hwtacacs gy
-----
HWTACACS-server template name   : gy
  Primary-authentication-server  : 172.31.1.11:49
  Primary-authorization-server   : 172.31.1.11:49
  Primary-accounting-server      : 172.31.1.11:49
  Secondary-authentication-server : 0.0.0.0:0
  Secondary-authorization-server  : 0.0.0.0:0
  Secondary-accounting-server    : 0.0.0.0:0
  Current-authentication-server   : 172.31.1.11:49
  Current-authorization-server    : 172.31.1.11:49
  Current-accounting-server       : 172.31.1.11:49
  Source-IP-address              : 0.0.0.0
  key authentication              : 790131
  key authorization               : 790131
  key accounting                  : 790131
  Quiet-interval (min)           : 5
  Response-timeout-Interval (sec) : 5
  Domain-included                 : No
  Traffic-unit                    : B
  Packet traffic-unit             : one-packet
```

View This command can be used in the following views:

- Any view

Related Command `hwtacacs scheme`

display icmp statistics

Purpose Use the `display icmp statistics` command to view the statistics information about ICMP packets.

Syntax `display icmp statistics`

Parameters None

Example To view statistics about ICMP packets, enter the following:

```
<SW5500> display icmp statistics
  Input: bad formats    0          bad checksum          0
         echo          5          destination unreachable 0
         source quench 0          redirects              0
         echo reply    10         parameter problem     0
         timestamp    0          information request    0
         mask requests 0          mask replies           0
         time exceeded 0
  Output: echo         10         destination unreachable 0
         source quench 0          redirects              0
         echo reply    5          parameter problem     0
         timestamp    0          information reply      0
         mask requests 0          mask replies           0
         time exceeded 0
```

Table 22 Output Description of the display icmp statistics command

Field	Description
bad formats	Number of input packets in bad format
bad checksum	Number of input packets with wrong checksum
echo	Number of input/output echo request packets
destination unreachable	Number of input/output packets with unreachable destination
source quench	Number of input/output source quench packets
redirects	Number of input/output redirected packets
echo reply	Number of input/output echo reply packets
parameter problem	Number of input/output packets with parameter problem
timestamp	Number of input/output timestamp packets
information request	Number of input information request packets
mask requests	Number of input/output mask request packets
mask replies	Number of input/output mask reply packets
information reply	Number of output information reply packets
time exceeded	Number of time exceeded packets

View This command can be used in the following views:

- Any view

Related Commands

- `display interface VLAN-interface`
- `reset ip statistics`

display igmp group

Purpose Use the `display igmp group` command to view the member information of the IGMP multicast group.

Syntax `display igmp group [group-address | interface interface-type interface-number]`

Parameters

<i>group-address</i>	Address of the multicast group.
<i>interface-type</i> <i>interface-number</i>	Interface type and interface number of the router, used to specify the specific interface.

Example View the member information of multicast group in the system.

```
<SW5500>display igmp group
LoopBack0 (20.20.20.20): Total 3 IGMP Groups reported:
  Group Address      Last Reporter  Uptime      Expires
  225.1.1.1          20.20.20.20   00:02:04    00:01:15
  225.1.1.3          20.20.20.20   00:02:04    00:01:15
  225.1.1.2          20.20.20.20   00:02:04    00:01:17
```

Table 23 Output Display of the display igmp group command

Field	Description
Group address	Multicast group address
Last Reporter	The last host reporting to join in the multicast group
Uptime	Time passed since multicast group is discovered (hh: mm: ss)
Expires	Specifies when the member will be removed from the multicast group (hh: mm: ss).

View This command can be used in the following views:

- Any View

Description You can specify to show the information of a group or the member information of the multicast group on an interface. The information displayed contains the multicast groups that are joined by the downstream hosts through IGMP or through command line.

Related Command `igmp host-join`

display igmp interface

Purpose Use the `display igmp interface` command to view the IGMP configuration and running information on an interface.

Syntax `display igmp interface [interface-type interface-number]`

Parameters

<i>interface-type</i>	
<i>interface-number</i>	Interface type and interface number of the router, used to specify the interface. If the parameters are omitted, information about all the interfaces running IGMP will be displayed.

Example View the IGMP configuration and running information of all interfaces.

```
<SW5500>display igmp interface
Vlan-interface1 (10.153.17.99):
  IGMP is enabled
  Current IGMP version is 2
  Value of query interval for IGMP(in seconds): 60
  Value of other querier time out for IGMP(in seconds): 120
  Value of maximum query response time for IGMP(in seconds): 10
  Value of robust count for IGMP: 2
  Value of startup query interval for IGMP(in seconds): 15
  Value of last member query interval for IGMP(in seconds): 1
  Value of query timeout for IGMP version 1(in seconds): 400
  Policy to accept IGMP reports: none
  Querier for IGMP: 10.153.17.99 (this router)
  IGMP group limit is 1024
  No IGMP group reported
```

View This command can be used in the following views:

- Any view

display igmp-snooping configuration

Purpose	Use the display igmp-snooping configuration command to display the configuration information about IGMP Snooping.
Syntax	display igmp-snooping configuration
Parameters	None
Example	<p>Display the configuration information about IGMP Snooping on the switch.</p> <pre><S5500> display igmp-snooping configuration Enable IGMP-Snooping. The router port timeout is 105 second(s). The max response timeout is 1 second(s). The host port timeout is 260 second(s).</pre> <p>The above information shows: IGMP Snooping has already been enabled, the aging time of the router port is 105 seconds, the maximum query response time is one second, and the aging time of multicast member ports is 260 seconds.</p>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ Any view
Description	When IGMP Snooping is enabled on the switch, this command displays the following information: IGMP Snooping state, aging time of the router port, maximum query response time, and aging time of multicast member ports.
Related Command	igmp-snooping

display igmp-snooping group

Purpose Use the **display igmp-snooping group** command to display information about the IP and MAC multicast groups under one VLAN (with **vlan vlan-id**) or all VLANs (without **vlan vlan-id**).

Syntax `display igmp-snooping group [vlan vlan-id]`

Parameters `vlan vlan-id` Specifies a VLAN ID.

Example Display information about the multicast groups under VLAN 2.

```
<S5500> display igmp-snooping group vlan 2
*****Multicast group table*****
Vlan(id):2.
Router port(s):Ethernet1/0/1
IP group(s):the following ip group(s) match to one mac group.
IP group address:230.45.45.1
Member port(s):Ethernet1/0/2
MAC group(s):
MAC group address:01-00-5e-2d-2d-01
Member port(s):Ethernet1/0/2
```

The above information shows:

- There exist multicast groups under VLAN 2.
- Ethernet 1/0/1 is the router port.
- The IP multicast group address is 230.45.45.1.
- Ethernet 1/0/2 is a member port of the IP multicast group.
- The MAC multicast group address is 0100-5e2d-2d01.
- Ethernet 1/0/2 is a member port of the MAC multicast group.

View This command can be used in the following views:

- Any view

Description This command displays the following information: VLAN ID, router port, IP multicast group address, member ports included in IP multicast group, MAC multicast group, MAC multicast group address, member ports included in MAC multicast group.

display igmp-snooping statistics

Purpose Use the **display igmp-snooping statistics** command to display the message statistics about IGMP Snooping.

Syntax `display igmp-snooping statistics`

Parameters None

Example Display the message statistics about IGMP Snooping.

```
<S5500> display igmp-snooping statistics
Received IGMP general query packet(s) number:0.
Received IGMP specific query packet(s) number:0.
Received IGMP V1 report packet(s) number:0.
Received IGMP V2 report packet(s) number:0.
Received IGMP leave packet(s) number:0.
Received error IGMP packet(s) number:0.
Sent IGMP specific query packet(s) number:0.
```

The above information shows that IGMP Snooping has received:

- Zero IGMP general query message
- Zero IGMP group-specific query message
- Zero IGMP V1 report message
- Zero IGMP V2 report message
- Zero IGMP leave message
- Zero IGMP error message

And IGMP Snooping has sent:

- Zero IGMP group-specific query message

View This command can be used in the following views:

- Any view

Description This command displays the following information: the numbers of the IGMP general query messages, IGMP group-specific query messages, IGMP V1 report messages, IGMP V2 report messages, IGMP leave messages and error IGMP messages received, and the number of the IGMP group-specific query messages sent.

Related Command `igmp-snooping`

display info-center

Purpose	Use the <code>display info-center</code> command to display the configuration of system log and the information recorded in the memory buffer.
Syntax	<code>display info-center</code>
Parameters	None
Example	<p>Show the system log information.</p> <pre><SW5500>display info-center Information Center: enabled Log host: 173.168.1.10, channel number:2, channel name:loghost, language:english , host facility local:7 Console: channel number:0, channel name:console Monitor: channel number:1, channel name:monitor SNMP Agent: channel number:5, channel name:snmpagent Log buffer: enabled, max buffer size:1024, current buffer size:256 current messages:6, channel number:4, channel name:logbuffer dropped messages:0, overwrote messages:0 Trap buffer: enabled, max buffer size:1024, current buffer size:256 current messages:0, channel number:3, channel name:trapbuffer dropped messages:0, overwrote messages:0 Information timestamp setting: log - date, trap - date, debug - boot XRN SWITCH OF this Device: LOG = disable; TRAP = disable; DEBUG = enable</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ Any view
Description	If the information in the current log/trap buffer is less than the specified <i>sizeval</i> , display the actual log/trap information.
Related Commands	<ul style="list-style-type: none">■ <code>info-center enable</code>■ <code>info-center logbuffer</code>■ <code>info-center loghost</code>■ <code>info-center console channel</code>■ <code>info-center monitor channel</code>

display interface

Purpose Use the `display interface` command to view the configuration information on the selected interface.

Syntax

```
display interface [ interface_type |  
interface_type interface_number ]
```

Parameters

<i>interface_type</i>	Specifies the interface type. This can be either Aux, Ethernet, GigabitEthernet, NULL, Vlan-interface.
<i>interface_number</i>	Specifies the interface number in the format unit-number/0/port-number. Valid values for the unit number are 1 to 8. Valid values for the port number are 1 to 28 or 1 to 52, depending on the number of ports you have on your unit.



You can use the `interface_name` at this command. This consists of the `interface_type` and the `interface_number` combined as a single parameter. For example, `Ethernet1/0/1`.

Example To display configuration information on Ethernet port 1/0/1, enter the following:

```
<SW5500>display interface Ethernet 1/0/1
```

The information displays in the following format:

```
Ethernet1/0/1 current state : UP  
IP Sending Frames' Format is PKTFMT_ETHNT_2, Hardware address is  
00e0-fc00-0010  
The Maximum Transmit Unit is 1500  
Media type is twisted pair, loopback not set  
Port hardware type is 100_BASE_TX  
100Mbps-speed mode, full-duplex mode  
Link speed type is autonegotiation, link duplex type is autonegotiation  
Flow-control is not enabled  
The Maximum Frame Length is 1536  
Broadcast MAX-ratio: 100%  
Allow jumbo frame to pass  
PVID: 1  
Mdi type: auto  
Port link-type: access  
  Tagged   VLAN ID : none  
  Untagged VLAN ID : 1  
Last 300 seconds input:  0 packets/sec 0 bytes/sec  
Last 300 seconds output: 0 packets/sec 0 bytes/sec  
Input(total):  0 packets, 0 bytes  
  - broadcasts, - multicasts  
Input(normal):  0 packets, 0 bytes  
  0 broadcasts, 0 multicasts  
Input:  0 input errors, 0 runts, 0 giants,  0 throttles, 0 CRC
```

```

    0 frame, - overruns, - aborts, - ignored, - parity errors
Output (total): 0 packets, 0 bytes
    - broadcasts, - multicasts, - pauses
Output (normal): 0 packets, 0 bytes
    0 broadcasts, 0 multicasts, 0 pauses
Output: 0 output errors, - underruns, - buffer failures
    - aborts, 0 deferred, 0 collisions, 0 late collisions
    - lost carrier, - no carrier

```

View

This command can be used in the following views:

- Any view

Description

Along with others, this interface could be a specific port's interface (for example, Ethernet1/0/1) or a specific VLAN interface (for example, vlan-interface 1).

Table 24 Output Description of the Display Interface command

Field	Description
Ethernet1/0/1 current state	Indicates the current state of the Ethernet port (up or down)
IP Sending frames' format	Displays the Ethernet frame format
Hardware address	Displays the port hardware address
Description	Displays the port description
The Maximum Transmit Unit	Indicates the maximum transmit unit
Media type	Indicates the type of media
loopback not set	Displays the port loopback test state
Port hardware type	Displays the port hardware type
100 Mbps-speed mode, full-duplex mode, link speed type is autonegotiation, link duplex type is autonegotiation	Indicates that the duplex mode and the rate have been auto-negotiated with the connected device, and have been set to 100 Mbps full-duplex.
Flow control is not enabled	Port flow control state
The Maximum Frame Length	Indicates the maximum length of the Ethernet frames that can pass through the port
Broadcast MAX ratio	Port broadcast storm suppression ratio
Allow jumbo frame to pass	Indicates that jumbo frame are allowed to pass through the port
PVID	Indicates the port default VLAN ID.
Mdi type	Indicates the cable type
Port link-type	Indicates the port link type

Table 24 Output Description of the Display Interface command (continued)

Field	Description
Tagged VLAN ID	Indicates the VLANs with packets tagged
Untagged VLAN ID	Indicates the VLANs with packets untagged
Last 300 minutes input rate: 0 packets/sec, 0 bytes/sec	Displays the input/output rate and the number of packets that were passed on this port in the last 300 seconds
Last 300 minutes output rate: 0 packets/sec, 0 bytes/sec	
Input(total): 0 packets, 0 bytes - broadcasts, - multicasts	The statistics information of input/output packets and errors on this port. A "-" indicates that the item isn't supported by the switch.
Input(normal): 0 packets, 0 bytes 0 broadcasts, 0 multicasts	
Input: 0 input errors, 0 runts, 0 giants, 0 throttles, 0 CRC 0 frame, - overruns, - aborts, - ignored, - parity errors	
Output(total): 0 packets, 0 bytes - broadcasts, - multicasts, - pauses	
Output(normal): 0 packets, 0 bytes 0 broadcasts, 0 multicasts, 0 pauses	
Output: 0 output errors, - underruns, - buffer failures - aborts, 0 deferred, 0 collisions, 0 late collisions - lost carrier, - no carrier	

display interface VLAN-interface

Purpose Use the **display interface vlan-interface** command to view the information about a specific VLAN interface, or all VLAN interfaces.

Use **display interface vlan-interface vlan_id** to display information on a specific VLAN interface.

Syntax `display interface vlan-interface [vlan_id]`

Parameters `vlan_id` Specifies the ID number of the VLAN interface. Valid values are 1 to 4094.

Example To display information on VLAN interface 1, enter the following:

```
<SW5500>display interface vlan-interface 1
```

The information displays in the following format:

```
Vlan-interface1 current state :UP
```

```
Line protocol current state :UP
```

```
IP Sending Frames' Format is PKTFMT_ETHNT_2, Hardware address is  
00e0-fc00-3971
```

```
Internet Address is 161.71.61.206/24 Primary
```

```
Description : Vlan-interface1 Interface
```

```
The Maximum Transmit Unit is 1500
```

```
<SW5500>
```

View This command can be used in the following views:

- Any view

Description The information displayed includes:

- Current status of the interface
- Current status of the line protocol
- VLAN interface description
- Maximum Transmit Unit (MTU)
- IP address and subnet mask
- Format of the IP frames
- MAC hardware address.

Related Command `interface VLAN-interface`

display ip host

Purpose Use the `display ip host` command to display all host names and their corresponding IP addresses.

Syntax `display ip host`

Parameters None

Example To display all host names and their corresponding IP addresses, type the following:

```
<SW5500>display ip host
```

The information displays in the following format:

Host	Age	Flags	Address
My	0	static	1.1.1.1
Aa	0	static	2.2.2.4

View This command can be used in the following views:

- Any view

display ip interface vlan-interface

Purpose Use the `display ip interface vlan-interface` command to view information on the specified interface.

Syntax `display ip interface vlan-interface vlan_id`

Parameters `vlan_id` Specifies the identifier of the vlan interface.

Example

To display information for VLAN-interface 1, enter the following:

```
<SW5500>display ip interface vlan-interface 1
```

The information displays in the following format:

```
Vlan-interfacel current state : DOWN
Line protocol current state : DOWN
Internet Address is 1.1.1.1/8 Primary
Broadcast address : 1.255.255.255
The Maximum Transmit Unit : 1500 bytes
input packets : 0, bytes : 0, multicasts : 0
output packets : 0, bytes : 0, multicasts : 0
TTL invalid packet number:          0
ICMP packet input number:          0
  Echo reply:                       0
  Unreachable:                      0
  Source quench:                    0
  Routing redirect:                  0
  Echo request:                     0
  Router advert:                    0
  Router solicit:                   0
  Time exceed:                      0
  IP header bad:                    0
  Timestamp request:                0
  Timestamp reply:                  0
  Information request:              0
  Information reply:                0
  Netmask request:                  0
  Netmask reply:                    0
  Unknown type:                     0
DHCP packet deal mode: global
```

View This command can be used in the following views:

- Any view

display ip ip-prefix

Purpose Use the `display ip ip-prefix` command to view the address prefix list.

Syntax `display ip ip-prefix [ip_prefix_name]`

Parameters `ip_prefix_name` Specifies displayed address prefix list name.

Example Display the information of the address prefix list named to `p1`.

```
<SW5500>display ip ip-prefix p1
name      index  conditions  ip-prefix / mask    GE  LE
p1        10     permit     10.1.0.0/16         17  18
```

Table 25 Output Description of the display ip-ip prefix command

Field	Description
name	Name of ip-prefix
index	Internal sequence number of ip-prefix
conditions	Mode: permit or deny
ip-prefix	Address and network segment length of ip-prefix
GE	Greater-equal value of ip-prefix network segment length
LE	Less-equal value of ip-prefix network segment length

View This command can be used in the following views:

- Any view

Related Command `ip ip-prefix`

display ip routing-table

Purpose Use the `display ip routing-table` command to view a summary of routing table information.

Syntax `display ip routing-table`

Parameters None

Example To view a summary of routing table information, enter the following:

```
<SW5500>display ip routing-table
```

The information displays in the following format:

```
Routing Table: public net
Destination/Mask Proto Pre CostNexthopInterface
1.1.1.0/24       DIRECT 0 0 1.1.1.1 Vlan-interface1
1.1.1.1/32       DIRECT 0 0 127.0.0.1 InLoopBack0
2.2.2.0/24       DIRECT 0 0 2.2.2.1 Vlan-interface2
2.2.2.1/32       DIRECT 0 0 127.0.0.1 InLoopBack0
3.3.3.0/24       DIRECT 0 0 3.3.3.1 Vlan-interface3
3.3.3.1/32       DIRECT 0 0 127.0.0.1 InLoopBack0
4.4.4.0/24       DIRECT 0 0 4.4.4.1 Vlan-interface4
4.4.4.1/32       DIRECT 0 0 127.0.0.1 InLoopBack0
127.0.0.0/8      DIRECT 0 0 127.0.0.1 InLoopBack0
127.0.0.1/32     DIRECT 0 0 127.0.0.1 InLoopBack0
```

Table 26 Output Description of the display ip routing-table command

Field	Description
Destination/Mask	Destination address/Mask length
Protocol	Routing protocol
Pre	Routing preference
Cost	Cost
Interface	Output interface, through which the data packet destined for the destination network is sent

View This command can be used in the following views:

- Any view

Description Each line in the table represents one route. The displayed information includes destination address/mask length, protocol, preference, cost, next hop and output interface.

Only the currently used route, that is the best route, is displayed.

display ip routing-table acl

Purpose Use the `display ip routing-table acl` command to view the route filtered through the specified ACL.

Syntax `display ip routing-table acl acl_number [verbose]`

Parameters

<code><i>acl_number</i></code>	Specifies the number of the IP ACL. Valid values are 2000 to 2999.
<code><i>verbose</i></code>	Displays verbose information about both the active and inactive routes that passed filtering rules. If you do not enter this parameter, the command only displays a summary of the active routes that passed filtering rules.

Example To display a summary of the active routes filtered through basic ACL 2000, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]acl number 2000
[SW5500-acl-basic-2000]rule permit source 10.1.1.1 0.0.0.255
[SW5500-acl-basic-2000]rule deny source any
[SW5500-acl-basic-2000]display ip routing-table acl 2000
```

The information displays in the following format:

```
Routes matched by access-list 2000:
Summary count: 4
Destination/Mask                               ProtocolPreCost
Nexthop      Interface
10.1.1.0/24   DIRECT0010.1.1.21
Vlan-interface1
10.1.1.2/32   DIRECT00127.0.0.1
InLoopBack0
```

For detailed description of the output information, see Table 27.

To display the verbose information of the active and inactive routes that are filtered through basic ACL 2000.

```
<SW5500>display ip routing-table acl 2000 verbose
```

The information displays in the following format:

```
Routes matched by access-list 2000:
Generate Default: no
+ = Active Route, - = Last Active, # = Both* = Next hop in use
Summary count:2

**Destination: 10.1.1.0Mask: 255.255.255.0
Protocol: #DIRECTPreference: 0
```

```

*NextHop: 10.1.1.2Interface: 10.1.1.2(Vlan-interface1)
Vlinkindex: 0
State: <Int ActiveU Retain Unicast>
Age: 7:24 Cost: 0/0Tag: 0

**Destination: 10.1.1.2Mask: 255. 255. 255. 255
Protocol: #DIRECTPreference: 0
*NextHop: 127.0.0.1Interface: 127.0.0.1(InLoopBack0)
Vlinkindex: 0
State: <NoAdvise Int ActiveU Retain Gateway Unicast>
Age: 7:24 Cost: 0/0 Tag: 0

```

Table 27 Output Description of the ip routing-table acl verbose command

Field	Description
Destination	Destination address
Mask	Mask
Protocol	Routing protocol
Preference	Routing preference
Nexthop	Next hop address
Interface	Output interface, through which the data packet destined for the destination network is sent
Vlinkindex	Virtual link index

Table 27 Output Description of the ip routing-table acl verbose command

Field	Description
State	<p>Route state description:</p> <p>ActiveU — The route is selected and is optimum.</p> <p>Blackhole — Blackhole route is similar to Reject route, but it will not send the ICMP unreachable message to the source end.</p> <p>Delete — The route is deleted.</p> <p>Gateway — Identifies that the route is not an interface route.</p> <p>Hidden — The route exists, but it is unavailable temporarily for some reasons (for example, configured policy or interface is Down). Moreover, you do not wish to delete it. Therefore, you need to hide it, so as to restore it again later.</p> <p>Holddown — Holddown is one kind of route redistribution policy adopted by some distance-vector (D-V) routing protocols (for example, RIP), through which these routing protocols can avoid the flooding of error routes and deliver the routing unreachable message accurately. For example, the RIP redistributes a certain route every a period of time regardless of whether the actually found routes destined for the same destination change. For more details, refer to the specific routing protocols.</p> <p>Int — The route is discovered by interior gateway protocol (IGP).</p> <p>NoAdvise — The routing protocol does not redistribute NoAdvise route when it redistributes routes based on the policy.</p> <p>NotInstall — The routing protocol generally selects the route with the highest precedence from its routing table, then places it in its core routing table and redistributes it. Although the NotInstall route cannot be placed in the core routing table, it is possibly that it is selected and redistributed.</p> <p>Reject — Unlike the normal routes, the Reject route will discard the packets that select it as their route, and the router will send ICMP unreachable message to the source end. Reject route is usually used for the network test.</p> <p>Retain — When the routes from the routing table are deleted, the routes with Retain flag will not be deleted. Using this function you can set Retain flag for some static routes, so that they can exist in the core routing table.</p> <p>Static — The route with Static flag will not be cleared from the routing table after you save it and reboot the router. Generally, the static route configured manually in the router belongs to a Static route</p> <p>Unicast — Unicast route.</p>
Age	Time to live.
Cost	Value of cost.

View

This command can be used in the following views:

- Any view.

Description

This command is used to display the routes that passed the filtering rules in the specified ACL.

The command only displays routes that passed basic ACL filtering rules.

display ip routing-table ip_address

Purpose

Use the `display ip routing-table ip_address` command to view routing information for a specific IP address, and you can also choose the type of information to display.

Use the `display ip routing-table ip_address mask` command to display the route that matches the specified IP destination address and subnet mask.

Use the `display ip routing-table ip_address longer-match` command to display all destination address routes that match destination IP addresses in natural mask range.

Use the `display ip routing-table ip_address verbose` command to display verbose information about both active and inactive routes.

Syntax

```
display ip routing-table ip_address [ mask ] [ longer-match ] [ verbose ]
```

Parameters

<code>ip_address</code>	Specifies the destination IP address.
<code>mask</code>	Specifies either the IP subnet mask (in x.x.x.x format), or the subnet mask length (in the range 0 to 32). Optional.
<code>longer-match</code>	Displays an address route that matches the destination IP address in natural mask range. Optional.
<code>verbose</code>	Displays verbose information about both active and inactive routes. Without this parameter, this command only displays a summary of active routes. Optional.

Example

There is corresponding route in natural mask range. Display the summary.

```
<SW5500>display ip routing-table 169.0.0.0
Routing Tables:
Summary count:1
Destination/MaskProtoPreCost NexthopInterface
169.0.0.0/16 Static6002.1.1.1LoopBack1
```

There are corresponding routes in the natural mask range. Display the detailed information.

```
<SW5500>display ip routing-table 169.0.0.0 verbose
Routing Tables:
Generate Default: no
+ = Active Route, - = Last Active, # = Both* = Next hop in use
Summary count:2
**Destination: 169.0.0.0Mask: 255.0.0.0
Protocol: #StaticPreference: 60
*NextHop: 2.1.1.1Interface: 2.1.1.1(LoopBack1)
Vlinkindex: 0
State: <Int ActiveU Static Unicast>
Age: 3:47 Cost: 0/0
```



```
**Destination: 169.0.0.0Mask: 255.254.0.0  
Protocol: #StaticPreference: 60  
*NextHop: 2.1.1.1Interface: 2.1.1.1(LoopBack1)  
Vlinkindex: 0  
State: <Int ActiveU Static Unicast>  
Age: 3:47 Cost: 0/0
```

For detailed description of output information, refer to Table 26.

View

This command can be used in the following views:

- Any view

Description

If the destination address, *ip_address*, has a corresponding route in natural mask range, this command will display all subnet routes or only the route best matching the destination address, *ip_address*, is displayed. And only the active matching route is displayed.

display ip routing-table ip_address1 ip_address2

Purpose

Use the `display ip routing-table ip_address1 mask1 ip_address2 mask2` command to view the route information for the specified address range.

Syntax

```
display ip routing-table ip_address1 mask1 ip_address2 mask2
[ verbose ]
```

Parameters

<code>ip_address1 mask1</code>	Specifies the destination IP address and subnet mask that you want to start the address range. This command displays the route for your chosen address range. The subnet mask can be entered as either a dotted decimal notation (x.x.x.x), or an integer in the range 0 to 32.
<code>ip_address2 mask2</code>	Specifies the IP address and subnet mask that you want to end the address range. The subnet mask can be entered as either a dotted decimal notation (x.x.x.x), or an integer in the range 0 to 32.
<code>verbose</code>	Displays the verbose information of both the active and inactive routes. Without this parameter, the command only displays a summary of active routes. Optional.

Example

To display the routing information of destination addresses ranging from 1.1.1.0 to 2.2.2.0., with a subnet mask of 24, enter the following:

```
<SW5500>display ip routing-table 1.1.1.0 24 2.2.2.0 24
```

The information displays in the following format:

```
Routing tables:
  Summary count: 3
Destination/Mask  Proto  Pre Cost NexthopInterface
1.1.1.0/24        DIRECT  00 1.1.1.1 Vlan-interface1
1.1.1.1/32        DIRECT  00 127.0.0.1 InLoopBack0
2.2.2.0/24        DIRECT  00 2.2.2.1 Vlan-interface2
```

For detailed description of output information, refer to Table 26.

View

This command can be used in the following views:

- Any view

display ip routing-table ip-prefix

Purpose

Use the command `display ip routing-table ip-prefix` command to display route information.

Use the command `display ip routing-table ip-prefix ip_prefix_name` to display information on the routes that passed filtering rules for the specified IP prefix name.

Use the command `display ip routing-table ip-prefix ip_prefix_name verbose` to display both the active and inactive routes that passed filtering rules.

Syntax

```
display ip routing-table ip-prefix ip_prefix_name [ verbose ]
```

Parameters

<code>ip_prefix_name</code>	Specifies the ip prefix list name.
<code>verbose</code>	Displays verbose information about both the active and inactive routes that passed filtering rules. Without this parameter, this command displays the summary of active routes that passed filtering rules.

Example

To display the summary information for ip prefix list abc2, active route only, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]ip ip-prefix abc2 permit 10.1.1.0 24 less-equal 32
[SW5500]display ip routing-table ip-prefix abc2
```

The information displays in the following format:

```
Routes matched by ip-prefix abc2:
Summary count: 2
Destination/MaskProtocol PreCost NexthopInterface
10.1.1.0/24 DIRECT 0010.1.1.2Vlan-interface1
10.1.1.2/32 DIRECT 00127.0.0.1InLoopBack0
```

To display the information on the active and inactive routes for prefix list abc2, enter the following:

```
[SW5500]display ip routing-table ip-prefix abc2 verbose
```

The information displays in the following format:

```
Routes matched by ip-prefix abc2:
+ = Active Route, - = Last Active, # = Both* = Next hop in use
Summary count:2
**Destination: 10.1.1.0Mask: 255.255.255.0
Protocol: #DIRECTPreference: 0
*NextHop: 10.1.1.2Interface: 10.1.1.2(Vlan-interface1)
Vlinkindex: 0
State: <Int ActiveU Retain Unicast>
Age: 3:23:44 Cost: 0/0Tag:0
```

```
**Destination: 10.1.1.2Mask: 255. 255. 255. 255
  Protocol: #DIRECTPreference: 0
  *NextHop: 127.0.0.1Interface: 127.0.0.1(InLoopBack0)
  Vlinkindex: 0
State: <NoAdvise Int ActiveU Retain Gateway Unicast>
  Age: 3:23:44 Cost: 0/0Tag: 0
```

For detailed description of output information, refer to Table 27.

View

This command can be used in the following views:

- Any view

Description

Without the **verbose** parameter, this command displays the summary of the active routes that passed filtering rules.

display ip routing-table protocol

Purpose

Use the `display ip routing-table protocol` command to view the route information for a specified protocol.

Syntax

```
display ip routing-table protocol protocol [ inactive | verbose ]
```

Parameters

<code>protocol</code>	Enter one of the following: <ul style="list-style-type: none">■ <code>direct</code>: Displays the direct connection route information■ <code>static</code>: Displays the static route information.■ <code>ospf</code>: Displays OSPF route information.■ <code>ospf-ase</code>: Displays OSPF ASE route information.■ <code>ospf-nssa</code>: Displays OSPF NSSA route information.■ <code>rip</code>: Displays RIP route information.
<code>inactive</code>	Displays inactive route information. Without this parameter, the command displays both active and inactive route information. Optional.
<code>verbose</code>	Displays verbose route information. Without this parameter, the command displays the route summary. Optional.

Example

To display a summary of all direct connection routes, enter the following:

```
<SW5500>display ip routing-table protocol direct
The information displays in the following format:
DIRECT Routing tables:
Summary count: 4
DIRECT Routing tables status:<active>:
Summary count: 3
Destination/MaskProtocol Pre Cost NexthopInterface
20.1.1.1/32    DIRECT    00127.0.0.1InLoopBack0
127.0.0.0/8   DIRECT    00127.0.0.1InLoopBack0
127.0.0.1/32  DIRECT    00127.0.0.1InLoopBack0
DIRECT Routing tables status:<inactive>:
Summary count: 1
Destination/MaskProtocol PreCostNexthopInterface
210.0.0.1/32  DIRECT    0    0127.0.0.1InLoopBack0
```

To display a summary of all static route information, enter the following:

```
<SW5500>display ip routing-table protocol static
```

The information displays in the following format:

```
STATIC Routing tables:
  Summary count: 1
STATIC Routing tables status:<active>:
```

```
Summary count: 0
STATIC Routing tables status:<inactive>:
Summary count: 1
Destination/Mask Protocol          Pre Cost Nexthop Interface
1.2.3.0/24      STATIC                60  0 1.2.4.5 Vlan-interface2
```

The displayed information helps you to confirm whether the configuration of the static routing is correct.

For detailed description of output information, refer to Table 26.

View

This command can be used in the following views:

- Any view

display ip routing-table radix

Purpose Use the `display ip routing-table radix` command to view the route information in a tree structure.

Syntax `display ip routing-table radix`

Parameters None

Example To display the route information, enter the following:

```
<SW5500>display ip routing-table radix
```

The information displays in the following format:

```
Radix tree for INET (2) inodes 7 routes 5:
  +-32+--{210.0.0.1
    +--0+
      | | +-8+--{127.0.0.0
      | | | +-32+--{127.0.0.1
      | +-1+
      | +-8+--{20.0.0.0
      | +-32+--{20.1.1.1
```

Table 28 Output Description of the display ip routing-table radix command

Field	Description
INET	Address suite
inodes	Number of nodes
routes	Number of routes

View This command can be used in the following views:

- Any view

display ip routing-table statistics

Purpose Use the `display ip routing-table statistics` command to display the routing information for all protocols.

Syntax `display ip routing-table statistics`

Parameters None

Example To display the integrated route information, enter the following:

```
<SW5500>display ip routing-table statistics
```

Routing tables:

Proto	route	active	added	deleted
DIRECT	24	4	25	1
STATIC	4	1	4	0
BGP	0	0	0	0
RIP	0	0	0	0
IS-IS	0	0	0	0
OSPF	0	0	0	0
O_ASE	0	0	0	0
O_NSSA	0	0	0	0
AGGRE	0	0	0	0
Total	28	5	29	1

Table 29 Output Description of the display ip routing-table statistics command

Field	Description
Proto	Routing protocol
route	Number of routes
active	Number of active routes
added	Number of added routes after the router is rebooted or the routing table is cleared last time.
deleted	Number of deleted routes (such routes will be freed in a period of time)

View This command can be used in the following views:

- Any view

Description The information includes the number of routes per protocol, the number of active routes per protocol, the number of routes added and deleted per protocol, and the number of routes that are labeled deleted but that are not deleted per protocol. The total number of routes in each of these categories is also displayed.

display ip routing-table verbose

Purpose	Use the <code>display ip routing-table verbose</code> command to display the verbose routing table information.
Syntax	<code>display ip routing-table verbose</code>
Parameters	None
Example	<p>To display the verbose routing table information, enter the following:</p> <pre><SW5500>display ip routing-table verbose</pre> <p>The information displays in the following format:</p> <pre>Routing Tables: Generate Default: no + = Active Route, - = Last Active, # = Both * = Next hop in use Destinations: 3 Routes: 3 Holddown: 0 Delete: 62 Hidden: 0 **Destination: 1.1.1.0 Mask: 255.255.255.0 Protocol: #DIRECT Preference: 0 *NextHop: 1.1.1.1 Interface: 1.1.1.1(Vlan-interface1) State: <Int ActiveU Retain Unicast> Age: 20:17:41 Cost: 0/0 **Destination: 1.1.1.1 Mask: 255.255.255.255 Protocol: #DIRECT Preference: 0 *NextHop: 127.0.0.1 Interface: 127.0.0.1(InLoopBack0) State: <NoAdvise Int ActiveU Retain Gateway Unicast> Age: 20:17:42 Cost: 0/0 **Destination: 2.2.2.0 Mask: 255.255.255.0 Protocol: #DIRECT Preference: 0 *NextHop: 2.2.2.1 Interface: 2.2.2.1(Vlan-interface2) State: <Int ActiveU Retain Unicast> Age: 20:08:05 Cost: 0/0</pre>

The meaning of route state is defined in Table 27. Other generated information is described in Table 30.

Table 30 Output Description of the display ip routing-table verbose command

Descriptor	Meaning
Holddown	The number of holddown routes. This refers to a route advertising policy that some distance vector routing protocols (such as RIP) use to avoid expansion of error routes and to improve the transmission speed and accuracy of unreachable routes. It usually advertises a static route at an interval, regardless of the changes to dynamic routes to the same destination. For details, see the specific routing protocol.
Delete	The number of deleted routes.
Hidden	The number of hidden routes, that is routes not available at present but still required. They can be hidden for future use.

View

This command can be used in the following views:

- Any view

Description

The information displayed includes the route state, the verbose description of each route and the statistics of the entire routing table.

All current routes, including inactive routes and invalid routes, are displayed.

display ip socket

Purpose Use the `display ip socket` command to display the information about the sockets in the current system.

Syntax `display ip socket [socktype sock-type] [task-id socket-id]`

Parameters

<i>sock-type</i>	Specifies the type of a socket: (tcp:1, udp 2, raw ip 3).
<i>task-id</i>	Specifies the ID of a task, with the value ranging from 1 to 100.
<i>socket-id</i>	Specifies the ID of a socket, with the value ranging from 0 to 3072.

Example To display the information about the socket of TCP type, enter the following:

```
<SW5500>display ip socket socktype 1
SOCK_STREAM:
Task = VTYD(18), socketid = 1, Proto = 6,
LA = 0.0.0.0:23, FA = 0.0.0.0:0,
sndbuf = 8192, rcvbuf = 8192, sb_cc = 0, rb_cc = 0,
socket option = SO_ACCEPTCONN SO_KEEPAALIVE SO_SENDDVNPID
SO_SETKEEPAALIVE,
socket state = SS_PRIV SS_ASYNC

Task = VTYD(18), socketid = 2, Proto = 6,
LA = 10.153.17.99:23, FA = 10.153.17.56:1161,
sndbuf = 8192, rcvbuf = 8192, sb_cc = 0, rb_cc = 0,
socket option = SO_KEEPAALIVE SO_OOBLINE SO_SENDDVNPID SO_SETKEEPAALIVE,
socket state = SS_ISCONNECTED SS_PRIV SS_ASYNC

Task = VTYD(18), socketid = 3, Proto = 6,
LA = 10.153.17.99:23, FA = 10.153.17.82:1121,
sndbuf = 8192, rcvbuf = 8192, sb_cc = 0, rb_cc = 0,
socket option = SO_KEEPAALIVE SO_OOBLINE SO_SENDDVNPID SO_SETKEEPAALIVE,
socket state = SS_ISCONNECTED SS_PRIV SS_ASYNC
```

Table 31 Output Description of the display ip socket Command

Field	Description
SOCK_STREAM	The socket type
Task	The ID of a task
socketid	The ID of a socket
Proto	The protocol number used by the socket
sndbuf	The sending buffer size of the socket
rcvbuf	The receiving buffer size of the socket
sb_cc	The current data size in the sending buffer. The value makes sense only for the socket of TCP type, because only TCP is able to cache data
rb_cc	The current data size in the receiving buffer
socket option	The option of the socket
socket state	The state of the socket

View

This command can be used in the following views:

- Any view

display ip statistics

Purpose Use the `display ip statistics` command to view the statistics information about IP packets.

Syntax `display ip statistics`

Parameters None

Example To view statistics about IP packets, enter the following:

```
<SW5500>display ip statistics
  Input:  sum          7120          local          112
          bad protocol  0          bad format     0
          bad checksum  0          bad options    0
  Output: forwarding   0          local          27
          dropped      0          no route      2
          compress fails 0
  Fragment: input      0          output         0
          dropped      0
          fragmented   0          couldn't fragment 0
  Reassembling: sum    0          timeouts      0
```

Table 32 Output Description of the display ip statistics Command

Field	Description
Input: sum	Sum of input packets
local	Number of received packets whose destination is the local device
bad protocol	Number of packets with wrong protocol number
bad format	Number of packets in bad format
bad checksum	Number of packets with wrong checksum
bad options	Number of packets that has wrong options
Output: forwarding	Number of forwarded packets
local	Number of packets that are sent by the local device
dropped	Number of dropped packets during transmission
no route	Number of packets that cannot be routed
compress fails	Number of packets that cannot be compressed
Fragment: input	Number of input fragments
output	Number of output fragments
dropped	Number of dropped fragments
fragmented	Number of packets that are fragmented
couldn't fragment	Number of packets that cannot be fragmented
Reassembling: sum	Number of packets that are reassembled
timeouts	Number of packets that time out

View

This command can be used in the following views:

- Any view

Related Commands

- `display ip interface vlan-interface`
- `reset ip statistics`

display isolate port

Purpose Use the `display isolate port` command to view port isolation information.

Syntax `display isolate port`

Parameters None

Example To display port isolation information, enter the following:

```
<SW5500>display isolate port
UNIT 1:
Ethernet1/0/1
```

View This command can be used in the following views:

- Any view

display lacp system-id

Purpose	Use the display lacp system-id command to view actor system ID, including system priority and system MAC address.
Syntax	display lacp system-id
Parameters	None
Example	To display the local system ID. <pre><SW5500>display lacp system-id Actor System ID: 0x8000, 00e0-fc00-0100</pre>
View	This command can be used in the following views: <ul style="list-style-type: none">■ Any view
Related Commands	<ul style="list-style-type: none">■ link-aggregation group agg-id description■ link-aggregation group agg-id mode

display link-aggregation interface

Purpose

Use the `display link-aggregation interface` command to view detailed link aggregation information at a designated port, including aggregation group ID for the port, port priority, operation key, LACP state flag, partner information (system ID, port number, port priority, operation key, LACP state flag, LACP packet statistics).

Syntax

```
display link-aggregation interface { interface_type interface_number |  
interface_name } [ to { interface_type interface-num | interface_name }  
]
```

Parameters

```
interface { interface_type  
interface_num |  
interface_name } [ to {  
interface_type interface_  
num | interface_name } ]
```

Specifies ports. You can specify multiple sequential ports with the `to` parameter, instead of specifying only one port.

interface_name Specifies port name, in the format of `interface_name = interface_type interface_num`.

interface_type Specifies port type and *interface_num* port number.

For more information, see the parameter item for the `interface` command.

Example

To display detailed link aggregation information of a link aggregation member port, enter the following:

```
<SW5500>display link-aggregation interface ethernet4/0/1
```

If the aggregation has been created manually, the display will be similar to the following:

```
Ethernet4/0/1:  
Attached AggID: 1  
Local:  
Port-Priority: 32768, Oper key: 1, Flag: 0x00  
Remote:  
System ID: 0x0, 0000-0000-0000  
Port Number: 0, Port-Priority: 0, Oper-key: 0, Flag: 0x00
```

If the aggregation is static or dynamic, the display will be similar to the following:

```
<SW5500>display link-aggregation interface ethernet4/0/1  
Ethernet4/0/1:  
Attached AggID: 20  
Local:  
Port-Priority: 32768, Oper key: 2, Flag: 0x3d  
Remote:  
System ID: 0x8000, 000e-84a6-fb00  
Port Number: 2, Port-Priority: 32768 , Oper-key: 10, Flag: 0x3d
```

```
Received LACP Packets: 8 packet(s), Illegal: 0 packet(s)  
Sent LACP Packets: 9 packet(s)
```

View

This command can be used in the following views:

- Any view

Description

Note:

Unlike a dynamic aggregation, a manual aggregation has no protocol to get the remote peer information of the partner. Therefore, every item for the remote peer is 0. This does not indicate the actual state of the remote peer.

Related Command

`display link-aggregation verbose`

display link-aggregation summary

Purpose

Use the `display link-aggregation summary` command to view summary information of all aggregation groups, including actor system ID, aggregation group ID, aggregate group type, partner system ID, number of selected ports, number of standby ports, load sharing type and master port number.

Syntax

```
display link-aggregation summary
```

Parameters

None

Example

To display summary information of all aggregation information, enter the following:

```
<SW5500>display link-aggregation summary
Aggregation Group Type: D -- Dynamic, S -- Static, M -- Manual
Loadsharing Type: Shar - Loadsharing, NonS - Non-Loadsharing
Actor ID: 0x8000, 00e0-fcff-ff04
```

```
AL   AL   Partner ID  SelectStandbyShareMaster
ID   Type           PortsPortsTypePort
-----
1    D    0x8000,00e0-fcff-ff01 10NonSEthernet4/0/1
10   M    none                    10NonSEthernet4/0/2
20   S    0x8000,00e0-fcff-ff01 10NonSEthernet4/0/3
```

View

This command can be used in the following views:

- Any view

display link-aggregation verbose

Purpose

Use the `display link-aggregation verbose` command to view detailed information of a link aggregation, including aggregation ID, the type of aggregation, load-sharing type, detailed local information (member ports, port status, port priority, LACP state flag and operation key), and detailed remote information (indexes of remote ports, port priority, LACP state flag, operation key and system ID.)

Syntax

```
display link-aggregation verbose [ agg_id ]
```

Parameters

agg_id Aggregation group ID, which must be a valid existing ID. Valid values are 1 to 416.

Example

To display detailed information of aggregation group 1, enter the following:

```
<SW5500>display link-aggregation verbose 1
Loadsharing Type: Shar -- Loadsharing, NonS -- Non-Loadsharing

Aggregation ID: 1, AggregationType: Manual, Loadsharing Type: NonS
Aggregation Description:
System ID: 0x8000, 000f-cbb7-2e00
Port Status: S -- Selected, U -- Unselected
Local:
  Port                Status  Priority Flag Oper-Key
-----
  Ethernet1/0/2       U       32768  0x00  1
  Ethernet1/0/3       U       32768  0x00  1
  Ethernet1/0/4       S       32768  0x00  1

Remote:
  Actor      Partner Priority Flag Oper-Key SystemID
-----
  Ethernet1/0/2 0 0 0x00 0 0x0,0000-0000-0000
  Ethernet1/0/3 0      0 0x000 0x0,0000-0000-0000
  Ethernet1/0/4 0      0 0x00 0 0x0,0000-0000-0000
<SW5500>
```

View

This command can be used in the following views:

- Any view

Description



Note: Unlike a dynamic aggregation, a manual aggregation has no protocol to get the remote peer information of the partner. Therefore, every item for the remote peer is 0. This does not indicate the actual state of the remote peer.

display local-server statistics

Purpose Use the `display local-server statistics` command to view the statistics of local RADIUS authentication server.

Syntax `display local-server statistics`

Parameters None

Example To display the statistics of local RADIUS authentication server, enter the following

```
<SW5500>display local-server statistics
The localserver packet statistics:
Receive:                0          Send:                0
Discard:                0          Receive Packet Error: 0
Auth Receive:          0          Auth Send:          0
Acct Receive:          0          Acct Send:          0
```

View This command can be used in the following views:

- Any view

Related Command `local-server`

display local-user

Purpose

Use the `display local-user` command to view the relevant information of all the local users or the specified one(s).

Syntax

```
display local-user [ domain isp-name | idle-cut { enable | disable } |
service-type { telnet | ftp | ssh | terminal | lan-access } | state {
active | block } | user-name user-name | vlan vlanid ]
```

Parameters

<code>domain <i>isp-name</i></code>	Configures to display all the local users in the specified ISP domain. <i>isp-name</i> specifies the ISP domain name with a character string not exceeding 24 characters. The specified ISP domain shall have been created.
<code>idle-cut</code>	Configures to display the local users according to the state of idle-cut function. <code>disable</code> means that the user disables the idle-cut function and <code>enable</code> means the user enables the function. This parameter only takes effect on the users configured as <i>lan-access</i> type. For other types of users, the <code>display local-user idle-cut enable</code> and <code>display local-user idle-cut disable</code> commands do not display any information.
<code>service-type</code>	Configures to display local user of a specified type. <code>telnet</code> means that the specified user type is telnet. <code>ftp</code> means that the specified user type is ftp. <code>ssh</code> means the specified user type is ssh. <code>terminal</code> means that the specified user type is terminal which refers to users who use the terminal service (login from the console port). <code>lan-access</code> means that the specified user type is lan-access which mainly refers to Ethernet accessing users, 802.1x supplicants for example.
<code>state { active block }</code>	Configures to display the local users in the specified state. <code>active</code> means that the system allows the user requesting network service and <code>block</code> means the system does not allow the user requesting network service.
<code>user-name <i>user-name</i></code>	Configures to display a user specified with <i>user-name</i> . <i>user-name</i> is the argument specifying the username. It is a character string not exceeding 80 characters, excluding <code>/</code> , <code>:</code> , <code>*</code> , <code>?</code> , <code><</code> and <code>></code> . The <code>@</code> character can only be used once in one username. The pure username (the part before <code>@</code> , namely the user ID) cannot exceed 55 characters.
<code>vlan <i>vlanid</i></code>	Configures to display the users belonged to specified VLAN. <i>vlanid</i> is the integer, ranging from 1 to 4094.

Example

To display the relevant information of all the local users, enter the following:

```
<SW5500>display local-user
The contents of local user xxx:
State:           Active           ServiceType Mask:
Idle Cut:        Disable
AccessLimit:     Disable           Current AccessNum: 0
Bind location:   Disable
Vlan ID:         Disable
Total 1 local user(s) Matched,1 listed.
```

View

This command can be used in the following views:

- Any view

Description

This command displays the relevant information about a specified or all the local users. The output can help you with the fault diagnosis and troubleshooting related to local user.

Related Command

`local-user`

display logbuffer

Purpose Use the **display logbuffer** command to display the status of the log buffer and the records in the log buffer.

Syntax `display logbuffer [unit unit-id] [level severity | size buffersize]* [| { begin | exclude | include } regular-expression]`

Parameters

unit-id Unit ID.

level Specifies an information severity level.

severity Information severity, ranging from 1 to 8.

Table 33 Severity definitions made on the information center

Severity	Value	Description
emergencies	1	Emergent errors
alerts	2	Errors that need to be corrected immediately
critical	3	Critical errors
errors	4	Errors that need to be considered but are not critical
warnings	5	Warnings that prompt possible errors
notifications	6	Information that needs to be noticed
informational	7	Normal prompting information
debugging	8	Debug information

size Specifies the size of the memory buffer you want to display.

buffersize Size of the memory buffer, represented by the number of messages it holds. It ranges from 1 to 1024 and defaults to 256.

| Filters output configuration information with a regular expression.

begin Displays configurations with the specified starting characters.

exclude Displays configurations excluding the specified characters.

include Displays configurations including the specified characters.

regular-expression Regular expression.

Example Display the status of the log buffer and the records in the log buffer.

```
<S5500> display logbuffer
Logging buffer configuration and contents:enabled
Allowed max buffer size : 1024
```



```
Actual buffer size : 512  
Channel number : 4 , Channel name : logbuffer  
Dropped messages : 0  
Overwritten messages : 0  
Current messages : 91
```

View

This command can be used in the following views:

- Any view

display loopback-detection

Purpose Use the **display loopback-detection** command to display whether loopback detection function is enabled or not.

Syntax `display loopback-detection`

Parameters None

Example Display whether loopback detection function is enabled or not.

```
<S5500> display loopback-detection
Port Ethernet1/0/1 loopback-detection is running
System Loopback-detection is running
Detection interval time is 30 seconds
There is no port existing loopback link
```

Table 34 Explain fields involved in loopback detection function

Fields	Explanation
Port GigabitEthernet1/0/1 loopback-detection is running.	Loopback detection function for GigabitEthernet1/0/1 is enabled.
System Loopback-detection is running.	System loopback detection function is enabled.
Detection interval time is 30 seconds.	Detection time interval is set to be 30 seconds.
There is no port existing loopback link.	Currently no port is detected with loopback.

View This command can be used in the following views:

- Any view

Description If loopback is enabled, then the time interval for the loopback detection function as well as information on the port will be displayed.

display mac-address

Purpose Use the `display mac-address` command to display MAC address table information.

Syntax `display mac-address [mac-addr [vlan vlan-id] | [static | dynamic | blackhole] [interface { interface-name | interface-type interface-num }] [vlan vlan-id] [count]]`

Parameters		
<code>mac-addr</code>		Specifies the MAC address.
<code>vlan-id</code>		Specifies the VLAN ID.
<code>static</code>		Static table entry, lost after resetting switch.
<code>dynamic</code>		Dynamic table entry, which will be aged.
<code>blackhole</code>		Blackhole table entry, the packet with this destination MAC address will be discarded.
<code>interface-type</code>		Specifies the interface type.
<code>interface-num</code>		Specifies the interface number.
<code>interface-name</code>		Specifies the interface name.

For details about the `interface-type`, `interface-num` and `interface-name` parameters, refer to the Port Configuration in this manual.

<code>count</code>		the display information will only contain the number of MAC addresses in the MAC address table if the user enters this parameter when using this command.
--------------------	--	---

Example Show the information of the entry with MAC address at 00e0-fc01-0101

```
<SW5500>sys
System View: return to User View with Ctrl+Z.
[SW5500]display mac-address 00e0-fc01-0101
MAC ADDR          VLAN ID STATEPORT INDEX  AGING TIME(s)
00e0-fc01-0101   1 LearnedEthernet1/0/1300
```

View This command can be used in the following views:

- Any view

Description When managing the Layer-2 addresses of the switch, the administrator can perform this command to view such information as the Layer-2 address table, address status (static or dynamic), Ethernet port of the MAC address, VLAN of the address, and system address aging time.

Related Commands

- `mac-address`
- `mac-address timer`

display mac-address aging-time

Purpose Use the `display mac-address aging-time` command to display the aging time of the dynamic entry in the MAC address table.

Syntax `display mac-address aging-time`

Parameters None

Example Display the aging time of the dynamic entry in the MAC address table.

```
<SW5500>sys
System View: return to User View with Ctrl+Z.
[SW5500]display mac-address aging-time
mac-address aging-time: 300s
```

The above information indicates that the aging time of the dynamic entry in the MAC address is 300s.

```
<SW5500>sys
System View: return to User View with Ctrl+Z.
[sw5500] display mac-address aging-time
mac-address aging-time: no-aging
```

The above information indicates that the dynamic entry in the MAC address table is no-aging.

View This command can be used in the following views:

- Any view

Related Commands

- `display mac-address`
- `mac-address`
- `mac-address timer`

display mac-address multicast static

Purpose

Use the **display mac-address multicast static** command to display the multicast MAC address entries manually configured on the switch, with each entry containing the following information: multicast MAC address, VLAN ID, MAC address state, port number(s), and aging time of each port.

Syntax

```
display mac-address multicast static [ count | mac-address vlan vlan-id
| vlan vlan-id ]
```

Parameters

mac-address* vlan *vlan-id Multicast MAC address entry in a specified VLAN.

count Displays the number of the MAC address entries.

vlan-id VLAN ID.

Example

Display all the multicast MAC address entries manually configured in VLAN 1.

```
<S5500>display mac-address multicast static vlan 1
MAC ADDR VLAN ID STATE PORT INDEX AGING TIME(s)
0100-0001-0001 Config static Ethernet1/0/1 N/A
                                                Ethernet1/0/2
                                                Ethernet1/0/3
                                                Ethernet1/0/4
--- 1 static mac address(es) found ---
```

View

This command can be used in the following views:

- Any view

Description

- Executing this command with neither ***mac-address* vlan *vlan-id*** nor ***vlan* *vlan-id*** will display all the multicast MAC address entries added on the switch.
- Executing this command with ***vlan* *vlan-id*** will display all the multicast MAC address entries added to the specified VLAN.
- Executing this command with ***mac-address* vlan *vlan-id*** will display the multicast MAC address entry added to the specified VLAN with the specified multicast MAC address.
- Executing this command with the **count** keyword will display the number of the configured multicast MAC address entries on the switch.

display mac-authentication

Purpose

Use the **display mac-authentication** command to display the global information about centralized MAC address authentication, including the state of centralized MAC address authentication (enabled or disabled), values of centralized MAC address authentication timers, the number of online users, MAC addresses during quiet period, and MAC authentication information about each port.

Syntax

```
display mac-authentication [ interface interface-list ]
```

Parameters

interface-list Lists of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of *interface-list* = { *interface-type interface-number* [to *interface-type interface-number*] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.

Example

Display the global information about centralized MAC address authentication.

```
<S5500> display mac-authentication
mac address authentication is Enabled.
authentication mode is UsernameAsMacAddress
Fixed username:mac
Fixed password:not configured
offline detect period is 300s
quiet period is 1 minute(s).
server response timeout value is 100s
max allowed user number is 1024
current user number amounts to 0
current domain: not configured, use default domain
Silent Mac User info:
MAC ADDR          From Port          Port Index
GigabitEthernet1/0/1 is link-up
MAC address authentication is Enabled
Authenticate success: 0, failed: 0
Current online user number is 0
MAC ADDR          Authenticate state  AuthIndex
...omitted
```

Table 35 Description on the fields of the display mac-authentication command

Field	Description
mac address authentication is Enabled	Centralized MAC address authentication is enabled.
authentication mode	Centralized MAC address authentication mode. The default is MAC address mode.
the Fixed username	User name of fixed mode. The default is mac.
the Fixed password	Password of fixed mode. It is not configured by default.

Table 35 Description on the fields of the display mac-authentication command (continued)

Field	Description
offline detect period	The offline-detect timer value. The timer sets the interval for a switch to check whether a user goes offline and is set to 300 seconds by default.
quiet period	Quiet timer value. The timer sets the quiet period and is set to 1 minute by default.
server response timeout value	Server-timeout timer value. The timer sets the timeout time for the connection between the switch and the RADIUS server and is set to 100 seconds by default.
max allowed user number	The maximum number of users supported by the switch, which defaults to 1,024.
current user number amounts to	The number of current users
current domain	The current domain, which is not configured by default.
Silent Mac User info	The information about the quiet user information. When a user fails to pass MAC address authentication because of incorrect user name or password input, the switch sets the user to be in quiet state. During quiet period, the switch does not authenticate this user.
GigabitEthernet1/0/1 is link-up	The link GigabitEthernet1/0/1 port connected to is up.
MAC address authentication is Enabled	MAC address authentication is enabled on GigabitEthernet1/0/1 port.
Authenticate success: 0, failed: 0	MAC address authentication statistics of the ports, including the times of successful and failed authentication.
Current online user number	The number of current online users
Authenticate state	User state, which can be: CONNECTING: Connecting SUCCESS: Authenticated FAILURE: Fail to pass authentication LOGOFF: Offline.

View

This command can be used in the following views:

- Any view

display memory

Purpose Use the **display memory** command to view the memory setting.

Syntax `display memory [unit unit-id]`

Parameters `unit-id` Specifies the unit ID.

Example To display the current memory setting, enter the following:

```
<SW5500> display memory
Unit 1
System Available Memory(bytes): 31608192
System Used Memory(bytes): 14970948
Used Rate: 47%
```

The displayed information is defined in Table 36.

Table 36 Output Description of the display memory command

Item	Description
Unit 1	Display the memory information of unit 1.
System Total Memory(bytes)	The total number of the Switch memory in bytes.
Total Used Memory(bytes)	The total number of the used Switch memory in bytes.
Used Rate	The used rate of the Switch memory.

View This command can be used in the following views:

- Any view

display memory

Purpose Use the **display memory** command to display the current system memory status.

Syntax `display memory [unit unit-id]`

Parameters `unit unit-id` Specifies the Unit ID of the switch

Example To display the current memory status, enter the following:

```
<SW5500>display memory
```

The information displays in the following format:

```
Unit 1
System Available Memory (bytes) : 31608192
System Used Memory (bytes) : 14723652
Used Rate: 46%
```

Table 37 Display information

Field	Description
System Available Memory (bytes)	The Total Memory of switch, unit in byte
System Used Memory (bytes)	The Total used Memory of switch, unit in byte
Used Rate	The memory used rate

View This command can be used in the following views:

- Any view

display memory limit

Purpose

Use the `display memory limit` command to display the memory setting and state information related to the Ethernet switch capacity, including available memory and state information about connections, such as times for disconnecting connections, times for reestablishing connections, and the current state of the system.

Syntax

```
display memory limit
```

Parameters

None

Example

Display the current memory setting and state information.

```
<SW5500>display memory limit
Current memory limit configuration information:
  system memory safety: 6 (MBytes)
  system memory limit: 5 (MBytes)
  auto-establish enabled
```

```
Free Memory: 16631660 (Bytes)
```

The state information about connection:

```
The times of disconnect: 0
The times of reconnect: 0
The current state: Normal
```

The displayed information is defined in Table 38.

Table 38 Output Description of the display memory limit command

Item	Description
system memory safety	The safety value of the Switch memory
system memory limit	The lower limit of the Switch memory
auto-establish enabled	The system allows recovering the connection automatically. (If the automatic recover is disabled, <code>auto-establish disable</code> will be displayed.)
Free Memory: 17781708 (Byte)	The size of the current idle memory is 17781708 bytes, that is, 17,782Mbytes.
The times of disconnect: 0	The times of the connection disconnecting of the Switch is 0.
The times of reconnect: 0	The times of the connection reestablishment of the Switch is 0.
The current state: Normal	The current state is normal. If entering the emergent state, the display will read <code>Emergence</code> .

View

This command can be used in the following views:

- Any view

display mirror

Purpose	Use the display mirror command to view port mirroring configuration, including monitored ports, monitor port and monitor direction, and so on.
Syntax	display mirror
Parameters	None
Example	To display the port mirroring configuration, enter the following: <pre><SW5500>system-view System View: return to User View with Ctrl+Z [SW5500] display mirror</pre>
View	This command can be used in the following views: <ul style="list-style-type: none">■ Any view
Related Commands	<ul style="list-style-type: none">■ mirroring-port■ monitor-port

display mirroring-group

Purpose Use the **display mirroring-group** command to display the parameter settings of a port mirroring group.

Syntax `display mirroring-group { group-id | all | local | remote-destination | remote-source }`

Parameters	<i>group-id</i>	The group number of a port mirroring group. Valid values are 1 to 20.
	<i>local</i>	Signifies that the specified mirroring group is a local port mirroring group.
	<i>remote-destination</i>	Signifies that the specified mirroring group is the destination group for remote mirroring.
	<i>remote-source</i>	Signifies that the specified mirroring group is the source group for remote mirroring.
	<i>all</i>	All mirroring groups.

Example Display the parameter setting of the mirroring group.

```
<S5500> display mirroring-group all
mirroring-group 1:
  type: local
  status: active
  mirroring port:
    Ethernet1/0/1 inbound
  monitor port: Ethernet1/0/2
```

View This command can be used in the following views:

- Any view

Description Local mirroring group information includes:

- Group number
- Group type: *local*
- Group state
- Information of the monitored port
- Information of the monitoring port

Information displayed on the destination mirroring group of remote mirroring includes:

- Group number
- Group type: *remote-destination*

- Group state
- Information of the destination port
- Remote-probe vlan information

Information displayed on the source mirroring group of remote mirroring includes:

- Group number
- Group type: ***remote-source***
- Group state
- Information of the source port
- Information of the reflector port
- Remote-probe vlan information

display mpm

Purpose The **display mpm** command displays information about the multicast port management parameters.

Syntax `display mpm [forwarding table | group]`

Parameters

<code>forwarding table</code>	Multicast forwarding table information.
<code>group</code>	MPM group and MAC information.

View This command can be used in the following views:

- Any view

display msdp brief

Purpose Use the `display msdp brief` command to display the brief information of the MSDP peer state.

Syntax `display msdp brief`

Parameters None

Example Display the brief information of the MSDP peer state.

```
<S5500> display msdp brief
MSDP Peer Brief Information
  Peer's Address      State   Up/Down time   AS      SA Count   Reset Count
  20.20.20.20         Up      00:00:13      100     0          0
```

Table 39 Description on the fields of the display msdp brief command

Field	Description
Peer's Address	Address of the MSDP peer
State	State
Up/Down time	Up/down time
AS	AS number
SA Count	SA count
Reset Count	Times of peer connection resets

View This command can be used in the following views:

- Any view

display msdp peer-status

Purpose Use the `display msdp peer-status` command to display the detailed information of the MSDP peer state.

Syntax `display msdp peer-status [peer-address]`

Parameters *peer-address* IP address of an MSDP peer, in the dotted decimal format.

Example Display the detailed information of MSDP peer state.

```
<S5500> display msdp peer-status 10.110.11.11
MSDP Peer 20.20.20.20, AS 100
Description:
Information about connection status:
  State: Up
  Up/down time: 14:41:08
  Resets: 0
  Connection interface: LoopBack0 (20.20.20.30)
  Number of sent/received messages: 867/947
  Number of discarded output messages: 0
  Elapsed time since last connection or counters clear: 14:42:40
Information about (Source, Group)-based SA filtering policy:
  Import policy: none
  Export policy: none
Information about SA-Requests:
  Policy to accept SA-Request messages: none
  Sending SA-Requests status: disable
Minimum TTL to forward SA with encapsulated data: 0
SAs learned from this peer: 0, SA-cache maximum for the peer: none
Input queue size: 0, Output queue size: 0
Counters for MSDP message:
  Count of RPF check failure: 0
  Incoming/outgoing SA messages: 0/0
  Incoming/outgoing SA requests: 0/0
  Incoming/outgoing SA responses: 0/0
  Incoming/outgoing data packets: 0/0
```

View This command can be used in the following views:

- Any view

Related Command `peer`

display msdp sa-cache

Purpose Use the `display msdp sa-cache` command to display (S, G) state learned from an MSDP peer.

Syntax `display msdp sa-cache [group-address | [source-address]] [autonomous-system-number]`

Parameters

<i>group-address</i>	Group address of the (S, G) entry.
<i>source-address</i>	Source address of the (S, G) entry. If you do not specify a source address, the system displays all source information of the specified group. If you specify neither a group address nor a source address, the system displays all SA caches.
<i>autonomous-system-number</i>	Number of the AS where the (S,G) entry comes from. Valid values are 1 to 65535.

Example Display SA messages learned from the MSDP peer.

```
<S5500> display msdp sa-cache
MSDP Total Source-Active Cache - 5 entries

(Source, Group)                Origin RP      Pro   AS   Uptime
Expires
(10.10.1.2, 225.1.1.1)         10.10.10.10   ?    ?   00:00:10
00:05:50
(10.10.1.3, 225.1.1.1)         10.10.10.10   ?    ?   00:00:11
00:05:49
(10.10.1.2, 225.1.1.2)         10.10.10.10   ?    ?   00:00:11
00:05:49
(10.10.2.1, 225.1.1.2)         10.10.10.10   ?    ?   00:00:11
00:05:49
(10.10.1.2, 225.1.2.2)         10.10.10.10   ?    ?   00:00:11
00:05:49

MSDP matched 5 entries
```

Table 40 Description on the fields of the `display msdp sa-cache` command

Field	Description
(Source, Group)	(S, G) entry
Origin RP	Source RP address
Pro	Inter-domain unicast routing protocol
AS	AS number
Uptime	Up time
Expires	Expiry of a (S, G) entry

View

This command can be used in the following views:

- Any view

Description

You must configure the **cache-sa-enable** command before the system can display the cache state information.

display msdp sa-count

Purpose Use the `display msdp sa-count` command to display the number of sources and groups in MSDP cache.

Syntax `display msdp sa-count [autonomous-system-number]`

Parameters *autonomous-system-number* Specifies the AS where a source and group come from. Valid values are 1 to 65535.

Example View the number of sources and groups in MSDP cache.

```
<S5500> display msdp sa-count
Number of cached Source-Active entries, counted by Peer
Peer's Address      Number of SA
10.10.10.10         5

Number of source and group, counted by AS
AS      Number of source  Number of group
100    3                  3

Total Source-Active entries: 5
```

Table 41 Description on the fields of the display msdp sa-count command

Field	Description
Peer's Address	Address of an MSDP peer
Number of SA	Number of SA messages
AS	AS number
Number of source	Number of sources
Number of group	Number of groups

View This command can be used in the following views:

- Any view

Description The debugging output of this command is available only after the configuration of the `cache-sa-enable` command.

display multicast forwarding-table

Purpose Use the `display multicast forwarding-table` to view the information of IP multicast forwarding table.

Syntax

```
display multicast forwarding-table [ group-address [ mask { mask / mask-length } ] | source-address [ mask { mask / mask-length } ] | incoming-interface { interface-type interface-number | register } ] *
```

Parameters	<i>group-address</i>	Multicast group address, used to specify a multicast group, ranging from 224.0.0.0 to 239.255.255.255.
	<i>source-address</i>	Unicast IP address of the multicast source.
	<i>incoming-interface</i>	Incoming interface of the multicast forwarding table.
	<i>register</i>	Register interface of PIM-SM.

Example View the multicast forwarding table information.

```
<SW5500>display multicast forwarding-table
Multicast Forwarding Cache Table
Total 2 entries

00001. (4.4.4.4, 224.2.254.84), iif Vlan-interface1, 0 oifs
    Matched 240 pkts(11288 bytes), Wrong If 0 pkts
    Forwarded 232 pkts(11288 bytes)

00002. (4.4.4.4, 224.2.149.17), iif Vlan-interface1, 1 oifs
    List of outgoing interface:
        01: Vlan-interface2
    Matched 236 pkts(3267 bytes), Wrong If 0 pkts
    Forwarded 233 pkts(3267 bytes)

Matched 2 entries
```

Table 42 Information from the display multicast forwarding-table command

Field	Description
Multicast Forwarding Cache Table	Multicast forwarding cache table
Total 2 entries	Total number of entries
00002	Sequence number of entries
(4.4.4.4, 224.2.149.17)	(s,g) Source IP Address, multicast group
If Vlan-interface 1, 1oifs	Multicast forwarding cache table has an incoming interface Vlan-interface 1 and one outgoing interface
List of outgoing interface: 01: Vlan-interface2	List of outgoing interface has an outgoing interface Vlan-interface 2
Matched 236 pkts (3267 bytes), Wrong if 0 pkts	236 matched packets (3267 bytes); 0 matched packets means wrong; 233 forwarded packets (3267 bytes)
Forwarded 233 pkts (3267 bytes)	
Matched 2 entries	2 matched entries

View

This command can be used in the following views:

- Any view

Related Command

`display multicast routing-table`

display multicast routing-table

Purpose Use the `display multicast routing-table` to view the information of IP multicast routing table.

Syntax

```
display multicast routing-table [ group-address [ mask { mask / mask-length } ] | source-address [ mask { mask / mask-length } ] | incoming-interface { interface-type interface-number | register } ]*
```

Parameters

<i>group-address</i>	Multicast group address, used to specify a multicast group and display the corresponding routing table information of the group. The value ranges from 224.0.0.0 to 239.255.255.255.
<i>source-address</i>	Unicast IP address of the multicast source.
<i>incoming-interface</i>	Incoming interface of the multicast route entry.
<i>register</i>	Register interface of PIM-SM.

Example View the routing table information corresponding to multicast group 225.1.1.1 in the multicast routing table.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]display multicast routing-table 225.1.1.1
Multicast Routing Table
Total 3 entries

(4.4.4.4, 224.2.149.17)
  Uptime: 00:15:16, Timeout in 272 sec
  Upstream interface: Vlan-interface1(4.4.4.6)
  Downstream interface list:
    Vlan-interface2(2.2.2.4), Protocol 0x1: IGMP

(4.4.4.4, 224.2.254.84)
  Uptime: 00:15:16, Timeout in 272 sec
  Upstream interface: Vlan-interface1(4.4.4.6)
  Downstream interface list: NULL

(4.4.4.4, 239.255.2.2)
  Uptime: 00:02:57, Timeout in 123 sec
  Upstream interface: Vlan-interface1(4.4.4.6)
  Downstream interface list: NULL

Matched 3 entries
```

Table 43 Information from the display multicast routing-table command

Field	Description
Multicast Routing Table	Multicast routing table
Total 3 entries	Total number of entries
(4.4.4.4, 224.2.149.17)	(s,g)

Table 43 Information from the display multicast routing-table command (continued)

Field	Description
Uptime: 00:15:16, Timeout in 272 sec	Multicast routing entry has been active 15 min. and 16 sec.
Upstream interface: Vlan-interface1 (4.4.4.6)	Upstream interface vlan-interface 1 (IP address is 4.4.4.6).
Downstream interface: Vlan-interface2 (2.2.2.4), Protocol 0x1:IGMP	Downstream interface list: has an interface Vlan-interface 2 (IP address is 2.2.2.4). The downstream interface is configured with IGMP groups.
Matched 3 entries	3 matched entries

View

This command can be used in the following views:

- Any view

Description

This command displays the multicast routing table information, while the **display multicast forwarding-table** command displays the multicast forwarding table information.

display multicast-source-deny

Purpose Use the **display multicast-source-deny** command to display the configuration information about the multicast source deny feature.

Syntax `display multicast-source-deny [interface interface_type interface_number]`

Parameters

<i>interface_type</i>	Port type.
<i>interface_number</i>	Port number.

Example Display the state of the multicast source deny feature on the ethernet 1/0/1 port.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] display multicast-source-deny ethernet 1/0/1
```

Display the state of the multicast source deny feature on each 100 Mbps Ethernet port.

```
[S5500] display multicast-source-deny interface ethernet
```

View This command can be used in the following views:

- Any view

Description Executing this command with neither port type nor port number specified will display the multicast source deny configurations on all the ports of the switch.

Executing this command with only port type specified will display the multicast source deny configurations on all the specified type of ports.

Executing this command with both port type and port number specified will display the multicast source deny configuration on the specified port.

display ndp

Purpose Use the **display ndp** command to display global NDP configuration information, including NDP packet interval, NDP information hold time and neighbor information of all the ports.

Syntax `display ndp [interface port-list]`

Parameters *port-list* Specifies a list of ports connected with the specified port. A list may contain consecutive or separated ports, or the combination of consecutive and separated ports. The argument is expressed as { *interface-type interface-number* / *interface-name* } [to { *interface-type interface-number* / *interface-name* }] } &<1-10>. *interface-type* specifies the port type. *interface-number* specifies the port number, expressed as slot number/port number. Key word to helps specify a port range.

Example Display NDP configuration information.

```
<aaa_0.S5500>display ndp
Neighbor Discovery Protocol is enabled.
Neighbor Discovery Protocol Ver: 1, Hello Timer: 60(s), Aging Timer:
180(s)
Interface: Ethernet1/0/1
Status: Enabled, Pkts Snd: 15835, Pkts Rvd: 2879, Pkts Err: 0

Interface: Ethernet1/0/2
Status: Enabled, Pkts Snd: 0, Pkts Rvd: 0, Pkts Err: 0

Interface: Ethernet1/0/3
Status: Enabled, Pkts Snd: 0, Pkts Rvd: 0, Pkts Err: 0

Interface: Ethernet1/0/4
Status: Enabled, Pkts Snd: 10362, Pkts Rvd: 10360, Pkts Err: 0

Interface: Ethernet1/0/5
Status: Enabled, Pkts Snd: 0, Pkts Rvd: 0, Pkts Err: 0

Interface: Ethernet1/0/6
Status: Enabled, Pkts Snd: 0, Pkts Rvd: 0, Pkts Err: 0

Interface: Ethernet1/0/7
Status: Enabled, Pkts Snd: 0, Pkts Rvd: 0, Pkts Err: 0

Interface: Ethernet1/0/8
Status: Enabled, Pkts Snd: 0, Pkts Rvd: 0, Pkts Err: 0

Interface: Ethernet1/0/9
Status: Enabled, Pkts Snd: 0, Pkts Rvd: 0, Pkts Err: 0
```

```
Interface: Ethernet1/0/10
  Status: Enabled, Pkts Snd: 0, Pkts Rvd: 0, Pkts Err: 0

Interface: Ethernet1/0/11
  Status: Enabled, Pkts Snd: 0, Pkts Rvd: 0, Pkts Err: 0

Interface: Ethernet1/0/12
  Status: Enabled, Pkts Snd: 0, Pkts Rvd: 0, Pkts Err: 0

Interface: Ethernet1/0/13
  Status: Enabled, Pkts Snd: 0, Pkts Rvd: 0, Pkts Err: 0

Interface: Ethernet1/0/14
  Status: Enabled, Pkts Snd: 0, Pkts Rvd: 0, Pkts Err: 0
```

Display NDP configuration information.

```
<aaa_0.S5500> display ndp interface Ethernet 1/0/1
Interface: Ethernet1/0/1
  Status: Enabled, Pkts Snd: 15835, Pkts Rvd: 2879, Pkts Err: 0
  Neighbor 1: Aging Time: 147(s)
    MAC Address : 00e0-fc00-5500
    Port Name   : Ethernet1/0/1
    Software Ver: V100R002B01D001
    Device Name : S5500 S3928
    Port Duplex : AUTO
    Product Ver : 5500-001
```

Table 44 Description on the fields of the display ndp command

Field	Description
Neighbor Discovery Protocol is enabled	The system NDP is enabled on the switch.
Neighbor Discovery Protocol Ver: 1	The NDP version is 1.
Hello Timer:	The current device transmits NDP packet every 60 seconds.
Aging Timer:	A neighbor keeps the NDP information of the current device for 180 seconds.
Interface:	Port number that specifies a port.
Status:	NDP status on the port.
Pkts Snd:	Number of NDP packets transmitted from a port.
Pkts Rvd:	Number of NDP packets received by a port.
Pkts Err:	Number of error NDP packets received by a port.
Neighbor 1: Aging Time:	Neighbor NDP information aging time of the neighbor connected by the port.
MAC Address	MAC address of a neighbor device.
Port Name	Port name of a neighbor device.
Software Ver	Software version of a neighbor device.
Device Name	Device name of a neighbor device.
Port Duplex	Port duplex mode of a neighbor device.
Product Ver	Product version of a neighbor device.

View

This command can be used in the following views:

- Any view

display ntdp

Purpose Use the **display ntdp** command to display the global NTDP information. The displayed information includes collected hops, ntdp timer, hop-delay, port-delay and time taken for last collection.

Syntax `display ntdp`

Parameters None

Example Display the global NTDP information.

```
<S5500> display ntdp
NTDP is running.
Hops      : 4
Timer     : 0 min(disable)
Hop Delay : 100 ms
Port Delay: 10 ms
Last collection total time: 92ms
```

Table 45 Description of global NTDP configuration information

Field	Description
NTDP is running.	The global NTDP is enabled on the local device.
Hops	Hops for topology collection.
Timer	Interval of periodic topology collection.
Hop Delay	Delay that the device forwards topology collection request.
Port Delay	Delay that the port forwards topology collection request.
Last collection total time	Time taken by last collection.

View This command can be used in the following views:

- Any view

Description This command is used for displaying the global NTDP information.

display ntdp device-list

Purpose Use the **display ntdp device-list** command to display the device information collected through NTDP.

Syntax `display ntdp device-list [verbose]`

Parameters **verbose** Displays the detailed information about the device.

Example Display the device list collected through NTDP.

```
<S5500> display ntdp device-list
MAC          HOP  IP          PLATFORM
00e0-fc00-3901  0    100.100.1.1/24  S5500
```

Table 46 Description of device list information collected through NTDP

Field	Description
MAC	MAC address of the device
HOP	Hops to the collecting device
PLATFORM	Platform information about device
IP	IP address and mask length of the VLAN1 on the device

Display the detailed device information collected through NTDP.

```
<S5500> display ntdp device-list verbose
Hostname    : S5500
MAC         : 00e0-fc00-5500
Hop         : 0
Platform    : S5500
IP          : 100.100.1.1/24
Version     :
3Com Versatile Routing Platform Software
VRP (tm) Software, Version 3.10
Copyright (c) 1998-2006 3Com Corporation. All rights reserved.
S5500 5500-0002
Cluster     : Candidate switch

Peer MAC      Peer Port ID      Native Port ID      Speed
Duplex
00e0-fc00-3190 Ethernet1/0/22      Ethernet3/0/21      100 FULL
-----

Hostname     : 5500-3
MAC          : 00e0-fc00-3190
Hop          : 1
Platform     : S5500
IP           : 16.1.1.1/24
Version      :
Huawei Versatile Routing Platform Software
VRP (tm) Software, Version 3.10
Copyright (c) 1998-2006 3Com Corporation. All rights reserved.
```

```
S5500 5500-0002
```

```
Cluster   : Candidate switch
```

Peer MAC Duplex	Peer Port ID	Native Port ID	Speed
00e0-fc00-5500 FULL	Ethernet3/0/21	Ethernet1/0/22	100
5600-0000-3334 FULL	GigabitEthernet7/0/32	Ethernet1/0/4	100

Table 47 Description of detailed information of devices collected through NTDP

Field	Description
Peer MAC	MAC address of the peer device
Native Port ID	Name of local port connected to the peer device
Peer Port ID	Name of peer port connected to the local device
Speed	Speed of the local port connected to the peer device
Duplex	Duplex mode of the local port connected to the peer device

View

This command can be used in the following views:

- Any view

display ntp-service sessions

Purpose Use the `display ntp-service sessions` command to display the status of all the sessions maintained by NTP service provided by the local equipment.

Syntax `display ntp-service sessions [verbose]`

Parameters `verbose` Displays detailed information about the sessions.

Default By default, the status of all the sessions maintained by NTP service provided by the local equipment will be displayed.

Example `<SW5500>display ntp-service sessions`

The information displays in the following format:

```
source          refid st now poll reach delay offset disp
*****
*****
[12345]212.125.95.4131.188.3.2212 18 64 377 339.8 10.8 0.9
note: 1 source(master),2 source(peer),3 selected,4 candidate,5
configured
```

View This command can be used in the following views:

- Any view

Description When you configure this command without the `verbose` parameter, the Switch will only display brief information about all the sessions it maintains.
With the `verbose` parameter configured, the Switch will display detailed information about all the sessions it maintains.

display ntp-service status

Purpose Use the command `display ntp-service status` to display the NTP service status.

Syntax `display ntp-service status`

Parameters None

Example `<SW5500>display ntp-service status`

The information displays in the following format:

```
clock status: unsynchronized
clock stratum: 16
reference clock ID: none
nominal frequency: 100.0000 Hz
actual frequency: 100.0000 Hz
clock precision: 2^17
clock offset: 0.0000 ms
root delay: 0.00 ms
root dispersion: 0.00 ms
peer dispersion: 0.00 ms
reference time: 00:00:00.000 UTC Jan 1 1900(00000000.00000000)
```

View This command can be used in the following views:

- Any view.

Description The following table describes the outputs:

Table 48 NTP service status information

Output	Meaning
clock status: unsynchronized	Local clock status: do not synchronize to any remote NTP server.
clock stratum: 16	Indicates the NTP stratum of local clock
reference clock ID	Indicates the address of a remote server of the reference ID, in the case that the local system has been synchronized by a remote NTP server or the ID of some clock source.
nominal frequency	Nominal frequency of the local system hardware clock.
actual frequency	Actual frequency of the local system hardware clock.
clock precision	Precision of local system clock
clock offset	Offsets of the local clock to the NTP server clock.
root delay	Root delay from local equipment to the master reference clock.
root dispersion	Dispersion of the local clock relative to the NTP server clock.
peer dispersion	Dispersion of the remote NTP server.
reference time	Reference timestamp.

display ntp-service trace

Purpose Use the `display ntp-service trace` command to display the brief information about every NTP server on the way from the local equipment to the reference clock source.

Syntax `display ntp-service trace`

Parameters None

Example


```
<SW5500>display ntp-service trace
```

The information displays in the following format:

```
server 127.0.0.1, stratum 8, offset 0.000000, synch distance 0.00000  
refid 127.127.1.0
```

View This command can be used in the following views:

- Any view

Description  *This command will be ineffective when the switches form an XRN network.*

display ospf abr-asbr

Purpose Use the `display ospf abr-asbr` command to view information about the Area Border Router (ABR) and Autonomous System Border Router (ASBR) of OSPF.

Syntax `display ospf [process-id] abr-asbr`

Parameters *process-id* Specifies the process ID of OSPF. Valid values are 1 to 65535. The command is applied to all current OSPF processes if you do not specify a process ID.

Example To display information on the ABR and ASBR of OSPF, enter the following:

```
<SW5500>display ospf abr-asbr
OSPF Process 1 with Router ID 10.110.98.138
Routing Table to ABR and ASBR
 I = Intra i = Inter A = ASBR B = ABR S = SumASBR
Destination Area Cost Nexthop Interface
IA 2.2.2.2 0.0.0.0 10 10.153.17.89 Vlan-interface1
```

Table 49 Output Description of the ospf abr-asbr command

Field	Description
Destination	Router ID of the ABR or ASBR
Area	Area where the router is connected with ASBR
Cost	The routing overhead value of the route
Nexthop	Nexthop address to the destination
Interface	The local output interface

View This command can be used in the following views:

- Any view

display ospf asbr-summary

Purpose Use the `display ospf asbr-summary` command to view the summary information of an OSPF imported route, or all OSPF imported routes.

Syntax `display ospf [process-id] asbr-summary [ip_address mask]`

Parameters

<i>process-id</i>	Specifies the process ID of OSPF. Valid values are 1 to 65535. The command is applied to all current OSPF processes if you do not specify a process ID.
<i>ip_address</i>	Specifies an IP address.
<i>mask</i>	Specifies an IP subnet mask.

Example To display the summary information of all OSPF imported routes, enter the following:

```
<SW5500>display ospf asbr-summary
OSPF Process 1 with Router ID 1.1.1.1
Summary Addresses
Total summary address count:  2

Summary Address
net      : 168.10.0.0
mask    : 255.254.0.0
tag     : 1
status  : Advertise
The Count of Route is 0

Summary Address
net      : 1.1.0.0
mask    : 255.255.0.0
tag     : 100
status  : DoNotAdvertise
The Count of Route is 0
```

Table 50 Output Description of the display ospf abr-asbr summary command

Field	Description
net	Destination network segment
Mask	IP subnet mask
tag	Tag
status	Status information including two values: <ul style="list-style-type: none">DoNotAdvertise — The summary routing information to the network segment will not be advertised.Advertise — The summary routing information to the network segment will be advertised.

View This command can be used in the following views:

- Any view

Description

If you do not specify an IP address and subnet mask, the summary information of all OSPF imported routes is displayed.

Related Command

`asbr-summary`

display ospf brief

Purpose Use the `display ospf brief` command to view OSPF summary information.

Syntax `display ospf [process-id] brief`

Parameters

<i>process-id</i>	Enter the process ID of OSPF. Valid values are 1 to 65535. If no process ID is specified, the command is applied to all current OSPF processes.
-------------------	--

Example To display OSPF summary information, enter the following:

```
<SW5500>display ospf brief
OSPF Process 1 with Router ID 10.110.95.189
OSPF Protocol Information
```

The information displays in the following format:

```
RouterID: 10.110.95.189  Border Router: AS
spf-schedule-interval: 5
Routing preference: Inter/Intra: 10 External: 150
Default ASE parameters: Metric: 1 Tag: 0.0.0.1 Type: 2
SPF computation count: 16
Area Count: 1  Nssa Area Count: 0

Area 0.0.0.0:
Authtype: none  Flags: <>
SPF scheduled: <>
Interface: 201.1.1.4 (Vlan-interface1)
Cost: 1 State: DR  Type: Broadcast
Priority: 1
Designated Router: 201.1.1.4
Backup Designated Router: 201.1.1.3
Timers: Hello 10, Dead 40, Poll 0, Retransmit 5, Transmit Delay 1
```

Table 51 Output Description of the display ospf brief command

Field	Description
RouterID	Router ID of the router
Border Router	Border routers for connection to the area, including autonomous system border router (ASBR) and area border router (ABR).
spf-schedule-interval	Interval of SPF schedule.
Authtype	Authentication type of OSPF.
Routing preference	Routing preference of OSPF. The internal route of OSPF includes intra/inter area route, and its default routing preference is 10. While that of the external route of OSPF is 150 by default.
Default ASE parameters	Default ASE parameters of OSPF, including metric, type, and tag.
SPF computation count	SPF computation count since OSPF is enabled.
Area Count	Areas connected to this router.

Table 51 Output Description of the display ospf brief command (continued)

Field	Description
Nssa Area Count	Number of NSSA areas.
SPF scheduled	SPF scheduled (flag).
Interface	IP address of the interface.
Cost	Cost of the interface.
State	State information
Type	OSPF network type of interface
Priority	Priority of interface
Designated Router	IP address of designated router
Backup Designated Router	IP address of backup designated router
Timers	OSPF timers: <ul style="list-style-type: none">■ Hello — Interval of hello packets■ Dead — Interval of dead neighbors■ Poll — Interval of poll■ Retransmit — Interval of retransmitting LSAs■ Transmit delay — Delay time of transmitting LSAs

View

This command can be used in the following views:

- Any view

display ospf cumulative

Purpose Use the `display ospf cumulative` command to view the OSPF cumulative information.

Syntax `display ospf [process-id] cumulative`

Parameters `process-id` Enter process ID of OSPF, ranging from 1 to 65535. The command is applied to all current OSPF processes if you do not specify a process ID.

Example To display the OSPF cumulative information, enter the following:

```
<SW5500>display ospf cumulative
OSPF Process 1 with Router ID 1.1.1.1
```

The information displays in the following format:

```
Cumulations

IO Statistics
Type                InputOutput
Hello                225437
DB Description      7886
Link-State Req      1818
Link-State Update   4853
Link-State Ack      2521
ASE: 1 Checksum Sum: FCAF
LSAs originated by this router
  Router: 50  SumNet: 40SumASB: 2
LSAs Originated: 92  LSAs Received: 33
Area 0.0.00.0:
  Neighbors: 1  Interfaces: 1
  Spf: 54  Checksum Sum F020
  rtr: 2 net: 0 sumasb: 0 sumnet: 1
Area 0.0.0.1:
  Neighbors: 0  Interfaces: 1
  Spf: 19  Checksum Sum 14EAD
  rtr: 1 net: 0sumasb: 1sumnet: 1
Routing Table:
Intra Area: 2  Inter Area: 0ASE: 1
```

Table 52 Output Description of the `display ospf cumulative` command

Field		Description
IO Statistics	Type	Type of input/output OSPF packet.
	Input	Number of received packets.
	Output	Number of transmitted packets.
ASE		Number of all ASE LSAs.
checksum sum		Checksum of ASE LSAs.
LSAs	originated	Number of originated LSAs.
	received	Number of received LSAs generated by other routers.

Table 52 Output Description of the display ospf cumulative command (continued)

Field		Description
Router		Number of all Router LSAs.
SumNet		Number of all Sumnet LSAs.
SumASB		Number of all SUMASB LSAs
Area	Neighbors	Number of neighbors in this area.
	Interfaces	Number of interfaces in this arera.
	Spf	Number of SPF computation count in this area.
	rtr, net, sumasb, sumnet	Number of all LSAs in this area.
Routing Table	Intra Area	Number of intra-area routes.
	Inter Area	Number of inter-area routes.
	ASE	Number of external routes.

View

This command can be used in the following views:

- Any view

display ospf error

Purpose Use the `display ospf error` command to view OSPF error information.

Syntax `display ospf [process-id] error`

Parameters *process-id* Specifies the process ID of OSPF. Valid values are 1 to 65535. The command is applied to all current OSPF processes if you do not specify a process ID.

Example To display the OSPF error information, enter the following:

```
<SW5500>display ospf error
OSPF Process 1 with Router ID 1.1.1.1
```

The information displays in the following format:

```
OSPF packet error statistics:
0: IP:received my own packet      0:OSPF: wrong packet type
0: OSPF: wrong version           0:OSPF: wrong checksum
0: OSPF: wrong area id          0:OSPF: area mismatch
0: OSPF: wrong virtual link     0:OSPF: wrong authentication type
0: OSPF: wrong authentication key0:OSPF: too small packet
0: OSPF: packet size > ip length 0:OSPF: transmit error
0: OSPF: interface down         0:OSPF: unknown neighbor
0: HELLO:netmask mismatch       0:HELLO: hello timer mismatch
0: HELLO:dead timer mismatch   0:HELLO: extern option mismatch
0: HELLO:router id confusion    0:HELLO: virtual neighbor unknown
0: HELLO:NBMA neighbor unknown 0:DD: neighbor state low
0: DD:router id confusion       0:DD: extern option mismatch
0: DD:unknown LSA type         0:LS ACK: neighbor state low
0: LS ACK: wrong ack           0:LS ACK: duplicate ack
0: LS ACK: unknown LSA type    0:LS REQ: neighbor state low
0: LS REQ: empty request       0:LS REQ: wrong request
0: LS UPD: neighbor state low  0:LS UPD: newer self-generate LSA
0: LS UPD: LSA checksum wrong  0:LS UPD:received less recent LSA
0: LS UPD:unknown LSA type     0:OSPF routing: next hop not exist
0: DD: MTU option mismatch0:ROUTETYPE: wrong type value
```

Table 53 Description of information generated by the display ospf error command

Field	Description
IP: received my own packet	Received my own packet
OSPF: wrong packet type	OSPF packet type error
OSPF: wrong version	OSPF version error
OSPF: wrong checksum	OSPF checksum error
OSPF: wrong area id	OSPF area ID error
OSPF: area mismatch	OSPF area mismatch
OSPF: wrong virtual link	OSPF virtual link error
OSPF: wrong authentication type	OSPF authentication type error
OSPF: wrong authentication key	OSPF authentication key error

Table 53 Description of information generated by the display ospf error command

Field	Description
OSPF: too small packet	OSPF packet too small
OSPF: packet size > ip length	OSPF packet size exceeds IP packet length
OSPF: transmit error	OSPF transmission error
OSPF: interface down	OSPF interface is down, unavailable
OSPF: unknown neighbor	OSPF neighbors are unknown
HELLO: netmask mismatch	Network mask mismatch
HELLO: hello timer mismatch	Interval of HELLO packet is mismatched
HELLO: dead timer mismatch	Interval of dead neighbor packet is mismatched
HELLO: extern option mismatch	Extern option of Hello packet is mismatched
HELLO: router id confusion	Hello packet: Router ID confusion
HELLO: virtual neighbor unknown	Hello packet: unknown virtual neighbor
HELLO: NBMA neighbor unknown	Hello packet: unknown NBMA neighbor
DD: neighbor state low	Database description (DD) packet: asynchronous neighbor state
DD: unknown LSA type	DD packet: unknown LSA type
LS ACK: neighbor state low	Link state acknowledgment (LS ACK) packet: asynchronous neighbor state
LS ACK: wrong ack	Link state acknowledgment packet: ack error
LS ACK: duplicate ack	Link state acknowledgment packet: ack duplication
LS ACK: unknown LSA type	Link state acknowledgment packet: unknown LSA type
LS REQ: neighbor state low	Link state request (LS REQ) packet
LS REQ: empty request	Link state request packet: empty request
LS REQ: wrong request	Link state request packet: erroneous request
LS UPD: neighbor state low	Link state update packet: asynchronous neighbor state
LS UPD: newer self-generate LSA	Link state update packet: newer LSA generated by itself
LS UPD: LSA checksum wrong	Link state update packet: LSA checksum error
LS UPD: received less recent LSA	Link state update packet: received less recent LSA
LS UPD: unknown LSA type	Link state update packet: unknown LSA type
OSPF routing: next hop not exist	Next hop of OSPF routing does not exist
DD: MTU option mismatch	MTU option of DD packet is mismatched
ROUTETYPE: wrong type value	Route type: the value of the type is wrong

View

This command can be used in the following views:

- Any view

display ospf interface

Purpose Use the `display ospf interface` command to view OSPF interface information for a specified port, or for all ports.

Syntax `display ospf [process-id] interface [interface-type port-number]`

Parameters

<i>process-id</i>	Enter the process ID of OSPF, ranging from 1 to 65535. The command is applied to all current OSPF processes if you do not specify a process ID.
<i>interface-type</i>	Enter the interface type.
<i>port-number</i>	Enter the port number.

Example To display OSPF interface information, enter the following:

```
<SW5500>display ospf interface vlan-interface 1
OSPF Process 1 with Router ID 1.1.1.1
```

The information displays in the following format:

```
Interfaces
Interface: 10.110.10.2 (Vlan-interface1)
  Cost: 1 State: BackupDR    Type: Broadcast
  Priority: 1
  Designated Router: 10.110.10.1
  Backup Designated Router: 10.110.10.2
  Timers: Hello 10, Dead 40, Poll 0, Retransmit 5, Transmit Delay 1
```

Table 54 Output Description of the display ospf interface command

Field	Description
Cost	Cost of the interface
State	State of the interface state machine
Type	Network type of OSPF
Priority	Priority of DR for interface election
Designated Router	Designated router on the network in which the interface resides
Backup Designated Router	Backup designated router on the network in which the interface resides
Timers	OSPF timers: <ul style="list-style-type: none"> ■ Hello — Interval of hello packets ■ Dead — Interval of dead neighbors ■ Poll — Interval of poll ■ Retransmit — Interval of retransmitting LSA ■ Transmit delay — Delay time of transmitting LSA

View This command can be used in the following views:

- Any view

Description

The information displayed includes OSPF configuration and running state.

display ospf lsdb

Purpose

Use the `display ospf lsdb` command to view database information about the OSPF connecting state.

Syntax

```
display ospf [ process-id ] [ area-id ] lsdb [ brief | [ asbr | ase |  
network | nssa | router | summary ] [ ip-address ] [ originate-router  
ip-address | self-originate ] ]
```

Parameters

<code>process-id</code>	Specifies the process ID of OSPF, ranging from 1 to 65535. The command is applied to all current OSPF processes if you do not specify a process ID.
<code>area-id</code>	Specifies the ID of the OSPF area, as either an ID number or an IP address.
<code>brief</code>	Enter to view brief information.
<code>asbr</code>	Enter to view information about summary ASBR-LSA.
<code>ase</code>	Enter to view information about AS-external-LSA.
<code>network</code>	Enter to view information about the Network LSA.
<code>nssa</code>	Enter to view information about the NSSA-external-LSA.
<code>router</code>	Enter to view information about the Router-LSA.
<code>summary</code>	Enter to view information about Summary-Net-LSA.
<code>originate-router</code>	Enter to view information about the LSA generator.
<code>self-originate</code>	Enter to view information about self-originated LSA.

Example

To display database information about the OSPF connecting state, enter the following:

```
<SW5500>display ospf lsdb  
OSPF Process 1 with Router ID 1.1.1.1
```

The information displays in the following format:

```
Link State Database  
  
Area: 0.0.0.0  
Type LinkState ID AdvRouter AgeLenSequenceMetricWhere  
Rtr 2.2.2.2 2.2.2.2 46536 8000000c 0 SpfTree  
Rtr 1.1.1.1 1.1.1.1449 36 80000004 0 SpfTree  
Net 10.153.17.89 2.2.2.2 465 32 80000004 0 SpfTree  
SNet 10.153.18.0 1.1.1.1 35528 80000003 10 Inter List  
Area: 0.0.0.1  
Type LinkState ID AdvRouter AgeLenSequence MetricWhere  
Rtr 1.1.1.1 1.1.1.1 449 36 80000004 0 SpfTree  
Rtr 3.3.3.3 3.3.3.3 429 36 8000000a 0 Clist  
Net 10.153.18.89 3.3.3.3 429 32 80000003 0 SpfTree  
SNet 10.153.17.0 1.1.1.1355 28 80000003 10 Inter List
```

```
ASB 2.2.2.2 1.1.1.1 355 28 80000003 10 SumAsb List
AS External Database:
Type LinkState ID AdvRouter AgeLenSequence MetricWhere
ASE 10.153.18.0 1.1.1.1100636 80000002 1 Ase List
ASE 10.153.16.0 2.2.2.2798 36 80000002 1 Uninitialized
ASE 10.153.17.0 2.2.2.2623 36 80000003 1Uninitialized
ASE 10.153.17.0 1.1.1.1 118836 80000002 1 Ase List
```

Table 55 Output Description of the display ospf lsdb command

Field	Description
Type	Type of the LSA
LinkStateID	Link state ID of the LSA
AdvRouter	Router ID of the router originating the LSA
Age	Age of the LSA
Len	Length of the LSA
Sequence	Sequence number of the LSA
Metric	Cost from the router originating the LSA to LSA destination
Where	Location of the LSA

```
<SW5500> display ospf lsdb ase
OSPF Process 1 with Router ID 1.1.1.1
Link State Data Base
type:ASE
ls id:2.2.0.0
adv rtr:0.0.0.2
ls age:349
len:36
seq#:80000001
chksum:0xfcaf
Options:(DC)
Net mask:255.255.0.0
Tos 0 metric:1
E type:2
Forwarding Address:0.0.0.0
Tag:1
```

Table 56 Output Description of the display ospf lsdb ase command

Field	Description
type	Type of the LSA
ls id	Link state ID of the LSA
adv rtr	Router ID of the router originating the LSA
ls age	Age of the LSA
len	Length of the LSA
Seq#	Sequence number of the LSA
chksum	Checksum of the LSA
Options	Options of the LSA
Net mask	Network mask
E type	Type of external route
Forwarding Address	Forwarding address
Tag	Tag

View

This command can be used in the following views:

- Any view

display ospf nexthop

Purpose Use the `display ospf nexthop` command to view the information about the next-hop.

Syntax `display ospf [process-id] nexthop`

Parameters *process-id* Specifies the process ID of OSPF. Valid values are 1 to 65535. The command is applied to all current OSPF processes if you do not specify a process ID.

Example To display the OSPF next-hop information, enter the following:

```
<SW5500>display ospf nexthop
OSPF Process 1 with Router ID 1.1.1.1
```

The information displays in the following format:

```
Address          Type   RefcountIntf Addr Intf Name
-----
202.38.160.1     Direct 3202.38.160.1   Vlan-interface2
202.38.160.2     Neighbor 1202.38.160.1   Vlan-interface2
```

Table 57 Output Description of the display ospf nexthop Command

Field	Description
Address	Address of the next hop
Type	Type of the next hop
Refcount	Reference count of the next hop, that is, number of routes using the next hop
Intf Addr	IP address of the interface to the next hop
Intf Name	The interface to the next hop

View This command can be used in the following views:

- Any view

display ospf peer

Purpose

Use the `display ospf peer` command to view detailed OSPF peer information.

Use the `display ospf peer brief` command to view brief information of every peer in the OSPF Autonomous System, in particular the peer number of all states in every area.

Syntax

```
display ospf [ process-id ] peer [ brief ]
```

Parameters

process-id Specifies the process ID of OSPF. Valid values are 1 to 65535. The command is applied to all current OSPF processes if you do not specify a process ID.

Example

To view the information on an SPF peer, enter the following:

```
<SW5500>display ospf peer
OSPF Process 1 with Router ID 1.1.1.1
```

The information displays in the following format:

```
Neighbors
Area 0.0.0.0 interface 10.153.17.88(Vlan interface1)'s neighbor(s)
  RouterID: 2.2.2.2 Address: 10.153.17.89
  State: Full Mode: Nbr is Master Priority: 1
  DR: 10.153.17.89 BDR: 10.153.17.88
  Dead times expires in 31s
  Neighbor has been up for 01:14:14
```

Table 58 Output Description of the display ospf peer Command

Field	Description
RouterID	Router ID of neighbor router
Address	Address of the interface, through which neighbor router communicates with the router
State	State of adjacency relation
Mode	Master/Slave mode formed by negotiation in exchanging DD packet
Priority	Priority of DR/BDR for neighbor election
DR	IP address of the interface of elected DR
BDR	IP address of the interface of elected BDR
Dead timer expires in 31 seconds	If no hello packet received from the peer within this interval, the peer will be considered to be invalid.
Neighbor has been up for 01:14:14	Time of neighbor connection

To view brief information for every peer, enter the following:

```
<SW5500>display ospf peer brief
OSPF Process 1 with Router ID 1.1.1.1
Neighbor Statistics
Area ID Down Attempt Init 2-Way ExStart Exchange Loading Full Total
0.0.0.0 0 0 0 0 0 0 0 0 1 1
```



```
0.0.0.1 0 0 0 0 0 0 1 1
Total 0 0 0 0 0 0 0 2 2
```

Table 59 Output Description of the display ospf peer brief Command

Field	Description
Area ID	Area ID
Down	The initial state for OSPF to establish neighbor relation, which indicates that the OSPF router has not received the message from a certain neighbor router within a period of time.
Attempt	Enabled in the NBMA environment, such as Frame Relay, X.25 or ATM. It indicates that OSPF router has not received the message from a certain neighbor router within a period of time, but still attempts to send a Hello packet to the adjacent routers for their communications with a lower frequency.
Init	Indicates that the OSPF router has received a Hello packet from a neighbor router, but its IP address is not contained in the Hello packet. Therefore, a two-way communication between them has not been established.
2-Way	It indicates that a two-way communication between an OSPF router and a neighbor router has been established. DR and BDR can be selected in this state (or higher state)
ExStart	In this state, the router determines the sequence number of the initial database description (DD) packet used for data exchange, so that it can obtain the latest link state information.
Exchange	Indicates that the OSPF router sends DD packets to its neighbor routers to exchange link state information.
Loading	In this state, OSPF router requests routes from the neighbor based on the updated link state information from neighbor routers and its expired information, and waits for response from neighbor routers.
Full	Indicates that database synchronization between the routers has been completed, and their link state databases are consistent.

View

This command can be used in the following views:

- Any view

display ospf peer brief

Purpose Use the **display ospf peer brief** command to display the brief information about the OSPF neighbors in different areas, including Router ID, interface, state, and so on.

Syntax `display ospf [process-id] peer brief`

Parameters *process-id* OSPF process ID. Valid values are 1 to 65535.

Example Display the brief information about OSPF neighbors in each area.

```
<S5500> display ospf peer brief
                OSPF Process 1 with Router ID 1.1.1.1
                Neighbor Brief Information

Area 0.0.0.1:
Router ID      Address          Pri  DeadTime(s)  Interface          State
2.2.2.2       192.168.0.2     1    39           Vlan-interface 1
Full/BDR
```

Table 60 Description on the fields of the display ospf peer brief command

Field	Description
Router ID	Router ID of the neighbor router
Address	IP address of the interface adjacent to the neighbor router
Pri	Priority of the neighbor router
DeadTime(s)	Dead time (in seconds) of the neighbor router
Interface	Type and number of the local router interface connected to the neighbor router
State	State of the neighbor router: "State/DR" is displayed in this field if the neighbor router is a designated router. "State/BDR" is displayed in this field if the neighbor router is a backup designated router. For the available states, refer to Table 2-2.

View This command can be used in the following views:

- Any view

display ospf peer statistics

Purpose Use the `display ospf peer statistics` command to display the statistics about the OSPF neighbors in different areas, that is, the numbers of the neighbors in different states in each area.

Syntax `display ospf [process-id] peer statistics`

Parameters `process-id` OSPF process ID. Valid values are 1 to 65,535.

Example Display the statistics about the OSPF neighbors in different areas.

```
<S5500> display ospf peer statistics
                OSPF Process 1 with Router ID 1.1.1.1
                Neighbor Statistics

Area ID          Down  Attempt  Init  2-Way  ExStart  Exchange  Loading  Full
Total
0.0.0.1          0    0         0    0     0       0         0        1
1
Total            0    0         0    0     0       0         0        1
1
```

Table 61 Description on the fields of the display ospf peer statistics command

Field	Description
Area ID	Area ID
Down	This is the initial state when the OSPF establishes a neighbor relationship. This state indicates that the OSPF router does not receive information from the neighbor router in a specific period.
Attempt	This state is valid only in an NBMA environment, such as frame relay, X.25 or ATM. It indicates that the OSPF router has not received any information from a neighbor router for a period, but still needs to send Hello packets to the neighbor router in a relatively low frequency to make contact with the router.
Init	This state indicates the OSPF router has received a Hello packet from the neighbor router, but its IP address is not contained in the Hello packet, that is, the two-way communication connection between the two parties has not yet been established.
2-Way	This state indicates that a two-way communication connection has been established between the OSPF router and the neighbor router. The selection of DR and BDR is completed in this state or in a higher state.
ExStart	In this state, the router determines the initial sequence number of the database description (DD) packets for data exchange, to ensure that the link state information the router obtains is always the latest one.
Exchange	In this state, the OSPF router sends DD packets to the neighbor router to exchange link state information.
Loading	In this state, the OSPF router sends a link state request to the neighbor router according to the update link state information received from the neighbor router and the expired information saved in this router, and waits for a response from the neighbor router.
Full	This state indicates that the synchronization of databases between the two routers which have established neighbor relationship to each other is completed, and the link state databases in the two routers are now consistent with each other.

Table 61 Description on the fields of the display ospf peer statistics command (continued)

Field	Description
Total	Total numbers of the neighbors in different states

View

This command can be used in the following views:

- Any view

display ospf request-queue

Purpose Use the `display ospf request-queue` command to view information about the OSPF request-queue.

Syntax `display ospf [process-id] request-queue`

Parameters *process-id* Specifies the process ID of OSPF. Valid values are 1 to 65535. The command is applied to all current OSPF processes if you do not specify a process ID.

Example To display the information on the OSPF request-queue, enter the following:

```
<SW5500>display ospf request-queue
```

The information displays in the following format:

```
The Router's Neighbors is  
RouterID:1.1.1.1Address:1.1.1.1  
Interface:1.1.1.3Area:0.0.0.0  
LSID:1.1.1.3AdvRouter:1.1.1.3 Sequence:80000017 Age:35
```

Table 62 Output Description of the display ospf request-queue command

Field	Description
Router ID	Router ID of neighbor router
Address	Address of the interface, through which neighbor routers communicate with the router
Interface	Address of the interface on the network segment
Area	Area number of OSPF
LSID:1.1.1.3	Link State ID of the LSA
AdvRouter	Router ID of the router originating the LSA
Sequence	Sequence number of the LSA, used to discover old and repeated LSAs
Age	Age of the LSA

View This command can be used in the following views:

- Any view

display ospf retrans-queue

Purpose Use the `display ospf retrans-queue` command to view information on the OSPF retransmission queue.

Syntax `display ospf [process-id] retrans-queue`

Parameters *process-id* Specifies the process ID of OSPF. Valid values are 1 to 65535. The command is applied to all current OSPF processes if you do not specify a process ID.

Example To display information on the OSPF retransmission queue, enter the following:

```
<SW5500>display ospf retrans-queue
OSPF Process 200 with Router ID 103.160.1.1
```

The information displays in the following format:

```
The Router's Neighbors is
RouterID: 162.162.162.162 Address: 103.169.2.2
Interface: 103.169.2.5 Area: 0.0.0.1
Retrans list:
Type: ASE LSID:129.11.77.0 AdvRouter:103.160.1.1
Type: ASE LSID:129.11.108.0 AdvRouter:103.160.1.1
```

View This command can be used in the following views:

- Any view

display ospf routing

Purpose Use the `display ospf routing` command to view the information about the OSPF routing table.

Syntax `display ospf [process-id] routing`

Parameters *process-id* Specifies process ID of OSPF. Valid values are 1 to 65535. The command is applied to all current OSPF processes if you do not specify a process ID.

Example To view information on the OSPF routing table, enter the following:

```
<SW5500>display ospf routing  
OSPF Process 1 with Router ID 1.1.1.1
```

The information displays in the following format:

```
Routing tables  
Routing for Network  
DestinationCostTypeNextHopAdvRouterArea  
10.110.0.0/161Net10.110.10.11.1.1.10  
10.10.0.0/16 1Stub10.10.0.13.3.3.30  
Total Nets: 2  
Intra Area: 2 Inter Area: 0 ASE: 0 NSSA: 0
```

Table 63 Output Description of the display ospf routing command

Field	Description
Destination	Destination of network segment
Cost	Cost of route
Type	Type of route
NextHop	Next hop of route
AdvRouter	Router ID of the router advertising the route
Area	Area ID
Intra Area	Number of intra-area routes
Inter Area	Number of inter-area routes
ASE	Number of external routes
NSSA	Number of NSSA routes

View This command can be used in the following views:

- Any view

display ospf vlink

Purpose Use the `display ospf vlink` command to view the information about OSPF virtual links.

Syntax `display ospf [process-id] vlink`

Parameters *process-id* Specifies the process ID of OSPF. Valid values are 1 to 65535. The command is applied to all current OSPF processes if you do not specify a process ID.

Example To view OSPF virtual links information, enter the following:

```
<SW5500>display ospf vlink
OSPF Process 1 with Router ID 1.1.1.1
```

The information displays in the following format:

```
Virtual links
Virtual-link Neighbor-id -> 2.2.2.2, State: Full
      Cost: 0 State: Full Type: Virtual
Transit Area: 0.0.0.2
      Timers: Hello 10, Dead 40, Poll 0, Retransmit 5, Transmit Delay 1
```

Table 64 Output Description of the display ospf vlink command

Field	Description
Virtual-link Neighbor-id	Router ID of virtual-link neighbor router
State	State
Interface	IP address of the interface on the virtual link
Cost	Route cost of the interface
Type	Type: virtual link
Transit Area	ID of transit area that the virtual link passes, and it cannot be backbone area, Stub area, or NSSA area
Timers	OSPF timers: <ul style="list-style-type: none"> n Hello — Interval of hello packets n Dead — Interval of dead neighbors n Poll — Interval of poll n Retransmit — Interval of retransmitting LSA n Transmit delay — Delay time of transmitting LSA

View This command can be used in the following views:

- Any view

display packet-filter

Purpose Use the `display packet-filter` command to view the information of the packet filter function. The displayed content includes ACL number, sub-item name and activation status.

Syntax `display packet-filter { interface { interface-name | interface-type interface-num } | unitid unit-id }`

Parameters

<code>interface { <i>interface-name</i> <i>interface-type</i> <i>interface-num</i> }</code>	Interface of the Switch.
<code>unitid <i>unit-id</i></code>	Unit ID. If user inputs this parameter, all the packet-filtering information of the specified unit will be displayed.

Example To display the information of the activated ACL of all interfaces, enter the following:

```
<SW5500>display packet-filter unitid 1
```

View This command can be used in the following views:

- Any view

Related Command `port`

display password-control

Purpose Use the **display password-control** command to display the information about the global password control for all users.

Syntax `display password-control`

Parameters None

Example Display the information about the current password control for all users.

```
<S5500]> display password-control
Global password settings for all users:
Password Aging:      Enabled (90 days)
Password Length:    Enabled (10 Characters)
Password History:    Enabled (Max history-record num : 6)
Password alert-before-expire : 7 days
Password Authentication-timeout : 60 seconds
Password Attemp-failed action : Disable
Password History was last reset 38 days ago.
```

The following table describes the output fields of the **display password-control** command.

Table 65 Description on the fields of the display password-control command

Field	Description
Password Aging	Password aging time
Password Length	Minimum password length
Password history	History password recording
Password alert-before-expire	Alert time before password expiration
Password Authentication-timeout	Timeout time for password authentication
Password Attemp-failed action	Number of password attempts
History password was last reset 38 days ago	Time when the history password record was last cleared

View This command can be used in the following views:

- Any view

display password-control blacklist

Purpose

Use the **display password-control blacklist** command to display the information about one or all users who have been added to the blacklist because of password attempt failure.

Syntax

```
display password-control blacklist [ username username | ipaddress  
ip-address ]
```

Parameters

<i>username</i>	Name of the user who has been added to the blacklist.
<i>ip-address</i>	IP address of the user who has been added to the blacklist.

Example

Display the information about all the users who have been added to the blacklist because of password attempt failure.

```
<S5500> display password-control blacklist  
USERNAME          IP  
Jack              10.1.1.2  
The number of users in blacklist is :1
```

View

This command can be used in the following views:

- Any view

display password-control super

Purpose	Use the display password-control super command to display the information about the password control for super passwords, including the password aging time and the minimum password length.
Syntax	display password-control super
Parameters	None
Example	Display the information about the password control for super passwords. <pre>S5500<S5500> display password-control super Super's password settings: Password Aging: Enabled(90 days) Password min-Length: Enabled(10 Characters)</pre>
View	This command can be used in the following views: <ul style="list-style-type: none">■ Any view

display pim bsr-info

Purpose Use the `display pim bsr-info` to display the BSR information

Syntax `display pim bsr-info`

Parameters None

Example

```
<SW5500>display pim bsr-info
Current BSR Address: 20.20.20.30
Priority: 0
Mask Length: 30
Expires: 00:01:55
Local host is BSR
```

Table 66 Output description of the display pim bsr command

Field	Description
BSR	Boot strap router
Priority	Priority of BSR
Mask Length:30	Length of mask
Expires:00:01:55	Expire Time

View This command can be used in the following views:

- Any view

Related Commands

- `c-bsr`
- `c-rp`

display pim interface

Purpose Use the `display pim interface` to display the PIM configuration information about an interface.

Syntax `display pim interface [interface-type interface-number]`

Parameters

<i>interface-type</i>	Specifies the interface type.
<i>interface-number</i>	Specifies interface number.

Example

```
<SW5500>display pim interface
PIM information of VLAN-interface 2:
  IP address of the interface is 10.10.1.20
  PIM is enabled
  PIM version is 2
  PIM mode is Sparse
  PIM query interval is 30 seconds
PIM neighbor limit is 128
  PIM neighbor policy is none
  Total 1 PIM neighbor on interface
  PIM DR(designated router) is 10.10.1.20
```

Table 67 Output description of the display pim interface command

Field	Description
PIM version	Version of PIM
PIM mode	PIM mode enabled on the interface (DM or SM)
PIM query interval	Hello packet interval
PIM neighbor limit	Limit of the PIM neighbors on an interface. No neighbor can be added any more when the limit is reached.
PIM neighbor policy	Filtering policy of the PIM neighbors on the current interface.
PIM DR	Designated router.

View This command can be used in the following views:

- Any view

display pim neighbor

Purpose Use the `display pim neighbor` to view the PIM neighbor information.

Syntax `display pim neighbor [interface interface-type interface-number]`

Parameters

<i>interface-type</i>	
<i>interface-number</i>	Interface type and interface number, used to specify the interface.

Example

```
<SW5500>display pim neighbor
Neighbor AddressInterface NameUptime Expires
8.8.8.6          VLAN-interface101637 89
```

Table 68 Output description about PIM neighbors

Field	Description
Neighbor Address	Neighbor address
Interface	Interface where the neighbor has been discovered
Uptime	Time passed since the multicast group has been discovered
Expires	Specifies when the member will be removed from the group

View This command can be used in the following views:

- Any view

display pim routing-table

Purpose Use the `display pim routing-table` to view the contents of the PIM multicast routing table.

Syntax

```
display pim routing-table [ { { *g [ group-address [ mask { mask-length / mask } ] ] | **rp [ rp-address [ mask { mask-length / mask } ] ] } | { group-address [ mask { mask-length / mask } ] | source-address [ mask { mask-length / mask } ] } * } | incoming-interface { interface-type interface-num / interface-name | null } | { dense-mode | sparse-mode } ] *
```

Parameters

**rp	(*, *, RP) route entry.
g	(, G) route entry.
group-address	Address of the multicast group.
source-address	IP address of the multicast source.
incoming-interface	Router entry with the specified incoming interface.

Example View the contents of the PIM multicast routing table on the router.

```
<SW5500>display pim routing-table
PIMSM Routing Table
Total 0 (*,*,RP), 0 (*,G), 2 (S,G)

(192.168.1.2, 224.2.178.130),
Protocol 0x20: PIMSM, Flag 0x4: SPT
UpTime: 23:59, Timeout after 196 seconds
Upstream interface: VLAN-interface2, RPF neighbor: NULL
Downstream interface list: NULL

(192.168.1.2, 224.2.181.90),
Protocol 0x20: PIMSM, Flag 0x4: SPT
UpTime: 23:59, Timeout after 196 seconds
Upstream interface: VLAN-interface2, RPF neighbor: NULL
Downstream interface list: NULL

Total 2 entries listed
```

Table 69 Output description about PIM routing table

Field	Description
RP	Rendezvous Point
(S,G)	Source address, multicast group
PIM-SM	PIM Sparse Mode
SPT	Shortest Path Tree
RPF	Reverse Path Forwarding

View

This command can be used in the following views:

- Any view

Related Command

display multicast routing-table

display pim rp-info

- Purpose** Use the `display pim rp-info` to view the RP information of multicast group.
- Syntax** `display pim rp-info [group-address]`
- Parameters** *group-address* Specifies the group address to be showed. If no multicast group is specified, the RP information about all multicast groups will be displayed.
- Example**
- ```
<SW5500>display pim rp-info
PIM-SM RP-SET information:
BSR is: 192.168.1.1
Group/MaskLen: 224.0.0.0/4
RP 192.168.1.1, Version 2
priority: 0
uptime(from last update): 29:11, to expire in: 2:02
```
- View** This command can be used in the following views:
- Any view
- Description** In addition, this command can also show the BSR and static RP information.

# display poe interface

---

**Purpose** Use the `display poe interface` command to view the PoE status of a specific port or all ports on the Switch.

**Syntax** `display poe interface [ interface-name | interface-type interface-num ]`

**Parameters**

|                             |                     |
|-----------------------------|---------------------|
| <code>interface-name</code> | /                   |
| <code>interface-type</code> |                     |
| <code>interface-num</code>  | Port on the Switch. |

**Example** Display the PoE status of the Ethernet port Ethernet1/0/10.

```
[SW5500]display poe interface ethernet1/0/10
Port power enabled :enable
Port power ON/OFF :on
Port power status :Standard PD
Port power mode :signal
Port PD class :0
port power priority :low
Port max power :15400 mW
Port current power :460 mW
Port peak power :552 mW
Port average power :547 mW
Port current :10 mA
Port voltage :51 V
```

Display the PoE status of all ports.

```
[sw5500]display poe interface
PORT INDEX POWER ENABLE MODE PRIORITY STATUS
Ethernet1/0/1 off enable signal low Detection
Ethernet1/0/2 off enable signal low Detection
Ethernet1/0/3 off enable signal low Detection
Ethernet1/0/4 off enable signal low Detection
Ethernet1/0/5 off enable signal low Detection
Ethernet1/0/6 off enable signal low Detection
Ethernet1/0/7 off enable signal low Detection
Ethernet1/0/8 off enable signal low Detection
Ethernet1/0/9 off enable signal low Detection
Ethernet1/0/10 off enable signal low Detection
Ethernet1/0/11 off enable signal low Detection
Ethernet1/0/12 off enable signal low Detection
Ethernet1/0/13 off enable signal low Detection
Ethernet1/0/14 off enable signal low Detection
Ethernet1/0/15 off enable signal low Detection
Ethernet1/0/16 off enable signal low Detection
Ethernet1/0/17 off enable signal low Detection
Ethernet1/0/18 off enable signal low Detection
Ethernet1/0/19 off enable signal low Detection
Ethernet1/0/20 off enable signal low Detection
Ethernet1/0/21 off enable signal low Detection
Ethernet1/0/22 off enable signal low Detection
Ethernet1/0/23 off enable signal low Detection
```

|                |     |         |        |     |              |
|----------------|-----|---------|--------|-----|--------------|
| Ethernet1/0/24 | off | enable  | signal | low | Detection    |
| Ethernet1/0/25 | off | disable | signal | low | User set off |
| Ethernet1/0/26 | off | disable | signal | low | User set off |
| Ethernet1/0/27 | off | disable | signal | low | User set off |
| Ethernet1/0/28 | off | disable | signal | low | User set off |
| Ethernet1/0/29 | off | disable | signal | low | User set off |
| Ethernet1/0/30 | off | disable | signal | low | User set off |
| Ethernet1/0/31 | off | disable | signal | low | User set off |
| Ethernet1/0/32 | off | disable | signal | low | User set off |
| Ethernet1/0/33 | off | disable | signal | low | User set off |
| Ethernet1/0/34 | off | disable | signal | low | User set off |
| Ethernet1/0/35 | off | disable | signal | low | User set off |
| Ethernet1/0/36 | off | disable | signal | low | User set off |
| Ethernet1/0/37 | off | disable | signal | low | User set off |
| Ethernet1/0/38 | off | disable | signal | low | User set off |
| Ethernet1/0/39 | off | disable | signal | low | User set off |
| Ethernet1/0/40 | off | disable | signal | low | User set off |
| Ethernet1/0/41 | off | disable | signal | low | User set off |
| Ethernet1/0/42 | off | disable | signal | low | User set off |
| Ethernet1/0/43 | off | disable | signal | low | User set off |
| Ethernet1/0/44 | off | disable | signal | low | User set off |
| Ethernet1/0/45 | off | disable | signal | low | User set off |
| Ethernet1/0/46 | off | disable | signal | low | User set off |
| Ethernet1/0/47 | off | disable | signal | low | User set off |
| Ethernet1/0/48 | off | disable | signal | low | User set off |

## View

This command can be used in the following views:

- Any view

# display poe power

---

## Purpose

Use the `display poe interface power` command, you can view the power information of a specific port or all ports on the Switch.

## Syntax

```
display poe interface power [interface-name | interface-type
interface-num]
```

## Parameters

```
interface-name |
interface-type
interface-num Port on the Switch.
```

## Example

Display the power information of port Ethernet1/0/10.

```
[SW5500]display poe interface power ethernet1/0/10
Port power :12400 mW
```

Display the power information of all ports.

```
[SW5500]display poe power
PORT INDEXPOWER (mW) PORT INDEXPOWER (mW)
Ethernet1/0/10
Ethernet1/0/2100
Ethernet1/0/3200
Ethernet1/0/4300
Ethernet1/0/5400
Ethernet1/0/6500
Ethernet1/0/7600
Ethernet1/0/8700
Ethernet1/0/9800
Ethernet1/0/10900
Ethernet1/0/111000
Ethernet1/0/121100
Ethernet1/0/131200
Ethernet1/0/141300
Ethernet1/0/151400
Ethernet1/0/161500
Ethernet1/0/171600
Ethernet1/0/181700
Ethernet1/0/191800
Ethernet1/0/201900
Ethernet1/0/212000
Ethernet1/0/222100
Ethernet1/0/232200
Ethernet1/0/242300
Ethernet1/0/252400
Ethernet1/0/262500
Ethernet1/0/272600
Ethernet1/0/282700
Ethernet1/0/290
Ethernet1/0/300
Ethernet1/0/310
Ethernet1/0/320
Ethernet1/0/333200
```

```
Ethernet1/0/343300
Ethernet1/0/353400
Ethernet1/0/363500
Ethernet1/0/373600
Ethernet1/0/383700
Ethernet1/0/393800
Ethernet1/0/403900
Ethernet1/0/414000
Ethernet1/0/424100
Ethernet1/0/434200
Ethernet1/0/444300
Ethernet1/0/454400
Ethernet1/0/464500
Ethernet1/0/474600
Ethernet1/0/484700
```

## View

This command can be used in the following views:

- Any view

# display poe power supply

---

**Purpose** Use the `display poe powersupply` command to view the parameters of the power sourcing equipment (PSE).

**Syntax** `display poe powersupply`

**Parameters** None

**Example** Display the PSE parameters.

```
[SW5500]display poe powersupply
PSE ID :1
PSE Legacy Detection :disable
PSE Total Power Consumption :12000 mW
PSE Available Power :268000 mW
PSE Peak Value :12000 mW
PSE Average Value :12000 mW
PSE Software Version :290
PSE Hardware Version :000
PSE CPLD Version :021
PSE Power-Management mode :auto
```

**View** This command can be used in the following views:

- Any view

# display poe-profile

---

**Purpose** Use the **display poe-profile** command to display detailed configuration information of the created PoE Profile for a switch.

**Syntax** `display poe-profile { all-profile | interface interface-type  
interface-number | name profilename }`

|                   |                         |                                                                                                                                                                                                      |
|-------------------|-------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | <i>interface-type</i>   | Indicates type of the interface,                                                                                                                                                                     |
|                   | <i>interface-number</i> | Specifies the port ID.                                                                                                                                                                               |
|                   | <i>profilename</i>      | Name of the PoE Profile to be displayed, consisting of a string 1 to 15 characters long. The <b>profilename</b> cannot be reserved keywords like all, interface, user, undo, user-based, port-based. |

**Example** Display detailed configuration information for the PoE Profile by the name of profile-test.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] display poe-profile name profile-test
```

**View** This command can be used in the following views:

- Any view



# display port

---

**Purpose** Use the `display port hybrid` command to view the ports whose link type is hybrid. Use the `display port trunk` command to view the ports whose link type is trunk.

**Syntax** `display port { hybrid | trunk }`

|                   |                     |                             |
|-------------------|---------------------|-----------------------------|
| <b>Parameters</b> | <code>hybrid</code> | Displays the hybrid ports.  |
|                   | <code>trunk</code>  | Displays the trunked ports. |

**Example** To display the currently configured hybrid ports, enter the following:

```
<SW5500>display port hybrid
```

The details display in the following format:

```
The following hybrid ports exist:
 Ethernet1/0/1 Ethernet1/0/2
```

This example indicates that the current configuration has two hybrid ports, Ethernet1/0/1 and Ethernet1/0/2.

**View** This command can be used in the following views:

- Any view

# display port-security

---

**Purpose** Use the **display port-security** command to display the information about port security configuration (including global configuration and all or specific port configuration).

**Syntax** `display port-security [ interface interface-list ]`

**Parameters** `interface interface-list` Specifies an Ethernet port list, which can contain multiple Ethernet ports. The *interface-list* argument is in the format of { *interface-type interface-number* [ to *interface-type interface-number* ] } & < 1-10 >, where *interface-type* represents a port type, *interface-number* represents a port number, and & < 1-10 > means you can specify up to 10 ports or port ranges.

**Example** Display the security configuration on Ethernet1/0/1 port.

```
<S5500> display port-security interface Ethernet1/0/1
Equipment port security is enabled
addressLearn trap is Enabled
Violation trap is Enabled
dot1x logon trap is Enabled
dot1x logoff trap is Enabled
dot1x logfailure trap is Enabled
vlan id assigned is NULL
OUI value:
 Index is 1, OUI value is 00efec

Ethernet1/0/1 is link-up
port mode is Userlogin
NeedtoKnow mode is disabled
Intrusion mode is disableportTemporarily
max mac-address num is 0
```

**Table 70** Description on the fields of the display port-security command

| Field                              | Description                                                                         |
|------------------------------------|-------------------------------------------------------------------------------------|
| Equipment port security is enabled | The port security feature is enabled on the switch.                                 |
| addressLearn trap is Enabled       | The sending of MAC address learning trap messages is enabled.                       |
| Violation trap is Enabled          | The sending of intrusion detection trap messages is enabled.                        |
| dot1x logon trap is Enabled        | The sending of 802.1x user logon (authentication success) trap messages is enabled. |
| dot1x logoff trap is Enabled       | The sending of 802.1x user logoff trap messages is enabled.                         |
| dot1x logfailure trap is Enabled   | The sending of 802.1x user authentication failure trap messages is enabled.         |
| vlan id assigned is NULL           | The delivered VLAN ID is Null.                                                      |

**Table 70** Description on the fields of the display port-security command (continued)

| Field                                    | Description                                                                                                                       |
|------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| Index is 1, OUI value is 00efec          | The OUI value is 00efec and the OUI index is 1.                                                                                   |
| Ethernet1/0/1 is link-up                 | The link state of port Ethernet 1/0/1 is up.                                                                                      |
| port mode is Userlogin                   | The security mode of the port is Userlogin.                                                                                       |
| NeedtoKnow mode is disabled              | The NTK feature is disabled.                                                                                                      |
| Intrusion mode is disableportTemporarily | The intrusion detection action mode is disableportTemporarily.                                                                    |
| max mac-address num is 0                 | The maximum number of MAC addresses allowed to access the port is zero, that is, there is no limit on the number of access users. |
| stored mac-address num is 0              | The number of current users is zero.                                                                                              |

## View

This command can be used in the following views:

- Any view

## Description

Use the **display port-security** command to display the information about port security configuration (including global configuration and all or specific port configuration).

By checking the output of this command, you can verify the current configuration.



### **CAUTION:**

- This command will display global and all ports' security configuration information if the **interface-list** argument is not specified.
- This command will display global and particular port's security configuration information if the **interface-list** argument is specified.

# display port vlan-vpn

---

**Purpose** Use the **display port vlan-vpn** command to display the information about VLAN VPN configuration of the current system, including current IPID value, VLAN-VPN ports, VLAN-VPN uplink ports and whether the inner tag priority replication function is enabled.

**Syntax** `display port vlan-vpn`

**Parameters** None

**Example** Display the VLAN-VPN configuration of the system.

```
<S5500> display port vlan-vpn
Ethernet1/0/1
 VLAN-VPN TPID: 8100

Ethernet1/0/2
 VLAN-VPN status: enabled
 VLAN-VPN VLAN: 1
 VLAN-VPN inner-cos-trust status: disable
 VLAN-VPN TPID: 8100

Ethernet1/0/3
 VLAN-VPN TPID: 8100

Ethernet1/0/4
 VLAN-VPN TPID: 8100
.....(Omitted)
```

**View** This command can be used in the following views:

- Any view

# display power

---

**Purpose** Use the `display power` command to display the working state of the built-in power supply.

**Syntax** `display power [ unit unit-id ] [ power-ID ]`

**Parameters**

|                                  |                                     |
|----------------------------------|-------------------------------------|
| <code>unit <i>unit-id</i></code> | Specifies the Unit ID of the switch |
| <code><i>power-ID</i></code>     | Power ID.                           |

**Example** Show power state.

```
<SW5500>display power 1
Unit1
power 1 State: Normal
```

**View** This command can be used in the following views:

- Any view

# display protocol-priority

---

|                   |                                                                                                             |
|-------------------|-------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | Use the <b>display protocol-priority</b> command to display the priority of protocol packets.               |
| <b>Syntax</b>     | <code>display protocol-priority</code>                                                                      |
| <b>Parameters</b> | None                                                                                                        |
| <b>Example</b>    | Display the priority of protocol packets.<br><pre>&lt;S5500&gt; display protocol-priority</pre>             |
| <b>View</b>       | This command can be used in the following views: <ul style="list-style-type: none"><li>■ Any view</li></ul> |

# display protocol-vlan interface

---

## Purpose

Use the **display protocol-vlan interface** command to display the protocol information and protocol indexes configured for specified ports.

## Syntax

```
display protocol-vlan interface { { interface-type interface-number [to interface-type interface-number] } | all }
```

## Parameters

```
{ interface-type interface-number [to interface-type interface-number] }
```

Ranges of Ports, the protocol-related information about which is to be displayed. The to keyword specifies a port number range. If you do not specify this keyword, this argument specifies a single port. The interface-type argument is port type, and interface-num is port number.

all

Displays the protocol-related information about all ports.

## Example

Display protocol information and protocol index configured for Ethernet1/0/1 and Ethernet1/0/2 ports.

```
<S5500> display protocol-vlan interface ethernet1/0/1 to ethernet1/0/2
Interface: Ethernet1/0/1
VLAN ID Protocol-Index Protocol-type
50 1 ip
80 2 ip
100 1 ip
100 2 ipx ethernetii
Interface: Ethernet1/0/2
VLAN ID Protocol-Index Protocol-type
50 2 ipx raw
80 1 at
100 3 mode snap etype 0x0abc
100 5 mode llc dsap 0xac ssap 0xbd
```

## View

This command can be used in the following views:

- Any view'

# display protocol-vlan vlan

---

**Purpose** Use the **display protocol-vlan vlan** command to display the protocol information and protocol indexes configured for specified VLANs.

**Syntax** `display protocol-vlan vlan { vlan-id [ to vlan-id ] | all }`

**Parameters**

|                      |                                                                                                                                                                          |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>vlan-id</code> | VLAN ID. Valid values are 1 to 4,094.                                                                                                                                    |
| <code>to</code>      | Specifies a VLAN ID range. Make sure the <code>vlan-id</code> argument to the right of this keyword is larger than or equal to the argument to the left of this keyword. |
| <code>all</code>     | Specifies all VLANs.                                                                                                                                                     |

**Example** Display the protocol information and protocol indexes configured for VLAN 10 through VLAN 20.

```
<S5500> display protocol-vlan vlan 10 to 20
VLAN ID: 10
VLAN Type: Protocol-based VLAN
 Protocol-Index Protocol-Type
 1 IP
 2 IP
 3 IPX ETH II
 4 AT
VLAN ID: 15
VLAN Type: Protocol-based VLAN
 Protocol-Index Protocol-Type
 1 ip
 2 mode snap etype 0x0abc
```

**View** This command can be used in the following views:

- Any view

**Related Command** `display vlan`



# display qos cos-local-precedence-map

---

**Purpose** Use the `display qos cos-local-precedence-map` command to view COS and Local-precedence map

**Syntax** `display qos cos-local-precedence-map`

**Parameters** None

**Example** Display COS and Local-precedence map.

```
<SW5500>display qos cos-local-precedence-map
cos-local-precedence-map:
 802.1p & local precedence : 0 1 2 3 4 5 6 7

 queue: 2 0 1 3 4 5 6 7
```

**View** This command can be used in the following views:

- Any view

# display qos-interface all

---

**Purpose** Use the **display qos-interface all** command to display all the QoS settings of the port.

**Syntax** `display qos-interface { interface-name | interface-type interface-num | unit-id } all`

**Parameters**

|                                                                                         |                                                                                                                                          |
|-----------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| <code><i>interface-name</i> /<br/><i>interface-type</i><br/><i>interface-num</i></code> | Specifies the port of the switch. Specify this parameter and the switch will display the parameter configurations of the specified port. |
| <code><i>unit-id</i></code>                                                             | Specifies the unit ID. Specify this parameter and the switch will display the parameter configurations of the specified unit.            |

**Example** Display all the configurations of QoS parameters for unit 1.

```
<SW5500> display qos-interface 1 all
Ethernet1/0/1: traffic-limit
 Inbound:
 Matches: Acl 2000 rule 0 running
 Target rate: 128 Kbps
 Exceed action: remark-dscp 63
Ethernet1/0/1: traffic-priority
 Inbound:
 Matches: Acl 2000 rule 0 running
 Priority action: cos best-effort
Ethernet1/0/1: traffic-redirect
 Inbound:
 Matches: Acl 2000 rule 0 running
 Redirected to: interface Ethernet1/0/2
Ethernet1/0/1: traffic-statistic
 Inbound:
 Matches: Acl 2000 rule 0 running
 0 packet inprofile
 0 packet outprofile
Ethernet1/0/1: mirrored-to
 Inbound:
 Matches: Acl 2000 rule 0 running
---- More ----
```

**View** This command can be used in the following views:

- Any view

**Description** If you do not input interface parameters, this command will display all QoS setting information for the Switch, including traffic policing, rate limit at interface, and so on.

If you input interface parameters, this command will display QoS setting information of the specified interfaces, including traffic policing, rate limit at interfaces, and so on.

**Related Command**

`port`

# display qos-interface line-rate

---

**Purpose** Use the `display qos-interface line-rate` command to view the traffic rate limitations of the interface output.

**Syntax** `display qos-interface { interface-name | interface-type interface-num | unit-id } line-rate`

**Parameters**

|                         |                          |
|-------------------------|--------------------------|
| <i>interface-name</i> / |                          |
| <i>interface-type</i>   |                          |
| <i>interface-num</i>    | Interface of the Switch. |
| <i>unit-id</i>          | Unit ID of the Switch.   |

**Example** Display the parameter configuration of interface traffic rate limitation.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500] display qos-interface line-rate
Ethernet1/0/1: line-rate
 Inbound: 128 kbps
```

**View** This command can be used in the following views:

- Any view

**Description** If you do not specify interface parameters, you will view the traffic rate limitations of all interfaces' output. If you enter interface parameters, you will view the parameter settings of traffic rate limitations of the specified interfaces' output.

**Related Command** `port`

# display qos-interface mirrored-to

---

**Purpose** Use the `display qos-interface mirrored-to` command to view the settings of the traffic mirror.

**Syntax** `display qos-interface { interface-name | interface-type interface-num | unit-id } mirrored-to`

**Parameters**

|                                                                          |                                                                                              |
|--------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| <i>interface-name</i> /<br><i>interface-type</i><br><i>interface-num</i> | Interface of the Switch, for detailed description, refer to the port command in this manual. |
| <i>unit-id</i>                                                           | Unit ID of the Switch.                                                                       |

**Example** To display the settings of traffic mirror, enter the following:

```
<SW5500> display qos-interface ethernet1/0/1 mirrored-to
Ethernet1/0/1: mirrored-to
Inbound:
 Matches: Acl 2000 rule 0 running
 Mirrored to: monitor interface
```

**View** This command can be used in the following views:

- Any view

**Description** This command is used for displaying the settings of traffic mirror. The information displayed includes the ACL of traffic to be mirrored and the observing port.

**Related Commands**

- `mirrored-to`
- `port`

# display qos-interface traffic-limit

---

**Purpose** Use the `display qos-interface traffic-limit` command to view the traffic limit settings.

**Syntax** `display qos-interface { interface-name | interface-type interface-num | unit-id } traffic-limit`

**Parameters**

|                                      |                                       |
|--------------------------------------|---------------------------------------|
| <code><i>interface-name</i> /</code> |                                       |
| <code><i>interface-type</i></code>   |                                       |
| <code><i>interface-num</i></code>    | Specifies an Interface of the Switch. |
| <code><i>unit-id</i></code>          | Unit ID of the Switch.                |

**Example** Display the traffic limit settings.

```
<SW5500> display qos-interface ethernet1/0/1 traffic-limit
Ethernet1/0/1: traffic-limit
 Inbound:
 Matches: Acl 2000 rule 0 running
 Target rate: 128 Kbps
 Exceed action: remark-dscp 63
```

**View** This command can be used in the following views:

- Any view

**Description** If you set the port parameters, the configuration information about the specified port will be displayed. The information displayed includes the ACL of the traffic to be limited, the limited average rate and the settings of some related policing action.

**Related Commands**

- `port`
- `traffic-limit`

# display qos-interface traffic-priority

---

**Purpose** Use the `display qos-interface traffic-priority` command to view the traffic priority settings.

**Syntax** `display qos-interface { interface-name | interface-type interface-num | unit-id } traffic-priority`

**Parameters**

|                                                                                                                 |                                       |
|-----------------------------------------------------------------------------------------------------------------|---------------------------------------|
| <code><i>interface-name</i></code> /<br><code><i>interface-type</i></code><br><code><i>interface-num</i></code> | Specifies an interface of the Switch. |
| <code><i>unit-id</i></code>                                                                                     | Unit ID of the Switch.                |

**Example** Display the traffic priority settings.

```
<SW5500>display qos-interface Ethernet1/0/1 traffic-priority
Ethernet1/0/1: traffic-priority
 Inbound:
 Matches: Acl 2000 rule 0 running
 Priority action: cos best-effort
```

**View** This command can be used in the following views:

- Any view

**Description** This command is used for displaying the traffic priority settings. The information displayed includes the ACL corresponding to the traffic tagged with priority, priority type and value.

**Related Commands**

- `port`
- `traffic-priority`

# display qos-interface traffic-statistic

---

**Purpose** Use the `display qos-interface traffic-statistic` command to view the traffic statistics information.

**Syntax** `display qos-interface { interface-name | interface-type interface-num | unit-id } traffic-statistic`

**Parameters**

|                                      |                                 |
|--------------------------------------|---------------------------------|
| <code><i>interface-name</i> /</code> |                                 |
| <code><i>interface-type</i></code>   |                                 |
| <code><i>interface-num</i></code>    | Specifies a port of the Switch. |
| <code><i>unit-id</i></code>          | Unit ID of the Switch.          |

**Example** Display the traffic statistics information.

```
<SW5500>display qos-interface Ethernet1/0/1 traffic-statistic
Ethernet1/0/1: traffic-statistic
 Inbound:
 Matches: Acl 2000 rule 0 running
 0 packet inprofile
 0 packet outprofile
```

**View** This command can be used in the following views:

- Any view

**Description** The information displayed includes the ACL corresponding to the traffic to be counted and the number of packets counted.

**Related Commands**

- `port`
- `traffic-statistic`



# display qos-profile

---

**Purpose** Use the `display qos-profile` command to view QoS profile configuration information.

**Syntax** `display qos-profile { all | profile-name | interface { interface-name / interface-type interface-num } | user user-name }`

|                   |                                                                                               |                                                        |
|-------------------|-----------------------------------------------------------------------------------------------|--------------------------------------------------------|
| <b>Parameters</b> | <code>all</code>                                                                              | Displays all QoS profiles.                             |
|                   | <code><i>profile-name</i></code>                                                              | The profile name.                                      |
|                   | <code>interface { <i>interface-name</i> / <i>interface-type</i> <i>interface-num</i> }</code> | Displays the QoS profile delivered to a specific port. |
|                   | <code>user <i>user-name</i></code>                                                            | Displays the QoS profile mapped with a specific user.  |

**Example** To display QoS profile configuration information, enter the following:

```
<SW5500> display qos-profile all
qos-profile: qos-profile student, 2 actions
 packet-filter inbound ip-group 2000 rule 0
 packet-filter inbound link-group 4000 rule 0
```

**View** This command can be used in the following views:

- Any view

# display queue-scheduler

---

**Purpose** Use the **display queue-scheduler** command to view queue scheduling mode and corresponding parameter configuration

**Syntax** **display queue-scheduler**

**Parameters** None

**Default** The default is Weighted Round Robin.

**Example** To display the queue scheduling mode, enter the following:

```
<SW5500> display queue-scheduler
Queue scheduling mode: weighted round robin
weight of queue 0: 1
weight of queue 1: 2
weight of queue 2: 3
weight of queue 3: 4
weight of queue 4: 5
weight of queue 5: 9
weight of queue 6: 13
weight of queue 7: 15
```

**View** This command can be used in the following views:

- Any view

**Related Command** **queue-scheduler**

# display radius

---

**Purpose** Use the `display radius` command to view the configuration information of all RADIUS schemes or a specified one.

**Syntax** `display radius [ radius-scheme-name ]`

**Parameters** `radius-scheme-name` Specifies the RADIUS scheme name with a character string not exceeding 32 characters. If not specified, all RADIUS schemes are displayed by default.

**Example** To display the configuration information of all the RADIUS schemes, enter the following.

```
<SW5500>display radius

SchemeName =system Index=0 Type=3Com
Primary Auth IP =127.0.0.1 Port=1645 State=block
Primary Acct IP =127.0.0.1 Port=1646 State=block
Second Auth IP =0.0.0.0 Port=1812 State=block
Second Acct IP =0.0.0.0 Port=1813 State=block
Auth Server Encryption Key= 3Com
Acct Server Encryption Key= 3Com
Accounting method = required
TimeOutValue(in second)=3 RetryTimes=3 RealtimeACCT(in minute)=12
Permitted send realtime PKT failed counts =5
Retry sending times of noresponse acct-stop-PKT =500
Quiet-interval(min) =5
Username format =without-domain
Data flow unit =Byte
Packet unit =1

Total 1 RADIUS scheme(s). 1 listed
```

**View** This command can be used in the following views:

- Any view

**Related Command** `radius-scheme`

# display radius statistics

---

**Purpose** Use the `display radius statistics` command to view the statistics information of RADIUS packet.

**Syntax** `display radius statistics`

**Parameters** None

**Example** To display the statistics information of RADIUS packets, enter the following:

```
<SW5500>display radius statistics

state statistic(total=0):
DEAD=1048 AuthProc=0 AuthSucc=0
AcctStart=0 RLTSend=0 RLWait=0
AcctStop=0 OnLine=0 Stop=0
StateErr=0
Receive and Send packets statistic:
Send PKT total :0 Receive PKT total:0
RADIUS received packets statistic:
Code= 2,Num=0 ,Err=0
Code= 3,Num=0 ,Err=0
Code= 5,Num=0 ,Err=0
Code=11,Num=0 ,Err=0
Code=22,Num=0 ,Err=0

Running statistic:
RADIUS received messages statistic:
Normal auth request ,Num=0 ,Err=0 ,Succ=0
EAP auth request ,Num=0 ,Err=0 ,Succ=0
Account request ,Num=0 ,Err=0 ,Succ=0
Account off request ,Num=0 ,Err=0 ,Succ=0
Leaving request ,Num=0 ,Err=0 ,Succ=0
PKT auth timeout ,Num=0 ,Err=0 ,Succ=0
```

**View** This command can be used in the following views:

- Any view

**Description** This command outputs the statistics information about the RADIUS packets. The displayed packet information can help with RADIUS diagnosis and troubleshooting.

**Related Command** `radius-scheme`

# display remote-ping

**Purpose** Use the **display remote-ping** command to display the test results.

**Syntax** `display remote-ping { results | history } [ administrator-name test-tag ]`

**Parameters**

|                           |                                                 |
|---------------------------|-------------------------------------------------|
| <b>results</b>            | Displays the latest test results.               |
| <b>history</b>            | Displays the test history.                      |
| <b>administrator-name</b> | Name of the administrator who created the test. |
| <b>test-tag</b>           | Test tag.                                       |

**Example** Display the latest test results of the test group administrator icmp.

```
<S5500> display remote-ping results administrator icmp
Remote-ping entry(admin administrator, tag icmp) test result:
 Destination ip address:10.10.10.10
 Send operation times: 10 Receive response times: 10
 Min/Max/Average Round Trip Time: 1/2/1
 Square-Sum of Round Trip Time: 13
 Last complete test time: 2004-11-25 16:28:55.0
Extend result:
 SD Maximal delay: 0 DS Maximal delay: 0
 Packet lost in test: 0%
 Disconnect operation number:0 Operation timeout number:0
 System busy operation number:0 Connection fail number:0
 Operation sequence errors:0 Drop operation number:0

Other operation errors:0
```

**Table 71** Description on the fields of the display remote-ping results command

| Field                           | Description                                                                           |
|---------------------------------|---------------------------------------------------------------------------------------|
| Destination ip address          | Destination IP address                                                                |
| Send operation times            | Packet sending times                                                                  |
| Receive response times          | Successful packet sending times                                                       |
| Min/Max/Average Round Trip Time | Min/max/average round trip time (RTT)                                                 |
| Square-Sum of Round Trip Time   | Quadratic sum of RTTs                                                                 |
| Last complete test time         | Time of the last successful send operation in the test                                |
| SD Maximal delay                | Max delay from the source to the destination                                          |
| DS Maximal delay                | Max delay from the destination to the source                                          |
| Packet lost in test             | Rate of the lost packets in the test                                                  |
| Disconnect operation number     | Number of the disconnect operations forcibly performed by the opposite party          |
| Operation timeout number        | Number of the send operations getting no response within the timeout time in the test |

**Table 71** Description on the fields of the display remote-ping results command (continued)

| Field                        | Description                                                                      |
|------------------------------|----------------------------------------------------------------------------------|
| System busy operation number | Number of the failed send operations due to system busy in the test              |
| Connection fail number       | Number of the failed attempts to establish a connection with the opposite party. |
| Operation sequence errors    | Number of the out-of-sequence packets received                                   |
| Drop operation number        | Number of the failed system resource assignment operations                       |
| Other operation errors       | Number of other errors                                                           |

Display the test history of the test group administrator icmp.<S5500> display remote-ping history administrator icmp

Remote-ping entry(admin administrator, tag icmp) history record:

| Index | Response | Status | LastRC | Time                  |
|-------|----------|--------|--------|-----------------------|
| 1     | 1        | 1      | 0      | 2004-11-25 16:28:55.0 |
| 2     | 1        | 1      | 0      | 2004-11-25 16:28:55.0 |
| 3     | 1        | 1      | 0      | 2004-11-25 16:28:55.0 |
| 4     | 1        | 1      | 0      | 2004-11-25 16:28:55.0 |
| 5     | 1        | 1      | 0      | 2004-11-25 16:28:55.0 |
| 6     | 2        | 1      | 0      | 2004-11-25 16:28:55.0 |
| 7     | 1        | 1      | 0      | 2004-11-25 16:28:55.0 |
| 8     | 1        | 1      | 0      | 2004-11-25 16:28:55.0 |
| 9     | 1        | 1      | 0      | 2004-11-25 16:28:55.9 |
| 10    | 1        | 1      | 0      | 2004-11-25 16:28:55.9 |

**Table 72** Description on the fields of the display remote-ping history command

| Field    | Description                                                                                                                                                                                                                                                                                                                   |
|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Response | Round trip time in ms or timeout time. It is 0 if the test fails.                                                                                                                                                                                                                                                             |
| Status   | Result value of the send operation, including:<br>1: responseReceived<br>2: unknown<br>3: internalError<br>4: requestTimedOut<br>5: unknownDestinationAddress<br>6: noRouteToTarget<br>7: interfacelInactiveToTarget<br>8: arpFailure<br>9: maxConcurrentLimitReached<br>10: unableToResolveDnsName<br>11: invalidHostAddress |
| LastRC   | Last response code received (this code is based on the specific implementation). When the ICMP Echo function is enabled, if an ICMP response containing ICMP_ECHOREPLY(0) is received, it indicates the detection succeeds.                                                                                                   |
| Time     | Test time                                                                                                                                                                                                                                                                                                                     |

## View

This command can be used in the following views:

- Any view

## **Description**

If a test group is specified by using the administrator-name and test-tag arguments, the system displays the test results of the specified test group. Otherwise the system displays the test results of all the test groups.

## **Related Command**

- **remote-ping**
- **test-enable**

# display resilient-arp

---

**Purpose** Use the **display resilient-arp** command to view resilient ARP state information of the units, the resilient ARP packet-sending VLAN interfaces.

**Syntax** `display resilient-arp [ unit unit-id ]`

**Parameters** *unit-id* Specifies the unit ID. Valid values are 1 to 8.

**Example** To display resilient ARP state information of Unit 1, enter the following:

```
<SW5500>display resilient-arp unit 1
The state of unit 1 is: L3Master
The sending interface(s):
Vlan-interface2
Vlan-interface1
Md5 authentication switch is on
```

**View** This command can be used in the following views:

- Any view

**Description** If no unit ID is specified, the system displays the resilient ARP state information of all units. Otherwise, the system only displays the resilient ARP state information of the designated units.



# display rip

---

**Purpose** Use the `display rip` command to view the current RIP running state and its configuration information.

**Syntax** `display rip`

**Parameters** None

**Example** To display the current running state and configuration information of RIP, enter the following:

```
<SW5500>display rip
RIP is running
 public net VPN-Instance
 Checkzero is on Default cost : 1
 Summary is on Preference : 100
 Period update timer : 30
 Timeout timer : 180
 Garbage-collection timer : 120
 No peer router
 Network :
 202.38.168.0
```

**Table 73** Output Description of the display rip command

| Field                          | Description                                           |
|--------------------------------|-------------------------------------------------------|
| RIP is running                 | RIP is active                                         |
| Checkzero is on                | Zero field checking is enabled                        |
| Default cost:1                 | The default route cost is 1                           |
| Summary is on                  | Routes are summarized automatically                   |
| Preference: 100                | The preference of RIP is 100                          |
| Period update timer : 30       | The three RIP timers                                  |
| Timeout timer : 180            |                                                       |
| Garbage-collection timer : 120 |                                                       |
| No peer router                 | No destination address of a transmission is specified |
| Network: 202.38.168.0          | RIP enabled on network segment 202.38.168.0           |

**View** This command can be used in the following views:

- Any view

# display rip interface

---

**Purpose** Use the **display rip interface** command to display information about RIP interfaces.

**Syntax** `display rip interface`

**Parameters** None

**Example** Display information about RIP interfaces.

```
<S5500> display rip interface
 RIP Interface: public net

Address Interface Ver MetrIn/Out Input Output Split-horizon
1.0.0.1 Vlan-interface100 2 0/1 on on on
```

**Table 74** Description on the fields of the display rip interface command body

| Field         | Description                                                                                                                                                                      |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Address       | IP address of the interface on which the RIP protocol is running (in RIP view, the <b>network</b> command is used to enable RIP on the network segment this address belongs to). |
| Interface     | Name of the interface on which the RIP protocol is running. The Address field gives the IP address of this interface.                                                            |
| Ver           | Version of the RIP protocol running on the interface                                                                                                                             |
| MetrIn/Out    | Attached route metric added when receiving/sending a route                                                                                                                       |
| Input         | Whether or not the interface is allowed to receive RIP packets (on for allowed, off for inhibited).                                                                              |
| Output        | Whether or not the interface is allowed to send RIP packets (on for allowed, off for inhibited).                                                                                 |
| Split-horizon | Whether or not split-horizon is enabled (on for enabled, and off for disabled)                                                                                                   |

**View** This command can be used in the following views:

- Any view

# display rmon alarm

---

**Purpose** Use the `display rmon alarm` command to view RMON alarm information.

**Syntax** `display rmon alarm [ alarm-table-entry ]`

**Parameters** `alarm-table-entry` Alarm table entry index.

**Example** Display the RMON alarm information.

```
<SW5500>display rmon alarm
Alarm table 1 owned by 3COM is VALID.
 Samples absolute value : 1.3.6.1.2.1.16.1.1.1.4.1
<etherStatsOctets.1>
 Sampling interval : 10(sec)
 Rising threshold : 1000(linked with event 1)
 Falling threshold : 100(linked with event 1)
 When startup enables : risingOrFallingAlarm
 Latest value : 0
```

**Table 75** Output description of the display rmon alarm command

| Field                  | Description                                                                                                                      |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Alarm table 1          | Index 1 in the alarm table                                                                                                       |
| 3Com                   | Owner                                                                                                                            |
| VALID                  | The entry corresponding to the index is valid                                                                                    |
| Samples absolute value | Sampling the absolute value of the node 1.3.6.1.2.1.16.1.1.1.4.1                                                                 |
| Sampling interval      | The interval of sampling the value                                                                                               |
| Rising threshold1      | Rising threshold. When sampling value rises from normal value to this threshold, rising threshold alarm will be triggered.       |
| Falling threshold      | Falling threshold. When sampling value decreases from normal value to this threshold, falling threshold alarm will be triggered. |
| startup                | The first trigger                                                                                                                |
| risingOrFallingAlarm   | The type of the first alarm: Specifies to alarm when exceeding the rising threshold or the falling threshold                     |

**View** This command can be used in the following views:

- Any view

**Related Command** `rmon alarm`

# display rmon event

---

**Purpose** Use the `display rmon event` command to view RMON events.

**Syntax** `display rmon event [ event-table-entry ]`

**Parameters** `event-table-entry` Entry index of event table.

**Example** Show the RMON event.

```
<SW5500>display rmon event
Event table 1 is VALID, and owned by 3COM.
 Description: null.
 Will cause log-trap when triggered, last triggered at 0days
00h:02m:27s.
```

**Table 76** Output description of the display rmon event command

| Field                                                                   | Description                                                                                         |
|-------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| Event table 1                                                           | Index 1 in event table                                                                              |
| VALID                                                                   | The entry corresponding to the index is valid                                                       |
| 3COM                                                                    | Owner                                                                                               |
| Description                                                             | Event description                                                                                   |
| Will cause log-trap when triggered, last triggered at 0days 00h:02m:27s | When the event is triggered, it will cause the log-trap. And the last triggered time is 00h:02m:27s |

**View** This command can be used in the following views:

- Any view

**Description** The display includes event index in event table, owner of the event, description to the event, action caused by event (log or alarm information), and occurrence time of the latest event (counted on system initiate/boot time in centiseconds).

**Related Command** `rmon event`

# display rmon eventlog

---

**Purpose** Use the `display rmon eventlog` command to display RMON event log.

**Syntax** `display rmon eventlog [ event-number ]`

**Parameters** *event-number* Entry index of event table.

**Example** Show the RMON event log.

```
<SW5500>display rmon eventlog 1
Event table 1 owned by 3Com is VALID.
Generates eventLog 1.1 at 0days 00h:01m:39s.
Description: The 1.3.6.1.2.1.16.1.1.1.4.1 defined in alarm table 1,
less than(or =) 100 with alarm value 0. Alarm sample type is absolute.
Generates eventLog 1.2 at 0days 00h:02m:27s.
Description: The alarm formula defined in private alarm table 1,
less than(or =) 100 with alarm value 0. Alarm sample type is absolute.
```

**Table 77** Output description of the display rmon eventlog command

| Field                                       | Description                                                                    |
|---------------------------------------------|--------------------------------------------------------------------------------|
| Event table 1                               | Index 1 in event table                                                         |
| 3Com                                        | Owner                                                                          |
| VALID                                       | The entry corresponding to the index is valid                                  |
| Description                                 | Event description                                                              |
| less than (or =) 100 with alarm value 0     | The alarm sample value is less than or equal to 100                            |
| Alarm sample type is absolute               | The type of alarm sampling is absolute                                         |
| Generates eventLog 1.2 at 0days 00h:02m:27s | The eventlog corresponding to the index 1.2 is generated at 0days 00h:02m:27s. |

**View** This command can be used in the following views:

- Any view

**Description** The display includes description about event index in event table, description to the event, and occurrence time of the latest event (counted on system initiate/boot time in centisecond).

# display rmon history

---

**Purpose** Use the `display rmon history` command to view the latest RMON history sampling information (including utility, error number and total packet number).

**Syntax** `display rmon history [ port-num ]`

**Parameters** *port-num* Ethernet port name.

**Example** Show the RMON history information.

```
<SW5500>display rmon history ethernet 2/0/1
History control entry 1 owned by 3Com is VALID,
 Samples interface : Ethernet1/0/1<ifEntry.642>
 Sampling interval : 10(sec) with 10 buckets max
 Latest sampled values :
 Dropevents :0 , octets :0
 packets :0 , broadcast packets :0
 multicast packets :0 , CRC alignment errors :0
 undersize packets :0 , oversize packets :0
 fragments :0 , jabbers :0
 collisions :0 , utilization :0
```

**Table 78** Output description of the display rmon history command

| Field                 | Description                                   |
|-----------------------|-----------------------------------------------|
| History control table | Index number in history control table         |
| 3COM                  | Owner                                         |
| VALID                 | The entry corresponding to the index is valid |
| Samples interface     | The sampled interface                         |
| Sampling interval     | Sampling interval                             |
| buckets               | Records in history control table              |
| dropevents            | Dropping packet events                        |
| octets                | Sent/received octets in sampling time         |
| packets               | Packets sent/received in sampling time        |
| broadcastpackets      | Number of broadcast packets                   |
| multicastpackets      | Number of multicast packets                   |
| CRC alignment errors  | Number of CRC error packets                   |
| undersized            | Number of undersized packets                  |
| oversized packets     | Number of oversized packets                   |
| fragments             | Number of undersized and CRC error packets    |
| jabbers               | Number of oversized and CRC error packets     |
| collisions            | Number of collision packets                   |
| utilization           | Utilization                                   |

## **View**

This command can be used in the following views:

- Any view

## **Related Command**

`rmon history`

# display rmon history unit

---

**Purpose** Use the **display rmon history unit** command to collect RMON history data of a specified fabric unit.

**Syntax** `display rmon history unit unit-id`

**Parameters** `unit-id` Unit ID of a unit in a fabric.

**Example** Display RMON history data of unit 3.

```
<S5500> display rmon history unit 3
```

**View** This command can be used in the following views:

- Any view

**Related Command** `rmon history`



# display rmon prialarm

**Purpose** Use the `display rmon prialarm` command to display information about extended alarm table.

**Syntax** `display rmon prialarm [ prialarm-table-entry ]`

**Parameters** *prialarm-table-entry* entry of extended alarm table.

**Example** Display alarm information about extended RMON.

```
<SW5500>display rmon prialarm
Prialarm table 1 owned by 3Com is VALID.
 Samples absolute value : .1.3.6.1.2.1.16.1.1.1.4.1
 Sampling interval : 10(sec)
 Rising threshold : 1000(linked with event 1)
 Falling threshold : 100(linked with event 1)
 When startup enables : risingOrFallingAlarm
 This entry will exist : forever.
 Latest value : 0
```

**Table 79** Output description of the display rmon prialarm command

| Field                                      | Description                                                                                                                      |
|--------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Prialarm table 1                           | Index of extended alarm entry.                                                                                                   |
| owned by 3COM                              | Creator of the extended alarm entry.                                                                                             |
| VALID                                      | The entry corresponding to the index is valid                                                                                    |
| Samples absolute value                     | Sampling the absolute value of the node 1.3.6.1.2.1.16.1.1.1.4.1                                                                 |
| Rising threshold                           | Rising threshold. When sampling value rises from normal value to this threshold, rising threshold alarm will be triggered.       |
| Falling threshold                          | Falling threshold. When sampling value decreases from normal value to this threshold, falling threshold alarm will be triggered. |
| linked with event 1                        | Corresponding event index of ring and falling threshold alarm.                                                                   |
| When startup enables: risingOrFallingAlarm | Kind of first alarm. It may trigger rising threshold alarm or falling threshold alarm or both.                                   |
| This entry will exist forever              | The lifespan of this alarm entry which can be forever or a specified period of time.                                             |
| Latest value : 0                           | The value of the latest sampling.                                                                                                |

**View** This command can be used in the following views:

- Any view

**Related Command** `rmon prialarm`

# display rmon statistics

---

**Purpose** Use the `display rmon statistics` command to display RMON statistics.

**Syntax** `display rmon statistics [ port-num ]`

**Parameters** `port-num` Ethernet port number.

**Example** Show RMON statistics.

```
<SW5500>display rmon statistics Ethernet 1/0/1
Statistics entry 1 owned by 3Com is VALID.
 Interface : Ethernet1/0/1<ifEntry.642>
 Received :
 octets :0 , packets :0
 broadcast packets :0 , multicast packets:0
 undersized packets :0 , oversized packets:0
 fragments packets :0 , jabbers packets :0
 CRC alignment errors:0 , collisions :0
 Dropped packet (insufficient resources):0
 Packets received according to length (octets):
 64 :0 , 65-127 :0 , 128-255 :0
 256-511:0 , 512-1023:0 , 1024-1518:0
```

**Table 80** Output description of the display rmon statistics command

| Field                                   | Description                                   |
|-----------------------------------------|-----------------------------------------------|
| Interface                               | Port                                          |
| 3Com                                    | Owner                                         |
| VALID                                   | The entry corresponding to the index is valid |
| octets                                  | Received/Sent octets in sampling time         |
| packets                                 | Packets received/sent in sampling time        |
| broadcast packets                       | Number of broadcast packets                   |
| multicast packets                       | Number of multicast packets                   |
| undersized packets                      | Number of undersized packets                  |
| oversized packets                       | Number of oversized packets                   |
| fragments packets                       | Number of undersized and CRC error packets    |
| jabbers                                 | Number of oversized and CRC error packets     |
| CRC alignment errors                    | Number of CRC error packets                   |
| collisions                              | Number of collision packets                   |
| Dropped packet (insufficient resources) | Dropping packet events                        |

**View** This command can be used in the following views:

- Any view

## **Description**

The displayed information includes collision, CRC (Cyclic Redundancy Check) and queue, undersized or oversized packet, timeout, fragment, broadcast, multicast, unicast, and bandwidth utility.

## **Related Command**

`rmon statistics`

# display rmon statistics unit

---

**Purpose** Use the **display rmon statistics unit** command to collect RMON statistics data of a specified fabric unit.

**Syntax** `display rmon statistics unit unit-id`

**Parameters** `unit-id` Unit ID of an unit in a fabric.

**Example** Display RMON statistics data of unit 2.  

```
<S5500> display rmon statistics unit 2
```

**View** This command can be used in the following views:

- Any view

**Related Command** `rmon statistics`

# display route-policy

---

**Purpose** Use the `display route-policy` command to view the configured Route-policy

**Syntax** `display route-policy [ route_policy_name ]`

**Parameters** `route_policy_name` Specify displayed Route-policy name.

**Example** Display the information of Route-policy named as policy1.

```
<SW5500>display route-policy policy1
Route-policy : policy1
 Permit 10 : if-match (prefixlist) p1
 apply cost 100
 matched : 0 denied : 0
```

**Table 81** Output Description of the display route-policy command

| Field        | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Route-policy | Name of ip-prefix                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Permit 10    | Information of the route-policy with mode as permit and node as 10: <ul style="list-style-type: none"><li>■ if-match (prefixlist) p1 — The configured if-match clause</li><li>■ apply cost 100 — Apply routing cost 100 to the routes matching the conditions defined by if-match clause</li><li>■ matched — Number of routes matching the conditions set by if-match clause</li><li>■ denied — Number of routes not matching the conditions set by if-match clause</li></ul> |

**View** This command can be used in the following views:

- Any view

**Related Command** `route-policy`

# display rsa local-key-pair public

---

**Purpose** Use the **display rsa local-key-pair public** command to display the public key of the server host key pair. If no key pair is generated, the system prompts "RSA keys not found".

**Syntax** **display rsa local-key-pair public**

**Parameters** None

**Example** <S5500> display rsa local-key-pair public

```

=====
Time of Key pair created: 02:15:56 2000/04/02
Key name: S5500_Host
Key type: RSA encryption Key
=====
Key code:
3047
 0240
 C968B224 D3DD880B 65758B4F AD281531 8BC8A915
 48D30D34 F29B9BE3 4F35DFD6 C8AB3135 0727590B
 80700BA1 6D62CF05 DF9960A4 59466486 E0A36F95
 A76B28C7
 0203
 010001

Host public key for PEM format code:
---- BEGIN SSH2 PUBLIC KEY ----
AAAAB3NzaC1yc2EAAAADAQABAAQhADX9/Nk0pXI2n9A58Yt9+IGbssAdzN28FGk
tFHKrzW6MU8a57DYhETGhFmaVrqVG9COBn3Kk0RI2GsUUuI/ujN6tM1lzf0h/eZs
CaZfB6BnaTHH9X1A/Qc+WCa5jmWyB5u3V1CpTUWVd8smXZg8wHuOsd4DK6zcp48H
l1KgSYCK69A87Q==
---- END SSH2 PUBLIC KEY ----

Public key code for pasting into OpenSSH authorized_keys file:
ssh-rsa
AAAAB3NzaC1yc2EAAAADAQABAAQhADX9/Nk0pXI2n9A58Yt9+IGbssAdzN28FGktFHKrz
w6
MU8a57DYhETGhFmaVrqVG9COBn3Kk0RI2GsUUuI/ujN6tM1lzf0h/eZsCaZfB6BnaTHH9X
1A/Qc+WCa5
jmWyB5u3V1CpTUWVd8smXZg8wHuOsd4DK6zcp48Hl1KgSYCK69A87Q== rsa-key

```

**View** This command can be used in the following views:

- Any view

**Related Command** **rsa local-key-pair create**

# display rsa peer-public-key

---

## Purpose

Use the **display rsa peer-public-key** command to display the client public key of the specified RSA key pair. If no key name is specified, the command displays all public keys of the client

## Syntax

```
display rsa peer-public-key [brief | name keyname]
```

## Parameters

|                |                                                                                |
|----------------|--------------------------------------------------------------------------------|
| <b>brief</b>   | Displays brief information about all public keys on the client.                |
| <b>keyname</b> | Name of the client public key, consisting of a string 1 to 64 characters long. |

## Example

Display all public keys on the client.

```
<S5500> display rsa peer-public-key brief
Address Bits Name

 1023 abcd
 1024 hq
```

Display the public key of the client key pair abcd.

```
<S5500> display rsa peer-public-key name abcd
=====
Key name: abcd
Key address:
=====
Key Code:
308186
 028180
 739A291A BDA704F5 D93DC8FD F84C4274 631991C1 64B0DF17 8C55FA83
3591C7D4
 7D5381D0 9CE82913 D7EDF9C0 8511D83C A4ED2B30 B809808E B0D1F52D
045DE408
 61B74A0E 135523CC D74CAC61 F8E58C45 2B2F3F2D A0DCC48E 3306367F
E187BDD9
 44018B3B 69F3CBB0 A573202C 16BB2FC1 ACF3EC8F 828D55A3 6F1CDDC4
BB45504F
 0201
 25
```

## View

This command can be used in the following views:

- Any view

# display saved-configuration

---

**Purpose** Use the **display saved-configuration** command to display the current configuration file in the flash memory of an Ethernet switch.

**Syntax** `display saved-configuration [ unit unit-id ] [ by-linenum ]`

**Parameters**

|                                  |                                    |
|----------------------------------|------------------------------------|
| <code>unit <i>unit-id</i></code> | Specifies the unit ID of a switch. |
| <code>by-linenum</code>          | Displays the number of each line.  |

**Example** Display the current configuration file in the flash memory, and display the number of each line.

```
<S5500> display saved-configuration by-linenum
 1: #
 2: sysname 5600-EI
 3: #
 4: mirroring-group 2 local
 5: #
 6: radius scheme system
 7: #
 8: domain system
 9: #
10: vlan 1
11: #
12: vlan 3
13: #
14: interface Vlan-interface1
15: #LOCCFG. MUST NOT DELETE
16: #
17: interface Aux1/0/0
18: #
19: interface GigabitEthernet1/0/1
20: #
21: interface GigabitEthernet1/0/2
22: #
23: interface GigabitEthernet1/0/3
24: mirroring-group 2 mirroring-port inbound
25: #
26: interface GigabitEthernet1/0/4
27: mirroring-group 2 mirroring-port inbound
28: #
29: interface GigabitEthernet1/0/5
30: mirroring-group 2 mirroring-port inbound
31: #
32: interface GigabitEthernet1/0/6
33: mirroring-group 2 monitor-port
34: #
35: interface GigabitEthernet1/0/7
36: #
37: interface GigabitEthernet1/0/8
38: #
39: interface GigabitEthernet1/0/9
```



```
40: #
41: interface GigabitEthernet1/0/10
42: #
43: interface GigabitEthernet1/0/11
44: #
45: interface GigabitEthernet1/0/12
46: #
47: interface GigabitEthernet1/0/13
48: #
49: interface GigabitEthernet1/0/14
50: #
51: interface GigabitEthernet1/0/15
52: #
53: interface GigabitEthernet1/0/16
54: #
55: interface GigabitEthernet1/0/17
56: #
57: interface GigabitEthernet1/0/18
58: #
59: interface GigabitEthernet1/0/19
60: #
61: interface GigabitEthernet1/0/20
62: #
63: interface GigabitEthernet1/0/21
64: #
65: interface GigabitEthernet1/0/22
66: #
67: interface GigabitEthernet1/0/23
68: #
69: interface GigabitEthernet1/0/24
70: #
71: #TOPOLOGYCFG. MUST NOT DELETE
72: #
73: undo irf-fabric authentication-mode
74: #GLBCFG. MUST NOT DELETE
75: #
76: interface NULL0
77: #
78: cluster
79: ip-pool 10.100.10.1 255.255.255.0
80: #
81: snmp-agent
82: snmp-agent local-engineid 800007DB0012A99022406877
83: snmp-agent sys-info version all
84: #
85: undo cluster enable
86: #
87: user-interface aux 0 7
88: user-interface vty 0 4
89: #
90: return
```

The above configurations are listed in the following order: global, port, and user interface configurations.

## View

This command can be used in the following views:

- Any view

**Description**

If an Ethernet switch does not work normally after it is powered on, you can use the **display saved-configuration** command to view the startup configurations of the Ethernet switch.

# display schedule reboot

---

**Purpose** Use the `display schedule reboot` command to check the configuration of related parameters of the switch schedule reboot terminal service.

**Syntax** `display schedule reboot`

**Parameters** None

**Example** Display the configuration of the schedule reboot terminal service parameters of the current switch.

```
<SW5500>display schedule reboot
System will reboot at 03:41 2000/04/02 (in 1 hours and 27 minutes).
```

**View** This command can be used in the following views:

- Any view

**Related Commands**

- `reboot`
- `schedule reboot at`
- `schedule reboot delay`
- `undo schedule reboot`

# display sftp source-ip

---

**Purpose** Use the **display sftp source-ip** command to display the source IP address of the SFTP client. If no source IP address is specified, 0.0.0.0 is displayed.

**Syntax** `display sftp source-ip`

**Parameters** None

**Example** Display the source IP address of the SFTP client.

```
<S5500> display sftp source-ip
The source IP you specified is 192.168.1.1
```

**View** This command can be used in the following views:

- Any view

# display snmp-agent

---

**Purpose** Use the `display snmp-agent engineid` command to view the engine ID of current device.

**Syntax** `display snmp-agent { local-engineid | remote-engineid }`

**Parameters**

|                              |                   |
|------------------------------|-------------------|
| <code>local-engineid</code>  | Local engine ID.  |
| <code>remote-engineid</code> | Remote engine ID. |

**Example** Display the engine ID of current device.

```
<SW5500>display snmp-agent engineid
Local SNMP engineID: 0000000902000000C025808
```

**View** This command can be used in the following views:

- Any view

**Description** SNMP engine is the core of SNMP entity. It performs the function of sending, receiving and authenticating SNMP message, extracting PDU, packet encapsulation and the communication with SNMP application.

# display snmp-agent community

---

**Purpose** Use the `display snmp-agent community` command to display the currently configured community names.

**Syntax** `display snmp-agent community [ read | write ]`

**Parameters**

|                    |                                            |
|--------------------|--------------------------------------------|
| <code>read</code>  | Displays read-only community information.  |
| <code>write</code> | Displays read-write community information. |

**Example** Display the currently configured community names.

```
<SW5500>display snmp-agent community
community name:public
group name:public
storage-type: nonVolatile

community name:tom
group name:3Com
storage-type: nonVolatile
```

**View** This command can be used in the following views:

- Any view

# display snmp-agent group

---

**Purpose** Use the `display snmp-agent group` command to display group name, safe mode, state of various views and storage modes.

**Syntax** `display snmp-agent group [ group-name ]`

**Parameters** *groupname* Group name. Valid values are 1 to 32 bytes.

**Example** Display SNMP group name and safe mode.

```
<SW5500>display snmp-agent group
groupname: public
Security model: v2c noAuthnoPriv
readview:v1default
writeview: no writeview specified
notifyview: *tv.FFFFFFFF
storage-type: volatile
```

The following table describes the output fields.

**Table 82** Output description of the display snmp-agent group command

| Field          | Description                                                 |
|----------------|-------------------------------------------------------------|
| groupname      | SNMP Group name of the user                                 |
| Security model | The security model adopted by SNMP                          |
| readview       | Read-only MIB view name corresponding to that group         |
| writeview      | Writable MIB view corresponding to that group               |
| notifyview     | The name of the notify MIB view corresponding to that group |
| storage-type   | Storage type                                                |

**View** This command can be used in the following views:

- Any view

# display snmp-agent mib-view

---

|                   |                                                                                                                            |                                                            |
|-------------------|----------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------|
| <b>Purpose</b>    | The <code>display snmp-agent mib-view</code> command is used to view the MIB view configuration information of the Switch. |                                                            |
| <b>Syntax</b>     | <code>display snmp-agent mib-view [ exclude   include   viewname <i>mib-view</i> ]</code>                                  |                                                            |
| <b>Parameters</b> | <code>exclude</code>                                                                                                       | Displays the SNMP mib view excluded.                       |
|                   | <code>include</code>                                                                                                       | Displays the SNMP mib view included.                       |
|                   | <code>viewname</code>                                                                                                      | Displays the SNMP mib view according to the mib view name. |
|                   | <code>mib-view</code>                                                                                                      | Specifies the mib view name.                               |

**Example** Display the information about the currently configured MIB view.

```
<SW5500>display snmp-agent mib-view
View name:ViewDefault
 MIB Subtree:snmpUsmMIB
 Subtree mask:
 Storage-type: nonVolatile
 View Type:excluded
 View status:active

View name:ViewDefault
 MIB Subtree:snmpVacmMIB
 Subtree mask:
 Storage-type: nonVolatile
 View Type:excluded
 View status:active

View name:ViewDefault
 MIB Subtree:snmpModules.18
 Subtree mask:
 Storage-type: nonVolatile
 View Type:excluded
 View status:active
```

**View** This command can be used in the following views:

- Any view

**Description** The `display snmp-agent mib-view` command is used to view the MIB view configuration information of the Switch.



*If the SNMP Agent is disabled, "Snmp Agent disabled" will be displayed after you execute the above **display** commands.*



# display snmp-agent statistics

**Purpose** Use the `display snmp-agent statistics` command to view the current state of SNMP communication.

**Syntax** `display snmp-agent statistics`

**Parameters** None

**Example** Display the current state of SNMP communication.

```
<SW5500>display snmp-agent statistics
0 Messages delivered to the SNMP entity
0 Messages which were for an unsupported version
0 Messages which used an unknown community name
0 Messages which represented an illegal operation for the community
supplied
0 ASN.1 or BER errors in the process of decoding
0 MIB objects retrieved successfully
0 MIB objects altered successfully
0 Get-request PDUs accepted and processed
0 Get-next PDUs accepted and processed
0 Set-request PDUs accepted and processed
3 Messages passed from the SNMP entity
0 SNMP PDUs which had a tooBig error (Maximum packet size 1500)
0 SNMP PDUs which had a noSuchName error
0 SNMP PDUs which had a badValue error
0 SNMP PDUs which had a general error
0 Response PDUs accepted and processed
3 Trap PDUs accepted and processed
```

The following table describes the output fields.

**Table 83** Output description of the display snmp-agent statistics command

| Field                                                                        | Description                                                                |
|------------------------------------------------------------------------------|----------------------------------------------------------------------------|
| 0 Messages delivered to the SNMP entity                                      | Total number of the input SNMP packets                                     |
| 0 Messages which were for an unsupported version                             | Number of packets with version information error                           |
| 0 Messages which used an unknown community name                              | Number of packets with community name error                                |
| 0 Messages which represented an illegal operation for the community supplied | Number of packets with authority error corresponding to the community name |
| 0 ASN.1 or BER errors in the process of decoding                             | Number of SNMP packets with encoding error                                 |
| 0 MIB objects retrieved successfully                                         | Number of variables requested by NMS                                       |
| 0 MIB objects altered successfully                                           | The number of variables set by NMS                                         |
| 0 Get-request PDUs accepted and processed                                    | Number of the received packets requested by get                            |
| 0 Get-next PDUs accepted and processed                                       | Number of the received packets requested by get-next                       |

**Table 83** Output description of the display snmp-agent statistics command (continued)

| Field                                                           | Description                                              |
|-----------------------------------------------------------------|----------------------------------------------------------|
| 0 Set-request PDUs accepted and processed                       | Number of the received packets requested by set          |
| 3 Messages passed from the SNMP entity                          | Total number of the output SNMP packets                  |
| 0 SNMP PDUs which had a tooBig error (Maximum packet size 1500) | Number SNMP packet with too_big error                    |
| 0 SNMP PDUs which had a noSuchName error                        | Number of the packets requesting nonexistent MIB objects |
| 0 SNMP PDUs which had a badValue error                          | Number of SNMP packets with Bad_values error             |
| 0 SNMP PDUs which had a general error                           | Number of SNMP packets with General_errors               |
| 0 Response PDUs accepted and processed                          | Number of the response packets sent                      |
| 3 Trap PDUs accepted and processed                              | Number of the sent Trap packets                          |

**View**

This command can be used in the following views:

- Any view

**Description**

This command provides a counter for SNMP operations.

# display snmp-agent sys-info

---

**Purpose** Use the `display snmp-agent sys-info` command to view the system information of SNMP configuration.

**Syntax** `display snmp-agent sys-info [ contact | location | version ]*`

**Parameters** None

**Example** Display the character string sysContact (system contact).

```
<SW5500>display snmp-agent sys-info contact
The contact person for this managed node:
Mr.Smith -Tel:3306
```

Display the system location.

```
<SW5500>display snmp-agent sys-info location
The physical location of this node:
Boston USA
```

Display the version information of running SNMP

```
<SW5500>display snmp-agent sys-info version
SNMP version running in the system:
SNMPv3
```

**View** This command can be used in the following views:

- Any view

**Description** The information includes the character string sysContact (system contact), the character string describing the system location, the version information about the running SNMP in the system.

# display snmp-agent trap-list

---

**Purpose** Use the **display snmp-agent trap-list** command to display trap list information.

**Syntax** `display snmp-agent trap-list`

**Parameters** None

**Example** Display the trap list information.

```
<S5500> display snmp-agent trap-list
configuration trap enable
flash trap enable
ospf trap enable
standard trap enable
system trap enable
vrrp trap enable

Enable traps :6; Disable traps 0
```

**View** This command can be used in the following views:

- Any view

**Related Command** `snmp-agent trap enable`

# display snmp-agent usm-user

---

**Purpose** Use the `display snmp-agent usm-user` command to view information of all the SNMP usernames in the group username list.

**Syntax** `display snmp-agent usm-user [ engineid engineid | group groupname | username username ]`

|                   |                  |                                                     |
|-------------------|------------------|-----------------------------------------------------|
| <b>Parameters</b> | <i>engineid</i>  | Displays user information with specified engine ID. |
|                   | <i>username</i>  | Displays user information with specified user name. |
|                   | <i>groupname</i> | Displays user information of specified group.       |

**Example** Display the information of all the current users.

```
<SW5500>display snmp-agent usm-user
User name: hello
 Group name: hellogroup
 Engine ID: 800007DB00E0FC0055006877
 Storage-type: nonVolatile
 UserStatus: active
 Acl:2000
```

**View** This command can be used in the following views:

- Any view

# display snmp-proxy unit

---

**Purpose** Using `display snmp-proxy unit` command, you can view statistics information of SNMP proxy.

**Syntax** `display snmp-proxy unit unit-id`

**Parameters** *unit-id* Unit ID of the switch.

**Example** View statistics information of SNMP proxy on unit 1.

```
<SW5500> display snmp-proxy unit 1
Number of GetReq msgs received :0
Number of GetReq msgs sent :0

Number of GetNextReq msgs Received :0
Number of GetNextReq msgs sent :0

Number of GetResp msgs received :0
Number of GetResp msgs sent :0

Number of GetNextResp msgs received :0
Number of GetNextResp msgs sent :0

Number of SnmpMibSync msgs received :0
Number of SnmpMibSync msgs sent :0

Number of SnmpMibGetCntrReq msgs received :0
Number of SnmpMibGetCntrReq msgs sent :0

Number of SnmpMibGetCntrResp msgs received :0
Number of SnmpMibGetCntrResp msgs sent :0
```

**View** This command can be used in the following views:

- Any view

# display ssh server

---

**Purpose** Use the **display ssh server** command to display the status or session information about the SSH server

**Syntax** `display ssh server { status | session }`

**Parameters**

|                      |                                   |
|----------------------|-----------------------------------|
| <code>status</code>  | Displays SSH status information.  |
| <code>session</code> | Displays SSH session information. |

**Example** Display the status information about the SSH server.

```
<S5500> display ssh server status
SSH version : 1.99
SSH connection timeout : 60 seconds
SSH Authentication retries : 3 times
SFTP Server: Enable
```

Display the session information about the SSH server.

```
<S5500> system-view
[S5500] display ssh server session
Conn Ver Encry State Retry Username
VTY 0 2.0 AES started 0 1
```

**View** This command can be used in the following views:

- Any view

**Description**  **CAUTION:** Users using SecureCRT as the client side software will fail to log onto a switch if they check the Enable OpenSSH agent forwarding option.

**Related Commands**

- `ssh server authentication-retries`
- `ssh server timeout`

# display ssh server-info

---

**Purpose** Use the **display ssh server-info** command to display the association between the server public keys configured on the client and the servers.

**Syntax** `display ssh server-info`

**Parameters** None

**Example** Display the association between the server public keys and the servers.

```
[S5500] display ssh server-info
Server Name (IP) Server public key name

192.168.0.1 abc_key01
192.168.0.2 abc_key02
```

**View** This command can be used in the following views:

- Any view



# display ssh-server source-ip

---

|                   |                                                                                                                                                                     |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | Use the <b>display ssh-server source-ip</b> command to display the source IP address of the SSH server. If no source IP address is specified, 0.0.0.0 is displayed. |
| <b>Syntax</b>     | <code>display ssh-server source-ip</code>                                                                                                                           |
| <b>Parameters</b> | None                                                                                                                                                                |
| <b>Example</b>    | Display the source IP address of the SSH server.<br><br><pre>&lt;S5500&gt; display ssh-server source-ip<br/>The source IP you specified is 192.168.1.1</pre>        |
| <b>View</b>       | This command can be used in the following views: <ul style="list-style-type: none"><li>■ Any view</li></ul>                                                         |

# display ssh user-information

---

**Purpose** Use the **display ssh user-information** command to display information about the current SSH users, including user name, authentication mode, key name and authorized service types. If the **username** is specified, the command displays information about the specified user.

**Syntax** `display ssh user-information [ username ]`

**Parameters** **username** SSH user name, consisting of a string 1 to 80 characters long.

**Example** Display information about the current user.

```
<S5500> display ssh user-information
Username Authentication-type User-public-key-name
Service-type
kj rsa null stelnet|sftp
```

**View** This command can be used in the following views:

- Any view

**Related Commands**

- `ssh user assign rsa-key`
- `ssh user service-type`
- `ssh user username authentication-type`

# display ssh2 source-ip

---

|                   |                                                                                                                                                                |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | Use the <b>display ssh2 source-ip</b> command to display the source IP address of the SSH2 client. If no source IP address is specified, 0.0.0.0 is displayed. |
| <b>Syntax</b>     | <code>display ssh2 source-ip</code>                                                                                                                            |
| <b>Parameters</b> | None                                                                                                                                                           |
| <b>Example</b>    | Display the source IP address of the SSH2 client.<br><br><pre>&lt;S5500&gt; display ssh2 source-ip<br/>The source IP you specified is 192.168.0.1</pre>        |
| <b>View</b>       | This command can be used in the following views: <ul style="list-style-type: none"><li>■ Any view</li></ul>                                                    |

# display startup

---

|                        |                                                                                                                                                                                                                                                                                                                                                                                                       |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>         | Use the <b>display startup</b> command to display the information about the startup configuration files on one switch or all switches in the fabric, including the names of the currently used, the to-be-used main and backup startup configuration files.                                                                                                                                           |
| <b>Syntax</b>          | <code>display startup [ unit <i>unit-id</i> ]</code>                                                                                                                                                                                                                                                                                                                                                  |
| <b>Parameters</b>      | <code>unit <i>unit-id</i></code> Unit ID of a switch.                                                                                                                                                                                                                                                                                                                                                 |
| <b>Example</b>         | Display the information about the startup configuration files on unit 1 in the fabric.<br><br><pre>&lt;S5500&gt; display startup unit 1 MainBoard:   Current Startup saved-configuration file:      NULL   Next main startup saved-configuration file:   flash:/123.cfg   Next backup startup saved-configuration file: flash:/back.cfg   Bootrom-access enable state:                  enabled</pre> |
| <b>View</b>            | This command can be used in the following views: <ul style="list-style-type: none"><li>■ Any view</li></ul>                                                                                                                                                                                                                                                                                           |
| <b>Description</b>     | Executing the <b>display startup</b> command without <b>unit <i>unit-id</i></b> will display the settings in the whole fabric.                                                                                                                                                                                                                                                                        |
| <b>Related Command</b> | <code>startup saved-configuration</code>                                                                                                                                                                                                                                                                                                                                                              |

# display stop-accounting buffer

---

**Purpose** Use the **display stop-accounting-buffer** command to view information on the stop-accounting requests buffered in the switch.

**Syntax** `display stop-accounting-buffer hwtacacs-scheme hwtacacs-scheme-name`

**Parameters**

|                                     |                                                                                                                                                                                                                     |
|-------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>hwtacacs-scheme</code>        |                                                                                                                                                                                                                     |
| <code>hwtacacs-scheme-name</code> : | Displays information on buffered stop-accounting requests related to the HWTACACS scheme specified by <i>hwtacacs-scheme-name</i> . Valid values are a character string not exceeding 32 characters, excluding "?". |

**Example** Display information on the buffered stop-accounting requests related to the HWTACACS scheme "3Com".

```
<S5500> display stop-accounting-buffer hwtacacs-scheme 3Com
```

**View** This command can be used in the following views:

- Any view

**Related Commands**

- `reset stop-accounting-buffer`
- `retry stop-accounting`
- `stop-accounting-buffer enable`

# display stp

---

## Purpose

Use the **display stp** command to display the status and statistics of specified spanning trees, and hereby analyze and maintain the topology of a network and to make MSTP operate properly.

## Syntax

```
display stp [instance instance-id] [interface interface-list | slot slot-number] [brief]
```

## Parameters

|                                |                                                                                                                                                                                                                                                                                                                                        |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b><i>instance-id</i></b>      | ID of the spanning tree instance. Valid values are 0 to 16. A value of 0 specifies the CIST.                                                                                                                                                                                                                                           |
| <b><i>interface-list</i></b>   | List of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of <i>interface-list</i> = { <i>interface-type interface-number</i> [ to <i>interface-type interface-number</i> ] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument. |
| <b>slot <i>slot-number</i></b> | Specifies the slot whose STP information is to be displayed.                                                                                                                                                                                                                                                                           |
| <b>brief</b>                   | Displays only port status and protection measures taken for the ports.                                                                                                                                                                                                                                                                 |

## Example

Display the status of a spanning tree.

```
<S5500> display stp instance 0 interface Ethernet 1/0/1 to Ethernet 1/0/4 brief
MSTID Port Role STP State Protection
0 Ethernet1/0/1 ALTE DISCARDING LOOP
0 Ethernet1/0/2 DESI FORWARDING NONE
0 Ethernet1/0/3 DESI FORWARDING NONE
0 Ethernet1/0/4 DESI FORWARDING NONE
```

**Table 84** Description on the fields of the display stp command

| Field      | Description                                                   |
|------------|---------------------------------------------------------------|
| MSTID      | ID of the MSTI in the MST region                              |
| Port       | Port number corresponding to the spanning tree instance       |
| Role       | Port role                                                     |
| STP State  | STP state of the port, which can be forwarding or discarding. |
| Protection | Protection type of the port                                   |

## View

This command can be used in the following views:

- Any view

## Description

The information displayed by this command depends on what parameters you specify:

- With neither spanning tree instance nor port lists specified: spanning tree information about all spanning tree instances on all ports is displayed by port number.
- With only the spanning tree instance specified: information about the spanning tree instance on all ports is displayed by port number.
- With only the port lists specified: information about all spanning tree instances on the specified ports is displayed by port number.
- With both spanning tree instance and port lists specified: information about the specified spanning tree instance and the specified ports is displayed by spanning tree instance ID.

MSTP status information includes the following:

- Global CIST parameters: Protocol operation mode, switch priority in the CIST instance, MAC address, Hello time, Max Age, Forward delay, Max hop count, the common root bridge of the CIST, the external path cost for the switch to reach the CIST common root bridge, the region root, the internal path cost for the switch to reach the region root, CIST root port of the switch, and the status of the BPDU protection function (enabled or disabled).
- CIST port parameters: Port protocol, port role, port priority, path cost, the designated bridge, the designated port, edge port/non-edge port, connected/not connected to a point-to-point link, the maximum transmission speed, the type of the root protection feature, VLAN mappings, Hello time, Max age, Forward delay, Message-age time, and Remaining-hops.
- Global MSTI parameters: MSTI ID, bridge priority of the instance, region root, internal path cost, MSTI root port, and Master bridge.
- MSTI port parameters: Port status, role, priority, path cost, the designated bridge, the designated port, and Remaining Hops.

The statistics includes the number of the TCN BPDUs, the configuration BPDUs, the RST BPDUs, and the MST BPDUs transmitted/received by the port.

## Related Command

`reset stp`

# display stp ignored-vlan

---

|                    |                                                                                                                                                          |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>     | Use the <code>display stp ignored-vlan</code> command to view the list of STP-Ignored VLANs.                                                             |
| <b>Syntax</b>      | <code>display stp ignored-vlan</code>                                                                                                                    |
| <b>Parameters</b>  | None                                                                                                                                                     |
| <b>Example</b>     | To display the list of STP-Ignored VLANs, enter the following:<br><br><pre>&lt;SW5500&gt;display stp ignored-vlan STP-Ignored VLAN: 10, 20, 30, 40</pre> |
| <b>View</b>        | This command can be used in the following views: <ul style="list-style-type: none"><li>■ Any view</li></ul>                                              |
| <b>Description</b> | After a STP-Ignored VLAN is configured, the packets of this VLAN will be forwarded on any Switch port, with no restriction from the calculated STP path. |



# display stp region-configuration

---

## Purpose

Use the **display stp region-configuration** command to display the MST region configurations that are effective, including the region name, region revision level, and spanning tree instance-to-VLAN mappings configured for the switch.

## Syntax

```
display stp region-configuration
```

## Parameters

None

## Example

Display the configurations of the MST regions.

```
<S5500> display stp region-configuration
Oper Configuration
 Format selector :0
 Region name :hello
 Revision level :0

 Instance Vlans Mapped
 0 21 to 4094
 1 1 to 10
 2 11 to 20
```

**Table 85** Description on the fields of the display stp region-configuration command

| Field                 | Description                                               |
|-----------------------|-----------------------------------------------------------|
| Format selector       | Selector specified by MSTP                                |
| Region name           | Name of the MST region                                    |
| Revision level        | Revision level of the MST region                          |
| Instance Vlans Mapped | Spanning tree instance-to-VLAN mappings in the MST region |

## View

This command can be used in the following views:

- Any view

## Related Command

```
stp region-configuration
```

# display stp tc

---

|                        |                                                                                                                                                                                                  |
|------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>         | Use the <b>display stp tc</b> command to display the number of topology changes and/or topology change notifications that an active port has received.                                           |
| <b>Syntax</b>          | <b>display stp tc</b>                                                                                                                                                                            |
| <b>Parameters</b>      | None                                                                                                                                                                                             |
| <b>Example</b>         | To display the number of topology changes and/or notifications, enter the following:<br><br><pre>&lt;SW5500&gt;display stp tc<br/>-----Stp port received----- TC-----or----- TCN----count-</pre> |
| <b>View</b>            | This command can be used in the following views: <ul style="list-style-type: none"><li>■ Any view</li></ul>                                                                                      |
| <b>Related Command</b> | <ul style="list-style-type: none"><li>■ <b>reset stp</b></li></ul>                                                                                                                               |

# display tcp statistics

---

**Purpose** Use the `display tcp statistics` command to view the statistics information about TCP packets.

**Syntax** `display tcp statistics`

**Parameters** None

**Example** To view statistics about TCP packets, enter the following:

```
<SW5500>display tcp statistics
Received packets:
Total: 753
packets in sequence: 412 (11032 bytes)
window probe packets: 0, window update packets: 0
checksum error: 0, offset error: 0, short error: 0
duplicate packets: 4 (88 bytes), partially duplicate packets: 5 (7
bytes)
out-of-order packets: 0 (0 bytes)
packets of data after window: 0 (0 bytes)
packets received after close: 0
ACK packets: 481 (8776 bytes)
duplicate ACK packets: 7, too much ACK packets: 0

Sent packets:
Total: 665
urgent packets: 0
control packets: 5 (including 1 RST)
window probe packets: 0, window update packets: 2
data packets: 618 (8770 bytes) data packets retransmitted: 0 (0 bytes)
ACK-only packets: 40 (28 delayed)

Retransmitted timeout: 0, connections dropped in retransmitted timeout:
0
Keepalive timeout: 0, keepalive probe: 0, Keepalive timeout, so
connections disconnected : 0
Initiated connections: 0, accepted connections: 0, established
connections: 0
Closed connections: 0 (dropped: 0, initiated dropped: 0)
Packets dropped with MD5 authentication: 0
Packets permitted with MD5 authentication: 0
```

**View** This command can be used in the following views:

- Any view

**Description** The statistics information about TCP packets are divided into two major kinds which are Received packets and Sent packets. Each kind of packet is further divided into different kinds such as window probe packets, window update packets, duplicate

packets, and out-of-order packets. Some statistics information that is closely related to TCP connection, such as window probe packets, window update packets, and data packets retransmitted, is also displayed. All of this displayed information is measured in packets.

## **Related Commands**

- `display tcp status`
- `reset tcp statistics`

# display tcp status

---

**Purpose** Use the `display tcp status` command to view the TCP connection state.

**Syntax** `display tcp status`

**Parameters** None

**Example** To display the state of all TCP connections, enter the following:

```
<SW5500>display tcp status
TCPCB Local Add:portForeign Add:portState
03e37dc4 0.0.0.0:40010.0.0.0:0Listening
04217174 100.0.0.204:23100.0.0.253:65508EstablishedOutput
```

**Table 86** Output Description of the display tcp status command

| Field            | Description                    |
|------------------|--------------------------------|
| Local Add:port   | Local IP address: local port   |
| Foreign Add:port | Remote IP address; remote port |
| State            | State of the TCP link          |

**View** This command can be used in the following views:

- Any view

# display telnet-server source-ip

---

|                   |                                                                                                                                                                           |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | Use the <b>display telnet-server source-ip</b> command to display the source IP address of the Telnet server. If no source IP address is specified, 0.0.0.0 is displayed. |
| <b>Syntax</b>     | <code>display telnet-server source-ip</code>                                                                                                                              |
| <b>Parameters</b> | None                                                                                                                                                                      |
| <b>Example</b>    | Display the source IP address of the Telnet server.<br><br><pre>&lt;S5500&gt; display telnet-server source-ip<br/>The source IP you specified is 192.168.1.1</pre>        |
| <b>View</b>       | This command can be used in the following views: <ul style="list-style-type: none"><li>■ Any view</li></ul>                                                               |

# display tftp source-ip

---

**Purpose** Use the **display tftp source-ip** command to display the source IP address of the TFTP client. If no source IP address is specified, 0.0.0.0 is displayed.

**Syntax** `display tftp source-ip`

**Parameters** None

**Example** Display the source IP address of the TFTP client.

```
<S5500> system-view
[S5500] display tftp source-ip
The source IP you specify is 192.168.0.1
```

**View** This command can be used in the following views:

- Any view

# display this

---

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>     | Use the <b>display this</b> command to display the running configurations in the current view of the system.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Syntax</b>      | <b>display this</b> [ by-linenum ]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Parameters</b>  | <b>by-linenum</b> Displays the number of each line.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Example</b>     | <p>Display the running configuration parameters in the current view of the system with each line number.</p> <pre>&lt;S5500&gt; display this by-linenum   1: #   2: interface GigabitEthernet1/0/3   3:  voice vlan enable   4:  mirroring-group 2 mirroring-port inbound   5: #   6: return</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>View</b>        | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ Any view</li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Description</b> | <p>After performing a group of configurations in a view, you can use the <b>display this</b> command to verify the configuration results by checking the currently valid parameters.</p> <ul style="list-style-type: none"><li>■ This command will not display the currently valid configuration parameters which have the same values with the corresponding default working parameters.</li><li>■ This command will not display the parameters whose corresponding functions do not take effect even though these parameters have been configured.</li><li>■ Executing this command in different interface views will display the configurations on the corresponding interfaces.</li><li>■ Executing this command in different protocol views will display the configurations in the corresponding protocol views.</li><li>■ Executing this command in different protocol sub-views will display the configurations in the corresponding protocol sub-views.</li></ul> |



# display time-range

---

**Purpose** Use the `display time-range` command to view the configuration and status of the current time range. You will see the active or inactive state outputs respectively.

**Syntax** `display time-range { all | name }`

**Parameters**

|                   |                                                                                                                                                   |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>all</code>  | Displays all the time-range.                                                                                                                      |
| <code>name</code> | Specifies the name of the time range. Valid values are a character string that starts with a letter (a-z or A-Z), and is 1 to 32 characters long. |

**Example** Display all the time ranges.


```
<SW5500>display time-range all
Current time is 14:36:36 Apr/1/2000 Thursday

Time-range : hhy (Inactive)
 from 08:30 2-5-2005 to 18:00 2-19-2005

Time-range : hhy1 (Inactive)
 from 08:30 2-5-2003 to 18:00 2-19-2003
```

**View** This command can be used in the following views:

- Any view

**Description**  *The system has a delay of about 1 minute when updating the ACL state, while the `display time-range` command applies the current time. Therefore when `display time-range` displays that a time range is active, the ACL using it may not have been activated yet.*

**Related Command** `time-range`

# display transceiver-information interface

---

## Purpose

Use the **display transceiver-information interface** command to display information about a specified optical port, including:

- Hardware type
- Interface type
- Wavelength
- Vender
- Serial number
- Transfer distance

## Syntax

```
display transceiver-information interface interface-type
interface-number
```

## Parameters

|                         |              |
|-------------------------|--------------|
| <i>interface-type</i>   | Port type.   |
| <i>interface-number</i> | Port number. |

## Example

Display information about the GigabitEthernet1/0/1 optical port.

```
<S5500> display transceiver-information interface GigabitEthernet 1/0/1
Hardware Type : -
Interface Type : SFP
Wave Length(nm) : -
Vender Name : Infineon
Serial Number : 36876794
Transfer Distance (m)
 9um Fiber : 0
 50um Fiber : 500
 62.5um Fiber : 300
 Copper Line : 0
```

## View

This command can be used in the following views:

- Any view

# display trapbuffer

---

**Purpose** Use the **display trapbuffer** command to display the status of the trap buffer and the records in the trap buffer.

**Syntax** `display trapbuffer [ unit unit-id ] [ size buffersize ]`

|                   |                   |                                                                                                                                              |
|-------------------|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | <b>unit-id</b>    | Unit ID.                                                                                                                                     |
|                   | <b>size</b>       | Specifies the size of the trap buffer.                                                                                                       |
|                   | <b>buffersize</b> | Size of the memory buffer, represented by the number of messages it holds. Valid values are 1 to 1024. If not specified, the default is 256. |

**Example** Display the status of the trap buffer and the records in the trap buffer.

```
<S5500> display trapbuffer
Trapping Buffer Configuration and contents:
enabled
allowed max buffer size : 1024
actual buffer size : 256
channel number : 3 , channel name : trapbuffer
dropped messages : 0
overwrote messages : 0
current messages : 6

#Dec 31 14:01:25 2004 S5500 DEV/2/LOAD FINISHED:
 Trap 1.3.6.1.4.1.2011.2.23.1.12.1.20: frameIndex is 0, slotIndex 0.4

#Dec 31 14:01:33 2004 S5500 DEV/2/BOARD STATE CHANGE TO NORMAL:
 Trap 1.3.6.1.4.1.2011.2.23.1.12.1.11: frameIndex is 0, slotIndex 0.2

#Dec 31 14:01:40 2004 S5500 DEV/2/BOARD STATE CHANGE TO NORMAL:
 Trap 1.3.6.1.4.1.2011.2.23.1.12.1.11: frameIndex is 0, slotIndex 0.
.....
```

**View** This command can be used in the following views:

- Any view

**Description** Executing the command with the size buffersize parameters will display the latest trap records, with the number of the records being the specified size at most.

# display udp-helper server

---

- Purpose** Use the `display udp-helper server` command to view the information of destination Helper server corresponding to the VLAN interface.
- Syntax** `display udp-helper server [ interface vlan-interface vlan_id ]`
- Parameters** *vlan\_id* VLAN interface ID.
- Example** To display the information of destination Helper server corresponding to the VLAN interface 1, enter the following:
- ```
<SW5500>display udp-helper server interface vlan-interface 1
interface name  server addresspackets sent
VLAN-interface1 192.1.1.20
```
- View** This command can be used in the following views:
- Any view

display udp statistics

Purpose Use the `display udp statistics` command to view UDP traffic statistic information.

Syntax `display udp statistics`

Parameters None

Example To display the UDP traffic statistic information, enter the following:

```
<SW5500>display udp statistics
Received packet:
Total:0
checksum error:0
shorter than header:0, data length larger than packet:0
no socket on port:0
broadcast:0
not delivered, input socket full:0
input packets missing pcb cache:0
Sent packet:
Total:0
```

View This command can be used in the following views:

- Any view

Related Command `reset udp statistics`

display unit

Purpose Using `display unit unit-id interface` command, you can view all port interfaces for the specified unit.

Syntax `display unit unit-id interface`

Parameters `unit-id` Specifies Unit ID. Valid values are 1 to 8.

Example Display the port information for all ports on Unit 1.

```
<SW5500>display unit 1 interface
Aux1/0/0 current state :DOWN
Line protocol current state :DOWN
Internet protocol processing : disabled
Description : Aux1/0/0 Interface
The Maximum Transmit Unit is 1500
Data drive mode: interactive
    5 minutes input rate 0.0 bytes/sec, 0.0 packets/sec
    5 minutes output rate 0.0 bytes/sec, 0.0 packets/sec
    0 packets input, 1000 bytes
    0 packets output, 27317 bytes
    error: Parity 0, Frame 0, Overrun 0, FIFO 0
DCD=UP DTR=UP DSR=UP RTS=UP CTS=UP
Ethernet1/0/1 current state : DOWN
IP Sending Frames' Format is PKTFMT_ETHNT_2, Hardware address is
00e0-fc00-5500
(Omitted)
```

View This command can be used in the following views:

- Any view

display user-interface

Purpose Use the `display user-interface` command to view information on a user interface.

Syntax `display user-interface [type number | number] [summary]`

Parameters

- `type number` Specifies the type and number of the user interface you want to display details on, for example VTY 3.
- `number` Specifies the index number of the user interface you want to display details on.
- `summary` Displays the summary of a user interface.

Example To display information on a user interface with an index number of 0, enter the following.

```
<SW5500>display user-interface aux 0
```

The information is displayed in the following format:

```
Idx  Type      Tx/Rx      Modem Privi Auth  Int
  0   AUX 0    19200      -    3    P    -

+      : Current user-interface is active.
F      : Current user-interface is active and work in async mode.
Idx    : Absolute index of user-interface.
Type   : Type and relative index of user-interface.
Privi  : The privilege of user-interface.
Auth   : The authentication mode of user-interface.
Int    : The physical location of UIs.
A      : Authentication use AAA.
N      : Current UI need not authentication.
P      : Authentication use current UI's password.
```

Table 87 Output description of the display user-interface command

Field	Description
+	Indicates that the user interface is in use
F	Current user interface is in use and working in asynchronous mode
Idx	Displays the index number of the user interface
Type	Displays the type and type number of the user interface
Tx/Rx	Displays the user interface speed
Modem	Displays the modem operation mode
Privi	Indicates the command level that can be accessed from this user interface
Auth	Indicates the user interface authentication method
Int	Indicates the physical location of the user interface

Display the summary information of user interface 0.

```
<SW5500>display user-interface 0 summary
0: U

1 character mode users.      (U)
1 total UIs in use.
UI's name: aux0
```

Table 88 Output Description of the display user-interface summary command

Field	Description
0: U	User interface type
1 character mode users	One type of user interface
1 total UIs in use	The total number of user interfaces in use
UI's name	User interface name

View

This command can be used in the following views:

- Any view

Description

You can choose to access this information by user interface type and type number, or by user interface index number. The information displayed is the same whichever access method you use.

This command without the *summary* parameter displays user interface type, absolute/relative index, transmission speed, priority, authentication methods, and physical location. This command with the *summary* parameter displays one user interface in use with user interface name and other user interface information.

display users

Purpose Use the `display users` command to view information on the current user interface. Use the `display users all` command to view the information on all user interfaces.

Syntax `display users [all]`

Parameters `all` Displays information on all user interfaces.

Example To display information on the current user interface, enter the following

```
[SW5500]display users
The information displays in the following format:
      UI      DelayTypeIPAddressUsernameUserlevel
F 0 AUX 0      00:00:003
```

The categories of information displayed are as follows:

Table 89 Output description of the display users command

Field	Description
F	Indicates that the user interface is in use and is working in asynchronous mode
UI	Number of the first list is the absolute number of user interface. Number of the second list is the relative number of user interface
Delay	Indicates the interval from the latest input until now, in seconds.
Type	Indicates the user interface type.
IPAddress	Displays initial connection location, namely the host IP address of the incoming connection.
Username	Display the login name of the user who is using this interface
Userlevel	Display the level of the user using this user interface

View This command can be used in the following views:

- Any view

display version

Purpose	Use the display version command to view the software version, issue date and the basic hardware configuration information.
Syntax	<code>display version</code>
Parameters	None
Description	Display the information about the system version. <SW5500>display version
View	This command can be used in the following views: <ul style="list-style-type: none">■ Any view

display vlan

Purpose

Use the **display vlan** command to display the ports operating in the manual/automatic mode in the current voice VLAN.

Syntax

```
display vlan vlan-id
```

Parameters

vlan-id

Voice VLAN ID. Valid values are 1 to 4,094.

Example

Display the ports included in the current voice VLAN, assuming that the current voice VLAN is VLAN 6.

```
<S5500> dis vlan 6
VLAN ID: 6
VLAN Type: static
Route Interface: not configured
Description: VLAN 0006
Name: VLAN 0006
Tagged Ports:
  Ethernet1/0/5
Untagged Ports:
  Ethernet1/0/6
```

The output indicates that Ethernet1/0/5 and Ethernet1/0/6 ports are in the current voice VLAN.

View

This command can be used in the following views:

- Any view

Related Command

```
voice vlan enable
```

display vlan

Purpose

Use the **display vlan** command to view related information about specific VLANs, specific types of VLAN or all VLANs.

Use the command **display vlan *vlan_id*** to display information on a specific VLAN.

Use the command **display vlan all** to display information on all the VLANs.

Use the command **display vlan dynamic** to display information on VLANs created dynamically by the system.

Use the command **display vlan static** to display information of VLAN created statically by the system.

Syntax

```
display vlan [ vlan_id | all | static | dynamic ]
```

Parameters

<i>vlan_id</i>	Displays information on a specified VLAN.
all	Displays information on all VLANs.
static	Displays information on VLANs created statically by the system.
dynamic	Displays information on VLANs created dynamically by the system.

Example

To display information about VLAN 1:

```
<SW5500>display vlan 1
VLAN ID: 1
VLAN Type: static
Route Interface: configured
IP Address: 161.71.61.206
Subnet Mask: 255.255.255.0
Description: VLAN 0001
Tagged Ports:
  GigabitEthernet1/0/52 GigabitEthernet2/0/27
Untagged Ports:
  Ethernet1/0/1      Ethernet1/0/2      Ethernet1/0/3
  Ethernet1/0/4      Ethernet1/0/5      Ethernet1/0/6
  Ethernet1/0/7      Ethernet1/0/8      Ethernet1/0/9
  Ethernet1/0/10     Ethernet1/0/11     Ethernet1/0/12
  Ethernet1/0/13     Ethernet1/0/14     Ethernet1/0/15
  Ethernet1/0/16     Ethernet1/0/17     Ethernet1/0/18
  Ethernet1/0/19     Ethernet1/0/20     Ethernet1/0/21
  Ethernet1/0/22     Ethernet1/0/23     Ethernet1/0/24
  Ethernet1/0/25     Ethernet1/0/26     Ethernet1/0/27
  Ethernet1/0/28     Ethernet1/0/29     Ethernet1/0/30
  Ethernet1/0/31     Ethernet1/0/32     Ethernet1/0/33
  Ethernet1/0/34     Ethernet1/0/35     Ethernet1/0/36
  Ethernet1/0/37     Ethernet1/0/38     Ethernet1/0/39
  Ethernet1/0/40     Ethernet1/0/41     Ethernet1/0/42
```

```
Ethernet1/0/43      Ethernet1/0/44      Ethernet1/0/45
Ethernet1/0/46      Ethernet1/0/47      Ethernet1/0/48
GigabitEthernet1/0/50 GigabitEthernet1/0/51 Ethernet2/0/1
Ethernet2/0/2       Ethernet2/0/3       Ethernet2/0/4
Ethernet2/0/5       Ethernet2/0/6       Ethernet2/0/7
Ethernet2/0/8       Ethernet2/0/9       Ethernet2/0/10
Ethernet2/0/11      Ethernet2/0/12      Ethernet2/0/13
Ethernet2/0/14      Ethernet2/0/15      Ethernet2/0/16
Ethernet2/0/17      Ethernet2/0/18      Ethernet2/0/19
Ethernet2/0/20      Ethernet2/0/21      Ethernet2/0/22
Ethernet2/0/23      Ethernet2/0/24      GigabitEthernet2/0/25
GigabitEthernet2/0/26 GigabitEthernet2/0/28
```

<SW5500>

View

This command can be used in the following views:

- Any view

Description

The information includes: VLAN type, whether the Route interface has been configured on the VLAN, the Broadcast Suppression max-ratio, the VLAN description, and a list of the tagged and untagged ports that belong to the VLAN.

Related Command

vlan

display voice vlan oui

Purpose Use the **display voice vlan oui** command to display the OUI address supported by the current system and its relative features.

Syntax `display voice vlan oui`

Parameters None

Example To display the OUI address of Voice VLAN, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]display voice vlan oui
Oui Address          Mask                Description
00e0-bb00-0000      ffff-ff00-0000    3com phone
0003-6b00-0000      ffff-ff00-0000    Cisco phone
00e0-7500-0000      ffff-ff00-0000    Polycom phone
00d0-1e00-0000      ffff-ff00-0000    Pingtel phone
00aa-bb00-0000      ffff-ff00-0000    ABC
```

View This command can be used in the following views:

- Any view

Related Command ■ `voice vlan enable`

display voice vlan status

Purpose Use the `display voice vlan status` command to display the relative Voice VLAN features including the Voice VLAN status, the configuration mode, or the current Voice VLAN port status.

Syntax `display voice vlan status`

Parameters None

Example To enable the Voice VLAN on VLAN 2 and display the Voice VLAN status, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]display voice vlan status
Voice Vlan status: ENABLE
Voice Vlan ID: 2
Voice Vlan configuration mode: AUTO
Voice Vlan security mode: Security
Voice Vlan aging time: 100 minutes
Current voice vlan enabled port:
-----
Ethernet1/0/2, Ethernet1/0/3,
```

View This command can be used in the following views:

- Any view

Related Command ■ `voice vlan enable`

display vrrp

Purpose

Use the **display vrrp** command to display the information about the VRRP state or VRRP statistics.

Syntax

```
display vrrp [ interface vlan-interface valn-id | statistics [
vlan-interface vlan-id ] ] [ virtual-router-ID ]
```

Parameters

interface	Displays VRRP information about the specified VLAN interface.
vlan-interface <i>vlan-id</i>	Specifies a VLAN interface ID.
statistics	Displays VRRP statistics.
virtual-router-ID	VRRP backup group ID. Valid values are 1 to 255.

Example

Display the statistics about all the backup groups on the switch.

```
<S5500> display vrrp statistics
Interface           : Vlan-interface10
VRID                : 1
Checksum Errors    : 0           Version Errors           : 0
VRID Errors        : 0           Advertisement Interval Errors : 0
IP TTL Errors      : 0           Auth Failures            : 0
Invalid Auth Type  : 0           Auth Type Mismatch       : 0
Packet Length Errors : 0       Address List Errors       : 0
Become Master      : 2           Priority Zero Pkts Rcvd   : 0
Advertise Rcvd     : 0           Priority Zero Pkts Sent   : 1
Invalid Type Pkts Rcvd : 0
```

Table 90 Description on the fields of the display vrrp command

Field	Description
Interface	Interface in which the backup group resides
VRID	Backup group ID
Checksum Errors	Times of checksum error
Version Errors	Times of version error
VRID Errors	Times of backup group ID error
Advertisement Interval Errors	Times of advertisement time interval error
IP TTL Errors	Times of TTL error
Auth Failures	Times of authentication error
Invalid Auth Type	Times of invalid authentication type
Auth Type Mismatch	Mismatched times of authentication type
Packet Length Errors	Times of VRRP packet length error
Address List Errors	Times of the virtual IP address list error
Become Master	Times of becoming a master
Priority Zero Pkts Rcvd	Number of the received advertisement packets with the priority of 0
Advertise Rcvd	Number of the received advertisement packets
Priority Zero Pkts Sent	Number of the sent advertisement packets with the priority of 0

Table 90 Description on the fields of the display vrrp command (continued)

Field	Description
Invalid Type Pkts Rcvd	Times of packet type error

View

This command can be used in the following views:

- Any view

Description

When VRRP status information is displayed:

- If the interface index and backup group ID are not specified, the state information about all the backup groups on the switch is displayed.
- If only the interface index is specified, the state information about all the backup groups on the interface is displayed.
- If both the interface index and backup group ID are specified, the state information about the specified backup group on the interface is displayed.

When VRRP statistics information is displayed:

- If the interface index and backup group ID are not specified, the statistics about all the backup groups on the switch is displayed.
- If only the interface index is specified, the statistics about all the backup groups on the interface is displayed.
- If both the interface index and backup group ID are specified, the statistics about the specified backup group on the interface is displayed.

display webcache

Purpose	Use the <code>display webcache</code> command to view the configuration of parameters for Webcache redirection and whether the webcache is accessible.
Syntax	<code>display webcache</code>
Parameters	None
Example	<p>To display the configuration of parameters for Webcache redirection and webcache status, enter the following:</p> <pre>[SW5500] display webcache webcache IP address: 1.1.1.1 webcache MAC address: 00e0-fc00-0000 webcache port: Ethernet1/0/1 webcache VLAN: 1 webcache TCP port: 80 webcache redirect VLAN: VLAN 2 Valid webcache exclusion lists: 2.2.2.2 255.255.0.0 webcache status: accessible</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ Any view

display xrn-fabric

Purpose Use the `display xrn-fabric` command to view the information of the entire fabric, including unit ID, unit name, operation mode.

Syntax `display xrn-fabric [port]`

Parameters `port` Displays the Fabric port information.

Example To display fabric information, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]display xrn-fabric ?
  port  Display the fabric port information
<cr>

[SW5500]display xrn-fabric
Fabric name is SW5500 , system mode is L3.
Fabric authentication: no authentication, unit number: 1.
Unit Name                               Unit ID
SW5500  1(*)
```

View This command can be used in the following views:

- Any view

Description An asterisk (*) is used to indicate which unit you have connected to via a console connection.

dldp

Purpose

Use the **dldp** command to either enable or disable the DLDP on either all the optical switches or current switch.

In System view, use the **dldp** command to either enable or disable the DLDP globally on all optical ports of the switch.

In Ethernet Port view, use the **dldp** command to enable or disable the DLDP on the current port.

Syntax

```
dldp { enable | disable }
```

Parameters

None

Default

By default, DLDP is disabled.



When you use the `dldp enable/dldp disable` command in System view to enable/disable DLDP globally on all optical ports of the switch, this command is valid only for the existing optical ports on the device. It is not valid for those added subsequently.

Example

Enable DLDP globally on all optical ports of the switch.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] dldp enable
All fiber ports except fabric ports have enabled DLDP!
```

View

This command can be used in the following views:

- System view
- Ethernet Port view

Description

In system view:


- Use the **dldp enable** command to enable DLDP globally on all optical ports of the switch.
- Use the **dldp disable** command to disable DLDP globally on all optical ports of the switch.

In Ethernet port view:

- Use the **dldp enable** command to enable DLDP on the current port.
- Use the **dldp disable** command to disable DLDP on the current port.

The commands can apply to a non-optical port as well as an optical port.

dldp authentication-mode

Purpose	Use the dldp authentication-mode command to set the DLDP authentication mode and password for the ports of the local and peer devices.	
Syntax	<pre>dldp authentication-mode { none simple <i>password</i> md5 <i>password</i> } undo dldp authentication-mode</pre>	
Parameters	md5	Sets the authentication mode to MD5.
	none	Performs no authentication.
	simple	Sets the authentication mode to plain text.
	<i>password</i>	Authentication password, consisting of a string in plain text 1 to 16 characters long.
Example	<p>Set the DLDP authentication mode and password for the ports connected with fiber cables or copper twisted pairs, between the two devices (S5500A and S5500B) to plain text and password1 respectively.</p> <ul style="list-style-type: none"> ■ Configure S5500A: <pre><S5500A> system-view System View: return to User View with Ctrl+Z. [S5500A] dldp authentication-mode simple password1</pre> ■ Configure S5500B: <pre><S5500B> system-view System View: return to User View with Ctrl+Z. [S5500B] dldp authentication-mode simple password1</pre> 	
View	This command can be used in the following views: <ul style="list-style-type: none"> ■ System view 	
Description	By default, authentication mode is none.	
		<i>When you configure the DLDP authentication mode and authentication password, make sure the same DLDP authentication mode and password are set for the ports of the local and peer devices, which are connected with the optical fiber cable or copper twisted pair. Otherwise, DLDP authentication fails. DLDP cannot work when DLDP authentication fails.</i>
Related Command	dldp unidirectional-shutdown	

dldp interval

Purpose

Use the **dldp interval** command to set the time interval for sending advertisement packets.

Use the **undo dldp interval** command to restore the default time interval.

Syntax

```
dldp interval integer
```

```
undo dldp interval
```

Parameters

integer

Time interval for sending DLDP frames. Valid values are 5 to 100 seconds.
If not specified, the default time interval is 10 seconds.

Example

Set the time interval for sending advertisement packets to 20 seconds.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] dldp interval 20
```

View

This command can be used in the following views:

- System view

Description

For any port where DLDP is enabled, when DLDP is in advertisement state, it sends advertisement packets through the port at the intervals of this value.



Note:

- The time interval you define applies to all ports with DLDP enabled.
- The time interval should be shorter than one-third of the STP convergence time, which is generally 30 seconds. If too long time interval is set, an STP loop may occur before DLDP shut down unidirectional links. On the contrary, if too short time interval is set, network traffic increases, and port bandwidth is reduced.

dldp reset

Purpose

Use the **dldp reset** command to reset the DLDP status of either the current port or all the ports disabled by DLDP.

In System view, use the **dldp reset** command to reset the DLDP status of all the ports disabled by DLDP.

In Ethernet Port view, use the **dldp reset** command to reset the DLDP status of the current port disabled by DLDP.

Syntax

```
dldp reset
```

Parameters

None

Example

Reset the DLDP status of all the ports disabled by DLDP.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] dldp reset
```

View

This command can be used in the following views:

- System view
- Ethernet Port view

Description

After the **dldp reset** command is executed, the DLDP status of these ports changes from disable to active and DLDP restarts to probe the link status of the fiber cables or copper twisted pairs.

Related Commands

- **dldp**
- **dldp unidirectional-shutdown**

dldp unidirectional-shutdown

Purpose

Use the **dldp unidirectional-shutdown** command to set DLDAP handling mode when a unidirectional link is found.

Use the **undo dldp unidirectional-shutdown** command to restore the default setting.

Syntax

```
dldp unidirectional-shutdown { auto | manual }
```

```
undo dldp unidirectional-shutdown
```

Parameters

auto	In this mode, when DLDAP finds a unidirectional link or finds (in the enhanced mode) that the peer end is down, it automatically disables the corresponding port. If no handling mode is specified, auto is the default mode used.
manual	In this mode, when DLDAP finds an unidirectional link or finds (in the enhanced mode) that the peer end is down, instead of disabling the port automatically, it stops the DLDAP packets sending/receiving on the port and prompts the user to disable the port manually.

Example

Configure DLDAP to automatically disable the corresponding port when a unidirectional link is found.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] dldp unidirectional-shutdown auto
```

View

This command can be used in the following views:

- System view

Related Command

dldp work-mode

dldp work-mode

Purpose

Use the **dldp work-mode** command to set the DLDP operating mode.

Use the **undo dldp work-mode** command to restore the default DLDP operating mode.

Syntax

```
dldp work-mode { enhance | normal }
```

```
undo dldp work-mode
```

Parameters

enhance

Configures the DLDP to work in enhanced mode. In this mode, DLDP probes actively whether neighbors exist when neighbor entries age out.

normal

Configures the DLDP to work in normal mode. In this mode, DLDP does not probe actively whether neighbors exist when neighbor entries age out. If no mode is specified, normal is the default mode used.

Example

Configure DLDP to work in enhanced mode.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] dldp work-mode enhance
```

View

This command can be used in the following views:

- System view

dns-list

Purpose

Use the **dns-list** command to configure one or multiple DNS server IP addresses for a global DHCP address pool.

Use the **undo dns-list** command to remove one or all DNS server IP addresses configured for the DHCP address pool.

Syntax

```
dns-list ip-address&<1-8>
```

```
undo dns-list { ip-address | all }
```

Parameters

ip-address&<1-8>

IP address of a DNS server. &<1-8> string means you can provide up to eight DNS server IP addresses. When inputting more than one IP address, separate two neighboring IP addresses with a space.

all

Specifies all configured DNS server IP addresses.

Default

By default, no DNS server IP address is configured.

Example

Enter system view.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.
```

Configure the DNS server IP address 1.1.1.254 for global DHCP address pool 0.

```
[S5500] dhcp server ip-pool 0  
[S5500-dhcp-pool-0] dns-list 1.1.1.254
```

View

This command can be used in the following views:

- DHCP Address Pool view

Description

If you execute the dns-list command repeatedly, the new configuration overwrites the previous one.



This command applies only to the S5500-EI series among Switch 5500-Series Switches.

Related Commands

- **dhcp server dns-list**
- **dhcp server ip-pool**

domain

Purpose Use the `domain` command to configure an ISP domain or enter the view of an existing ISP domain.

Use the `undo domain` command to cancel a specified ISP domain.

Syntax

```
domain { isp-name | default { disable | enable isp-name }}
undo domain isp-name
```

Parameters

<code><i>isp-name</i></code>	Specifies an ISP domain name. The name is expressed with a character string not exceeding 24 characters, excluding "/", ":", "*", "?", "<", and ">".
<code>default enable <i>isp-name</i></code>	Enables the default ISP domain specified by <i>isp-name</i> .
<code>default disable</code>	Restores the default ISP domain to <i>system</i> .

Default By default, a domain named *system* has been created in the system. The attributes of *system* are all default values.

Example To create a new ISP domain, marlboro.net, and enters its view, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]domain marlboro.net
New Domain added.
[SW5500-isp-marlboro.net]
```

View This command can be used in the following views:

- System view

Description ISP domain is a group of users belonging to the same ISP. Generally, for a username in the `userid@isp-name` format, taking `gw20010608@3Com163.net` as an example, the *isp-name* (that is, `3Com163.net`) following the `@` is the ISP domain name. When 3Com 5500 Series Ethernet Switches control user access, as for an ISP user whose username is in `userid@isp-name` format, the system will take `userid` part as username for identification and take *isp-name* part as domain name.

The purpose of introducing ISP domain settings is to support the application environment with several ISP domains. In this case, an access device may have supplicants from different ISP domains. Because the attributes of ISP users, such as username and password structures, service types, may be different, it is necessary to separate them by setting ISP domains. In ISP Domain View, you can configure a

complete set of exclusive ISP domain attributes for each ISP domain, which includes AAA schemes (RADIUS scheme applied and so forth.)

For a Switch, each supplicant belongs to an ISP domain. The system supports up to 16 ISP domains. If a user has not reported its ISP domain name, the system will put it into the default domain.

When this command is used, if the specified ISP domain does not exist, the system will create a new ISP domain. All the ISP domains are in the **active** state when they are created.

Related Commands

- **access-limit**
- **display domain**
- **radius-scheme**
- **state**

domain-name

Purpose

Use the **domain-name** command to configure a domain name for the DHCP clients of a global DHCP address pool.

Use the **undo domain-name** command to remove the domain name.

Syntax

```
domain-name domain-name
```

```
undo domain-name
```

Parameters

domain-name

Domain name for the DHCP clients of a global DHCP address pool, consisting of a string from 3 to 50 characters long.

Default

By default, no domain name is configured for the DHCP clients of a global DHCP address pool.

Example

Enter system view.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.
```

Configure the domain name mydomain.com for the DHCP clients of the global DHCP address pool 0.

```
[S5500] dhcp server ip-pool 0  
[S5500-dhcp-pool-0] domain-name mydomain.com
```

View

This command can be used in the following views:

- DHCP Address Pool view

Description



This command applies only to the S5500-EI series among Switch 5500-Series Switches.

Related Commands

- **dhcp server domain-name**
- **dhcp server ip-pool**

dot1x

Purpose

Use the `dot1x` command to enable 802.1x on the specified port or globally, (that is on the current device).

Use the `undo dot1x` command to disable the 802.1x on the specified port or globally.

Syntax

```
dot1x [ interface interface-list ]
```

```
undo dot1x [ interface interface-list ]
```

Parameters

`interface interface-list` Ethernet port list including several Ethernet ports.
`interface-list` = { `interface-num` [to `interface-num`] } & < 1-10 >. `interface-num` specifies a single Ethernet port in the format `interface-num` = { `interface-type interface-num` | `interface-name` }, where `interface-type` specifies the port type, `interface-num` specifies the port number and `interface-name` specifies the port name. For the respective meanings and value ranges, read the parameter of the Port Configuration section.

Default

By default, 802.1x is disabled on all the ports and globally on the device.

Example

To enable 802.1x on Ethernet 1/0/1, enter the following.

```
<SW5500>system-view
System View: return to User View with Ctrl-Z
[SW5500]dot1x interface ethernet 1/0/1
To enable 802.1x globally, enter the following.
[SW5500]dot1x
```

View

This command can be used in the following views:

- Ethernet Port view

Description

This command is used to enable the 802.1x on the current device or on the specified port. When it is used in System View, if the parameter `ports-list` is not specified, 802.1x will be globally enabled. If the parameter `ports-list` is specified, 802.1x will be enabled on the specified port. When this command is used in Ethernet Port View, the parameter `interface-list` cannot be entered and 802.1x can only be enabled on the current port.

The configuration command can be used to configure the global or port 802.1x performance parameters before or after 802.1x is enabled. Before 802.1x is enabled

globally, if the parameters are not configured globally or for a specified port, they will maintain the default values.

After the global 802.1x performance is enabled, only when port 802.1x performance is enabled will the configuration of 802.1x become effective on the port.

Related Command

`display dot1x`

dot1x authentication-method

Purpose

Use the **dot1x authentication-method** command to set 802.1x authentication mode.

Use the **undo dot1x authentication-method** command to revert to the default 802.1x authentication mode.

Syntax

```
dot1x authentication-method { chap | pap | eap }
```

```
undo dot1x authentication-method
```

Parameters

chap

Authenticates supplicant systems using challenge handshake authentication protocol (CHAP). CHAP is a three-way handshake authentication protocol. It has satisfactory security performance and is securer than other authentication modes. With this protocol employed, only usernames are transmitted for supplicant system to be authenticated. If no value is specified, CHAP is the default 802.1x authentication mode.

pap

Authenticates supplicant systems using password authentication protocol (PAP). With this protocol employed, passwords are transmitted in plain text.

eap

Authenticates supplicant systems using extensible authentication protocol (EAP). With this protocol employed, authentication information about supplicant systems is sent to authentication servers in the form of EAP packet. To authenticate supplicant systems using PEAP, EAP-TLS, EAP-TTLS, or EAP-MD5, you can specify the eap keyword.

Example

Enter system view.

```
<S5500> system-view
```

Specify to authenticate supplicant systems using EAP.

```
[S5500] dot1x authentication-method eap
```

View

This command can be used in the following views:

- System view

Related Command

```
display dot1x
```

dot1x authentication-method

Purpose Use the `dot1x authentication-method` command to configure the authentication method for the 802.1x user.

Use the `undo dot1x authentication-method` command to restore the default authentication method of the 802.1x user.

Syntax

```
dot1x authentication-method { chap | pap | eap md5-challenge }
undo dot1x authentication-method
```

Parameters

Chap	Use CHAP authentication method. If no other authentication method is specified, CHAP authentication is used for 802.1x user authentication.
Pap	Use PAP authentication method.
Eap	Use EAP authentication method. At present, only md5 encryption method is available

Example Configure 802.1x user to use PAP authentication

```
<SW5500>system-view
System View: return to User View with Ctrl-Z
[SW5500]dot1x authentication-method pap
```

View This command can be used in the following views:

- System view

Description Password Authentication Protocol (PAP) is a kind of authentication protocol with two handshakes. It sends the password in the form of simple text.

Challenge Handshake Authentication Protocol (CHAP) is a kind of authentication protocol with three handshakes. It only transmits the username, not the password. CHAP is more secure and reliable.

In the process of EAP authentication, the Switch directly sends authentication information of an 802.1x user to a RADIUS server in the form of an EAP packet. It is not necessary to transfer the EAP packet to a standard RADIUS packet first and then send it to RADIUS server.



To use PAP, CHAP or EAP authentication, RADIUS server should support PAP, CHAP or EAP authentication respectively.

Related Command `display dot1x`

dot1x dhcp-launch

Purpose

Use the `dot1x dhcp-launch` command to set 802.1x to prevent the Switch from triggering user ID authentication for users who configure static IP addresses in a DHCP environment.

Use the `undo dot1x dhcp-launch` command to allow the Switch to trigger ID authentication.

Syntax

```
dot1x dhcp-launch
```

```
undo dot1x dhcp-launch
```

Parameters

None

Default

By default, the Switch can trigger user ID authentication for users who configure static IP addresses in a DHCP environment.

Example

Prevent the Switch from triggering the authentication ID for users who configure static IP addresses in a DHCP environment.

```
<SW5500>system-view  
System View: return to User View with Ctrl-Z  
[SW5500]dot1x dhcp-launch
```

View

This command can be used in the following views:

- System view

Related Command

`dot1x`

dot1x guest-vlan

Purpose

Use the **dot1x guest-vlan** command to enable the Guest VLAN function for specified Ethernet ports.

Use the **undo dot1x guest-vlan** command to disable the Guest VLAN function for specified Ethernet ports.

Syntax

```
dot1x guest-vlan vlan-id [ interface interface-list ]
```

```
undo dot1x guest-vlan vlan-id [ interface interface-list ]
```

Parameters

vlan-id

VLAN ID to be assigned to the Guest VLAN. This argument ranges from 1 to 4,094. If not specified, the default is 1.

interface-list

List of Ethernet ports for which the Guest VLAN function is to be enabled. You can specify multiple Ethernet ports by providing this argument in the form of *interface-list = { interface-type interface-number [to interface-type interface-num] } &<1-10>*, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.

Note:



- When being executed in system view, these two commands apply to all ports if you do not provide the *interface-list* argument. If you provide this argument, these two commands apply to the specified ports.
- When being executed in Ethernet port view, these two commands apply to the current port and the *interface-list* argument is not needed.

Example

Enter system view.

```
<S5500> system-view
```

Create VLAN 2.

```
[S5500] vlan 2
```

Enter Ethernet1/0/1 port view.

```
[S5500] interface ethernet1/0/1
```

Configure the port to operate in the port-based authentication mode.

```
[S5500-Ethernet1/0/1] dot1x port-method portbased
```

Configure VLAN 2 to be a Guest VLAN.

```
[S5500-Ethernet1/0/1] dot1x guest-vlan 2
```

View

This command can be used in the following views:

- System view
- Ethernet Port view

Description



CAUTION:

The Guest VLAN function is available only when the switch operates in the port-based authentication mode.

Only one Guest VLAN can be configured for a switch.

Supplicant systems that are not authenticated, fail to pass the authentication, or are offline belong to Guest VLANs.

Before configuring the Guest VLAN function, make sure the VLAN to be specified as the Guest VLAN already exists.

dot1x max-user

Purpose

Use the **dot1x max-user** command to configure a limit to the amount of supplicants on the specified interface using 802.1x.

Use the **undo dot1x max-user** command to restore the default value.

Syntax

```
dot1x max-user user-number [ interface interface-list ]
```

```
undo dot1x max-user [ interface interface-list ]
```

Parameters

user-number Specifies the limit to the amount of supplicants on the port, ranging from 1 to 1024. If not specified, the default maximum user number is 1024.

interface interface-list Ethernet interface list including several Ethernet interfaces, expressed in the format ***interface-list*** = { ***interface-num*** [to ***interface-num***] } & < 1-10 >. ***interface-num*** specifies a single Ethernet interface in the format ***interface-num*** = { ***interface-type interface-num*** | ***interface-name*** }, where ***interface-type*** specifies the interface type, ***interface-num*** specifies the interface number and ***interface-name*** specifies the interface name. For the respective meanings and value ranges, see the parameters in the Port Command chapter.

Example

Configure the interface Ethernet 1/0/2 to hold no more than 32 802.1x users.

```
<SW5500>system-view
System View: return to User View with Ctrl-Z
[SW5500]dot1x max-user 32 interface ethernet 1/0/2
```

View

This command can be used in the following views:

- Ethernet Port view

Description

This command is used for setting a limit to the amount of supplicants that 802.1x can hold on the specified interface. This command takes effect on the interface specified by the parameter ***interface-list*** when executed in System View. It takes effect on all the interfaces when no interface is specified. The parameter ***interface-list*** cannot be entered when the command is executed in Ethernet Port View and it takes effect only on the current interface.

Related Command

display dot1x

dot1x port-control

Purpose

Use the `dot1x port-control` command to configure the mode for 802.1x to perform access control on the specified interface.

Use the `undo dot1x port-control` command to restore the default access control mode.

Syntax

```
dot1x port-control { auto | authorized-force | unauthorized-force } [ interface interface-list ]
```

```
undo dot1x port-control [ interface interface-list ]
```

Parameters

<code>auto</code>	Automatic identification mode, configuring the initial state of the interface as unauthorized. The user is only allowed to receive or transmit EAPoL packets but not to access the network resources. If the user passes the authentication flow, the interface will Switch over to the authorized state and then the user is allowed to access the network resources. If not specified, auto is the default identification mode.
<code>authorized-force</code>	Forced authorized mode, configuring the interface to always stay in authorized state and the user is allowed to access the network resources without authentication/authorization.
<code>unauthorized-force</code>	Forced unauthorized mode, configuring the interface to always stay in non-authorized mode and the user is not allowed to access the network resources.
<code>interface <i>interface-list</i></code>	Ethernet interface list including several Ethernet interfaces, expressed in the format <code><i>interface-list</i> = { <i>interface-num</i> [to <i>interface-num</i>] } &lt; 1-10 ></code> . <code><i>interface-num</i></code> specifies a single Ethernet interface in the format <code><i>interface-num</i> = { <i>interface-type</i> <i>interface-num</i> <i>interface-name</i> }</code> , where <code><i>interface-type</i></code> specifies the interface type, <code><i>interface-num</i></code> specifies the interface number and <code><i>interface-name</i></code> specifies the interface name. For the respective meanings and value ranges, see the parameters of the Port Command chapter.

Example

To configure the interface Ethernet 1/0/2 to be in force-unauthorized state, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl-Z
[SW5500]dot1x port-control force-unauthorized interface ethernet 1/0/2
```

View

This command can be used in the following views:

- Ethernet Port view

Description

This command is used to set the mode, or the interface state, for 802.1x to perform access control on the specified interface. This command has an effect on the interface specified by the parameter *interface-list* when executed in System View. It has an effect on all the interfaces when no interface is specified. The parameter *interface-list* cannot be entered when the command is executed in Ethernet Port View and it has an effect only on the current interface.

Related Command

`display dot1x`

dot1x port-method

Purpose

Use the `dot1x port-method` command to configure the base for 802.1x to perform access control on the specified interface.

Use the `undo dot1x port-method` command to restore the default access control base.

Syntax

```
dot1x port-method { macbased | portbased } [ interface interface-list ]  
undo dot1x port-method [ interface interface-list ]
```

Parameters

<code>macbased</code>	Configures the 802.1x authentication system to perform authentication on the supplicant based on MAC address. If not specified, <code>macbased</code> is the default value used.
<code>portbased</code>	Configures the 802.1x authentication system to perform authentication on the supplicant based on interface number.
<code>interface <i>interface-list</i></code>	Ethernet interface list including several Ethernet interfaces, expressed in the format <code><i>interface-list</i> = { <i>interface-num</i> [to <i>interface-num</i>] } &lt; 1-10 ></code> . <code><i>interface-num</i></code> specifies a single Ethernet interface in the format <code><i>interface-num</i> = { <i>interface-type</i> <i>interface-num</i> <i>interface-name</i> }</code> , where <code><i>interface-type</i></code> specifies the interface type, <code><i>interface-num</i></code> specifies the interface number and <code><i>interface-name</i></code> specifies the interface name. For the respective meanings and value ranges, see the parameters in the Port Command chapter.

View

This command can be used in the following views:

- Ethernet Port view

Example

To authenticate the supplicant based on the interface number on Ethernet 1/0/3, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl-Z  
[SW5500]dot1x port-method portbased interface ethernet 1/0/3
```

Description

This command is used to set the base for 802.1x to perform access control, namely authenticate the users, on the specified interface. When `macbased` is used, the users accessing this interface must be authenticated independently, and as such will be able to access the network as long as they independently require. When `portbased` is used, only the first user on that port needs to be authenticated. Subsequent users

accessing the network through this port are considered authenticated. However if the original user terminates his connection, the other users will need to be re-authenticated.

This command has an effect on the interface specified by the parameter ***interface-list*** when executed in System View. It has an effect on all the interfaces when no interface is specified. The parameter *interface-list* cannot be input when the command is executed in Ethernet Port View and it has an effect only on the current interface.

Related Command

`display dot1x`

dot1x quiet-period

Purpose Use the `dot1x quiet-period` command to enable the quiet-period timer.

Use the `undo dot1x quiet-period` command to disable this timer.

Syntax `dot1x quiet-period`

`undo dot1x quiet-period`

Parameters None

Default By default, the quiet-period timer is disabled.

Example To enable quiet-period timer, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl-Z
[SW5500]dot1x quiet-period
```

View This command can be used in the following views:

- System view

Description If an 802.1x user has not been authenticated, the Authenticator will keep quiet for a while (which is specified by quiet-period timer) before launching the authentication again. During the quiet period, the Authenticator does not do anything related to 802.1x authentication.

Related Commands

- `display dot1x`
- `dot1x timer`

dot1x retry

Purpose

Use the `dot1x retry` command to configure the maximum times a Switch can retransmit the authentication request frame to the supplicant.

Use the `undo dot1x retry` command to restore the default maximum retransmission time.

Syntax

```
dot1x retry max-retry-value
```

```
undo dot1x retry
```

Parameters

max-retry-value

Specifies the maximum times an Ethernet switch can retransmit the authentication request frame to the supplicant, ranging from 1 to 10.

If not specified, the default value is 3, meaning that the switch can retransmit the authentication request frame to the supplicant 3 times.

Example

To configure the current device to transmit an authentication request frame to the user for no more than 9 times, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl-Z  
[SW5500]dot1x retry 9
```

View

This command can be used in the following views:

- System view

Description

After the Switch has transmitted an authentication request frame to the user for the first time, if no user response is received during the specified time-range, the Switch will re-transmit authentication request to the user. This command is used to specify how many times the Switch can re-transmit the authentication request frame to the supplicant. When the time is 1, the Switch is configured to transmit the authentication request frame only once. 2 indicates that the Switch is configured to transmit authentication request frame once again when no response is received for the first time and so on. This command has an effect on all the ports after configuration.

Related Command

```
display dot1x
```

dot1x retry-version-max

Purpose

Use the **dot1x retry-version-max** command to set the maximum number of retries for a switch to send version request packets to an online supplicant system.

Use the **undo dot1x retry-version-max** command to revert to the default maximum number of retries.

Syntax

```
dot1x retry-version-max max-retry-version-value
```

```
undo dot1x retry-version-max
```

Parameters

max-retry-version-value Maximum number of retries to send version request packets to an online supplicant system. This argument ranges from 1 to 10. If not specified, the default is 3.

Example

Enter system view.

```
<S5500> system-view
```

Configure the maximum number of retries for the switch to send version request packets to online supplicant systems to be 6.

```
[S5500] dot1x retry-version-max 6
```

View

This command can be used in the following views:

- System view

Description

After sending a version request packet to a supplicant system, a switch sends another one to the supplicant system if it does not receive the response from the supplicant system for the period set by the version checking timer. It continues to send version request packets to the supplicant system if it still does not receive the response from the supplicant system. Such a process goes on and on until the maximum number of retries is reached. If the maximum number of retries is reached and the supplicant system still does not respond, the switch ceases checking the client version of the supplicant system and continues the followed authentication procedures.

These two commands apply to all ports with the version checking function enabled.

Related Commands

- **display dot1x**
- **dot1x timer**

dot1x supp-proxy-check

Purpose

Use the **dot1x supp-proxy-check** command to enable the supplicant system checking function for specified Ethernet ports.

Use the **undo dot1x supp-proxy-check** command to disable the supplicant system checking function for specified Ethernet ports.

Syntax

```
dot1x supp-proxy-check { logoff | trap } [ interface interface-list ]
```

```
undo dot1x supp-proxy-check { logoff | trap } [ interface interface-list ]
```

Parameters

logoff	Disconnects a supplicant system if the supplicant system is detected logging in through a proxy or through more than one network adapters.
trap	Sends Trap packets if the supplicant system is detected logging in through a proxy or through more than one network adapters.
interface <i>interface-list</i>	Specifies a list of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of <i>interface-list</i> = { <i>interface-type interface-number</i> [to <i>interface-type interface-num</i>] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.



- When being executed in system view, these two commands apply to all ports if you do not provide the *interface-list* argument. If you provide this argument, these two commands apply to the specified ports.
- When being executed in Ethernet port view, these two commands apply to the current port and the *interface-list* argument is not needed.

Example

Enter system view.

```
<S5500> system-view
```

Configure to disconnect the supplicant systems connected to Ethernet1/0/1 through Ethernet1/0/8 ports if the supplicant systems are detected logging in through proxies.

```
[S5500] dot1x supp-proxy-check logoff
```

```
[S5500] dot1x supp-proxy-check logoff interface Ethernet 1/0/1 to  
Ethernet 1/0/8
```

Configure to send Trap packets if the supplicant systems connected to Ethernet1/0/9 port are detected logging in through proxies.

```
[S5500] dot1x supp-proxy-check trap
```

```
[S5500] dot1x supp-proxy-check trap interface Ethernet 1/0/9
```

View

This command can be used in the following views:

- System view
- Ethernet Port view

Description

By default, the supplicant system checking function is disabled on an Ethernet port.

The supplicant system checking function checks for:

- Supplicant systems logging in through proxies
- Supplicant systems logging in through IE proxies
- Whether or not a supplicant system logs in with more than one network adapters installed in it being active

A 3Com Switch 5500 Family switch can optionally take the following measures against any of the three cases:

- Disconnecting the supplicant system and sending Trap packets (This can be achieved by using the **dot1x supp-proxy-check logoff** command.)
- Sending Trap packets without disconnecting the supplicant system (This can be achieved by using the **dot1x supp-proxy-check trap** command.)

To achieve this function, following are to meet for 802.1x clients and CAMS.

- The 802.1x clients are capable of detecting multiple network adapters, proxies, and IE proxies.
- CAMS is configured to disable use of multiple network adapters, proxies, or IE proxies.

By default, an 802.1x client allows the use of multiple network adapters, proxies, and IE proxies. If CAMS is configured to disable the use of multiple network adapters, proxies, or IE proxies, it prompts the 802.1x client to disable use of multiple network adapters, proxies, or IE proxies through messages after the supplicant system passes the authentication.



- This function needs the support of 3Com's 802.1x client.
- As for the proxy detecting function, you need to enable this function on both the 802.1x client and CAMS. You need also to enable client version detecting on the switch (refer to the **dot1x version-check** command for more).
- To utilize the supplicant system checking function on a port, you need to enable the function in system view and then in Ethernet port view.

Related Command

display dot1x

dot1x timer

Purpose

Use the `dot1x timer` command to configure the 802.1x timers.

Use the `undo dot1x timer` command to restore the default values.

Syntax

```
dot1x timer { handshake-period handshake-period-value | quiet-period
quiet-period-value | tx-period tx-period-value | supp-timeout
supp-timeout-value | server-timeout server-timeout-value }
```

```
undo dot1x timer { handshake-period | quiet-period | tx-period |
supp-timeout | server-timeout }
```

Parameters

<code>handshake-period</code>	This timer begins after the user has passed authentication. After setting the handshake-period, the system will send a handshake packet every handshake period seconds. Suppose the dot1x handshake-period time is configured as N, the system will consider the user as having logged off and will set the user state as logoff if the system does not receive a response from the user for N consecutive times.
<code>handshake-period-value</code>	Handshake period. Valid values are 1 to 1024 seconds. If not specified, the default is 15 seconds.
<code>quiet-period</code>	Specifies the quiet timer. If an 802.1x user has not passed the authentication, the Authenticator will keep quiet for a while (which is specified by quiet-period timer) before launching the authentication again. During the quiet period, the Authenticator does not do anything related to 802.1x authentication.
<code>quiet-period-value</code>	Specifies how long the quiet period is. Valid values are 10 to 120 seconds. If not specified, the default is 60 seconds.
<code>server-timeout</code>	Specifies the timeout timer of an Authentication Server. If an Authentication Server has not responded before the specified period expires, the Authenticator will re-send the authentication request.
<code>server-timeout-value</code>	Specifies how long the duration of a timeout timer of an Authentication Server is. Valid values are 100 to 300 seconds. If not specified, the default is 100 seconds.
<code>supp-timeout</code>	Specifies the authentication timeout timer of a Supplicant. After the Authenticator sends Request/Challenge request packet which requests the MD5 encrypted text, the supp-timeout timer of the Authenticator begins to run. If the Supplicant does not respond back successfully within the time range set by this timer, the Authenticator will re-send the above packet.

<i>supp-timeout-value</i>	Specifies how long the duration of an authentication timeout timer of a Supplicant is. Valid values are 10 to 120 seconds. If not specified, the default is 30 seconds.
<i>tx-period</i>	Specifies the transmission timeout timer. After the Authenticator sends the Request/Identity request packet which requests the user name or user name and password together, timer of the Authenticator begins to run. If the Supplicant does not respond back with authentication reply packet successfully, then the Authenticator will re-send the authentication request packet.
<i>tx-period-value</i>	Specifies how long the duration of the transmission timeout timer is. Valid values are 10 to 120 seconds. If not specified, the default is 30 seconds

Example

To set the Authentication Server timeout timer to 150s, enter the following:

```
<SW5500> system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]dot1x timer server-timeout 150.
```

View

This command can be used in the following views:

- System view

Description

802.1x has many timers that control the rational and orderly interacting of the Supplicant, the Authenticator and the Authentication Server. This command can set some of the timers (while other timers cannot be set) to adapt the interaction process. Changing the timers could be necessary in some special cases, but generally the user should keep the default values.

Related Command

display dot1x

dot1x timer ver-period

Purpose

Use the **dot1x timer ver-period** command to set the version checking timer for 802.1x client.

Use the **undo dot1x timer ver-period** command to resume the default value of the version checking timer.

Syntax

```
dot1x timer ver-period ver-period-value
```

```
undo dot1x timer ver-period
```

Parameters

ver-period-value

Ver-period value in seconds to be set. Valid values are 1 to 30 seconds.
If not specified, the default is 30 seconds.

Example

Enter system view.

```
<S5500> system-view
```

Set the version checking timer to 5 seconds.

```
[S5500] dot1x timer ver-period 5
```

View

This command can be used in the following views:

- System view

Description

After sending a version request packet to a supplicant system, a switch sends another one to the supplicant system if it does not receive the response from the supplicant system for the period set by the version checking timer.

Normally, the default version checking timer value is recommended.

Related Command

```
display dot1x
```

dot1x version-check

Purpose

Use the **dot1x version-check** command to enable 802.1x client version checking for specified Ethernet ports.

Use the **undo dot1x version-check** command to disable 802.1x client version checking for specified Ethernet ports.

Syntax

```
dot1x version-check [ interface interface-list ]
```

```
undo dot1x version-check [ interface interface-list ]
```

Parameters

interface *interface-list* Specifies a list of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of *interface-list* = { *interface-type interface-number* [to *interface-type interface-num*] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.

Example

Enter system view.

```
<S5500> system-view
```

Configure Ethernet1/0/1 port to check the version of the 802.1x client upon receiving authentication packets.

```
[S5500-Ethernet1/0/1] dot1x version-check
```

View

This command can be used in the following views:

- System view
- Ethernet Port view

Description

By default, 802.1x client version checking is disabled on an Ethernet port.



Note:

- When being executed in system view, these two commands apply to all ports if you do not provide the *interface-list* argument. If you provide this argument, these two commands apply to the specified ports.
- When being executed in Ethernet port view, these two commands apply to the current port and the *interface-list* argument is not needed.

duplex

Purpose

Use the **duplex** command to configure the duplex mode of an Ethernet port to auto-negotiation, full duplex or half-duplex.

Use the **undo duplex** command to restore the duplex mode of a port to the default mode (auto-negotiation).

Syntax

```
duplex { auto | full | half }
```

```
undo duplex
```

Parameters

auto Sets the port to auto-negotiation.

full Sets the port to full-duplex.

half Sets the port to half-duplex.

Example

To configure the Ethernet port "Ethernet1/0/1" to auto-negotiation, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface ethernet 1/0/1  
[SW5500-Ethernet1/0/1]duplex auto
```

View

This command can be used in the following views:

- Ethernet Port view

Related Command

speed

enable snmp trap updown

Purpose

Use the `enable snmp trap updown` command to enable the current port to transmit the LINK UP and LINK DOWN trap information.

Use the `undo enable snmp trap updown` command to disable the current port to transmit the LINK UP and LINK DOWN trap information.

Syntax

```
enable snmp trap updown
```

```
undo enable snmp trap updown
```

Parameters

None

Example

Enable the current port Ethernet1/0/1 to transmit the LINK UP and LINK DOWN trap information.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface Ethernet 1/0/1  
[SW5500-Ethernet1/0/1]enable snmp trap updown  
[SW5500-Ethernet1/0/1]
```

View

This command can be used in the following views:

- Ethernet Port view

end-station polling ip-address

Purpose

Use the `end-station polling ip-address` command to configure the IP address requiring periodic testing.

Use the `undo end-station polling ip-address` command to delete the IP address requiring periodic testing.

Syntax

```
end-station polling ip-address ip-address
```

```
undo end-station polling ip-address ip-address
```

Parameters

ip-address Specifies the IP address.

Example

Configure 202.38.160.244 requiring periodical testing.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]end-station polling ip-address 202.38.160.244
```

View

This command can be used in the following views:

- System view

Description

The switch can ping an IP address every one minute to test if it is reachable. Three PING packets can be sent at most for every IP address in every testing with a time interval of five seconds. If the switch cannot ping successfully the IP address after the three PING packets, it assumes that the IP address is unreachable.

You can configure up to 50 IP addresses by using the command repeatedly.

Related Commands

- `ping`
- `tracert`

execute

Purpose

Use the **execute** command to execute the specified batch file.

Syntax

```
execute filename
```

Parameters

filename

Name of the batch file, consisting of a string up to 256 characters in length, with a suffix of ".bat".

Example

To execute the batch file "test.bat" in the directory of "flash:", enter the following:

```
<SW5500>sys  
System View: return to User View with Ctrl+Z.  
[SW5500]execute test.bat
```

View

This command can be used in the following views:

- System view

Description

The batch command executes the command lines in the batch file one by one. There should be no invisible character in the batch file. If invisible characters are found, the batch command will quit the current execution. The forms and contents of the commands are not restricted in the batch file.

exit

Purpose Use the **exit** command to terminate the connection to the remote SFTP server and return to system view.

This command has the same function as the **bye** and **quit** commands.

Syntax **exit**

Parameters None

Example Terminate the connection to the remote SFTP server.

```
sftp-client> exit  
[S5500]
```

View This command can be used in the following views:

- SFTP Client view

expired

Purpose

Use the **expired** command to configure the lease time of the IP addresses in a global DHCP address pool.

Use the **undo expired** command to restore the default lease time.

Syntax

```
expired { day day [ hour hour [ minute minute ] ] | unlimited }  
undo expired
```

Parameters

day <i>day</i>	Specifies the number of days. Valid values are 0 to 365. If not specified, the default lease time is one day.
hour <i>hour</i>	Specifies the number of hours. Valid values are 0 to 23.
minute <i>minute</i>	Specifies the number of minutes. Valid values are 0 to 59.
unlimited	Specifies that the lease time is unlimited. (But actually, the system limits the maximum lease time to about 25 years.)

Example

Enter system view.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.
```

Set the lease time of the IP addresses in the global DHCP address pool 0 to 1 day, 2 hours and 3 minutes.

```
[S5500] dhcp server ip-pool 0  
[S5500-dhcp-pool-0] expired day 1 hour 2 minute 3
```

View

This command can be used in the following views:

- DHCP Address Pool view

Description



An IP address is considered to be expired if its lease time is after the year 2106.

This command applies only to the S5500-EI series among Switch 5500-Series Switches.

Related Commands

- **dhcp server expired**
- **dhcp server ip-pool**

fabric port enable

Purpose

Use the **fabric port enable** command to configure a port to be a fabric port.

Use the undo **fabric port enable** command to configure a port to be a non-fabric port. A fabric unit quits the fabric if none of its ports are fabric ports.

Syntax

```
fabric port port-type port-number enable
```

Parameters

port-type

The port type configured to be a fabric port. Currently, this argument can only be GigabitEthernet.

port-number

Port number of the port to be configured to be a fabric port.

Example

Configure GigabitEthernet1/1/3 port to be a fabric port.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] fabric port GigabitEthernet1/1/3 enable
```

View

This command can be used in the following views:

- System view

file prompt

Purpose Use the `file prompt` command to modify the prompt mode of file operations on the Switch.

Syntax `file prompt { alert | quiet }`

Parameters

<code>alert</code>	Select confirmation on dangerous file operations. If not specified, the default value is alert.
<code>quiet</code>	No confirmation prompt on file operations.

Example Configure the prompt mode of file operation as `quiet`.

```
<SW5500>sys
System View: return to User View with Ctrl+Z
[SW5500]file prompt quiet
[SW5500]
```

View This command can be used in the following views:

- System view

Description If the prompt mode is set as `quiet`, so no prompts are shown for file operations, some non-recoverable operations may lead to system damage.

filter-policy export

Purpose

Use the `filter-policy export` command to configure to set the filtering conditions of the routing information advertised by a certain type of routing protocols.

Use the `undo filter-policy export` command to cancel the filtering conditions set.

Syntax

```
filter-policy { acl_number | ip-prefix ip_prefix_name } export [ protocol ]
```

```
undo filter-policy { acl_number | ip-prefix ip_prefix_name } export [ protocol ]
```

Parameters

acl_number Specifies the number of the access control list used for matching the destination address field of the routing information.

ip_prefix_name Specifies the address prefix list used for matching the routing information destination address field.

protocol Specifies the routing information of which kind of route protocol to be filtered.

Example

Define the filtering rules for advertising the routing information of RIP. Only the routing information passing the filtering of address prefix list p1 will be advertised by RIP.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]rip
[SW5500-rip]filter-policy ip-prefix p1 export
```

View

This command can be used in the following views:

- Routing Protocol view

Description

By default, the advertised routing information is not filtered.

It may be necessary that only the routing information that meets special conditions can be advertised. Then, the filter-policy command can be used to set the filtering conditions for the advertised routing information. Only the routing information passing the filter can be advertised.

Related Command

`filter-policy import`

filter-policy export

Purpose

Use the `filter-policy export` command to configure RIP to filter the advertised routing information.

Use the `undo filter-policy export` command to configure RIP not to filter the advertised routing information. This is the default.

Syntax

```
filter-policy { acl_number | gateway gateway-ip | ip-prefix  
ip_prefix_name | route-policy route-policy-name } export  
[routing_process]
```

```
undo filter-policy { acl_number | gateway gateway-ip | ip-prefix  
ip_prefix_name | route-policy route-policy-name } export  
[routing_process]
```

Parameters

acl_number

Specifies the number of the ACL that you want to use to filter the destination addresses of the routing information.

gateway-ip

ip_prefix_name

Specifies the name of the address prefix list that you want to use to filter the destination addresses of the routing information.

route-policy-name

Route policy name that filters routing information. After enabling RIP protocol, you can determine which routes are to be sent/received based on `acl/cost/interface/ip/ip-prefix/tag` fields.

routing_protocol

Specifies the routing protocol whose routing information is to be filtered. This can be one of the following:

- `direct`—Specifies direct routes
- `ospf`—Specifies Open Shortest Path First (OSPF).
- `ospf-ase`—Specifies OSPF external routes.
- `ospf-nssa`—Specifies OSPF NSSA external routes.
- `static`—Specifies static routes.

Example

To filter the advertised route information using ACL 2000, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]rip  
[SW5500-rip]filter-policy 2000 export
```

View

This command can be used in the following views:

- RIP view

Related Commands

- `acl`
- `filter-policy import`
- `ip ip-prefix`

filter-policy export

Purpose

Using the `filter-policy export` command, you can configure how OSPF filters the advertised routing information.

Using the `undo filter-policy export` command, you can cancel the filtering rules.

Syntax

```
filter-policy { acl_number | gateway gateway-ip | ip-prefix  
ip_prefix_name } export [ routing_protocol ]
```

```
undo filter-policy { acl_number | gateway gateway-ip | ip-prefix  
ip_prefix_name } export [ routing_protocol ]
```

Parameters

<i>acl_number</i>	Specifies an access control list number.
<i>ip_prefix_name</i>	Specifies the name of the address prefix list.
<i>routing_protocol</i>	Specifies the protocol advertising the routing information. This can be one of the following: direct, rip and static.

Example

To configure OSPF to only advertise the routing information permitted by acl 2000, enter the following commands:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]acl number 2000  
[SW5500-acl-basic-2000]rule permit source 11.0.0.0 0.255.255.255  
[SW5500-acl-basic-2000]rule deny source any  
[SW5500-acl-basic-2000]quit  
[SW5500]router id 1.1.1.1  
[SW5500]ospf  
[SW5500-ospf-1]filter-policy 2000 export
```

View

This command can be used in the following views:

- OSPF view

Description

Only the routing information that meets these conditions is advertised.

By default, no filtering of the distributed routing information is performed.

Related Commands

- `acl`
- `ip ip-prefix`

filter-policy import

Purpose

Use the `filter-policy import` command to set the condition for filtering the routing information.

Use the `filter-policy gateway import` command to filter the received routing information advertised by a specified router.

Use the `undo filter-policy import` command to cancel the setting of filter condition

Use the `undo filter-policy gateway import` command to cancel the setting of the filtering condition.

Syntax

```
filter-policy gateway ip_prefix_name import
undo filter-policy gateway ip_prefix_name import
filter-policy { acl_number | ip-prefix ip_prefix_name } import
undo filter-policy { acl_number | ip-prefix ip_prefix_name } import
```

Parameters

<code>acl_number</code>	Specifies the access control list number used for matching the destination address field of the routing information.
<code>ip-prefix ip_prefix_name</code>	Specifies the prefix address list name. Its matching object is the destination address field of the routing information.
<code>gateway ip_prefix_name</code>	Specifies the prefix address list name of the neighbor router address. Its matching object is the routing information advertised by the specified neighbor router.

Default

By default, the received routing information is not filtered.

Example

Define the filtering rule for receiving routing information of RIP. Only the routing information filtered through the address prefix list p1 can be received by RIP.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]rip
[SW5500-rip]filter-policy ip-prefix p1 import
```

View

This command can be used in the following views:

- Routing Protocol view

Description

It may be necessary that only the routing information that meets special conditions can be received. Then, the filter-policy command can be used to set the filtering conditions for the received routing information. Only the routing information passing the filtration can be received.

Related Command

`filter-policy export`

filter-policy import

Purpose

Use the `filter-policy import` command to configure the switch to filter global routing information.

Use the `filter-policy gateway import` command to configure the switch to filter the routing information received from a specified address.

Use the `undo filter-policy import` command to disable filtering of received global routing information.

Use the `undo filter-policy gateway import` command to configure the switch not to filter the routing information received from the specified address.

Syntax

```
filter-policy gateway ip_prefix_name import
```

```
undo filter-policy gateway ip_prefix_name import
```

```
filter-policy { acl_number | ip-prefix ip_prefix_name [ gateway  
ip-prefix-name ] | route-policy route-policy-name } import
```

```
undo filter-policy { acl_number | ip-prefix ip_prefix_name | [ gateway  
ip-prefix-name ] | route-policy route-policy-name } import
```

Parameters

<code>gateway ip_prefix_name</code>	Specifies the name of the address prefix list. This is used to filter the addresses of this neighboring routers advertising the routing information.
<code>acl_number</code>	Specifies an ACL number. This is used to filter the destination addresses of the routing information.
<code>ip_prefix_name</code>	Specifies the name of the address prefix list. This is used to filter the destination addresses of the routing information.
<code>route-policy-name</code>	Route policy name that filters routing information. After enabling RIP protocol, you can determine which routes are to be sent/received based on acl/cost/interface/ip/ip-prefix/tag fields.

Default

By default, RIP does not filter the received routing information.

Example

To configure the filtering of the global routing information using acl 2000, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]rip
[SW5500-rip]filter-policy 2000 import
```

View

This command can be used in the following views:

- RIP view

Related Commands

- `acl`
- `filter-policy export`
- `ip ip-prefix`

filter-policy import

Purpose Using the `filter-policy import` command, you can configure how OSPF filters the routing information received.

Using the `undo filter-policy import` command, you can cancel the filtering of the received routing information received.

Syntax

```
filter-policy { acl-number | ip-prefix ip-prefix-name | gateway
ip_prefix_name } import
```

```
undo filter-policy { acl-number | ip-prefix ip-prefix-name | gateway
ip_prefix_name } import
```

Parameters

<code>acl_number</code>	Specifies the access control list number used for filtering the destination addresses of the routing information.
<code>ip_prefix_name</code>	Specifies the name of address prefix list used for filtering the destination addresses of the routing information.
<code>gateway ip_prefix_name</code>	Specifies the name of address prefix list used for filtering the addresses of the neighboring routers advertising the routing information.

Default

Only the routing information that meets these conditions can be received.

No filtering of the received routing information is performed.

Example

To filter the received routing information using the rules defined by access control list 2000, enter the following commands:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]acl number 2000
[SW5500-acl-basic-2000]rule permit source 20.0.0.0 0.255.255.255
[SW5500-acl-basic-2000]rule deny source any
[SW5500-acl-basic-2000]quit
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]filter-policy 2000 import
```

View

This command can be used in the following views:

- OSPF view

Description

In some cases, it may be required that only the routing information meeting some conditions can be received. Then, the `filter-policy` command can be used to set the

filtering conditions for the routing information to be received. Only the routing information passing the filtration can be received.

fixdisk

Purpose Use the **fixdisk** command to recover lost chains in a storage device.

Syntax `fixdisk [unit1>flash]`

Parameters `unit1>flash` Device name.

View This command can be used in the following views:

- Any view

flow-control

Purpose

Use the `flow-control` command to configure the flow control mode on the AUX (Console) port to hardware, software or none.

Use the `undo flow-control` command to restore the default flow control mode (no flow control).

Syntax

```
flow-control { hardware | none | software }  
undo flow-control
```

Parameters

<code>hardware</code>	Sets hardware flow control.
<code>none</code>	Sets no flow control.
<code>software</code>	Sets software flow control.

Example

To configure software flow control on the AUX (Console) port, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]user-interface aux 0  
[SW5500-ui-aux0]flow-control software
```

View

This command can be used in the following views:

- User Interface view

Description



This command can only be performed in the AUX User Interface view.

flow-control

Purpose Use the `flow-control` command to enable flow control on an Ethernet port. This avoids discarding data packets due to congestion.

Use the `undo flow-control` command to disable flow control.

Syntax

```
flow-control
undo flow-control
```

Parameters None

Default By default, flow control is disabled.

Example To enable flow control on port "Ethernet1/0/1", enter the following.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]flow-control
[SW5500-Ethernet1/0/1]
```

View This command can be used in the following views:

- Ethernet Port view

format

Purpose Use the **format** command to format the storage device. All of the files on the storage device will be lost and non-recoverable. Specially, configuration files will be lost after formatting flash memory.

Syntax `format filesystem`

Parameters `filesystem` Device name.

Example Format flash:

```
<Sw5500>format unit1>flash:
All data on unit1>flash: will be lost , proceed with format ? [Y/N] y
% Now begin to format flash, please wait for a while...
Format unit1>flash: completed
```

View This command can be used in the following views:

- User view

free user-interface

Purpose

Use the **free user-interface** command to reset a specified user interface to its default settings. The user interface will be disconnected after the reset.

Use **free user-interface type** to reset the interface with the specified type and type number to its default settings.

Use **free user-interface number** to reset the interface with the specified index number to its default settings.

Syntax

```
free user-interface { type | number }
```

Parameters

type

Specifies the type and type number of the user interface to be reset.

number

Specifies the index number of the user interface to be reset.

Example

To reset user interface AUX 1 from another user interface on the Switch, enter the following:

```
<SW5500>free user-interface aux 1
```

After the command is executed, user interface AUX 1 is disconnected. When you next log in using user interface AUX 1, it opens using the default settings.

View

This command can be used in the following views:

- User view

Description



You cannot use this command on the current user interface.

free web-users

Purpose Use the **free web-users** command to disconnect a specified Web user or all Web users by force.

Syntax `free web-users { all | user-id userid | user-name username }`

Parameters	userid	Web user ID.
	username	User name of the Web user. This argument can contain 1 to 80 characters.
	all	Specifies all Web users.

Example Disconnect all Web users by force.

```
<S5500> free web-users all
```

View This command can be used in the following views:

- User view

frequency

Purpose	Use the frequency command to configure the automatic test interval. Use the undo frequency command to disable automatic test.		
Syntax	<pre>frequency interval undo frequency</pre>		
Parameters	<table><tr><td><i>interval</i></td><td>Automatic test interval. Valid Interval values are 0 to 65535 seconds. If not specified, the default is 0, meaning that no automatic test will be performed.</td></tr></table>	<i>interval</i>	Automatic test interval. Valid Interval values are 0 to 65535 seconds. If not specified, the default is 0, meaning that no automatic test will be performed.
<i>interval</i>	Automatic test interval. Valid Interval values are 0 to 65535 seconds. If not specified, the default is 0, meaning that no automatic test will be performed.		
Example	Set the automatic test interval to 10 seconds. <pre><S5500> system-view System View: return to User View with Ctrl+Z. [S5500] remote-ping administrator icmp [S5500-remote-ping-administrator-icmp] frequency 10</pre>		
View	This command can be used in the following views: <ul style="list-style-type: none">■ Remote-Ping Test Group view		
Description	If the argument <i>interval</i> is greater than 0, the system will automatically perform the same test at intervals specified by this argument.		
Related Command	<code>count</code>		

ftm stacking-vlan

Purpose

Use the `ftm stacking-vlan` command to specify the stacking VLAN of the Switch.

Use the `undo ftm stacking-vlan` command to set the stacking VLAN of the Switch to its default value.

Syntax

```
ftm stacking-vlan vlan-id
```

```
undo ftm stacking-vlan
```

Parameters

vlan-id

Specifies the VLAN used for stacking.
If no value is specified for the stacking VLAN, VLAN 4093 is used as the default.

Example

Set VLAN 2 as stacking VLAN.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500] ftm stacking-vlan 2
```

View

This command can be used in the following views:

- System view

Description

You should specify the stacking VLAN before the Fabric is established.

ftp

Purpose Use the **ftp** command to establish a control connection with a remote FTP server and enter FTP client view.

Syntax `ftp [ipaddress [port]]`

Parameters

<i>ipaddress</i>	IP address of a remote FTP server.
<i>port</i>	Port number of the remote FTP server.

Example Connect to the remote FTP server with IP address 1.1.1.1.

```
<S5500> ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in.
```

View This command can be used in the following views:

- User view

ftp cluster

Purpose Use the **ftp cluster** command to establish a control connection with a cluster FTP server. This command also leads you to FTP client view.

Syntax `ftp cluster`

Parameters None

Example Connect to the cluster FTP server.

```
<123_1.S5500> ftp cluster
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in.
```

View This command can be used in the following views:

- User view

ftp { cluster | remote-server } source-interface

Purpose Use the `ftp { cluster | remote-server } source-interface` command to use a specified source interface to establish a connection with an FTP server.

Syntax `ftp { cluster | remote-server } source-interface interface-type
interface-number`

Parameters	<code>cluster</code>	Specifies the cluster FTP server.
	<code>remote-server</code>	IP address or host name of an FTP server.
	<code>interface-type</code>	Source interface type. When the specified interface does not exist, the command fails.
	<code>interface-number</code>	Source interface number.

Example Use a specified source interface to establish a connection with a remote FTP server.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] ftp 192.168.8.8 source-interface Vlan-interface 1
```

View This command can be used in the following views:

- User view

ftp { cluster | remote-server } source-ip

Purpose Use the `ftp { cluster | remote-server } source-ip` command to use a specified source IP address to establish a connection with an FTP server.

Syntax `ftp { cluster | remote-server } source-ip ip-addr`

Parameters	<code>cluster</code>	Specifies the cluster FTP server.
	<code>remote-server</code>	IP address or host name of an FTP server.
	<code>ip-addr</code>	Source IP address.

Example Use a specified source IP address to establish a connection with a remote FTP server.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] ftp 192.168.8.8 source-ip 192.168.0.1
```

View This command can be used in the following views:

- User view

ftp dir

Purpose Use the `dir` command to query a specified file.

Syntax `dir [filename [localfile]]`

Parameters

<i>filename</i>	File name to be queried.
<i>localfile</i>	Saved local file name.

Example Query the file `temp.c` and save the results in the file `temp1`.

```
<SW5500>ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in.
[ftp]dir temp.c temp1
200 Port command okay.
150 Opening ASCII mode data connection for temp.c.
...226 Transfer complete.
FTP: 63 byte(s) received in 6.700 second(s) 9.00 byte(s)/sec.
[ftp]
```

View This command can be used in the following views:

- FTP Client view

Description If no parameter of this command is specified, then all the files in the directory will be displayed.

ftp disconnect

Purpose Use the **ftp disconnect** command to terminate the FTP connection of a specified user at the FTP server end.

Syntax `ftp disconnect user-name`

Parameters *user-name* Name of an FTP user, consisting of a character string 1 to 56 characters long.

Example Terminate the FTP connection of user abc.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] ftp disconnect abc
[S5500]
%Apr 2 00:03:11:155 2000 5500-EI FTPS/5/USEROUT:- 1 -User
abc(192.168.0.10) logged out
```

View This command can be used in the following views:

- System view

ftp-server

Purpose

Use the **ftp-server** command to configure a public FTP server on the management device for cluster members.

Use the **undo ftp-server** command to cancel the public configurations for cluster members.

Syntax

```
ftp-server ip-address
```

```
undo ftp-server
```

Parameters

ip-address

IP address of the FTP server configured for the cluster.

Default

By default, the management device acts as the FTP Server.

Example

Configure the IP address of FTP server for the cluster on the management device.

```
<aaa_0.S5500>system-view  
System View: return to User View with Ctrl+Z.  
[aaa_0.S5500]cluster  
[aaa_0.S5500-cluster] ftp-server 1.0.0.9
```

View

This command can be used in the following views:

- Cluster view

Description

Only after you configure the IP address for the FTP server, member devices within the cluster can access the FTP server through the management device.

ftp server enable

Purpose	<p>Use the ftp server enable command to enable FTP server and allow FTP users to log in.</p> <p>Use the undo ftp server command to disable FTP server and inhibit FTP users from logging in.</p>
Syntax	<pre>ftp sever enable undo ftp sever</pre>
Parameters	None
Default	By default, FTP server is disabled.
Example	<p>Disable FTP server.</p> <pre><S5500> sys System View: return to User View with Ctrl+Z. [S5500] undo ftp server % Close FTP server [S5500]</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view
Description	<p>You can use the commands here to enable or disable FTP server. Disabling FTP server can prevent the Ethernet switch from being attacked by unknown users.</p>

ftp-server source-interface

Purpose

Use the **ftp-server source-interface** command to specify source interface for the FTP server.

Use the **undo ftp source-interface** command to clear the source interface configuration. After that, the source address in the packets sent to the FTP client is determined by the system.

Syntax

```
ftp-server source-interface interface-type interface-number
```

```
undo ftp-server source-interface
```

Parameters

interface-type Source interface type. If you specify a nonexistent interface in the command, your configuration fails.

interface-number Source interface number.

Example

Specify source interface for the FTP server.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] ftp-server source-interface Vlan-interface 2
```

View

This command can be used in the following views:

- System view

ftp-server source-ip

Purpose

Use the **ftp-server source-ip** command to specify source IP address for the FTP server.

Use the **undo ftp-server source-ip** command to clear the source IP address configuration. After that, the source address in the packets sent to the FTP client is determined by the system.

Syntax

```
ftp-server source-ip ip-addr
```

```
undo ftp-server source-ip
```

Parameters

ip-addr

Source IP address. If the *ip-addr* in the command is not an address of the device, your configuration fails.

Example

Specify source IP address for the FTP server.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] ftp-server source-ip 192.168.1.1
```

View

This command can be used in the following views:

- System view

ftp source-interface

Purpose

Use the **ftp source-interface** command to specify source interface for the FTP client.

Use the **undo ftp source-interface** command to clear source interface configuration. After that, the source address in the packets sent to the FTP server is determined by the system.

Syntax

```
ftp source-interface interface-type interface-number
```

```
undo ftp source-interface
```

Parameters

interface-type Source interface type. If you specify a nonexistent interface in the command, your configuration fails.

interface-number Source interface number.

Example

Specify source interface for the FTP client.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] ftp source-interface Vlan-interface 1
```

View

This command can be used in the following views:

- System view

ftp source-ip

Purpose

Use the **ftp source-ip** command to specify source IP address for the FTP client.

Use the **undo ftp source-ip** command to clear the source IP address configuration. After that, the source address in the packets sent to the FTP server is determined by the system.

Syntax

```
ftp source-ip ip-addr
```

```
undo ftp source-ip
```

Parameters

ip-addr

Source IP address. If the *ip-addr* in the command is not an address of the device, your configuration fails.

Example

Specify source IP address for the FTP client.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] ftp source-ip 192.168.0.1
```

View

This command can be used in the following views:

- System view

ftp timeout

Purpose

Use the `ftp timeout` command to configure connection timeout interval.

Use the `undo ftp timeout` command to restore the default connection timeout interval.

Syntax

```
ftp timeout minute
```

```
undo ftp timeout
```

Parameters

minute

Connection timeouts (measured in minutes). Valid values are 1 to 35791 minutes. If no value is specified, the default connection timeout time is 30 minutes.

Example

Set the connection timeout to 36 minutes.

```
<SW5500>sys
System View: return to User View with Ctrl+Z.
[SW5500]ftp timeout 36
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

After a user logs on to an FTP Server and has established connection, if the connection is interrupted or cut abnormally by the user, FTP Server will still hold the connection. The connection timeout can avoid this problem. If the FTP server has no command interaction with a client for a specific period of time, it considers the connection to have failed and disconnects the client.

garp timer

Purpose

Use the **garp timer** command to set the GARP Hold, Join or Leaver timer of the port to a specified value.

Use the **undo garp timer** command to restore the default value of the GARP Hold, Join or Leaver timer of the port.

Syntax

```
garp timer { hold | join | leave } timer-value
```

```
undo garp timer { hold | join | leave }
```

Parameters

hold	GARP Hold timer. When a GARP entity receives a piece of registration information, it does not send out the Join message immediately. Instead, it starts the Hold timer, puts all registration information it receives before the timer times out into one Join message and sends out the message after the timer times out.
join	GARP Join timer. To transmit the Join messages reliably to other entities, a GARP entity sends each Join message two times. The Join timer is used to define the interval between the two sending operations of each Join message.
leave	GARP Leave timer. When a GARP entity expects to unregister a piece of attribute information, it sends out a Leave message. Any GARP entity receives this message starts its Leave timer, and unregisters the attribute information if it does not receives a Join message again before the timer times out.
timer-value	Value of the specified GARP timer (Hold, Join or Leave) in centiseconds, with a step size of five. If no values are specified, the default values are 10 for Hold timers; 20 for Join timers; and 60 for Leave timers, respectively.

Example

Set the timeout time of the GARP Join timer on the port GigabitEthernet1/0/1 to 20 centiseconds.

```
<S4200G> system-view  
System View: return to User View with Ctrl+Z.  
[S4200G] interface Ethernet1/0/1  
[S4200G-Ethernet1/0/1] garp timer join 20
```

View

This command can be used in the following views:

- Ethernet Port view

Description

The ranges of the timers vary depending on the values of other timers. You can set a timer to a value out of the current range by set the associated timer to another value.

The following table describes the relations between the timers:

Table 91 Relationships between the timers

Timer	Lower threshold	Upper threshold
Hold	10 centiseconds	This upper threshold is less than or equal to one-half of the value of the Join timer. You can change the threshold by changing the value of the Join timer.
Join	This lower threshold is greater than or equal to twice the value of the Hold timer. You can change the threshold by changing the value of the Hold timer.	This upper threshold is less than one-half of the value of the Leave timer. You can change the threshold by changing the value of the Leave timer.
Leave	This lower threshold is greater than twice the value of the Join timer. You can change the threshold by changing the value of the Join timer.	This upper threshold is less than the value of the LeaveAll timer. You can change the threshold by changing the value of the LeaveAll timer.
LeaveAll	This lower threshold is greater than the value of the Leave timer. You can change threshold by changing the value of the Leave timer.	32,765 centiseconds

Related Command

`display garp timer`

garp timer leaveall

Purpose

Use the **garp timer leaveall** command to set the GARP LeaveAll timer to a specified value.

Use the **undo garp timer leaveall** command to restore the default value of the GARP LeaveAll timer.

Syntax

```
garp timer leaveall timer-value
```

```
undo garp timer leaveall
```

Parameters

timer-value

Value of the GARP LeaveAll timer (in centiseconds). Valid values are 65 to 32,765 seconds, with a step size of 5. This value must be greater than the value of the Leave timer.
If not specified, the default is 1,000 centiseconds (that is, 10 seconds).

Example

Set the GARP LeaveAll timer to 100 centiseconds.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] garp timer leaveall 100
```

View

This command can be used in the following views:

- System view

Description

Once a GARP entity starts up, it starts the LeaveAll timer, and sends out a LeaveALL message after the timer times out, so that other GARP entities can re-register all the attribute information on this entity. After that, the entity restarts the LeaveAll timer to begin a new cycle.

Related Command

```
display garp timer
```

gateway-list

Purpose

Use the **gateway-list** command to configure one or multiple gateway IP addresses for the DHCP clients of a DHCP address pool.

Use the **undo gateway-list** command to remove one or all the configured gateway IP addresses configured for the DHCP address pool.

Syntax

```
gateway-list ip-address&<1-8>
```

```
undo gateway-list { ip-address | all }
```

Parameters

ip-address&<1-8>	IP address of a gateway. &<1-8> means you can provide up to eight gateway IP addresses. When inputting more than one IP address, separate two neighboring IP addresses with a space.
all	Specifies all configured gateway IP addresses.

Default

By default, no gateway IP address is configured.

Example

Enter system view.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.
```

Configure the gateway IP address 10.110.1.99 for the global DHCP address pool 0.

```
[S5500] dhcp server ip-pool 0  
[S5500-dhcp-pool-0] gateway-list 10.110.1.99
```

View

This command can be used in the following views:

- DHCP Address Pool view

Description

If you execute the gateway-list command repeatedly, the new configuration overwrites the previous one.



This command applies only to the S5500-EI series among Switch 5500-Series Switches.

get

Purpose Use the **get** command to download a remote file and save the file to the local device.

Syntax `get remotefile [localfile]`

Parameters

<i>localfile</i>	Local file name.
<i>remotefile</i>	File name on the FTP server.

Example Download the file temp1.c and save it to the local file temp.c.

```
<S5500> ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in.
[ftp] get temp1.c temp.c
200 Port command okay.
150 Opening ASCII mode data connection for temp1.c.
..226 Transfer complete.
FTP: 1709 byte(s) received in 2.176 second(s) 0.00 byte(s)/sec.
[ftp]
```

View This command can be used in the following views:

- FTP Client Command view

Description If no local file name is specified, the switch will save the remote file locally with the same file name as that on the remote FTP server

gratuitous-arp learning enable

Purpose

Use the **gratuitous-arp-learning enable** command to enable the gratuitous ARP packet learning function.

Use the **undo gratuitous-arp-learning enable** command to disable the gratuitous ARP packet learning function.

Syntax

```
gratuitous-arp-learning enable
```

```
undo gratuitous-arp-learning enable
```

Parameters

None

Default

By default, the gratuitous ARP packet learning function is enabled.

Example

Enable the gratuitous ARP packet learning function on the switch named S5500A.

```
<S5500A> system-view
System View: return to User View with Ctrl+Z.
[S5500A] gratuitous-arp-learning enable
```

View

This command can be used in the following views:

- System view

Description

When the gratuitous ARP packet learning function is enabled on a switch and the switch receives a gratuitous ARP packet, the switch updates the corresponding ARP entry (if available in the cache of the switch) using the hardware address of the sender carried in the gratuitous ARP packet. A switch operates like this whenever it receives a gratuitous ARP packet.

gvrp

Purpose

Use the **gvrp** command to enable GVRP globally (in system view) or on a port (in Ethernet port view).

Use the **undo gvrp** command to disable GVRP globally (in system view) or on a port (in Ethernet port view).

Syntax

gvrp

undo gvrp

Parameters

None

Default

By default, GVRP is disabled both globally and on ports.

Example

Enable GVRP globally.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] gvrp
```

View

This command can be used in the following views:

- System view
- Ethernet Port view

Description



Note:

- *Before enabling GVRP on a port, you must first enable GVRP globally.*
- *If GVRP is disabled globally, it is also disabled on ports and you are not allowed to enable it on port.*
- *You can enable/disable GVRP only on Trunk port.*
- *After enabling GVRP on the Trunk port, you are not allowed to change the port type from Trunk to another.*

Related Command

display gvrp status

gvrp registration

Purpose Use the **gvrp registration** command to configure the GVRP registration type on a port.

Use the **undo gvrp registration** command to restore the default GVRP registration type on a port.

Syntax

```
gvrp registration { fixed | forbidden | normal }  
undo gvrp registration
```

Parameters

fixed	Allows the manual creation and registration of VLAN on the current port, and inhibits the dynamic registration and unregistration of VLAN on the current port.
forbidden	Unregisters all the VLANs except VLAN 1 on the current port, and inhibits the creation and registration of any other VLAN on the current port.
normal	Allows both manual and dynamic creation, registration, and unregistration of VLANs on the current port.


Default By default, the registration type is **normal**.

Example Configure the GVRP registration type on the port Ethernet1/0/1 to fixed.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] interface Ethernet1/0/1  
[S5500-Ethernet1/0/1] gvrp registration fixed
```

View This command can be used in the following views:

- Ethernet Port view

Description  *These commands can be operated only on Trunk port.*

Related Command **display gvrp statistics**

header

Purpose

Use the **header** command to configure the system to display a header during user log in.

Use the **undo header { shell | incoming | login }** command to delete the specified header.

Syntax

```
header { shell | incoming | login } text
```

```
undo header { shell | incoming | login }
```

Parameters

<code>login</code>	Login information in case of authentication. It is displayed before the user is prompted to enter user name and password.
<code>shell</code>	User conversation established header, the information output after user conversation has been established. If authentication is required, it is prompted after the user passes authentication.
<code>incoming</code>	Login header, the information output after a Modem user logs in. If authentication is required, it is prompted after the user passes authentication. In this case, no shell information is output.
<code>text</code>	Specifies the title text. If you do not choose any keyword in the command, the system displays the login information by default. The system supports two types of input mode: you can input all the text in one line (a maximum of 256 characters, including command key word, can be entered); or you can input all the text in several lines using the <Enter> key, and more than 256 characters can be entered. The text starts and ends with the first character. After entering the last character, press the <Enter> key to exit the interactive process.

Example

Configure the header of setting up a session.

Mode 1: Input in one line

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]header shell %SHELL: Hello! Welcome%
```

The starting and ending characters must be the same, and press the <Enter> key to finish a line.

When you log on the Switch again, the terminal displays the configured session establishment title.

```
[SW5500]quit
<SW5500>quit
Please press ENTER
SHELL: Hello! Welcome
```

The initial character "%" is not the header contents.

```
<SW5500>
Mode 2: Input in several lines
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]header shell % SHELL:
```

After you press the <Enter> key, the system prompts the following message:

Input banner text, and quit with the character '%'.
 Input the rest of your text and end the input with the first letter:

```
Hello! Welcome %
```

Press the <Enter> key.

```
[SW5500]
```

When you log on the Switch again, the terminal displays the configured session establishment title.

```
[SW5500]quit
<SW5500>quit
Please press ENTER
%SHELL:
```

The initial character "%" is the header contents.

```
Hello! Welcome
<SW5500>
```

View

This command can be used in the following views:

- System view

Description

When the user logs in, and a connection is activated, the **login** header displays. After the user successfully logs in, the **shell** header displays.

The first characters in the text are regarded as the start and stop characters. After you type in the stop character, the system will exit the header command automatically.

If you do not want to use the control characters, you can type in text with the same characters at the beginning and end, and press *Enter*.



If you press <Enter> after typing any of the three keywords shell, login and incoming in the command, then what you type after the word header is the contents of the login information, instead of identifying header type.

You can judge whether the initial character can be used as the header contents this way:

- 1 If there is only one character in the first line and it is used as the identifier, this initial character pairs with the ending character and is not the header contents.*
- 2 If there are many characters in the first line but the initial and ending characters are different, this initial character pairs with the ending character and is the header contents.*
- 3 There are many characters in the first line and the initial character is identical with the ending character, this initial character is not the header contents.*

help

Purpose Use the **help** command to get the help information about the specified or all SFTP client commands.

Syntax `help [command]`

Parameters *command* Specifies the name of a command.

Example Display the help information about the **get** command.

```
sftp-client> help get
get remote-path [local-path] Download file
Default local-path is the same with remote-path
```

View This command can be used in the following views:

- SFTP Client view

Description If the **command** argument is not specified, the help information about all commands is displayed.

history-command max-size

Purpose

Use the command `history-command max-size` to specify the amount of previously entered commands that you want the Switch to save.

Use the `undo history-command max-size` command to restore the default value.

Syntax

```
history-command max-size value
```

```
undo history-command max-size
```

Parameters

`value`

Specifies the number of previously entered commands that you want the Switch to save. You may enter any value between 0 and 256.

If no value is specified, the default is 10. (That is, the 10 most recently entered commands are saved.)

Example

To set the history buffer to 20, that is to save the 20 most recently-entered commands, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]user-interface aux 0
[SW5500-ui-aux0]history-command max-size 20
```

View

This command can be used in the following views:

- User Interface view

Description

To display the most recently-entered commands, up to the specified maximum, use the command `display history-command`.

holdtime

Purpose Use the **holdtime** command to configure the valid holdtime of a switch.
Use the **undo holdtime** command to restore the default holdtime value.

Syntax `holdtime seconds`
`undo holdtime`

Parameters `seconds` Valid holdtime in seconds. Valid values are 1 to 255.

Example Set the cluster holdtime as 30 seconds.

```
<aaa_0.S5500>system-view
System View: return to User View with Ctrl+Z.
[aaa_0.S5500]cluster
[aaa_0.S5500-cluster] holdtime 30
```

View This command can be used in the following views:

- Cluster view

Description By default, the valid holdtime is 60 seconds.

If the switch does not receive any information of a peer device during the holdtime, it will set the state of the peer device to “down”. When the communication resumes, the relevant member device will be re-added to the cluster (automatically). If the downtime does not go beyond the valid holdtime specified by the user, the member device stays in the normal state and needs not to be added again.

The commands can only be executed on the management device, which will advertise the cluster timer value to the member devices.

host-route

Purpose

Use the **host-route** command to configure RIP to accept host routes. This is the default.

Use the **undo host-route** command to configure RIP to reject host routes.

Syntax

host-route

undo host-route

Parameters

None

Example

To configure RIP to reject a host route, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]rip  
[SW5500-rip]undo host-route
```

View

This command can be used in the following views:

- RIP view

hwtacacs nas-ip

Purpose

Use the **hwtacacs nas-ip** command to specify the source address of the **hwtacacs** packet sent from NAS.

Use the **undo hwtacacs nas-ip** command to restore the default setting.

Syntax

```
hwtacacs nas-ip ip-address
```

```
undo hwtacacs nas-ip
```

Parameters

ip-address Source IP address, in dotted decimal format.

Default

By default, the source address is not specified, that is, the address of the interface sending the packet serves as the source address.

This command specifies only one source address; therefore, the newly configured source address may overwrite the original one.

Example

Configure the switch to send hwtacacs packets from 129.10.10.1.

```
[S5500] hwtacacs nas-ip 129.10.10.1
```

View

This command can be used in the following views:

- System view

Description

By specifying the source address of the hwtacacs packet, you can avoid unreachable packets as returned from the server upon interface failure. The source address is normally recommended to be a loopback interface address.

hwtacacs scheme

Purpose

Use the **hwtacacs scheme** command to enter the HWTACACS view. If you specified a nonexistent scheme, a new HWTACACS scheme will be created.

Use the **undo hwtacacs scheme** command to delete a HWTACACS scheme.

Syntax

```
hwtacacs scheme hwtacacs-scheme-name
```

```
undo hwtacacs scheme hwtacacs-scheme-name
```

Parameters

hwtacacs-scheme-name: Name of a HWTACACS scheme, consisting of a character string 1 to 32 characters long.

Example

Create a HWTACACS scheme named test1 and enter the HWTACACS view.

```
[S5500] hwtacacs scheme test1  
[S5500-hwtacacs-test1]
```

View

This command can be used in the following views:

- System view

icmp

Purpose Use the **icmp** command to specify the Internet Control Message Protocol (ICMP) parameters.

Syntax `icmp [redirect | unreachable]`

Parameters

<code>redirect</code>	ICMP redirect.
<code>unreach</code>	ICMP unreachable.

View This command can be used in the following views:

- Any view

idle-cut

Purpose	Use the <code>idle-cut</code> command to configure the user template in the current ISP domain.	
Syntax	<code>idle-cut { disable enable <i>minute flow</i> }</code>	
Parameters	<code>disable</code>	Disables the user to use idle-cut function.
	<code>enable</code>	Enables the user to use the function.
	<code>minute</code>	Specifies the maximum idle time (in minutes). Valid values are 1 to 120 minutes.
	<code>flow</code>	Specifies the minimum data traffic (in bytes). Valid values are 1 to 10,240,000 bytes.
Default	By default, after an ISP domain is created, this attribute in user template is <code>disable</code> , that is, the user idle-cut is disabled.	
Example	<p>To enable the user in the current ISP domain, 3Com163.net, to use the idle-cut attribute specified in the user template (that is, enabling the user to use the idle-cut function). The maximum idle time is 50 minutes and the minimum data traffic is 500 bytes.</p> <pre><SW5500> system-view System View: return to User View with Ctrl+Z. [SW5500]domain marlboro.net [SW5500-isp-marlboro.net]idle-cut enable 50 500</pre>	
View	This command can be used in the following views:	
	<ul style="list-style-type: none">■ ISP Domain view	
Description	<p>The user template is a set of default user attributes. If a user requesting for the network service does not have some required attributes, the corresponding attributes in the template will be endeavored to him as default ones. The user template of the Switch you are using may only provide user idle-cut settings. After a user is authenticated, if the idle-cut is configured to enable or disable by neither the user nor the RADIUS server, the user will adopt the idle-cut state in the template.</p> <p>Because a user template only works in one ISP domain, it is necessary to configure user template attributes for users from different ISP domain respectively.</p>	
Related Command	<code>domain</code>	

idle-timeout

Purpose

Use the `idle-timeout` command to configure the amount of time you want to allow a user interface to remain idle before it is disconnected.

Use the `undo idle-timeout` command to restore the default idle-timeout.

Syntax

```
idle-timeout minutes [ seconds ]
```

```
undo idle-timeout
```

Parameters

<i>minutes</i>	Specifies the number of minutes you want to allow a user interface to remain idle before it is disconnected. Valid values are 0 to 35791. If not specified, the default is 10 minutes.
<i>seconds</i>	Specifies the number of seconds in addition to the number of minutes. This parameter is optional.

Example

To configure the timeout value to 1 minute on the AUX User Interface, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]user-interface aux 0
[SW5500-ui-aux0]idle-timeout 1
```

View

This command can be used in the following views:

- User Interface view

Description

To disable idle timeout, set the `idle-timeout` value to 0.

if-match { acl | ip-prefix }

Purpose

Use the `if-match { acl | ip-prefix }` command to configure the IP address range to match the Route-policy.

Use the `undo if-match { acl | ip-prefix }` command to cancel the setting of the match rule.

Syntax

```
if-match { acl acl_number | ip-prefix ip_prefix_name }
```

```
undo if-match [ acl | ip-prefix ]
```

Parameters

acl_number Specifies the number of the access control list used for filtration

ip_prefix_name Specifies the prefix address list used for filtration

Example

Define one **if-match** sub-statement. When the sub-statement is used for filtering route information, the route information filtered by the route destination address through address prefix list p1 can pass the **if-match** sub-statement.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]route-policy permit node 1
    % New sequence of this list
[SW5500-route-policy]if-match ip-prefix p1
```

View

This command can be used in the following views:

- Route Policy view

Description

Filtration is performed by quoting an ACL or a prefix address list.

Related Commands

- `if-match interface`
- `if-match ip next-hop`
- `if-match cost`
- `if-match tag`
- `route-policy`
- `apply cost`
- `apply tag`

if-match cost

Purpose

Use the `if-match cost` command to configure one of the match rules of route-policy to match the cost of the routing information.

Use the `undo if-match cost` command to cancel the configuration of the match rule.

Syntax

```
if-match cost value
```

```
undo if-match cost
```

Parameters

`value`

Specifies the required route metric value. Valid values are 0 to 4294967295.

Default

By default, no match sub-statement is defined.

Example

A match sub-statement is defined, which allows the routing information with routing cost 8 to pass this match sub-statement.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]route-policy permit node 1
    % New sequence of this list
[SW5500-route-policy]if-match cost 8
```

View

This command can be used in the following views:

- Route Policy view

Related Commands

- `if-match interface`
- `if-match { acl | ip-prefix }`
- `if-match ip next-hop`
- `if-match tag`
- `route-policy`
- `apply cost`
- `apply tag`

if-match interface

Purpose Use the `if-match interface` command to match the route whose next hop is the designated interface.

Use the `undo if-match interface` command to cancel the setting of matching condition.

Syntax

```
if-match interface { interface_name | interface_type interface_number }  
undo if-match interface
```

Parameters

<i>interface_type</i>	Specifies interface type.
<i>interface_number</i>	Specifies interface number.
<i>interface_name</i>	Specifies interface name.

Default By default, no match sub-statement is defined.

Example Define one match sub-statement to match the route whose next hop interface is Vlan-interface 1.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]route-policy permit node 1  
    % New sequence of this list  
[SW5500-route-policy]if-match interface Vlan-interface 1
```

View This command can be used in the following views:

- Route Policy view

Related Commands

- `if-match { acl | ip-prefix }`
- `if-match ip next-hop`
- `if-match cost`
- `if-match tag`
- `route-policy`
- `apply cost`
- `apply tag`

if-match ip next-hop

Purpose

Use the `if-match ip next-hop` command to configure one of the match rules of route-policy on the next hop address of the routing information.

Use the `undo if-match ip next-hop` command to cancel the setting of the ACL matching condition.

Use the `undo if-match ip next-hop ip-prefix` command to cancel the setting of the address prefix list matching condition.

Syntax

```
if-match ip next-hop { acl acl_number | ip-prefix ip_prefix_name }  
undo if-match ip next-hop [ ip-prefix ]
```

Parameters

<i>acl_number</i>	Specifies the number of the access control list used for filtration. Valid values are 1 to 99.
<i>ip_prefix_name</i>	Specifies the name of the prefix address list used for filtration.

Example

Define a match sub-statement. It permits the routing information, whose route next hop address passes the filtration of the prefix address list p1, to pass this match sub-statement.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]route-policy permit node 1  
    % New sequence of this list  
[SW5500-route-policy]if-match ip next-hop ip-prefix p1
```

View

This command can be used in the following views:

- Route Policy view

Description

Filtration is performed by quoting an ACL or a address prefix list.

Related Commands

- `if-match interface`
- `if-match { acl | ip-prefix }`
- `if-match cost`
- `if-match tag`
- `route-policy`
- `apply cost`
- `apply tag`

if-match tag

Purpose Use the `if-match tag` command to match the tag field of OSPF route information.

Use the `undo if-match tag` command to cancel the existing matching rules.

Syntax `if-match tag value`

`undo if-match tag`

Parameters `value` Specifies the value in tag field of OSPF route information.

Example Define one match sub-statement and enable the OSPF route information whose value of tag is 8 to pass the match sub-statement.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]route-policy permit node 1
    % New sequence of this list
[SW5500-route-policy]if-match tag 8
```

View This command can be used in the following views:

- Route Policy view

Related Commands

- `if-match interface`
- `if-match { acl | ip-prefix }`
- `if-match ip next-hop`
- `if-match cost`
- `route-policy`
- `apply cost`
- `apply tag`

igmp enable

Purpose

Use the **igmp enable** command to enable IGMP on an interface.

Use the **undo igmp enable** command to disable IGMP on the interface.

Syntax

```
igmp enable
undo igmp enable
```

Parameters

None

Default

By default, IGMP is disabled.

Example

Enable IGMP on Vlan-interface 10.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Vlan-interface 10
[SW5500-Vlan-interface10]igmp enable
```

View

This command can be used in the following views:

- VLAN Interface view

Description

The **igmp enable** command can be executed only if the multicast routing function is enabled. After multicast routing is enabled, you can initiate the IGMP feature configuration.

Related Command

```
multicast routing-enable
```

igmp group-limit

Purpose

Use the **igmp group-limit** command to configure the maximum number of multicast groups that can be added to a VLAN interface.

Use the **undo igmp group-limit** command to restore the default configuration.

Syntax

```
igmp group-limit limit
```

```
undo igmp group-limit
```

Parameters

limit

Maximum number of IGMP groups. Valid values are 0 to 256.

If not specified, the default is 256.

Example

Set the maximum number of IGMP groups that can be added to Vlan-interface 10 to 100.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] interface Vlan-interface 10
[S5500-Vlan-interface10] igmp group-limit 100
```

View

This command can be used in the following views:

- VLAN Interface view

Description

When using the **igmp group-limit** command, the Layer 3 switch does not process any new IGMP join messages if the limit is exceeded.

Re-executing this command will overwrite the old configuration with the new one.



Note:

- *If the number of multicast groups that have been added to an interface reaches the limit you configured, the system will not add any new multicast group to the interface.*
- *If you set the maximum number of IGMP groups on an interface to 1, the new group will take precedence over the old one. That is, when you add a new multicast group to the interface, the system automatically removes the old one from the interface and substitutes the new group for the old one.*
- *If the maximum number you configured on an interface is less than the number of the existing multicast groups on the interface, the system automatically removes some earlier groups from the interface until the number of existing multicast groups on the interface is no more than the configured number.*

igmp group-policy

Purpose

Use the `igmp group-policy` command to set the filter of multicast groups on an interface to control the accessing to the IP multicast groups.

Use the `undo igmp group-policy` command to remove the filter configured.

Syntax

```
igmp group-policy acl-number [ 1 | 2 | port { interface_type interface_num | interface_name } [ to { interface_type interface_num | interface_name } ] ]
```

```
undo igmp group-policy [ port { interface_type interface_num | interface_name } [ to { interface_type interface_num | interface_name } ] ]
```

Parameters

<i>acl-number</i>	Number of the basic IP ACL number, defining a multicast group range. Valid values are 2000 to 2999.
1	IGMP version 1.
2	IGMP version 2. If IGMP version is not specified, version 2 is used as default.
<i>port</i>	Packets received and sent by the port(s) and applied to the conditions set by the ACL will be filtered. And the port(s) must belong to the VLAN interface being configured by this command.

Default

By default, no filter is configured, that is, a host can join any multicast group.

Example

Configure the access-list 5.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]acl number 2000
[SW5500-acl-basic-2000]rule permit source 225.0.0.0 0.255.255.255
```

Configure so that only the hosts contained in the access-list 2000 connected to the VLAN-interface10 can be added to the multicast group, which is configured to use IGMP version 2.

```
[SW5500-vlan-interface10]igmp group-policy 2000 2
```

View

This command can be used in the following views:

- VLAN Interface view

Description

If you do not want the hosts on the network that the interface is on to join some multicast groups and receive the packets from the multicast groups, you can use this command to limit the range of the multicast groups serviced by the interface.

Related Command

`igmp host-join`

igmp host-join

Purpose

Use the `igmp host-join` command to enable a port in the VLAN interface of an ethernet Switch to join a multicast group.

Use the `undo igmp host-join` command to disable the configuration.

Syntax

```
igmp host-join group-address port { interface_type interface_num |  
interface_name } [ to { interface_type interface_num | interface_name  
} ]
```

```
undo igmp host-join group-address port { interface_type interface_num  
| interface_name } [ to { interface_type interface_num |  
interface_name } ]
```

Parameters

<i>group-address</i>	Multicast address of the multicast group that an interface will join.
<i>port</i>	Specifies the port in the VLAN interface.

Default

By default, an interface does not join any multicast group.

Example

Add port Ethernet 1/0/1 in VLAN-interface10 to the multicast group at 225.0.0.1.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]interface Vlan-interface 10  
[SW5500-vlan-interface10]igmp host-join 225.0.0.1 port Ethernet 1/0/1
```

View

This command can be used in the following views:

- VLAN Interface view

Related Command

`igmp group-policy`

igmp lastmember-queryinterval

Purpose

Use the `igmp lastmember-queryinterval` command to set the time interval before IGMP query router sends the IGMP group query message after it receives the IGMP Leave message from the host.

Use the `undo igmp lastmember-queryinterval` command to restore the default value.

Syntax

```
igmp lastmember-queryinterval seconds
```

```
undo igmp lastmember-queryinterval
```

Parameters

seconds

Time interval before IGMP query router sends the IGMP group query message after it receives the IGMP Leave message from the host. Valid values are 1 to 5 seconds.

If not specified, 1 second is the default.

Example

Set the query interval on Vlan-interface10 as 3 seconds.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Vlan-interface 10
[SW5500-Vlan-interface10]igmp lastmember-queryinterval 3
```

View

This command can be used in the following views:

- VLAN Interface view

Description

In the shared network, that is, a network segment including multiple hosts and multicast routers, the IGMP Querier is responsible for maintaining the IGMP group membership on the interface. When an IGMP v2 host leaves a group, it sends an IGMP Leave message. When the IGMP Leave message is received, the IGMP Querier must send an IGMP group-specific query message a specified number of times (set using the `igmp robust-count` command, with a default value of 2) in a specified time interval. (Set using the `igmp lastmember-queryinterval` command, with default value of 1 second).

If other hosts that are interested in the specified group receive the IGMP group specific query message from the IGMP Querier, they send back an IGMP Membership Report message within the specified maximum response time interval. If the IGMP Querier receives the IGMP Membership Report message within the defined period (equal to robust-value seconds), the IGMP Querier continues to maintain the membership of this group. When no IGMP Membership Report messages are received from any hosts within the defined period, the IGMP Querier considers it a timeout and stops membership maintenance for the group.

This command only takes effect on an IGMP Querier running IGMP v2. For a Querier running IGMP v1, this command cannot take effect because the IGMP group members cannot send an IGMP Leave message when they leave a group.

Related Commands

- **display igmp interface**
- **igmp robust-count**

igmp max-response-time

Purpose

Use the `igmp max-response-time` command to configure the maximum response time contained in the IGMP query messages.

Use the `undo igmp max-response-time` command to restore the default value.

Syntax

```
igmp max-response-time seconds
```

```
undo igmp max-response-time
```

Parameters

`seconds`

Maximum response time in the IGMP query messages in seconds. Valid values are 1 to 25. If not specified, the default is 10 seconds.

Example

Set the maximum response time carried in host-query message to 8 seconds.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]interface Vlan-interface 10  
[SW5500-vlan-interface10]igmp max-response-time 8
```

View

This command can be used in the following views:

- VLAN Interface view

Description

The maximum query response time determines the period for a switch to quickly detect that there are no more directly connected group members in a LAN.

Related Command

```
display igmp group
```

igmp proxy

Purpose

Use the **igmp proxy** command to specify an interface of an edge-network Layer 3 switch as the IGMP proxy interface of another interface.

Use the **undo igmp proxy** command to remove the configuration.

Syntax

```
igmp proxy vlan-interface interface-number
```

```
undo igmp proxy
```

Parameters

interface-number Proxy interface number.

Default

By the default, the IGMP proxy function is disabled.

Example

Configure VLAN 2 of the Layer 3 switch as the IGMP proxy interface of VLAN 1.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] multicast routing-enable
[S5500] interface vlan-interface 1
[S5500-Vlan-interface1] igmp enable
[S5500-Vlan-interface1] igmp proxy vlan-interface 2
```

View

This command can be used in the following views:

- Interface view

Description

Before configuring igmp proxy, you need to enable the PIM protocol on the interface. An interface cannot serve as the IGMP proxy interface for two or more other interfaces.

If you carry out the igmp proxy command repeatedly, the last configuration takes effect.



CAUTION:

- Multicast routing and IGMP should also be enabled on a proxy interface.
- Before configuring **igmp proxy**, you need to enable the PIM protocol on the interface.
- An interface cannot serve as the IGMP proxy interface for two or more other interfaces.

Related Command

pim neighbor-policy

igmp robust-count

Purpose

Use `igmp robust-count` command to set the number of sending the IGMP group query message after the IGMP Querier receives the IGMP Leave message from the host.

Use the `undo igmp robust-count` command to restore the default value.

Syntax

```
igmp robust-count robust-value
```

```
undo igmp robust-count
```

Parameters

robust-value

IGMP robust value, number of sending the IGMP group query message after the IGMP query router receives the IGMP Leave message from the host. Valid values are 2 to 5.
If no value is specified, the default is 2.

Example

Set the robust value at the Vlan-interface 10 as 3.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Vlan-interface 10
[SW5500-Vlan-interface10]igmp robust-count 3
```

View

This command can be used in the following views:

- VLAN Interface view

Description

In the shared network, that is, a network segment including multiple hosts and multicast routers, the IGMP Querier is responsible for maintaining the IGMP group membership on the interface. When an IGMP v2 host leaves a group, it sends an IGMP Leave message. When the IGMP Leave message is received, the IGMP Querier must send an IGMP group-specific query message a specified number of times (set using the `igmp robust-count` command, with a default value of 2) in a specified time interval. (Set using the `igmp lastmember-queryinterval` command, with default value of 1 second).

If other hosts that are interested in the specified group receive the IGMP group-specific query message from the IGMP Querier, they send back an IGMP Membership Report message within the specified maximum response time interval. If the IGMP Querier receives the IGMP Membership Report message within the defined period (equal to robust-value seconds), the IGMP Querier continues to maintain the membership of this group. When no IGMP Membership Report messages are received from any hosts within the defined period, the IGMP Querier considers it a timeout and stops membership maintenance for the group.

This command only takes effect on an IGMP Querier running IGMP v2. For a Querier running IGMP v1, this command cannot take effect because the IGMP group members cannot send an IGMP Leave message when they leave a group.

Related Commands

- `display igmp interface`
- `igmp lastmember-queryinterval`

igmp-snooping

Purpose Use the **igmp-snooping** command to enable or disable the IGMP Snooping.

Syntax `igmp-snooping { enable | disable }`

Parameters

<code>enable</code>	Enables IGMP Snooping.
<code>disable</code>	Disables IGMP Snooping.

Default By default, IGMP Snooping is disabled on the switch.

Example Enable IGMP Snooping on the switch.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] igmp-snooping enable
```

View This command can be used in the following views:

- System view
- VLAN view

igmp-snooping fast-leave

Purpose Use the `igmp-snooping fast-leave` command to enable IGMP fast leave processing.

Use the `undo igmp-snooping fast-leave` command to cancel the configuration.

Syntax

```
igmp-snooping fast-leave
undo igmp-snooping fast-leave
```

Parameters None

Default By default, IGMP fast leave processing is disabled.

Example Enable IGMP fast leave processing on the Ethernet1/0/1 port.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] interface Ethernet 1/0/1
[S5500-Ethernet1/0/1] igmp-snooping fast-leave
```

View This command can be used in the following views:

- Ethernet Port view

Description Normally, when receiving an IGMP Leave message, IGMP Snooping does not immediately remove the port from the multicast group, but sends a group-specific query message. If no response is received in a given period, it then removes the port from the multicast group.

If this command is executed, when receiving an IGMP Leave message, IGMP Snooping removes the port from the multicast group immediately. When the port has only one user, enabling IGMP fast leave processing can save bandwidth.



Note: If the client(s) under the port are IGMP V2-enabled, this feature operates normally. Otherwise, when the port has multiple users, the leave of one user may disrupt the multicast to every other user under the port in the same multicast group.

igmp-snooping group-limit

Purpose

Use the **igmp-snooping group-limit** command to set the maximum number of multicast groups the port can join.

Use the **undo igmp-snooping group-limit** command to restore the default setting.

Syntax

```
igmp-snooping group-limit [ vlan vlan-list | overflow-replace ]
```

```
undo igmp-snooping group-limit [ vlan vlan-list ]
```

Parameters

limit	Maximum number of multicast groups the port can join. Valid values are 1 to 256.
overflow-replace	Allows new multicast groups to replace existing multicast groups in this order: the multicast group with the least IP address will be replaced first.
vlan-list	VLAN list, in the format of { vlan-id [to vlan-id] }&<1-10>, where vlan-id ranges from 1 to 4,094, and &<1-10> represents you can input at most 10 VLAN IDs/ VLAN ID ranges.

Default

By default, there is no limit on the number of multicast groups the port can join.

Example

Allow the Ethernet1/0/1 port to join at most 200 multicast groups.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] interface Ethernet 1/0/1
[S5500-Ethernet1/0/1] igmp-snooping group-limit 200
```

View

This command can be used in the following views:

- Ethernet Port view

igmp-snooping group-policy

Purpose

Use the **igmp-snooping group-policy** command to configure an IGMP Snooping filter ACL.

Use the **undo igmp-snooping group-policy** command to remove the IGMP Snooping filter ACL.

Syntax

```
igmp-snooping group-policy acl-number vlan vlan-list
```

```
undo igmp-snooping group-policy vlan vlan-list
```

Parameters

acl-number	Basic ACL number, in the range of 2000 to 2999.
vlan-id	VLAN list, in the format of { vlan-id [to vlan-id] } &<1-10>, where vlan-id ranges from 1 to 4,094, and &<1-10> means you can input at most 10 VLAN IDs/VLAN ID ranges.

Default

By default, no IGMP Snooping filter ACL is configured on the switch.

Example

Configure ACL 2000 to allow users to order the multicast programs in the multicast groups of 225.0.0.0 to 225.255.255.255.

- Configure ACL 2000.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] acl number 2000
[S5500-acl-basic-2000] rule permit source 225.0.0.0 0.255.255.255
```

- Create VLAN 2 and add the Ethernet 1/0/1 port to VLAN 2.

```
[S5500] vlan 2
[S5500-vlan2] port Ethernet 1/0/1
```

- Allow the Ethernet 1/0/1 port under VLAN 2 to join only the IGMP multicast groups defined in the rule of ACL 2000.

```
[S5500] interface Ethernet 1/0/1
[S5500-Ethernet1/0/1] igmp-snooping group-policy 2000 vlan 2
```

Configure ACL 2001 to allow users to order the multicast programs in any multicast groups except those in 225.0.0.0 to 225.0.0.255.

- Configure ACL 2001.

```
[S5500] acl number 2001
[S5500-acl-basic-2001] rule deny source 225.0.0.0 0.0.0.255
[S5500-acl-basic-2001] rule permit source any
```

- Create VLAN 2 and add the Ethernet 1/0/2 port to VLAN 2.

```
[S5500] vlan 2
[S5500-vlan2] port Ethernet 1/0/2
```

- Allow the Ethernet 1/0/2 port under VLAN 2 to join any IGMP multicast groups except those defined in the deny rule of ACL 2001.

```
[S5500] interface Ethernet 1/0/2
[S5500-Ethernet1/0/2] igmp-snooping group-policy 2001 vlan 2
```

View

This command can be used in the following views:

- System view
- Ethernet Port view

Description

You can configure some multicast filter ACLs globally or on the switch ports connected to user ends so as to use the IGMP Snooping filter function to limit the multicast programs that the users can order. With this function, you can treat different VoD users in different ways by allowing different users to order different groups of programs.

In practice, when a user orders a multicast program, an IGMP report message is generated. When the message arrives at the switch, the switch examines the multicast filter ACL configured on the access port to determine if the port can join the corresponding multicast group or not. If yes, it adds the port to the forward port list of the multicast group. If not, it drops the IGMP report message and does not forward the corresponding data stream to the port. In this way, you can control the multicast programs that users can order.

An ACL rule defines a multicast address or a multicast address range (for example 224.0.0.1 to 239.255.255.255) and is used to:

- Allow the port(s) to join only the multicast group(s) defined in the rule by a permit statement.
- Inhibit the port(s) from joining the multicast group(s) defined in the rule by a deny statement.



- *One port can belong to multiple VLANs. But for each VLAN on the port, you can configure only one ACL.*
- *If no ACL rule is configured or the port does not belong to the specified VLAN, the filter ACL you configured does not take effect on the port.*
- *Since most devices broadcast unknown multicast packets, this function is often used together with the unknown multicast packet drop function to prevent multicast streams from being broadcasted to a filtered port as unknown multicast.*

igmp-snooping host-aging-time

Purpose	<p>Use the igmp-snooping host-aging-time command to set the aging time of multicast member ports.</p> <p>Use the undo igmp-snooping host-aging-time command to restore the default aging time.</p>
Syntax	<pre>igmp-snooping host-aging-time <i>seconds</i> undo igmp-snooping host-aging-time</pre>
Parameters	<p><i>seconds</i> Aging time of multicast member ports. Valid values are 200 to 1000 (in seconds).</p>
Default	By default, the aging time of multicast member ports is 260 seconds.
Example	<p>Set the aging time of multicast member ports to 300 seconds.</p> <pre><S5500>system-view System View: return to User View with Ctrl+Z. [S5500] igmp-snooping host-aging-time 300</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view
Description	The aging time of multicast member ports determines the refresh frequency of multicast group members. In an environment where multicast group members change frequently, you should set a relatively short aging time, and vice versa.
Related Command	igmp-snooping

igmp-snooping max-response-time

Purpose

Use the **igmp-snooping max-response-time** command to configure the maximum query response time.

Use the **undo igmp-snooping max-response-time** command to restore the default maximum time.

Syntax

```
igmp-snooping max-response-time seconds
```

```
undo igmp-snooping max-response-time
```

Parameters

seconds

Maximum query response time. Valid values are 1 to 25 (in seconds).

Default

By default, the maximum query response time is 10 seconds.

Example

Set the maximum response time to an IGMP Snooping query message to 15 seconds.

```
<S5500>system-view  
System View: return to User View with Ctrl+Z.  
[S5500] igmp-snooping max-response-time 15
```

View

This command can be used in the following views:

- System view

Description

The maximum response time you configured determines how long the switch can wait for a response to an IGMP Snooping query message.

Related Commands

- **igmp-snooping**
- **igmp-snooping router-aging-time**

igmp-snooping router-aging-time

Purpose	<p>Use the igmp-snooping router-aging-time command to configure the aging time of the router port.</p> <p>Use the undo igmp-snooping router-aging-time command to restore the default aging time.</p>		
Syntax	<pre>igmp-snooping router-aging-time <i>seconds</i> undo igmp-snooping router-aging-time</pre>		
Parameters	<table><tr><td><i>seconds</i></td><td>Aging time of the router port. Valid values are 1 to 1000 (in seconds).</td></tr></table>	<i>seconds</i>	Aging time of the router port. Valid values are 1 to 1000 (in seconds).
<i>seconds</i>	Aging time of the router port. Valid values are 1 to 1000 (in seconds).		
Default	By default, the aging time of the router port is 260 seconds.		
Example	<p>Set the aging time of the router port to 500 seconds.</p> <pre><S5500>system-view System View: return to User View with Ctrl+Z. [S5500] igmp-snooping router-aging-time 500</pre>		
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view		
Description	<p>The router port here refers to the port connecting the Layer 2 switch to the router. The Layer 2 switch receives IGMP general query messages from the router through this port. The aging time of the router port should be a value about 2.5 times of the general query interval.</p>		
Related Commands	<ul style="list-style-type: none">■ igmp-snooping■ igmp-snooping max-response-time		

igmp timer other-querier-present

Purpose

Use the `igmp timer other-querier-present` command to configure the timer of presence of the IGMP querier.

Use the `undo igmp timer other-querier-present` command to restore the default value.

Syntax

```
igmp timer other-querier-present seconds
```

```
undo igmp timer other-querier-present
```

Parameters

seconds

IGMP querier present timer value in seconds. Valid values are 1 to 131070.

If not specified, the default is 120 seconds, that is, twice the value of IGMP query message interval.

Example

Set querier to expire after 300 seconds.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Vlan-interface 10
[SW5500-vlan-interface10]igmp timer other-querier-present 300
```

View

This command can be used in the following views:

- VLAN Interface view

Description

On a shared network, where there are multiple multicast routers on the same network segment, the query router (querier for short) takes charge of sending query messages periodically on the interface. If other non-queriers receive no query messages within the valid period, the router will consider the previous Querier to be invalid and the router itself becomes the querier.

In IGMP version 1, the selection of a Querier is determined by the multicast routing protocol. In IGMP version 2, the router with the lowest IP address on the shared network segment acts as the querier.

Related Commands

- `display igmp interface`
- `igmp timer query`

igmp timer query

Purpose

Use the `igmp timer query` command to configure the interval at which a router interface sends IGMP query messages.

Use the `undo igmp timer query` command to restore the default value.

Syntax

```
igmp timer query seconds
```

```
undo igmp timer query
```

Parameters

`seconds`

The interval, in seconds, at which a router transmits IGMP query messages. Valid values are 1 to 65535. If not specified, the default is 60 seconds.

Example

Configure to transmit the host-query message every 60 seconds via VLAN-interface2.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]interface Vlan-interface 2  
[SW5500-vlan-interface2]igmp timer query 60
```

View

This command can be used in the following views:

- VLAN Interface view

Description

A multicast router periodically sends out IGMP query messages to attached segments to find hosts that belong to different multicast groups. The query interval can be modified according to the practical conditions of the network.

Related Command

```
igmp timer other-querier-present
```


igmp version

Purpose Use the `igmp version` command to specify the version of IGMP that a router uses.

Use the `undo igmp version` command to restore the default value.

Syntax `igmp version { 1 | 2 }`

`undo igmp version`

Parameters

1	IGMP Version 1.
2	IGMP Version 2. If not specified, IGMP Version 2 is used as the default.

Example Run IGMP Version 1 on VLAN-interface10.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Vlan-interface 10
[SW5500-vlan-interface10]igmp version 1
```

View This command can be used in the following views:

- VLAN Interface view

Description All routers on a subnet must support the same version of IGMP. After detecting the presence of IGMP Version 1 system, the Switch cannot automatically change to Version 2.

import-route

Purpose

Using the `import-route` command, you can import the external routing information of another routing protocol.

Using the `undo import-route` command, you can cancel the import of external routing information.

Syntax

```
import-route protocol [ cost value ] [ type value ] [ tag value ] [
route-policy route_policy_name ]
```

```
undo import-route protocol
```

Parameters

<code>protocol</code>	Specifies the source routing protocol to be imported. This can be one of the following: direct, rip, and static.
<code>route-policy</code> <code>route_policy_name</code>	Specifies a route policy name. Only routes that match the specified route policy are imported.
<code>cost value</code>	Specifies the cost of the imported route.
<code>type value</code>	Specifies the cost type of imported routes. Valid values are 1 or 2. If not specified, the default is 2.
<code>tag value</code>	Specifies the tag value for imported external routes.

Default

The routing information of other protocols is not imported.

Example

To configure an imported RIP route with the external route of type 2, a route tag of 33 and a route cost of 50, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]import-route rip type 2 tag 33 cost 50
```

View

This command can be used in the following views:

- OSPF view

Description



3Com recommends that you configure the route type, cost, and tag together in one command; otherwise, the new configuration overwrites the old one.

import-route

Purpose

Use the **import-route** command to import the routes of other protocols into RIP.

Use the **undo import-route** command to cancel the import of routes from other protocols. By default, RIP does not import any other protocol's route.

Syntax

```
import-route protocol [ cost value | route-policy route-policy-name ]  
undo import-route protocol
```

Parameters

<i>protocol</i>	Specifies the routing protocol to be imported. Valid values are any of the following: <ul style="list-style-type: none">■ direct■ ospf■ ospf-ase■ ospf-nssa■ static
<i>value</i>	Specifies the cost value of the route to be imported.
<i>route-policy</i> <i>route_policy_name</i>	Specifies a route-policy name. Only routes that match the conditions of the specified policy are imported.

Example

To import a static route with a cost of 4, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]rip  
[SW5500-rip]import-route static cost 4
```

To set the default cost, and then import an OSPF route with this default cost, enter the following two commands:

```
[SW5500-rip]default cost 3  
[SW5500-rip]import-route ospf
```

View

This command can be used in the following views:

- RIP view

Description

The **import-route** command can be used to import the route of another protocol with a certain cost value. RIP regards the imported route as its own route and transmits it with the specified cost value. This command can greatly enhance the RIP capability of obtaining routes, thus increases the RIP performance.

If the **cost value** is not specified, routes will be imported according to the **default cost** ranging from 1 to 16. If the imported route cost value is 16, then RIP continues to announce this cost to other routers running RIP, and marks this route with HOLDDOWN. However, this router can still forward packets until the Garbage Collection timer times out (defaults to 120 seconds).

Related Command`default cost`

import-source

Purpose

Use the **import-source** command to specify the (S, G) entries in this domain that need to be advertised when an MSDP peer creates an SA message.

Use the **undo import-source** command to cancel the configuration.

Syntax

```
import-source [ acl acl-number ]
```

```
undo import-source
```

Parameters

acl-number

Basic or advanced IP ACL number. Valid values are 2000 to 3999. An ACL controls SA message advertisement by filtering sources (basic ACL) and filtering sources or groups (advanced ACL). If you do not specify this argument, no multicast source is advertised.

Default

By default, an SA message advertise all the (S, G) entries in the domain.

Example

Specify the (S, G) entries in the multicast routing table to be advertised when an MSDP peer creates an SA message.

```
<S5500> system-view
[S5500] acl number 3101
[S5500-acl-adv-3101] rule permit ip source 10.10.0.0 0.0.255.255
destination 225.1.0.0 0.0.255.255
[S5500-acl-adv-3101] quit
[S5500] msdp
[S5500-msdp] import-source acl 3101
```

View

This command can be used in the following views:

- MSDP view

Description

In addition, you can also use the **peer sa-policy import** command or the **peer sa-policy export** command to filter forwarded SA messages.

info-center channel name

Purpose

Use the `info-center channel name` command to rename a channel specified by the `channel-number` as `channel-name`.

Use the `undo info-center channel command`, to restore the channel name.

Syntax

```
info-center channel channel-number name channel-name
```

```
undo info-center channel channel-number
```

Parameters

channel-number

Channel number. Valid values are 0 to 9, that is, system has ten channels.

channel-name

Channel name. Valid values are a character string not exceeding 30 characters, excluding "-", "/" or "\".

Example

Rename channel 0 as execonsole.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]info-center channel 0 name execonsole
[SW5500]
```

View

This command can be used in the following views:

- System view

Description



The channel name cannot be duplicated.

info-center console channel

Purpose Use the `info-center console channel` command to configure the channel through which the log information is output to the console.

Syntax

```
info-center console channel { channel-number | channel-name }  
  
undo info-center console channel
```

Parameters

<i>channel-number</i>	Channel number. Valid values are 0 to 9, that is, system has ten channels.
<i>channel-name</i>	Channel name. The name can be channel6, channel7, channel8, channel9, console, logbuffer, loghost, monitor, snmpagent, trapbuffer.

Description By default, the Switch 5500 does not output log information to the console.

Example Configure to output log information to the console through channel 0.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]info-center console channel 0  
[SW5500]
```

View This command can be used in the following views:

- System view

Description This command takes effect only after system logging is started.

Related Command

- `display info-center`
- `info-center enable`

info-center enable

Purpose Use the `info-center enable` command to enable the system log function.
Use the `undo info-center enable` command to disable system log function.

Syntax `info-center enable`
`undo info-center enable`

Parameters None

Default By default, system log function is enabled.

Example Enable the system log function.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]info-center enable
% Information center is enabled
[SW5500]
```

View This command can be used in the following views:

- System view

Description Only after the system log function is enabled can the system output the log information to the info-center loghost and console.

Related Commands

- `display info-center`
- `info-center console channel`
- `info-center logbuffer`
- `info-center loghost`
- `info-center monitor channel`

info-center logbuffer

Purpose

Use the **info-center logbuffer** command to configure output information to the memory buffer.

Use the **undo info-center logbuffer** command to cancel the information output to buffer.

Syntax

```
info-center logbuffer [ channel { channel-number | channel-name } |  
size buffersize ]
```

```
undo info-center logbuffer [ channel | size ]
```

Parameters

channel	Configures the channel to output information to buffer.
<i>channel-number</i>	Channel number. Valid values are 0 to 9, that is, system has ten channels.
<i>channel-name</i>	Channel name. Valid values are channel6, channel7, channel8, channel9, console, logbuffer, loghost, monitor, snmpagent, and trapbuffer.
size	Configures the size of buffer.
<i>buffersize</i>	Size of buffer (number of messages that can be kept); If not specified, the default size of the buffer is 512.

Example

Send log information to buffer and sets the size of buffer as 50.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]info-center logbuffer 50  
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

This command takes effect only after system logging is enabled.

Related Command

- **info-center enable**
- **display info-center**

info-center loghost

Purpose

Use the `info-center loghost` command to set the IP address of the info-center loghost to send information to it.

Use the `undo info-center loghost` command to cancel output to info-center loghost.

Syntax

```
info-center loghost host-ip-addr [ channel { channel-number |
channel-name } | facility local-number | language { chinese | english }
]
undo info-center loghost
```

Parameters

<code>host-ip-addr</code>	IP address of info-center loghost.
<code>channel</code>	Configures information channel of the info-center loghost.
<code>channel-number</code>	Channel number. Valid values are 0 to 9, that is, the system has ten channels.
<code>channel-name</code>	Channel name. Valid values are channel6, channel7, channel8, channel9, console, logbuffer, loghost, monitor, snmpagent, and trapbuffer.
<code>facility</code>	Configures the recording tool of info-center loghost.
<code>local-number</code>	Record tool of info-center loghost. Valid values are local0 to local7.
<code>language</code>	Sets the logging language.
<code>chinese, english</code>	Language used in log file.

Default

By default, switches do not output information to info-center loghost.

Example

Configure to send log information to the UNIX workstation at 202.38.160.1.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]info-center loghost 202.38.160.1
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

This command takes effect only after the system logging is enabled.

Related Commands

- `display info-center`
- `info-center enable`

info-center loghost source

Purpose

Use the `info-center loghost source` command to set the source address of packets sent to the loghost as the address of the interface specified by the `interface-name` parameter.

Use the `undo info-center loghost source` command to cancel the setting of the source address of the packets sent to the loghost.

Syntax

```
info-center loghost source interface-name
```

```
undo info-center source
```

Parameters

```
source interface-name
```

Sets the source address of packets sent to the loghost as the address of the interface specified by `interface-name`. Normally, the interface is a VLAN interface.

Example

Set the source address of the packets sent to the loghost as the address of the VLAN interface 1.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]info-center loghost source vlan-interface 1
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

This command takes effect only after the system logging is enabled.

Related Commands

- `display info-center`
- `info-center enable`

info-center monitor channel

Purpose

Use the `info-center monitor channel` command to set the channel to output the log information to the user terminal.

Use `undo info-center monitor channel` command to restore the channel to output the log information to the user terminal to the default value.

Syntax

```
info-center monitor channel { channel-number | channel-name }
```

```
undo info-center monitor channel
```

Parameters

channel-number Channel number. Valid values are 0 to 9, that is, the system has ten channels.

channel-name Channel name. Valid values are channel6, channel7, channel8, channel9, console, logbuffer, loghost, monitor, snmpagent, and trapbuffer.

Default

By default, switches do not output log information to user terminal.

Example

Configure channel 0 to output log information to user terminal.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]info-center monitor channel 0  
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

This command takes effect only after system logging is started.

Related Commands

- `display info-center`
- `info-center enable`

info-center snmp channel

Purpose

Use the `info-center snmp channel` command to specify new channel for transmitting the SNMP information.

Use `undo info-center snmp channel` command to restore the channel for transmitting the SNMP information to default value.

Syntax

```
info-center snmp channel { channel-number | channel-name }  
undo info-center snmp channel
```

Parameters

<i>channel-number</i>	Channel number. Valid values are 0 to 9, that is, the system has ten channels. If not specified, the default is channel 5.
<i>channel-name</i>	Channel name. Valid values are channel6, channel7, channel8, channel9, console, logbuffer, loghost, monitor, snmpagent, and trapbuffer.

Example

Configure channel 6 as the SNMP information channel.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]info-center snmp channel 6  
[SW5500]
```

View

This command can be used in the following views:

- System view

Related Command

```
display snmp
```

info-center source

Purpose

Use the `info-center source` command to add/delete a record to the information channel.

Use the `undo info-center source` command to delete the contents of the information channel.

Syntax

```
info-center source { modu-name | default } channel { channel-number | channel-name } [ debug { level severity | state state }* | log { level severity | state state }* | trap { level severity | state state } ] *
```

```
undo info-center source { modu-name | default } channel { channel-number | channel-name }
```

Parameters

<code>modu-name</code>	Module name. See Table 92.
<code>default</code>	All the modules.
<code>log</code>	Log information.
<code>trap</code>	Trap information.
<code>debugging</code>	Debugging information.
<code>level</code>	Level.
<code>severity</code>	Specifies the level of information output. It is recommended that the severity of information not be below the information level. If not specified, the default log information level is warnings; the default trap information level is debugging; and the default debugging information level is debugging.



If you only specify the level for one or two of the three types of information, the level(s) of the unspecified type(s) return to the default. For example, if you only define the level of the log information, then the levels of the trap and debugging information return to the defaults.

You may specify any of the following severity levels:

emergencies

Level 1 information, which cannot be used by the system.

alerts

Level 2 information, to be reacted immediately.

critical

Level 3 information, critical information.

errors

Level 4 information, error information.

warnings

level 5 information, warning information.

notifications



	Level 6 information, showed normally and important.
	informational Level 7 information, notice to be recorded.
	debugging Level 8 information, generated during the debugging progress.
channel-number	Channel number to be set.
channel-name	Channel name to be set. Valid values are channel6, channel7, channel8, channel9, console, logbuffer, loghost, monitor, snmpagent, and trapbuffer.
state	Set the state of the information.
state	Specify the state as on or off.
	By default, the log information level is warnings, the trap information level is debugging, the debugging information level is debugging.

Table 92 Module names in logging information

Module name	Description
8021X	802.1X module
ACL	Access control list module
AM	Access management module
ARP	Address resolution protocol module
CFAX	Configuration proxy module
CFG	Configuration management platform module
CFM	Configuration file management module
CMD	Command line module
COMMONSY	Common system MIB module
DEV	Device management module
DHCC	DHCP Client module
DHCP	Dynamic host configuration protocol module
DRV	Driver module
DRV_MNT	Driver maintenance module
ESP	End-station polling module
ETH	Ethernet module
FIB	Forwarding module
FTM	Fabric topology management module
FTMCMD	Fabric topology management command line module
FTPS	FTP server module
HA	High availability module
HTTPD	HTTP server module
IFNET	Interface management module
IGSP	IGMP snooping module
IP	IP module
IPC	Inter-process communication module
IPMC	IP multicast module
L2INF	Interface management module

Table 92 Module names in logging information (continued)

Module name	Description
LACL	LANswitch ACL module
LQOS	LANswitch QoS module
LS	Local server module
MPM	Multicast port management module
NTP	Network time protocol module
PPRDT	Protocol packet redirection module
PTVL	Driver port, VLAN (Port & VLAN) module
QACL	QoS/ACL module
QOSF	Qos profile module
RDS	Radius module
RM	Routing management
RMON	Remote monitor module
RSA	Revest, shamir and adleman encryption system
RTPRO	Routing protocol
SHELL	User interface
SNMP	Simple network management protocol
SOCKET	Socket
SSH	Secure shell module
STP	Spanning tree protocol module
SYSTEMIB	System MIB module
TELNET	Telnet module
UDPH	UDP helper module
VFS	Virtual file system module
VTY	Virtual type terminal module
WCN	Web management module
XM	XModem module

Example

Configure to enable the log information of STP module in SNMP channel and allows the output of the information with a level no higher than emergencies.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]info-center source stp channel snmpagent log level emergencies
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

For example, for the filter of IP module log output, you can configure to output the logs at a level higher than warnings to the log host and output those higher than informational to the log buffer. You can also configure to output the trap information on the IP module to a specified trap host.

The channels for filtering in all the directions are specified by this configuration command. All the information will be sent to the corresponding directions through

the specified channels. You can configure the channels in the output direction, channel filter information, filtering and redirecting of all kinds of information.

At present, the system distributes an information channel in each output direction by default, shown as follows:

Table 93 Information channel in each output direction by default

Output direction	Information channel name
Console	console
Monitor	monitor
Info-center loghost	loghost
Log buffer	logbuffer
Trap buffer	trapbuffer
snmp	snmpagent

In addition, each information channel has a default record with the module name "all" and module number as 0xffff0000. However, for different information channel, the default log, trap and debugging settings in the records may be different with one another. Use default configuration record if a module does not have any specific configuration record in the channel.

info-center switch-on

Purpose

Use the `info-center switch-on` command to turn on the information synchronization switch of the specified switch.

Use the `undo info-center switch-on` command to turn off the information synchronization switch of the specified switch.

Syntax

```
info-center switch-on { unit-id | master | all } [ debugging | logging  
| trapping ]*
```

```
undo info-center switch-on { unit-id | master | all } [ debugging |  
logging | trapping ]*
```

Parameters

<code>unit-id</code>	Unit ID of switch.
<code>master</code>	Master switch of Fabric.
<code>all</code>	All switches of Fabric.
<code>debugging</code>	Debugging information.
<code>logging</code>	Log information.
<code>trapping</code>	Trap information.

Default

By default, the debugging information synchronization switch on master unit is enabled, log information and trap information switches on master unit are disabled, all information synchronization switches on slave unit are disabled.

Example

To turn on the trapping information synchronization switch of the unit 2, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]info-center switch-on 2 trapping  
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

After the forming of a Fabric by switches that support the XRN, the log, debugging and trap information among the switches is synchronous. The synchronization process is as follows: each switch sends its own information to other switches in the Fabric and meantime receives the information from others, and then the switch updates the local information to ensure the information coincidence within the Fabric.

The switch provides command line to turn on/off the synchronization switch in every switch. If the synchronization switch of a switch is turned off, it does not send information to other switches but still receives information from others.

info-center synchronous

Purpose

Use the **info-center synchronous** command to enable the synchronous information output function.

Use the **undo info-center synchronous** command to disable the synchronous information output function.

Syntax

```
info-center synchronous
```

```
undo info-center synchronous
```

Parameters

None

Default

By default, the synchronous information output function is disabled.

Example

Enable synchronous information output function.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] info-center synchronous
Current IC terminal output sync is on
```

View

This command can be used in the following views:

- System view

Description

While enabled, the synchronous information output function allows the system to display command line prompts and users' input so far after each system output, helping users continue with their input.



Note:

- Use the **info-center synchronous** command to prevent users' input from being interrupted by system output and to realize synchronous information output.
- It is recommended that you disable this function during debugging, as the **info-center synchronous** command produces unnecessary output by displaying command line prompts after each piece of debugging information.

info-center timestamp

Purpose

Use the `info-center timestamp` command to configure the timestamp output format in debugging/trap information.

Use the `undo info-center timestamp` command to disable the output of timestamp field.

Syntax

```
info-center timestamp { log | trap | debugging } { boot | date | none }  
undo info-center timestamp { log | trap | debugging }
```

Parameters

<code>log</code>	Log information.
<code>trap</code>	Trap information.
<code>debugging</code>	Debugging information.
<code>boot</code>	Time elapsing after system starts. Format: xxxxxx.yyyyyy, xxxxxx is the high 32 bits of the elapsed time (in milliseconds) after system starts, and yyyyyy is the low 32 bits.
<code>date</code>	Current system date and time. It shows as yyyy/mm/dd-hh:mm:ss in Chinese environment and mm/dd/yyyy-hh:mm:ss in Western language environment.
<code>None</code>	No timestamp format.

Default

By default, datetime stamp is used.

Example

Configure the debugging information timestamp format as boot.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]info-center timestamp debugging boot  
[SW5500]
```

View

This command can be used in the following views:

- System view

info-center timestamp loghost

Purpose

Use the `info-center timestamp loghost` command to set the format of time stamp to be sent to log host.

Use the `undo info-center timestamp loghost` command to restore to the default system format.

Syntax

```
info-center timestamp loghost { date | no-year-date | none }
```

```
undo info-center timestamp loghost
```

Parameters

<code>date</code>	The current system time and date, in the format of yyyy/mm/dd-hh:mm:ss. If no value is specified, the date time stamp is used as the default.
<code>no-year-date</code>	The current system time and date without year information, in the format of yyyy/mm/dd-hh:mm:ss.
<code>none</code>	Indicates that the output log information does not include time stamp information.

Example

Set the time stamp to be sent to the log host as a format without year information.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] info-center timestamp loghost no-year-date
```

View

This command can be used in the following views:

- System view

info-center trapbuffer

Purpose

Use the `info-center trapbuffer` command to output information to the trap buffer.

Use the `undo info-center trapbuffer` command to cancel output information to trap buffer.

Syntax

```
info-center trapbuffer [ size buffersize ][ channel { channel-number | channel-name } ]
```

```
undo info-center trapbuffer
```

Parameters

<code>size</code>	Configures the size of the trap buffer. If not specified, the default is 256.
<code>buffersize</code>	Size of trap buffer (numbers of messages).
<code>channel</code>	Configures the channel to output information to trap buffer.
<code>channel-number</code>	Channel number. Valid values are 0 to 9, that is, the system has ten channels.
<code>channel-name</code>	Channel name.

Default

By default, output information is transmitted to the trap buffer.

Example

Send information to the trap buffer and sets the size of buffer as 30.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]info-center trapbuffer size 30
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

This command takes effect only after system logging is enabled.

Related Commands

- `display info-center`
- `info-center enable`

instance

Purpose

Use the **instance** command to map specified VLANs to a specified spanning tree instance.

Use the **undo instance** command to remove the mappings from specified VLANs to a specified spanning tree instance.

Syntax

```
instance instance-id vlan vlan-list
```

```
undo instance instance-id [ vlan vlan-list ]
```

Parameters

instance-id ID of a spanning tree instance. Valid values are 0 to 16. A value of 0 specifies the CIST. If not specified, the default is 0.

vlan-list List of VLANs. You must provide this argument in the form of *vlan-list* = { *vlan-id* [to *vlan-id*] }&<1-10>, where &<1-10> means that you can provide up to 10 VLAN IDs/VLAN ID lists for this argument. Normally, a VLAN ID can be a number ranging from 1 to 4094. VLANs with their IDs beyond this range (if the switch supports this kind VLAN IDs), such as VLAN 4095 and VLAN 4096, can only be mapped to the CIST (spanning tree instance 0).

Example

Map VLAN 2 to spanning tree instance 1.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp region-configuration  
[S5500-mst-region] instance 1 vlan 2
```

View

This command can be used in the following views:

- MST Region view

Description

When using the **undo instance**, the specified VLANs will then be mapped to the CIST (spanning tree instance 0) again. If you specify no VLAN in the **undo instance** command, all VLANs that are mapped to the specified spanning tree instance are mapped to the CIST again.

In MSTP, VLAN-to-spanning tree instance mappings are recorded in VLAN mapping tables. You can use the **instance** command to configure the VLAN mapping tables, that is, map VLANs to different spanning tree instances.



A VLAN cannot be mapped to multiple spanning tree instances. A VLAN-to-spanning tree instance mapping is automatically removed if you map the VLAN to another spanning tree instance.

Related Commands

- active region-configuration
- check region-configuration
- region-name
- revision-level
- vlan-mapping modulo

interface

Purpose Use the command `interface interface_type interface_number` to enter the interface of the specified port.

Syntax `interface interface_type interface_num | interface_name`

Parameters

<code>interface_type</code>	Specifies the interface type. The interface type can be either Aux, Ethernet, GigabitEthernet, NULL, Vlan-interface.
<code>interface_number</code>	Specifies the interface number in the format unit-number/0/port-number. Specifies the unit number. Valid values are 1 to 8. Specifies the port number. Valid values are 1 to 28 or 1 to 52, depending on the number of ports you have on your unit.



You can use the `interface_name` at this command. This consists of the `interface_type` and the `interface_number` combined as a single parameter. For example `Ethernet1/0/1`.

Example To enter the interface for port "Ethernet1/0/1", enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface ethernet1/0/1
[SW5500-ethernet1/0/1]
```

View This command can be used in the following views:

- System view

Description If you want to configure the parameters of an Ethernet port, you must first use this command to enter the Ethernet port view.

interface VLAN-interface

Purpose

Use the `interface vlan-interface` command to enter a VLAN interface view and use the related configuration commands.

Use the `undo interface vlan-interface` command to exit the current VLAN interface.

Syntax

```
interface vlan-interface vlan_id
```

```
undo interface vlan-interface vlan_id
```

Parameters

vlan_id

The ID of the VLAN interface you want to configure. Valid values are 1 to 4094. If not specified, the default is VLAN1, which cannot be deleted.

Example

To enter the interface view of VLAN1, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500] interface vlan-interface 1
[SW5500-Vlan-interface1]
```

View

This command can be used in the following views:

- System view

Related Command

```
display interface VLAN-interface
```

ip address

Purpose

Use the `ip address` command to configure either the primary or secondary IP address and IP subnet mask for a VLAN interface.

Use the `ip address ip_address mask` command to configure the primary IP address and IP subnet mask for a VLAN interface.

Use the `ip address ip_address mask sub` command to configure a secondary address and IP subnet mask for a VLAN interface.

Use the `undo ip address ip_address mask sub` command to cancel a secondary IP address and IP subnet mask of a VLAN interface.

Use the `undo ip address ip_address mask` command to cancel the primary IP address and IP subnet mask of a VLAN interface.

Use the `undo ip address` command without any parameters to delete the primary and secondary IP addresses of an interface.

Syntax

```
ip address ip_address { mask | mask_length } [ sub ]  
[ undo ] ip address [ ip-address { mask | mask_length } [ sub ] ]
```

Parameters

<i>ip_address</i>	Specifies the IP address of the VLAN interface. If not specified, the default IP address is Null.
<i>mask</i>	Specifies the IP subnet mask of the VLAN interface.
<i>mask_length</i>	Specifies the IP mask length of the VLAN interface.
<i>sub</i>	Specifies if the specified IP address and subnet mask are a secondary IP address and subnet mask for this VLAN interface.

Example

Configure the IP address of interface VLAN interface 1 as 202.38.10.66 and subnet mask as 255.255.255.0.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface vlan-interface 1  
[SW5500-vlan-interface1]ip address 202.38.10.66 255.255.255.0
```

View

This command can be used in the following views:

- VLAN Interface view

Description

Usually, only one IP address is required for each interface. If you want to connect the interface to several subnets, you can configure an IP addresses for each subnet.

Before you can cancel the primary IP address of an interface, you must cancel any secondary IP addresses.

The subnet address of an IP address can be identified by subnet mask. For instance, the IP address of an interface is 202.38.10.102, and the mask is 255.255.0.0. You can confirm that the subnet address is 202.38.0.0 by performing the logic operation "AND" on the IP address and mask.



Note that the VLAN interface cannot be configured with the secondary IP address if its IP address is set to be allocated by BOOTP or DHCP.

Related Command

```
display interface VLAN-interface
```

ip address bootp-alloc

Purpose	<p>Use the <code>ip address bootp-alloc</code> command to configure VLAN interface to obtain IP address using BOOTP.</p> <p>Use the <code>undo ip address bootp-alloc</code> command to remove the configuration.</p>
Syntax	<pre>ip address bootp-alloc undo ip address bootp-alloc</pre>
Parameters	None
Default	By default, the VLAN interface does not obtain an IP address using BOOTP.
Example	<p>To configure VLAN interface 1 to obtain IP address using BOOTP, enter the following:</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]interface vlan-interface 1 [SW5500-Vlan-interface1]ip address bootp-alloc</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ VLAN Interface view
Related Command	<code>display bootp client</code>

ip address dhcp-alloc

Purpose

Use the **ip address dhcp-alloc** command to configure VLAN interface to obtain IP address using DHCP.

Use the **undo ip address dhcp-alloc** command to remove the configuration.

Syntax

```
ip address dhcp-alloc
```

```
undo ip address dhcp-alloc
```

Parameters

None

Default

By default, the VLAN interface does not obtain an IP address using DHCP.

Example

To configure VLAN interface to obtain IP address using DHCP, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface vlan-interface 1  
[SW5500-Vlan-interface1]ip address dhcp-alloc
```

View

This command can be used in the following views:

- VLAN Interface view

ip host

Purpose

Use the **ip host** command to configure the host name and the host IP address in the Switch 5500's host table. This allows you to ping or Telnet a local device by host name.

Use the **undo ip host** command to remove the host name and the host IP address from the host table.

Syntax

```
ip host hostname ip_address
```

```
undo ip host hostname [ ip_address ]
```

Parameters

<i>hostname</i>	Specifies the host name of the connecting device, which may be up to 20 characters long. If not specified, the default host name is Null.
<i>ip_address</i>	Specifies the host's IP address. If not specified, the default IP address is Null.

Example

To enter a host name of Lanswitch1 for the IP address 202.38.0.8, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]ip host Lanswitch1 202.38.0.8
```

View

This command can be used in the following views:

- System view

Related Command

```
display ip host
```

ip http acl

Purpose

Use the `ip http acl` command to call an ACL and perform ACL control over the WEB network management users.

Use the `undo ip http acl` command to cancel the ACL control over the WEB network management users.

Syntax

```
ip http acl acl-number
```

```
undo ip http acl
```

Parameters

acl-number

Specifies a basic ACL. Valid values are a number from 2000 to 2999.

Example

To perform ACL control over the WEB network management users, enter the following: (Suppose ACL 2020 has been defined.)

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]ip http acl 2020  
[SW5500]
```

View

This command can be used in the following views:

- User Interface view

Description

This command calls numbered basic ACL only.

ip ip-prefix

Purpose

Use the `ip ip-prefix` command to configure an address prefix list or one of its items.

Use the `undo ip ip-prefix` command to delete an address prefix list or one of its items.

Syntax

```
ip ip-prefix ip_prefix_name [ index index_number ] { permit | deny }  
network len [ greater-equal greater_equal | less-equal less_equal ]
```

```
undo ip ip-prefix ip_prefix_name [ index index_number | permit | deny ]
```

Parameters

<code>ip_prefix_name</code>	Specifies the address prefix list name. It identifies one address prefix list uniquely.
<code>index_number</code>	Identifies an item in the prefix address list. The item with smaller index-number will be tested first.
<code>permit</code>	Specifies the match mode of the defined address prefix list items as permit mode.
<code>deny</code>	Specifies the match mode of the defined address prefix list items as deny mode.
<code>network</code>	Specifies the IP address prefix range (IP address). If it is 0.0.0.0 0, all the IP addresses are matched.
<code>len</code>	Specifies the IP address prefix range (mask length). If it is 0.0.0.0 0, all the IP addresses are matched.
<code>greater_equal, less_equal</code>	The address prefix range [greater-equal, less-equal] to be matched after the address prefix network len has been matched. The meaning of greater-equal is "larger than or equal to", and the meaning of less-equal is "less than or equal to". The range is len <= greater-equal <= less-equal <= 32. When only greater-equal is used, it denotes the prefix range [greater-equal, 32]. When only less-equal is used, it denotes the prefix range [len, less-equal].

Default

By default, there's no address prefix list.

Example

The prefix address list of this address indicates to match the bits 1 to 8 and the bits 17 to 18 for filtering the IP address with the bits 1 to 8 and the bits 17 to 18 of the specified IP network segment 10.0.192.0.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]ip ip-prefix p1 permit 10.0.192.0 8 greater-equal 17 less-equal  
18
```

View

This command can be used in the following views:

- System view

Description

The address prefix list is used for IP address filtering. An address prefix list may contain several items, and each item specifies one address prefix range. The inter-item filtering relation is "OR", that is, passing an item means passing the filtering of this address prefix list. Not passing the filtering of any item means not passing the filtration of this prefix address list.

The address prefix range may contain two parts, which are determined by *len* and [*greater-equal*, *less-equal*] respectively. If the prefix ranges of these two parts are both specified, the IP to be filtered must match the prefix ranges of these two parts.

If you specify *network len* as 0.0.0.0 0, it only matches the default route.

ip-pool

Purpose

Use the **ip-pool** command to configure a private IP address range for cluster members on the switch to be set as the management device.

Use the **undo ip-pool** command to cancel the IP address configurations of the cluster.

Syntax

```
ip-pool administrator-ip-address { ip-mask | ip-mask-length }  
undo ip-pool
```

Parameters

<i>administrator-ip-address</i>	IP address of the management device of the cluster.
<i>ip-mask</i>	Mask of the cluster IP address pool.
<i>ip-mask-length</i>	Mask length of the cluster IP address pool.

Example

Configure the IP address range of a cluster.

```
<S5500>system-view  
System View: return to User View with Ctrl+Z.  
[S5500]cluster  
[S5500-cluster] ip-pool 10.200.0.1 20
```

View

This command can be used in the following views:

- Cluster view

Description

Before setting up a cluster, the user should configure a private IP address pool for cluster member devices. When a candidate device is added, the management device will dynamically assign a private IP address, which can be used for communication inside the cluster. In this way, the user can use the management device to manage and maintain the member devices.

The commands can only be executed on a non-cluster-member switch. The IP address range of an existing cluster cannot be modified.

ip route-static

Purpose

Use the **ip route-static** command to configure a static route, whose validity depends on detecting results as follows: valid when the detecting result is reachable or invalid when the detecting result is unreachable.

Use the **undo ip route-static** command to remove an existing static route.

Syntax

```
ip route-static ip-address { mask | mask-length } next-hop [ preference preference-value ] [ reject | blackhole ] detect-group group-number
```

```
undo ip route-static ip-address { mask | mask-length } [ next-hop ] [ preference preference-value ]
```

Parameters

ip-address	IP address in dotted decimal notation.
mask	Subnet mask.
mask-length	Length of the subnet mask, that is, the number of successive bits in the subnet mask whose values are 1.
next-hop	Next hop IP address in dotted decimal notation.
preference-value	Preference value of the route. This argument ranges from 1 to 255.
reject	Specifies the route to be unreachable. If you specify this keyword when executing this command, any packet destined for the specified IP address is discarded, and the system informs the source that the destination is unreachable.
blackhole	Specifies the route to be a black hole. If you specify this keyword when executing this command, all outbound interfaces of the static route are the Null 0 interfaces regardless of the next hop. In addition, the system discards any packet transmitted along this route without informing the source.
group-number	Detecting group number. Valid values are 1 to 50.

Example

Configure a static route to 192.168.0.5/24 with 192.168.0.2 as the next hop. The route is to be enabled when the result of detecting group 10 is reachable.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] ip route-static 192.168.0.5 24 192.168.0.2 detect-group 10
```

View

This command can be used in the following views:

- System view

jumboframe enable

Purpose

Use the **jumboframe enable** command to allow jumbo frames to pass through the specified Ethernet port.

Use the **undo jumboframe enable** command to prevent jumbo frames from passing through an Ethernet port.

Syntax

```
jumboframe enable
```

```
undo jumboframe enable
```

Parameters

None

Example

Allow jumbo frames to pass through Ethernet port 1/0/1.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface ethernet 1/0/1  
[SW5500-Ethernet1/0/1]jumboframe enable  
[SW5500-Ethernet1/0/1]
```

View

This command can be used in the following views:

- Ethernet Port view

Description

If using the 3comoscfg.def default file, jumbo frame support is disabled on all ports. When it is enabled, frames between 1522 bytes and 9216 bytes are permitted.



*Only the Switch 5500-EI supports the **jumboframe** command.*

key

Purpose

Use the **key** command to configure a shared key for HWTACACS authentication, authorization or accounting.

Use the **undo key** command to delete the configuration.

Syntax

```
key { accounting | authentication | authorization } string
```

```
undo key { accounting | authentication | authorization } string
```

Parameters

accounting	Shared key of the accounting server.
authentication	Shared key of the authentication server.
authorization	Shared key of the authorization server.
<i>string</i>	The name of the shared key, comprised of a string up to 16 characters excluding the characters "?".

Example

Use "hello" as the shared key for HWTACACS accounting.

```
[S5500] hwtacacs scheme test1  
[S5500-hwtacacs-test1] key accounting hello
```

View

This command can be used in the following views:

- HWTACACS view

Description

By default, no key is set.

The HWTACACS client (the switch system) and HWTACACS server use MD5 algorithm to encrypt the exchanged packets. The two ends verify packets using a shared key. Only when the same key is used can both ends accept the packets from each other and give responses. So it is necessary to ensure that the same key is set on the switch and the HWTACACS server. If the authentication/authorization and accounting are performed on two server devices with different shared keys, you must set one shared key for each.

Related Command

```
display hwtacacs
```


lacp enable

Purpose Use the `lacp enable` command to enable LACP.
Use the `undo lacp enable` command to disable LACP.

Syntax `lacp enable`
`undo lacp enable`

Parameters None

Example To enable LACP at Ethernet1/0/1, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface ethernet 1/0/1  
[SW5500-Ethernet1/0/1]lacp enable  
[SW5500-Ethernet1/0/1]
```

View This command can be used in the following views:

- Ethernet Port view

Description The Switch will select the lowest port number as the master port for the link aggregation. This applies to all types of link aggregation. If the aggregation spans a stack of units (only available on the Switch 5500-EI) and the same ports are used, the unit number will be the tie-breaker. For example, 1/0/1 and 2/0/1 are in an aggregation. Port 1/0/1 will be the master port.

lacp port-priority

Purpose Use the `lacp port priority` command to configure port priority value.
Use the `undo lacp port-priority` command to restore the default value.

Syntax `lacp port-priority port-priority-value`
`undo lacp port-priority`

Parameters `port-priority-value` Port priority. Valid values are 0 to 65535.
If not specified, the default is 32768.

Example To set port priority as 64, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]lacp port-priority 64
[SW5500-Ethernet1/0/1]
```

View This command can be used in the following views:

- Ethernet Port view

Related Commands

- `display link-aggregation interface`
- `display link-aggregation verbose`

lacp system-priority

Purpose Use the `lacp system-priority` command to configure system priority value.

Use the `undo lacp system-priority` command to restore the default value.

Syntax `lacp system-priority system-priority-value`

`undo lacp system-priority`

Parameters `system-priority-value`

System priority. Valid values are 0 to 65535.
If not specified, the default is 32768.

Example To set system priority as 64, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]lacp system-priority 64
[SW5500]
```

View This command can be used in the following views:

- System view

Related Command `display lacp system-id`

language-mode

Purpose Use the `language-mode` command to choose the language of the command line interface.

Syntax `language-mode { chinese | english }`

Parameters

<code>chinese</code>	Sets the language of the command line interface to Chinese.
<code>english</code>	Sets the language of the command line interface to English. If not specified, the default is English.

Example To change the command line interface from English to Chinese, enter the following:

```
<SW5500-ui-aux0>language-mode chinese
```

View This command can be used in the following views:

- User view

lcd

Purpose Use the `lcd` command to display local working path of FTP Client.

Syntax `lcd`

Parameters None

Example Show local working path.

```
<SW5500>ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in
[ftp]lcd
% Local directory now flash:/temp
[ftp]
```

View This command can be used in the following views:

- FTP Client view

level

Purpose

Use the `level` command to configure user priority level.

Use the `undo level` command to restore the default user priority level.

Syntax

```
level level
```

```
undo level
```

Parameters

`level`

Specifies user priority level, an integer ranging from 0 to 3.

If not specified, the default user priority level is 0.

Example

To set the priority level of the user 3Com to 3, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]local-user 3Com1
[SW5500-luser-3Com1]level 3
```

View

This command can be used in the following views:

- Local User view

Description



If the configured authentication mode is none authentication or password authentication, the command level that a user can access after login depends on the priority of user interface. In the case of authentication requiring both username and password, however, the accessible command level depends on user priority level.

Related Command

`local-user`

line-rate

Purpose

Use the **line-rate** command, to limit the total rate of the packets received or delivered by interfaces.

Use the **undo line-rate** command, to cancel the configuration of limit rate at interfaces.

Syntax

```
line-rate { inbound | outbound } target-rate
```

```
undo line-rate { inbound | outbound }
```

Parameters

inbound	Limits the rate of received packets.
outbound	Limits the rate of delivered packets.
target-rate	The total limited rate of the packets sent by interfaces. Unit in Kbps. The number input must be a multiple of 64. For 100 Mbps port, the range is from 64 to 99968; for 1000 Mbps port, the range is from 64 to 1000000.

Example

Set the rate limitation of interface Ethernet1/0/1 to 128 kbps.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]interface Ethernet 1/0/1  
[SW5500-Ethernet1/0/1] line-rate inbound 128  
[SW5500]line-rate outbound 128
```

View

This command can be used in the following views:

- Ethernet Port view

Description

The granularity of line rate is 64 kbps.

link-aggregation group agg-id description

Purpose

Use the `link-aggregation group agg-id description` command to configure descriptor for an aggregation group.

Use the `undo link-aggregation group agg-id description` command to delete aggregation group descriptor.

Syntax

```
link-aggregation group agg-id description aname
```

```
undo link-aggregation group agg-id description
```

Parameters

<i>agg-id</i>	Aggregation group ID. Valid values are 1 to 416.
<i>aname</i>	Aggregation group name, consisting of a character string from 1 to 32 characters long.

Example

To configure myal1 as the descriptor of aggregation group 22, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]link-aggregation group 22 mode manual
[SW5500]link-aggregation group 22 description myal1
[SW5500]
```

View

This command can be used in the following views:

- System view

Related Command

```
display link-aggregation verbose
```


link-aggregation group agg-id mode

Purpose

Use the `link-aggregation group agg-id mode` command to create a manual or static aggregation group.

Use the `undo link-aggregation group` command to delete an aggregation group.

Syntax

```
link-aggregation group agg-id mode { manual | static }  
  
undo link-aggregation group agg-id
```

Parameters

<code>agg-id</code>	Aggregation group ID. Valid values are 1 to 416.
<code>manual</code>	Manual aggregation group.
<code>static</code>	Static aggregation group.

Example

To create manual aggregation group 22, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]link-aggregation group 22 mode manual
```

View

This command can be used in the following views:

- System view

Description

The Switch will select the lowest port number as the master port for the link aggregation. This applies to all types of link aggregation. If the aggregation spans a stack of units (only available on the Switch 5500-EI) and the same ports are used, the unit number will be the tie-breaker. For example, 1/0/1 and 2/0/1 are in an aggregation. Port 1/0/1 will be the master port.

A manual or static aggregation group can have up to eight ports. You can use the `link-aggregation group agg-id mode` command to change an existing dynamic aggregation group into a manual or static one. If the port number in a group exceeds eight, this operation fails and the system prompts you about the configuration failure.

Related Command

```
display link-aggregation summary
```

local-server

Purpose Use the `local-server` command to configure the parameters of local RADIUS server.
Use the `undo local-server` command to cancel a local RADIUS server.

Syntax

```
local-server nas-ip ip-address key password
undo local-server nas-ip ip-address
```

Parameters

<code>nas-ip <i>ip-address</i></code>	Set NAS-IP address of access server. <i>ip-address</i> is expressed in the format of dotted decimal. If not specified, the default local server with the NAS-IP address of 127.0.0.1 is used.
<code>key <i>password</i></code>	Set password of logon user. <i>password</i> is a character string up to 16 characters long.

Example To set the IP address of local RADIUS authentication server to 10.110.1.2 and the password to 3Com, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]local-server nas-ip 10.110.1.2 key 3Com
```

View This command can be used in the following views:

- System view

Description RADIUS service, which adopts authentication/authorization/accounting servers to manage users, is widely used in the Switch 5500. Besides, local authentication/authorization service is also used in these products and it is called local RADIUS function, that is, realize basic RADIUS function on the Switch.



When using local RADIUS server function, remember the number of the UDP port used for authentication is 1645 and that for accounting is 1646.

The password configured by this command must be the same as that of the RADIUS authentication/authorization packet configured by the command `key authentication` in the RADIUS Scheme View.

The Switch 5500 Series supports up to 16 local RADIUS authentication servers.

Related Commands

- `key`
- `radius-scheme`
- `state`

local-user

Purpose

Use the **local-user** command to add a local user and enter local user view.

Use the **undo local-user** command to delete the specified local user(s).

Syntax

```
local-user user-name
```

```
undo local-user { user-name | all [ service-type { telnet | ftp |  
lan-access | ssh | terminal } ] }
```

Parameters

user-name Local user name, a character string of no more than 80 characters. This string cannot contain the following characters: /:*?<>. It can contain no more than one "@" character; the pure user name (the part before "@", that is, the user ID) cannot be longer than 55 characters. The user name is case-insensitive; that is, the system considers "UserA" and "usera" the same user.

service-type Specifies a user type. You can specify one of the following user types: telnet, ftp, lan-access (this type of users are mainly Ethernet access users, for example, 802.1x users), ssh, and terminal (this type of users can use terminal service, that is, the users can log into the switch through Console port, AUX port, or Asynchronous serial port).

all Specifies all users.

Example

Add a local user named hello1.

```
<S5500> sys  
System View: return to User View with Ctrl+Z.  
[S5500] local-user hello1  
[S5500-luser-hello1]
```

View

This command can be used in the following views:

- System view

local-user password-display mode

Purpose

Use the `local-user password-display-mode` command to set the password display mode to be used when the switch displays the local users.

Use the `undo local-user password-display-mode` command to restore the default password display mode.

Syntax

```
local-user password-display-mode { auto | cipher-force }
```

```
undo local-user password-display-mode
```

Parameters

`auto`

Specifies to display passwords in the modes adopted when the passwords are set. If a password is set in cipher mode, the password will be displayed in cipher text; or else, the password will be displayed in plain text.

If not specified, the default password display mode of local users is auto.

`cipher-force`

Specifies to display passwords in cipher text forcibly.

Example

Set the password display mode to be used when the switch displays local users to ***cipher-force***.

```
[S5500] local-user password-display-mode cipher-force
```

View

This command can be used in the following views:

- System view

Description

If the ***cipher-force*** mode is adopted, the passwords will be displayed in cipher text even though the `password` command is used to specify the password display mode to simple.

lock

Purpose	Use the <code>lock</code> command to lock the current user interface and prevent unauthorized users from accessing it.
Syntax	<code>lock</code>
Parameters	None
Example	To lock the current user interface, enter the following: <pre><SW5500>lock Password: xxxx Again: xxxx</pre>
View	This command can be used in the following views: <ul style="list-style-type: none">■ User view
Description	An authorized user must enter a valid password to access the interface.

logging-host

Purpose

Use the **logging-host** command to configure a public logging host on the management device for member devices.

Use the **undo logging-host** command to cancel the logging host configuration.

Syntax

```
logging-host ip-address
```

```
undo logging-host
```

Parameters

ip-address

IP address of the logging host configured for the cluster.

Default

By default, no public logging host is configured.

Example

Configure the IP address of the logging host on the management device.

```
<aaa_0.S5500>system-view
System View: return to User View with Ctrl+Z.
[aaa_0.S5500]cluster
[aaa_0.S5500-cluster] logging-host 10.10.10.9
```

View

This command can be used in the following views:

- Cluster view

Description

Only after you assign an IP address for the logging host of the cluster, member devices can send log information to the logging host through the management device.

loopback

Purpose Use the **loopback** command to configure the Ethernet port to perform the loopback test to check if the Ethernet port works normally.

Syntax `loopback { external | internal }`

Parameters

external	External loop test.
internal	Internal loop test.

Default The loop test will finish automatically after being performed for a while.

Example To perform the internal loop test for Ethernet1/0/1, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]loopback internal
#Apr 2 02:46:02:29 2000 SW5500 L2INF/2/PORT LINK STATUS CHANGE:- 1 -
Trap 1.3.6.1.6.3.1.1.5.4: portIndex is 4227626, ifAdminStatus is 1,
ifOperStatus is 1

%Apr 2 02:46:02:225 2000 SW5500 L2INF/5/PORT LINK STATUS CHANGE:- 1 -
Ethernet1/0/1: is UP

%Apr 2 02:46:02:342 2000 SW5500 STP/2/SPEED:- 1 -Ethernet1/0/1's speed
changed
!
#Apr 2 02:46:02:521 2000 SW5500 L2INF/2/PORT LINK STATUS CHANGE:- 1 -
Trap 1.3.6.1.6.3.1.1.5.3: portIndex is 4227626, ifAdminStatus is 1,
ifOperStatus is 2

Loop internal succeeded.
[SW5500-Ethernet1/0/1]
[SW5500-Ethernet1/0/1]loopback internal
```

View This command can be used in the following views:

- Ethernet Port view

Description By default, the Ethernet port will not perform the loopback test.

loopback-detection control enable

Purpose	<p>Use the loopback-detection control enable command to enable loopback detection and control function for Trunk ports and Hybrid ports.</p> <p>Use the undo loopback-detection control enable command to disable loopback detection and control function for Trunk ports and Hybrid ports.</p>
Syntax	<pre>loopback-detection control enable undo loopback-detection control enable</pre>
Parameters	None
Default	By default, the loopback detection and control function is disabled for both the Trunk and Hybrid ports.
Example	<p>Enable the loopback detection and control function for Trunk port Ethernet1/0/1.</p> <pre><S5500> system-view System View: return to User View with Ctrl+Z. [S5500] loopback-detection enable [S5500] interface ethernet1/0/1 [S5500-Ethernet1/0/1] loopback-detection enable [S5500-Ethernet1/0/1] loopback-detection control enable</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ Ethernet Port view
Description	<ul style="list-style-type: none">■ When the loopback detection and control function is enabled, if system detects loopback for a port, it will shut down that port, send a Trap message to the terminal, and delete the corresponding MAC address forwarding entry.■ When the loopback detection and control function is disabled, if system detects loopback for a port, it will only send a Trap message to the terminal and the port will still work under normal working state.

**CAUTION:**

The above command does not work for Access ports as, as the loopback detection function is always enabled for Access ports.

loopback-detection enable

Purpose

Use the **loopback-detection enable** command to enable the loopback detection function globally or for a specific port.

Use the **undo loopback-detection enable** command to disable the loopback detection function globally or for a specific port.

Syntax

```
loopback-detection enable  
  
undo loopback-detection enable
```

Parameters

None

Default

By default, the loopback detection function is disabled.

Example

Enable the loopback detection function for Ethernet1/0/1 port.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] loopback-detection enable  
[S5500] interface ethernet1/0/1  
[S5500-Ethernet1/0/1] loopback-detection enable
```

View

This command can be used in the following views:

- System view
- Ethernet Port view

Description



CAUTION:

- Loopback detection for a port is enabled only when the **loopback-detection enable** command is enabled under both system view and port view.
- When the **undo loopback-detection enable** command is used under system view, the loopback detection function will be disabled for all ports.
- For Access port: If system detects loopback for a port, it will shut down that port, send a Trap message to the terminal, and delete the corresponding MAC address forwarding entry.
- For Trunk ports and Hybrid ports: If system detects loopback for a port, it will send a Trap message to the terminal. If the loopback detection and control function for that port is enabled at the same time, the system will then shut down the given port, send a Trap message to the terminal, and delete the corresponding MAC address forwarding entry.

Related Command `loopback-detection control enable`

loopback-detection interval-time

Purpose

Use the **loopback-detection interval-time** command to set the time interval for detecting the external loopback for a port.

Use the **undo loopback-detection interval-time** command to restore the time interval to default value.

Syntax

```
loopback-detection interval-time time
```

```
undo loopback-detection interval-time
```

Parameters

Time

Time interval for detecting the external loopback for a port, in seconds. Valid values are 5 to 300. If not specified, the default is 30 seconds.

Example

Set the time interval for regular external loopback detection to 10 seconds.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] loopback-detection interval-time 10
```

View

This command can be used in the following views:

- System view

Related Command

```
display loopback-detection
```

loopback-detection per-vlan enable

Purpose

Use the **loopback-detection per-vlan enable** command to enable loopback detection function for all VLANs with Trunk ports and Hybrid ports.

Use the **undo loopback-detection per-vlan enable** command to enable loopback detection function only for the default VLANs with Trunk ports and Hybrid ports.

Syntax

```
loopback-detection per-vlan enable
```

```
undo loopback-detection per-vlan enable
```

Parameters

None

Default

By default, system detects loopback only for the default VLANs with Trunk ports and Hybrid ports.

Example

Configure system to detect the loopback for all VLANs with Trunk port Ethernet1/0/1.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface ethernet1/0/1
[S5500-Ethernet1/0/1] loopback-detection per-vlan enable
```

View

This command can be used in the following views:

- Ethernet Port view

Description



CAUTION:

The above command does not work for Access ports.

ls

Purpose Use the **ls** command to display the files in the specified directory.

Syntax `ls [remote-path]`

Parameters *remote-path* Name of the intended directory.

Example Display the files in directory flash:/.

```
sftp-client> ls flash:/
-rwxrwxrwx 1 noone nogroup 1759 Aug 23 06:52 vrpcfg.cfg
-rwxrwxrwx 1 noone nogroup 225 Aug 24 08:01 pubkey2
-rwxrwxrwx 1 noone nogroup 283 Aug 24 07:39 pubkey1
-rwxrwxrwx 1 noone nogroup 225 Sep 28 08:28 pub1
drwxrwxrwx 1 noone nogroup 0 Sep 28 08:24 new1
drwxrwxrwx 1 noone nogroup 0 Sep 28 08:18 new2
-rwxrwxrwx 1 noone nogroup 225 Sep 28 08:30 pub2
```

View This command can be used in the following views:

- SFTP Client view

Description If the *remote-path* argument is not specified, the files in the current directory are displayed.

This command has the same function as the **dir** command.

mac-address

Purpose

Use the **mac-address** command to add/modify the MAC address table entry.

Use the **undo mac-address** command to delete MAC address table entry.

Syntax

```
mac-address { static | dynamic | blackhole } mac-address interface {
interface-name | interface-type interface-num } vlan vlan-id

undo mac-address [ { static | dynamic | blackhole } mac-address
interface { interface-name | interface-type interface-num } vlan vlan-id
]
```

Parameters

static	Static table entry, lost after resetting switch.
dynamic	Dynamic table entry, which will be aged.
blackhole	Blackhole table entry, the packet with this destination MAC address will be discarded.
mac-addr	Specifies the MAC address.
interface-type	Specifies the interface type.
interface-num	Specifies the interface number.
interface-name	Specifies the interface name.
vlan-id	Specifies the VLAN ID.

Example

Configure the port number corresponding to the MAC address 00e0-fc01-0101 as Ethernet1/0/1 in the address table, and sets this entry as static entry.

```
<SW5500>sys
System View: return to User View with Ctrl+Z.
[SW5500]mac-address static 00e0-fc01-0101 interface Ethernet 1/0/1 vlan
2
```

View

This command can be used in the following views:

- System view

Description

If the input address has been existing in the address table, the original entry will be modified. That is, replace the interface pointed by this address with the new interface and the entry attribute with the new attribute (dynamic entry and static entry).

All the (MAC unicast) addresses on a certain interface can be deleted. User can choose to delete any of the following addresses: address learned by system automatically, dynamic address configured by user, static address configured by user.

Related Command

display mac-address

mac-address max-mac-count

Purpose

Use the `mac-address max-mac-count` command to configure the maximum number of MAC addresses that can be learned by a specified Ethernet port.

Use the `undo mac-address-table max-mac-count` command to cancel the maximum limit on the number of MAC addresses learned by an Ethernet port.

Syntax

```
mac-address max-mac-count count
```

```
undo mac-address max-mac-count
```

Parameters

`count`

The number of MAC addresses a port can learn. Valid values are 0 to 32768. A value of 0 means that the port is not allowed to learn MAC addresses. If no maximum limit is set, the MAC address table controls the number of MAC addresses a port can learn.

Example

To configure the port "Ethernet 1/0/3" to learn at most 600 MAC addresses, enter the following:

```
<SW5500>sys
System View: return to User View with Ctrl+Z.
[SW5500]interface Ethernet 1/0/3
[SW5500-Ethernet1/0/3]mac-address max-mac-count 600
```

To cancel the maximum limit on the number of MAC addresses learned by the port "Ethernet1/0/3", enter the following:

```
<SW5500>sys
System View: return to User View with Ctrl+Z.
[SW5500]interface Ethernet 1/0/3
[SW5500-Ethernet1/0/3]undo mac-address max-mac-count
```

View

This command can be used in the following views:

- Ethernet Port view

Description

The port stops learning MAC addresses when the specified limit is reached.

Related Commands

- `mac-address`
- `mac-address timer`

mac-address multicast interface vlan

Purpose

Use the **mac-address multicast** command to add a multicast MAC address entry.

Use the **undo mac-address multicast** command to remove a multicast MAC address entry.

Syntax

```
mac-address multicast mac-address interface interface-list vlan vlan-id
```

```
undo mac-address multicast [ mac-address [ interface interface-list ]  
vlan vlan-id ]
```

Parameters

mac-address

Multicast MAC address.

interface-list

Forward port list, in the format of { { **interface-type interface-num** | **interface-name** } [to { **interface-type interface-num** | **interface-name** }] }&<1-10>. Where, **interface-type** and **interface-num** are the type and number of a port, **interface-name** is the name of a port, and &<1-10> means you can specify up to 10 ports/port ranges. For the value ranges of the three arguments, refer to the command parameter description in the *Port Configuration* module of this document.

vlan-id

VLAN ID.

Example

Add a multicast MAC address entry for VLAN 1, with the multicast MAC address 0100-5e0a-0805 and forward port Ethernet 1/0/1.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] mac-address multicast 0100-5e0a-0805 interface Ethernet 1/0/1  
vlan 1
```

View

This command can be used in the following views:

- System view

Description

A multicast address entry contains the following information: multicast MAC address, Forward port, and VLAN ID.

Related Command

display mac-address multicast static

mac-address multicast vlan

Purpose

Use the **mac-address multicast vlan** command to add a multicast MAC address entry.

Use the **undo mac-address multicast vlan** command to remove a multicast MAC address entry.

Syntax

```
mac-address multicast mac-address vlan vlan-id
```

```
undo mac-address multicast [ [ mac-address ] vlan vlan-id ]
```

Parameters

mac-address Multicast MAC address.

vlan-id VLAN ID.

Example

Add a multicast MAC address entry for VLAN 1, with the multicast MAC address 0100-1000-1000 and forward port Ethernet 1/0/1.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface Ethernet1/0/1
[S5500-Ethernet1/0/1]mac-address multicast 0100-1000-1000 vlan 1
```

View

This command can be used in the following views:

- Ethernet Port view

Description

A multicast MAC address entry contains a multicast MAC address, a VLAN ID, and some other information.

Related Command

```
display mac-address multicast static
```

mac-address timer

Purpose

Use the `mac-address timer` command to configure the aging time of the Layer-2 dynamic address table entry.

Use the `undo mac-address timer` command to restore the default value.

Syntax

```
mac-address timer { aging age | no-aging }
```

```
undo mac-address timer aging
```

Parameters

<code>aging <i>age</i></code>	Specifies the aging time (measured in seconds) of the Layer-2 dynamic address table entry. Valid values are 10 to 1000000. If not specified, the default aging time is 300 seconds.
<code>no-aging</code>	No aging time.

Example

Configure the entry aging time of Layer-2 dynamic address table to be 500 seconds.

```
<SW5500>sys  
System View: return to User View with Ctrl+Z.  
[SW5500]mac-address timer aging 500
```

View

This command can be used in the following views:

- System view

Description

Setting the aging time on the switch to be too long or too short will cause the switch to broadcast data packets without MAC addresses, this will affect the operational performance of the switch.

If the aging time is set too long, the switch will store out-of-date MAC address tables. This will consume MAC address table resources and the switch will not be able to update MAC address table according to the network change.

If aging time is set too short, the switch may delete valid MAC address table entries.

mac-authentication

Purpose

Use the **mac-authentication** command to enable centralized MAC address authentication globally (current device) or on specified ports.

Use the **undo mac-authentication** command to disable centralized MAC address authentication globally or on specified ports.

Syntax

```
mac-authentication [ interface interface-list ]
```

```
undo mac-authentication [ interface interface-list ]
```

Parameters

interface-list

Lists of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of *interface-list* = { *interface-type interface-number* [to *interface-type interface-number*] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.

Default

By default, centralized MAC address authentication is disabled both globally and on any port.

Example

Enable centralized MAC address authentication on GigabitEthernet 1/0/1 port.

```
<S5500> system-view
```

System View: return to User View with Ctrl+Z.

```
[S5500] mac-authentication interface GigabitEthernet 1/0/1
```

Enable centralized MAC address authentication feature globally.

```
[S5500] mac-authentication
```

View

This command can be used in the following views:

- System view
- Ethernet Port view

Description

When being executed in system view, the **mac-authentication** command enables centralized MAC address authentication globally if you do not provide the *interface-list* argument, otherwise, the command enables centralized MAC address authentication on the specified ports. When being executed in Ethernet port view, the command enables centralized MAC address authentication on the current port only. In this case, the *interface-list* is unnecessary.

You can configure centralized MAC address authentication-related parameters no matter whether or not centralized MAC authentication is enabled. If you do not

configure the parameters before enabling centralized MAC address authentication globally, the default parameters are adopted.



Note:

- To make the configuration of port-based centralized MAC address authentication take effect, you must enable global centralized MAC address authentication globally besides enabling port-based centralized MAC address authentication.
- For a port, the centralized MAC address authentication configuration and the maximum number of learned MAC addresses configuration are mutually exclusive. That is, if you enable the centralized MAC address authentication function for a port, the maximum number of learned MAC addresses configuration (see the **mac-address max-mac-count** command) is unavailable. And if you set the maximum number of learned MAC addresses, the centralized MAC address authentication configuration is unavailable.

mac-authentication authmode

Purpose

Use the **mac-authentication authmode** command to set MAC address authentication mode.

Use the **undo mac-authentication authmode** command to cancel the configured MAC address authentication mode.

Syntax

```
mac-authentication authmode { usernameasmacaddress | usernamefixed }  
  
undo mac-authentication authmode
```

Parameters

usernameasmacaddress	Authenticates users in MAC address mode.
usernamefixed	Authenticates users in fixed mode.

Default

By default, a switch authenticates users in MAC address mode.

Example

Configure to authenticate users in fixed mode.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] mac-authentication authmode usernamefixed
```

View

This command can be used in the following views:

- System view

Description

Use the **mac-authentication authmode** command to set MAC address authentication mode.

Use the **undo mac-authentication authmode** command to cancel the configured MAC address authentication mode.

- The **usernameasmacaddress** keyword specifies to authenticate users in MAC address mode. That is, the MAC address of a user is used as both the user name and password.
- The **usernamefixed** keyword specifies to authenticate users in fixed mode, where you need to configure both user name and password separately.

mac-authentication authpassword

Purpose

Use the **mac-authentication authpassword** command to set a password when a switch authenticates users in fixed mode.

Use the **undo mac-authentication authpassword** command to remove the configured password.

Syntax

```
mac-authentication authpassword password
```

```
undo mac-authentication authpassword
```

Parameters

password

Password for authentication, consisting of a character string from 1 to 63 characters long.

Default

By default, no password is configured for the fixed mode of MAC address authentication.

Example

Set the password to mac for fixed mode.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] mac-authentication authpassword mac
```

View

This command can be used in the following views:

- System view

mac-authentication authusername

Purpose

Use the **mac-authentication authusername** command to set a user name when a switch authenticates users in fixed mode.

Use the **undo mac-authentication authusername** command to restore the default user name.

Syntax

```
mac-authentication authusername username
```

```
undo mac-authentication authusername
```

Parameters

username

User name for authentication consisting of a character string from 1 to 55 characters long.
If not specified, the default user name is mac.

Example

Set the user name to vipuser for fixed mode.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] mac-authentication authusername vipuser
```

Restore the default user name.

```
[S5500] undo mac-authentication authusername
```

View

This command can be used in the following views:

- System view

mac-authentication domain

- Purpose**
- Use the **mac-authentication domain** command to configure an ISP domain for centralized MAC address authentication users.
- Use the **undo mac-authentication domain** command to restore the default ISP domain.
- Syntax**
- ```
mac-authentication domain isp-name

undo mac-authentication domain
```
- Parameters**
- |                 |                                                                                                                                           |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <i>isp-name</i> | ISP domain name consisting of a string up to 24 characters long. Note that this argument cannot contain "/", ":", "*", "?", "<", and ">". |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------|
- Default**
- By default, the domain for centralized MAC address authentication users is not configured.
- Example**
- Configure the domain for centralized MAC address authentication users to be Cams.
- ```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] mac-authentication domain Cams
```
- View**
- This command can be used in the following views:
- System view

mac-authentication timer

Purpose

Use the **mac-authentication timer** command to set centralized MAC address authentication timers.

Use the **undo mac-authentication timer** command to restore the default centralized MAC address authentication timers.

Syntax

```
mac-authentication timer { offline-detect offline-detect-value | quiet quiet-value | server-timeout server-timeout-value }
```

```
undo mac-authentication timer { offline-detect | quiet | server-timeout }
```

Parameters

offline-detect

offline-detect-value

Sets the offline-detect timer (in seconds). This timer sets the interval for a switch to test whether or not a user goes offline. Valid values for the *offline-detect-value* argument are 1 to 65,535. If not specified, the default is 300.

quiet *quiet-value*

Specifies the quiet timer. If a user fails to pass the authentication performed by a switch, the switch stops authenticating users for a period specified by the *quiet-value* before it authenticates users again. Valid values for the *quiet-value* argument are 1 to 3600 (in seconds). If not specified, the default is 1.

server-timeout

server-timeout-value

Specifies the server-timeout timer. If the connection between a switch and a RADIUS server times out when the switch authenticates a user on one of its ports, the switch turns down the user. Valid values for the *server-timeout-value* argument are 1 to 65,535 (in seconds). If not specified, the default is 100.

Example

Set the server-timeout timer to 150 seconds.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] mac-authentication timer server-timeout 150
```

View

This command can be used in the following views:

- System view

Related Command

display mac-authentication

management-vlan

Purpose

Use the **management-vlan** command to specify the management VLAN on the switch.

Use the **undo management-vlan** command to restore the default management VLAN.

Syntax

```
management-vlan vlan-id
```

```
undo management-vlan
```

Parameters

vlanid ID of management VLAN.

Default

By default, VLAN 1 is set as the management VLAN.

Example

Specify VLAN 2 as the management VLAN of the current switch.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] management-vlan 2
```

View

This command can be used in the following views:

- System view

Description

Follow these items when you configure the management VLAN:

- The management VLAN specified for devices in the same cluster must be the same VLAN.
- The management VLAN must be specified before the cluster is set up. You cannot change the management VLAN of an existing VLAN. If necessary, you can delete the cluster, re-specify the management VLAN and then re-create the cluster.

mdi

Purpose

Use the **mdi** command to configure the network cable type for an Ethernet port.

Use the **undo mdi** command to restore the default type. By default, the network cable type is recognized automatically (the **mdi auto** command).

Syntax

```
mdi { across | auto | normal }
```

```
undo mdi
```

Parameters

across	Configures the network cable type to cross-over cable. This option is not available on the Switch 5500.
auto	Configures the use of either straight-through cable or cross-over cable.
normal	Configures the network cable type to straight-through cable. This option is not available on the Switch 5500.

Example

To configure the network cable type of port "Ethernet1/0/1" as cross-over cable, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]mdi across
[SW5500-Ethernet1/0/1]
```

View

This command can be used in the following views:

- Ethernet Port view

Description



*Note: This command only has effect on 10/100BASE-T and 10/100/1000BASE-T ports. The Switch 5500 only supports **auto** (auto-sensing). If you enter another type, an error message displays.*

memory auto-establish disable

Purpose	Use the <code>memory auto-establish disable</code> command to disable the routing protocol connection that is forcibly disconnected to recover automatically when the idle memory of the Ethernet switch reaches this value.
Syntax	<code>memory auto-establish disable</code>
Parameters	None
Default	<p>By default, when the idle memory of the Ethernet switch recovers to a safety value, connections of all the routing protocols will always recover (when the idle memory of the Ethernet switch reduces to a lower limit, the connection will be disconnected forcibly).</p> <p>Thus, connections of all the routing protocols will not recover when the idle memory of the Ethernet switch recovers to a safety value. In this case, you need to restart the routing protocol to recover the connections.</p>
Example	<p>Disable memory resume of the current Ethernet switch and recover connections of all the protocols automatically.</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]memory auto-establish disable</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view
Related Commands	<ul style="list-style-type: none">■ <code>display memory limit</code>■ <code>memory auto-establish enable</code>■ <code>memory { safety limit }</code>

memory auto-establish enable

- Purpose** Use the `memory auto-establish enable` command to allow the routing protocol connection that is forcibly disconnected to recover automatically when the idle memory of the Switch reaches this value.
- Syntax** `memory auto-establish enable`
- Parameters** None
- Default** By default, when the idle memory of the Switch recovers to a safety value, connections of all the routing protocols will always recover (when the idle memory of the Ethernet switch reduces to a lower limit, the connection will be disconnected forcibly).
- Example** Enable memory resume of the current Switch and recover connections of all the protocols automatically.
- ```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]memory auto-establish enable
```
- View** This command can be used in the following views:
- System view
- Related Commands**
- `display memory limit`
  - `memory auto-establish disable`
  - `memory { safety | limit }`

# memory { safety | limit }

---

## Purpose

Use the `memory` command to configure the limit or safety of the Switch idle memory.

Use the `memory limit limit_value` command to configure the lower limit of the Switch idle memory.

Use the `memory safety safety_value` command to configure the safety value of the Switch idle memory.

Use the `memory safety safety_value limit limit_value` command to change both of the safety value and lower limit of the Switch idle memory.

Use the `undo memory` command to configure the safety value and the lower limit of the Switch idle memory to the default configuration.

## Syntax

```
memory { safety safety_value | limit limit_value }*
undo memory [safety | limit]
```

## Parameters

|                                  |                                                                                                                                                                                   |
|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>safety safety_value</code> | The safety value of the Switch idle memory, in Mbytes. Its range of valid values depends on the idle memory of the active Switch. If not specified, the default value is 4Mbytes. |
| <code>limit limit_value</code>   | The lower limit of the Switch idle memory, in Mbytes. Its range of valid values depends on the idle memory of the active Switch. If not specified, the default value is 2Mbytes.  |

## Example

Set the lower limit of the Switch idle memory to 1 Mbytes and the safety value to 3 Mbytes.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]memory safety 3 limit 1
%Apr 2 01:43:35:678 2000 SW5500 RM/5/RTLOG:- 1 -Changed the system
memory limit(5->1)/safety(6->3) successfully
```

## View

This command can be used in the following views:

- System view

## Description

When the idle memory of the Switch is less than this limit, all the routing protocol connections will be disconnected forcibly. The `limit_value` in the command must be less than the current idle memory safety value or the configuration will fail.

If you use the `memory auto-establish enable` command (the default configuration), the routing protocol connection that is forcibly disconnected will automatically recover when the idle memory of the Switch reaches this value. The

*safety\_value* in the command must be more than the current idle memory lower limit or the configuration will fail.

The *safety\_value* must be more than the *limit\_value* or the configuration will fail.

## Related Commands

- `display memory limit`
- `memory auto-establish disable`
- `memory auto-establish enable`

# messenger

---

## Purpose

Use the `messenger time` command to enable or disable the messenger alert and configure the related parameters.

Use the `undo messenger time` command to restore messenger alert to default settings.

## Syntax

```
messenger time { enable limit interval | disable }
undo messenger time
```

## Parameters

|                 |                                                                                                                                                                                                    |
|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>limit</i>    | Remaining-online-time threshold in minutes. Valid values are 1 to 60. When the remaining online time of a user is equal to this threshold, the Switch begins to send alert messages to the client. |
| <i>interval</i> | The sending interval of alert messages in minutes. Valid values are of 5 to 60.                                                                                                                    |

## Example

To configure to start the sending of alert messages when the user's remaining online time is 30 minutes and send the messages at an interval of five minutes, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]domain system
[SW5500-isp-system]messenger time enable 30 5
```

## View

This command can be used in the following views:

- ISP Domain view

## Description

By default, the messenger alert is disabled on the Switch.

This function allows the clients to inform the online users about their remaining online time through message alert dialog box.

The implementation of this function is as follows:

- On the Switch, use the `messenger time enable` command to enable this function and to configure the remaining-online-time threshold (the *limit* argument) and the alert message interval.
- If the threshold is reached, the Switch sends messages containing the user's remaining online time to the client at the interval you configured.
- The client keeps the user informed of the remaining online time through a message alert dialog box.



# mirrored-to

---

## Purpose

Use the **mirrored-to** command to enable ACL traffic identification and perform traffic mirroring.

Use the **undo mirrored-to** command to disable traffic mirroring

## Syntax

```
mirrored-to { inbound | outbound } { user-group acl-number [rule rule] | ip-group acl-number [rule rule [link-group acl-number rule rule]] | link-group acl-number [rule rule] } { cpu | monitor-interface }
```

```
undo mirrored-to { inbound | outbound } { user-group acl-number [rule rule] | ip-group acl-number [rule rule [link-group acl-number rule rule]] | link-group acl-number [rule rule] }
```

## Parameters

|                              |                                                                                                                                                                                                                                                                                                                     |
|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>inbound</b>               | Performs traffic mirror for the packets received by the interface.                                                                                                                                                                                                                                                  |
| <b>outbound</b>              | Performs traffic mirror for the packets sent by the interface.                                                                                                                                                                                                                                                      |
| <b>user-group acl-number</b> | Activates user-defined ACLs. <i>acl-number</i> : Sequence number of ACL, ranging from 5000 to 5999.                                                                                                                                                                                                                 |
| <b>ip-group acl-number</b>   | Activates IP ACLs, including basic and advanced ACLs. <i>acl-number</i> : Sequence number of ACL, ranging from 2000 to 3999.                                                                                                                                                                                        |
| <b>link-group acl-number</b> | Activates Layer 2 ACLs. <i>acl-number</i> : Sequence number of ACL, ranging from 4000 to 4999.                                                                                                                                                                                                                      |
| <b>rule rule</b>             | Specifies the sub-item of an active ACL, ranging from 0 to 65534; if not specified, all sub-items of the ACL will be activated. If only IP ACL or Layer 2 ACL are activated, this parameter can be omitted. If both IP and Layer 2 ACL are activated at the same time, the <i>rule</i> parameter cannot be omitted. |
| <b>cpu</b>                   | Specifies the traffic will be mirror to CPU                                                                                                                                                                                                                                                                         |
| <b>monitor-interface</b>     | Specifies that the destination port is the monitor port.                                                                                                                                                                                                                                                            |

## Example

To mirror the packets matching the ACL 2000 rules, whose action is permit, to the port Ethernet1/0/1, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Ethernet 1/0/1
[SW5500-Ethernet1/0/1]monitor-port
[SW5500-Ethernet1/0/1]quit
[SW5500]interface Ethernet 1/0/2
[SW5500-Ethernet1/0/2] mirrored-to ip-group 2000 monitor-interface
SW5500-Ethernet1/0/2]
```

**View**

This command can be used in the following views:

- Ethernet Port view

**Description**

This command is used for mirroring the traffic matching the specified ACL (whose action is permit). The observing port cannot be a Trunk port or aggregated port.

This command only supports one observing port. When you use the traffic mirror for the first time, you have to designate the observing port.

**Related Command**

`display qos-interface mirrored-to`

# mirroring group

---

## Purpose

Use the **mirroring-group** command to configure the port mirroring group.

Use the **undo mirroring-group** command to delete the port mirroring group.

## Syntax

```
mirroring-group group-id { local | remote-destination | remote-source }
```

```
undo mirroring-group { group-id | all | local | remote-destination |
remote-source }
```

## Parameters

|                           |                                                                                             |
|---------------------------|---------------------------------------------------------------------------------------------|
| <b><i>group-id</i></b>    | Group number of a port mirroring group. Valid values are 1 to 20.                           |
| <b>local</b>              | Specifies the mirroring group as a local port mirroring group.                              |
| <b>remote-destination</b> | Specifies the mirroring group as the destination mirroring group for remote port mirroring. |
| <b>remote-source</b>      | Specifies the mirroring group as the source mirroring group for remote mirroring.           |
| <b>all</b>                | Deletes all mirroring groups.                                                               |

## Example

Configure the mirroring group on the local switch.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] mirroring-group 1 local
```

## View

This command can be used in the following views:

- System view

# mirroring-group mirroring-port

---

## Purpose

Use the **mirroring-group mirroring-port** command to configure the monitored port.

Use the **undo mirroring-group mirroring-port** command to remove the configuration of the monitored port.

## Syntax

```
mirroring-group group-id mirroring-port mirroring-port-list { both |
inbound | outbound }
```

```
undo mirroring-group group-id mirroring-port mirroring-port-list { both
| inbound | outbound }
```

## Parameters

|                                                                   |                                                                   |
|-------------------------------------------------------------------|-------------------------------------------------------------------|
| <b><i>group-id</i></b>                                            | Group number of a port mirroring group. Valid values are 1 to 20. |
| <b><i>mirroring-port</i></b><br><b><i>mirroring-port-list</i></b> | The specified ACL for the monitored port.                         |
| <b>both</b>                                                       | Monitors both the inbound and outbound information of the port.   |
| <b>inbound</b>                                                    | Only monitors inbound information of the port.                    |
| <b>outbound</b>                                                   | Only monitors outbound information of the port.                   |

## Example

Configure Ethernet1/0/1 to be the monitored port, monitor and control all the inbound information of this port.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] mirroring-group 1 mirroring-port Ethernet1/0/1 inbound
```

## View

This command can be used in the following views:

- System view

# mirroring-group monitor-port

---

## Purpose

Use the **mirroring-group monitor-port** command to configure the monitoring port.

Use the **undo mirroring-group monitor-port** command to remove the configuration of the monitoring port.

## Syntax

```
mirroring-group group-id monitor-port monitor-port
```

```
undo mirroring-group group-id monitor-port monitor-port
```

## Parameters

**group-id** Group number of a port mirroring group. Valid values are 1 to 20.

**monitor-port** *monitor-port* The specified port to be monitored.

## Example

Configure Ethernet1/0/2 to be the monitoring port.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] mirroring-group 1 monitor-port Ethernet1/0/2
```

## View

This command can be used in the following views:

- System view

## Description

When a port is configured as a destination port of remote mirroring, its port type or default VLAN ID can no longer be modified.

# mirroring-group reflector-port

---

## Purpose

Use the **mirroring-group reflector-port** command to configure a reflector port.

Use the **undo mirroring-group reflector-port** command to remove the configuration of a reflector port.

## Syntax

```
mirroring-group group-id reflector-port reflector-port
```

```
undo mirroring-group group-id reflector-port reflector-port
```

## Parameters

***group-id*** Group number of a port mirroring group. Valid values are 1 to 20.

***reflector-port***  
***reflector-port*** The specified reflector port.

## Example

Configure Ethernet1/0/1 to be the reflector port, monitor and control all the inbound and outbound information of this switch.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] mirroring-group 1 reflector-port Ethernet1/0/1
```

## View

This command can be used in the following views:

- System view

# mirroring-group remote-probe vlan

---

## Purpose

Use the **mirroring-group remote-probe vlan** command to specify the remote-probe VLAN for a given mirroring group.

Use the **undo mirroring-group remote-probe vlan** command to delete the remote-probe VLAN configuration for a given mirroring group.

## Syntax

```
mirroring-group group-id remote-probe vlan remote-probe-vlan-id
```

```
undo mirroring-group group-id remote-probe vlan remote-probe-vlan-id
```

## Parameters

*group-id* The group number of a mirroring group. Valid values are 1 to 20.

**remote-probe vlan**  
*remote-probe-vlan-id* Specifies a remote-probe VLAN for a specified mirroring group.

## Example

Configure the remote-probe VLAN of mirroring group to be VLAN 100.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] mirroring-group 1 remote-probe vlan 100
```

## View

This command can be used in the following views:

- System view

# mirroring-port

---

## Purpose

Use the `mirroring-port` command to configure a mirroring port.

Use the `undo mirroring-port` command to remove setting of mirroring port.

## Syntax

```
mirroring-port { inbound | outbound | both }
```

```
undo mirroring-port
```

## Parameters

`inbound` | `outbound` | `both` Direction of mirrored packets:

- `inbound`; only mirrors the packets received via the port.
- `outbound`; only mirrors the packets sent by the port.
- `both`; mirrors all packets received and sent by the port.

## Example

To configure Ethernet1/0/1 as a monitored port, and monitor packets in both directions, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Ethernet 1/0/1
[SW5500-Ethernet1/0/1] mirroring-port both
[SW5500-Ethernet1/0/1]
```

## View

This command can be used in the following views:

- Ethernet Port view

## Description

The Switch supports one monitor port and one mirroring port. If several Switches form a Fabric, only one monitor port and one mirroring port can be configured in the Fabric. You need to configure the monitor port before configuring the monitored port.

## Related Command

```
display mirror
```



# mkdir

---

**Purpose** Use the **mkdir** command to create a directory on the remote SFTP server.

**Syntax** `mkdir remote-path`

**Parameters** `remote-path` Name of a directory on the remote SFTP server.

**Example** Create directory test on the remote SFTP server.

```
sftp-client> mkdir test
```

**View** This command can be used in the following views:

- SFTP Client view

# monitor-port

---

**Purpose**

Use the `monitor-port` command to configure a monitor port.

Use the `undo monitor-port` command to remove the setting of monitor port.

**Syntax**

```
monitor-port
```

```
undo monitor-port
```

**Parameters**

None

**Example**

To configure the port Ethernet1/0/4 as a monitor port, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Ethernet 1/0/4
[SW5500-Ethernet1/0/4] monitor-port
[SW5500-Ethernet1/0/4]
```

**View**

This command can be used in the following views:

- Ethernet Port view

**Description**

The Switch supports one monitor port and one mirroring port. If several Switches form a Fabric, only one monitor port and one mirroring port can be configured in the Fabric. You need to configure monitor port before configuring monitored port.

**Related Command**

```
display mirror
```

# more

---

**Purpose** Use the **more** command to display the contents of the specified file formatted as text.

**Syntax** `more file-path`

**Parameters** `file-path` File name.

**Example** Display contents of file test.txt.

```
<SW5500>more test.txt
AppWizard has created this test application for you.
This file contains a summary of what you will find in each of the files
that make up your test application.
Test.dsp
This file (the project file) contains information at the project level
and is used to build a single project or subproject. Other users can
share the project (.dsp) file, but they should export the makefiles
locally.
<SW5500>
```

**View** This command can be used in the following views:

- User view

# move

---

**Purpose** Use the `move` command to move files.

**Syntax** `move filepath-source filepath-dest`

**Parameters**

|                              |                        |
|------------------------------|------------------------|
| <code>filepath-source</code> | Source file name.      |
| <code>filepath-dest</code>   | Destination file name. |

**Example** Display the current directory information.

```
<SW5500>dir
Directory of unit1>flash:/
 0 -rw- 2145718 Jul 12 2001 12:28:08 ne80.bin
 1 drw- 0 Jul 12 2001 19:41:20 test
16125952 bytes total (13970432 bytes free)
```

```
<SW5500>dir unit1>flash:/test/
Directory of unit1>flash:/test/
 0 drw- 0 Jul 12 2001 20:23:37 subdir
 1 -rw- 50 Jul 12 2001 20:08:32 sample.txt
16125952 bytes total (13970432 bytes free)
```

Move `flash:/test/sample.txt` to `flash:/sample.txt`.

```
<SW5500>move flash:/test/sample.txt flash:/sample.txt
Move unit1>flash:/test/sample.txt to unit1>flash:/sample.txt
?[confirm]:y
% Moved file unit1>flash:/test/sample.txt unit1>flash:/sample.txt
```

Display the directory after moving a file.

```
<SW5500>dir
Directory of unit1>flash:/
 0 -rw- 2145718 Jul 12 2001 12:28:08 3Com.bin
 1 drw- 0 Jul 12 2001 19:41:20 test
 2 -rw- 50 Jul 12 2001 20:26:48 sample.txt
16125952 bytes total (13970432 bytes free)
<SW5500>dir flash:/test/
Directory of unit1>flash:/test/
 0 drw- 0 Jul 12 2001 20:23:37 subdir
16125952 bytes total (13970432 bytes free)
```

**View** This command can be used in the following views:

- User view

**Description** When the destination filename is the same as that of an existing file, the system will ask whether to overwrite the existing file.

# msdp

---

## Purpose

Use the **msdp** command to enable MSDP and enter MSDP view.

Use the **undo msdp** command to clear all configurations in MSDP view, release resources occupied by MSDP, and restore initial state.

## Syntax

**msdp**

**undo msdp**

## Parameters

None

## Example

Clear all configurations in MSDP view.

```
<S5500> system-view
[S5500] undo msdp
```

## View

This command can be used in the following views:

- System view

## Related Command

**peer**

# msdp-tracert

---

## Purpose

Use the `msdp-tracert` command to trace the path along which an SA message travels, so as to locate message loss and minimize configuration errors. After determining the path of the SA message, you can prevent SA flooding through correct configuration.

## Syntax

```
msdp-tracert source-address group-address rp-address [max-hops
max-hops] [next-hop-info | sa-info | peer-info]* [skip-hops
skip-hops]
```

## Parameters

|                       |                                                                                                                                              |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| <i>source-address</i> | Multicast source address.                                                                                                                    |
| <i>group-address</i>  | Multicast group address.                                                                                                                     |
| <i>rp-address</i>     | IP address of an RP.                                                                                                                         |
| <i>max-hops</i>       | Maximum number of hops to be traced. Valid values are 1 to 255.<br>If not specified, the default value is 16.                                |
| <i>next-hop-info</i>  | Collects the next hop information.                                                                                                           |
| <i>sa-info</i>        | Collects the SA entity information.                                                                                                          |
| <i>peer-info</i>      | Collects the MSDP peer information.                                                                                                          |
| <i>skip-hops</i>      | Number of skipped hops before the detailed information is collected. Valid values are 0 to 255.<br>If not specified, the default value is 0. |

## Example

Trace path information of (10.10.1.1, 225.2.2.2, 20.20.20.20).

```
<S5500> msdp-tracert 10.10.1.1 225.2.2.2 20.20.20.20
```

Specify the maximum number of hops to be traced and collect the detailed SA and MSDP peer information.

```
<S5500> msdp-tracert 10.10.1.1 225.2.2.2 20.20.20.20 max-hops 10
sa-info peer-info
MSDP tracert: press CTRL_C to break
D-bit: set if have this (S,G) in cache but with a different RP
RP-bit: set if this router is an RP
NC-bit: set if this router is not caching SA's
C-bit: set if this (S,G,RP) tuple is in the cache
MSDP trace route path information:
Router Address: 20.20.1.1
Fixed-length response info:
Peer Uptime: 10 minutes, Cache Entry Uptime: 30 minutes
D-bit: 0, RP-bit: 1, NC-bit: 0, C-bit: 1
Return Code: Reached-max-hops
Next Hop info:
Next-Hop Router Address: 0.0.0.0
SA info:
Count of SA messages received for this (S,G,RP): 0
Count of encapsulated data packets received for this (S,G,RP): 0
```

SA cache entry uptime: 00:30:00 , SA cache entry expiry time:  
00:03:32

Peering info:

Peering Uptime: 10 minutes, Count of Peering Resets: 3

**Table 94** Description on the fields of the msdp-tracert command

| Field                                                               | Description                                                                                                                                          |
|---------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| Router Address                                                      | The address used by the local router to establish an peering session with the Peer-PRF neighbor                                                      |
| Peer Uptime                                                         | The time of the peering session between the local router and a Peer-RPF neighbor, in minutes. The maximum value is 255.                              |
| Cache Entry Uptime                                                  | Up time of the (S, G, RP) entry in SA cache of the local router, in minutes. The maximum value is 255.                                               |
| D-bit: 1                                                            | An (S, G, RP) entry exists in the SA cache of the local router, but the RP is different from the RP specified in the request message.                |
| RP-bit: 1                                                           | The local router is an RP, but it may be another RP than the source RP in the (S, G, RP) entry.                                                      |
| NC-bit: 0                                                           | SA cache is enabled on the local router.                                                                                                             |
| C-bit: 1                                                            | An (S, G, RP) entry exists in SA cache of the local router.                                                                                          |
| Return Code:<br>Reached-max-hops                                    | Maximum <b>number of hops</b> is reached. Another possible value is:<br>Hit-src-RP: The router of this hop is the source RP in the (S, G, RP) entry. |
| Next-Hop Router Address:<br>0.0.0.0                                 | If you use the <b>next-hop-info</b> keyword, the address of Peer-RPF neighbor is displayed.                                                          |
| Count of SA messages<br>received for this (S,G,RP)                  | The number of SA messages received to trace the (S, G, RP) entry.                                                                                    |
| Count of encapsulated<br>data packets received for<br>this (S,G,RP) | The number of packets received to trace the (S, G, RP) entry.                                                                                        |
| SA cache entry uptime                                               | The up time of an SA cache entry                                                                                                                     |
| SA cache entry expiry time                                          | The expiry time of an SA cache entry                                                                                                                 |
| Peering Uptime: 10<br>minutes                                       | The time of the peering session between the local router and a Peer-PRF neighbor                                                                     |
| Count of Peering Resets                                             | <b>Count</b> of session resets                                                                                                                       |

## View

This command can be used in the following views:

- Any view

# multicast route-limit

---

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                    |                                                                                                                                                                   |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>     | <p>Use the <code>multicast route-limit</code> command to limit the capacity of multicast routing table.</p> <p>Use the <code>undo multicast route-limit</code> command to restore the limit to the default value.</p>                                                                                                                                                                                                                                                     |                    |                                                                                                                                                                   |
| <b>Syntax</b>      | <pre>multicast route-limit limit undo multicast route-limit</pre>                                                                                                                                                                                                                                                                                                                                                                                                         |                    |                                                                                                                                                                   |
| <b>Parameters</b>  | <table><tr><td><code>limit</code></td><td>Limits the capacity of the multicast routing table. Valid values are 0 to 1000.<br/>If not specified, the capacity of the routing table is set to 1000 by default.</td></tr></table>                                                                                                                                                                                                                                            | <code>limit</code> | Limits the capacity of the multicast routing table. Valid values are 0 to 1000.<br>If not specified, the capacity of the routing table is set to 1000 by default. |
| <code>limit</code> | Limits the capacity of the multicast routing table. Valid values are 0 to 1000.<br>If not specified, the capacity of the routing table is set to 1000 by default.                                                                                                                                                                                                                                                                                                         |                    |                                                                                                                                                                   |
| <b>Example</b>     | <p>Limit multicast routing table capacity at 256.</p> <pre>[SW5500]multicast route-limit 256</pre>                                                                                                                                                                                                                                                                                                                                                                        |                    |                                                                                                                                                                   |
| <b>View</b>        | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ System view</li></ul>                                                                                                                                                                                                                                                                                                                                                     |                    |                                                                                                                                                                   |
| <b>Description</b> | <p>When the preset capacity is exceeded, the router will discard new (S, G) protocol and data packets.</p> <p>If the existing route entries exceed the capacity value you configured using this command, the system will not delete the existing entries, but prompts the user with the following message: Existing route entries exceed the configured capacity value.</p> <p>The new configuration overwrites the old one if you run the command for a second time.</p> |                    |                                                                                                                                                                   |



# multicast routing-enable

---

**Purpose** Use the `multicast routing-enable` to enable IP multicast routing.  
Use the `undo multicast routing-enable` to disable IP multicast routing.

**Syntax** `multicast routing-enable`  
`undo multicast routing-enable`

**Parameters** None

**Default** By default, IP multicast routing is disabled.  
The system will not forward any multicast packet when IP multicast routing is disabled.

**Example** Enable IP multicast routing.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]multicast routing-enable
```

**View** This command can be used in the following views:

- System view

**Related Commands**

- `igmp enable`
- `pim dm`
- `pim sm`

# multicast-source-deny

---

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>     | <p>Use the <b>multicast-source-deny</b> command to enable the multicast source deny feature.</p> <p>Use the <b>undo multicast-source-deny</b> command to restore the default state of the multicast source deny feature.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Syntax</b>      | <pre>multicast-source-deny [ interface <i>interface-list</i> ]<br/>undo multicast-source-deny [ interface <i>interface-list</i> ]</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Parameters</b>  | <p><b>interface <i>interface-list</i></b> Specifies an Ethernet port list in the format of { { <b><i>interface-type interface-num</i></b>   <b><i>interface-name</i></b> } [ to { <b><i>interface-type interface-num</i></b>   <b><i>interface-name</i></b> } ] } &lt;1-10&gt;. Where, <b><i>interface-type</i></b> and <b><i>interface-num</i></b> are the type and number of a port, <b><i>interface-name</i></b> is the name of a port, and &lt;1-10&gt; means you can specify up to 10 ports/port ranges. For the value ranges of the three arguments, refer to the command parameter description in the <i>Port Configuration</i> module of this document.</p> |
| <b>Default</b>     | By default, the multicast source deny feature is disabled on every port.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Example</b>     | <p>Enable multicast source deny on all ports of the switch.</p> <pre>&lt;S5500&gt;system-view<br/>System View: return to User View with Ctrl+Z.<br/>[S5500] multicast-source-deny</pre> <p>Enable multicast source deny on the ports ethernet 1/0/1 to ethernet 1/0/10 and ethernet 1/0/12.</p> <pre>[S5500] multicast-source-deny interface ethernet 1/0/1 to ethernet<br/>1/0/10 ethernet 1/0/12</pre>                                                                                                                                                                                                                                                            |
| <b>View</b>        | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ System view</li><li>■ Ethernet Port view</li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Description</b> | <p>The purpose of the multicast source deny feature is to filter out multicast packets on an unauthorized multicast source port to prevent the user connected to the port from setting up a multicast server without permission.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                |

Executing this command in system view without specifying the ***interface-list*** argument will enable the feature globally (that is, on all the ports of the switch). Executing this command in system view with the ***interface-list*** argument specified will enable the feature on the specified port. Executing this command in Ethernet port view (you cannot specify the ***interface-list*** argument in this view) will enable the feature only on the current port.

# multicast-suppression

---

**Purpose** Use `multicast-suppression` to configure the amount of multicast traffic that will be accepted on a port.

**Syntax**

```
multicast-suppression { ratio | pps pps }

undo multicast-suppression
```

**Parameters**

|                      |                                                                                                                                                                                                                                                                                                                                                                                                  |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>ratio</code>   | Specifies the bandwidth ratio of multicast traffic allowed on an Ethernet port. Valid ratio values are 1 to 100. The incremental step is 1. The smaller the ratio is, the less bandwidth is allocated to multicast traffic and therefore less broadcast traffic is accepted on the Ethernet port.<br>If not specified, the default ratio is 100, meaning that all multicast traffic is accepted. |
| <code>pps pps</code> | Specifies the maximum number of multicast packets per second accepted on an Ethernet port. Valid values are 1 to 148810 pps.                                                                                                                                                                                                                                                                     |

**Example** Enable a limit of 20% of the available bandwidth on a port to be allocated to multicast traffic. Multicast traffic exceeding 20% of the ports bandwidth will be discarded.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]multicast-suppression 20
[SW5500-Ethernet1/0/1]
```

Specify the maximum packets per second of the multicast traffic on an Ethernet1/0/1 as 1000 Mpps.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]multicast-suppression pps 1000
[SW5500-Ethernet1/0/1]
```

**View** This command can be used in the following views:

- Ethernet Port view

**Description** Once the multicast traffic exceeds the value set by the user, the excess multicast traffic will be discarded. This feature can be used to ensure network service and prevent multicast storms.

# name

---

## Purpose

Use the **name** command to set a name for the assigned VLAN.

Use the **undo name** command to delete the name of the assigned VLAN.

## Syntax

**name** *string*

**undo name**

## Parameters

*string*

Name of the assigned VLAN, consisting of a character string from 1 to 32 characters long.

## Default

By default, the VLAN ID (like VLAN 0001) is used as the name of the assigned VLAN.

## Example

Set the name of VLAN 100 to test.

```
[S5500] vlan 100
[S5500-vlan100] name test
```

## View

This command can be used in the following views:

- VLAN view

## Description

This command is used for the dynamic VLAN assignment function. For the description of this function, refer to the **vlan-assignment-mode** command.

## Related Commands

- **dot1x guest-vlan**
- **vlan-assignment-mode**

# nas-ip

---

|                         |                                                                                                                                                                                                                                                                                 |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>          | <p>Use the <b>nas-ip</b> command to set the source IP address for HWTACACS packets sent from the NAS (switch), such that all the packets sent to the TACACS server carry the same source IP address.</p> <p>Use the <b>undo nas-ip</b> command to delete the configuration.</p> |
| <b>Syntax</b>           | <pre>nas-ip ip-address<br/><br/>undo nas-ip</pre>                                                                                                                                                                                                                               |
| <b>Parameters</b>       | <p><i>ip-address</i>                      Source IP address, in dotted decimal format.</p>                                                                                                                                                                                      |
| <b>Default</b>          | By default, the IP address of the sending interface is used as the source IP address.                                                                                                                                                                                           |
| <b>Example</b>          | <p>Configure the source IP address for HWTACACS packets sent from the NAS (switch) to 10.1.1.1.</p> <pre>[S5500] hwtacacs scheme test1<br/>[S5500-hwtacacs-test1] nas-ip 10.1.1.1</pre>                                                                                         |
| <b>View</b>             | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ HWTACACS view</li></ul>                                                                                                                                                         |
| <b>Description</b>      | <p>Specifying the source address for sending HWTACACS packet avoids the unreachability of packet returned from the server when the physical interface fails. Generally, the loopback interface address is recommended.</p>                                                      |
| <b>Related Commands</b> | <ul style="list-style-type: none"><li>■ <b>display hwtacacs</b></li><li>■ <b>hwtacacs nas-ip</b></li></ul>                                                                                                                                                                      |

# nbns-list

---

## Purpose

Use the **nbns-list** command to configure one or multiple NetBIOS server IP addresses for the DHCP clients of a global DHCP address pool.

Use the **undo nbns-list** command to remove one or all NetBIOS server IP addresses configured for the DHCP clients.

## Syntax

```
nbns-list ip-address&<1-8>
```

```
undo nbns-list { ip-address | all }
```

## Parameters

**ip-address&<1-8>**

IP address of a NetBIOS server. &<1-8> means you can provide up to eight NetBIOS server IP addresses. When inputting more than one IP address, separate two neighboring IP addresses with a space.

**all**

Specifies all configured NetBIOS server IP addresses.

## Default

By default, no NetBIOS server IP address is configured.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Configure the NetBIOS server IP address 10.12.1.99 for the global DHCP address pool 0.

```
[S5500] dhcp server ip-pool 0
[S5500-dhcp-pool-0] nbns-list 10.12.1.99
```

## View

This command can be used in the following views:

- DHCP Address Pool view

## Description

If you execute the nbns-list command repeatedly, the new configuration overwrites the previous one.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

## Related Commands

- **dhcp server ip-pool**
- **dhcp server nbns-list**
- **netbios-type**

# ndp enable

---

## Purpose

Use the **ndp enable** command to enable NDP on a system in system view, or to enable it on a port in Ethernet port view.

Use the **undo ndp enable** command to disable NDP on a system in system view, or to disable it on a port in Ethernet port view.

## Syntax

```
ndp enable [interface port-list]
```

```
undo ndp enable [interface port-list]
```

## Parameters

*port-list*

Specifies a list of ports connected with the specified port. A list may contain consecutive or separated ports, or the combination of consecutive and separated ports. The argument is expressed as { interface-type interface-number | interface-name } [ to { interface-type interface-number | interface-name } ] &<1-10>. interface-type specifies the port type. interface-number specifies the port number, expressed as slot number/port number. Key word to helps specify a port range.

## Default

By default, NDP is enabled for both a system and a port.

## Example

Enable NDP on the system.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] ndp enable
```

## View

This command can be used in the following views:

- System view
- Ethernet Port view



# ndp timer aging

---

## Purpose

Use the **ndp timer aging** command to set how long a device will hold the NDP packets received from the local device. After the aging timer expires, the device will discard the received NDP neighbor node information.

Use the **undo timer aging** command to restore the default NDP information aging time.

## Syntax

```
ndp timer aging aging-in-seconds
```

```
undo ndp timer aging
```

## Parameters

*aging-in-seconds*

Time to hold the NDP information on the neighbor node in seconds. Valid values are 5 to 255 seconds. If not specified, the NDP is aged in 180 seconds, by default.

## Example

Configure the aging time of NDP packet as 60, so that an adjacent device will discard the NDP packets from the local device 60 seconds after receiving them.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] ndp timer aging 60
```

## View

This command can be used in the following views:

- System view

## Description

A user can specify how long an adjacent device will hold the information of the local device. The adjacent device learns how long it will hold the NDP information from the aging time carried in NDP packets and discards the packets when the aging timer expires.

Normally NDP aging time is longer than the NDP packet interval. Otherwise, the neighbor information table of an NDP port will become unstable.

# ndp timer hello

---

|                         |                                                                                                                                                                                                                                         |                         |                                                                                                                                    |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>          | <p>Use the <b>ndp timer hello</b> command to define how often to transmit the NDP packets.</p> <p>Use the <b>undo ndp timer hello</b> command to restore the default NDP packet interval.</p>                                           |                         |                                                                                                                                    |
| <b>Syntax</b>           | <pre>ndp timer hello <i>seconds</i><br/><br/>undo ndp timer hello</pre>                                                                                                                                                                 |                         |                                                                                                                                    |
| <b>Parameters</b>       | <table><tr><td><b>timer-in-seconds</b></td><td>NDP packet interval. Valid values are 5 to 254 seconds. If not specified, NDP packets are transmitted every 60 second, by default.</td></tr></table>                                     | <b>timer-in-seconds</b> | NDP packet interval. Valid values are 5 to 254 seconds. If not specified, NDP packets are transmitted every 60 second, by default. |
| <b>timer-in-seconds</b> | NDP packet interval. Valid values are 5 to 254 seconds. If not specified, NDP packets are transmitted every 60 second, by default.                                                                                                      |                         |                                                                                                                                    |
| <b>Default</b>          | By default, NDP packets are transmitted every 60 seconds.                                                                                                                                                                               |                         |                                                                                                                                    |
| <b>Example</b>          | <p>Configure NDP packet interval as 80 seconds.</p> <pre>&lt;S5500&gt;system-view<br/>System View: return to User View with Ctrl+Z.<br/>[S5500] ndp timer hello 80</pre>                                                                |                         |                                                                                                                                    |
| <b>View</b>             | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ System view</li></ul>                                                                                                                   |                         |                                                                                                                                    |
| <b>Description</b>      | <p>A device shall refresh the NDP information of its adjacent nodes in time to maintain timely information as the adjacent nodes change. You can adjust the refreshing frequency for NDP information through configuration command.</p> |                         |                                                                                                                                    |

# netbios-type

---

## Purpose

Use the **netbios-type** command to configure the DHCP clients of a global address pool to be of specified NetBIOS node type.

Use the **undo netbios-type** command to restore the default NetBIOS node type.

## Syntax

```
netbios-type { b-node | h-node | m-node | p-node }
undo netbios-type
```

## Parameters

|                |                                                                                                                                                                |
|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>b-node:</b> | Specifies the broadcast type. Nodes of this type acquire host name-to-IP address mapping by broadcasting.                                                      |
| <b>p-node</b>  | Specifies the peer-to-peer type. Nodes of this type acquire host name-to-IP address mapping by communicating with the NetBIOS server.                          |
| <b>m-node</b>  | Specifies the mixed type. Nodes of this type are p-nodes with some broadcasting features.                                                                      |
| <b>h-node</b>  | Specifies the hybrid type. Nodes of this type are b-nodes with peer-to-peer communicating features. In not specified, the default NetBIOS node type is h-node. |

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Configure the DHCP clients of the global DHCP address pool 0 to be of b-node type.

```
[S5500] dhcp server ip-pool 0
[S5500-dhcp-pool-0] netbios-type b-node
```

## View

This command can be used in the following views:

- DHCP Address Pool view

## Description



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

## Related Commands

- **dhcp server ip-pool**
- **dhcp server netbios-type**
- **nbns-list**

# network

---

## Purpose

Use the **network** command to configure a dynamically assigned IP address range (where IP addresses will be dynamically assigned to DHCP clients).

Use the **undo network** command to remove a dynamically assigned IP address range.

## Syntax

```
network ip-address [mask-length | mask mask]
```

```
undo network
```

## Parameters

***ip-address*** IP address of a network segment., used to specify an IP address range.

***mask-length*** Length of a subnet mask. Valid values are 1 to 31.

***mask mask*** Specifies a subnet mask in dotted decimal notation.

If neither subnet mask nor mask length is specified in this command, the default subnet mask is adopted.

## Default

By default, no such IP address range is configured for a DHCP address pool.

## Example

Enter system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
```

Configure the dynamically assigned IP address range 192.168.8.0/24 for the global DHCP address pool 0.

```
[S5500] dhcp server ip-pool 0
[S5500-dhcp-pool-0] network 192.168.8.0 mask 255.255.255.0
```

## View

This command can be used in the following views:

- DHCP Address Pool view

## Description

By default, no such IP address range is configured for a DHCP address pool.



*You can configure only one such IP address range for a DHCP address pool. If you execute the network command repeatedly, the new configuration overwrites the previous one.*

*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

## Related Commands

- `dhcp server ip-pool`
- `dhcp server forbidden-ip`

# nm-interface vlan-interface

---

**Purpose** Use the **nm-interface vlan-interface** command to specify the network management (NM) interface of a management switch.

**Syntax** `nm-interface vlan-interface vlan_id`

**Parameters** `vlan_id` VLAN ID.

**Example** Configure Vlan-interface 2 as the NM interface.

```
<S5500> system-view
Enter system view, return to user view with Ctrl+Z.
[S5500] cluster
[S5500-cluster] nm-interface Vlan-interface 2
```

**View** This command can be used in the following views:

- Cluster view

## Description

By specifying the NM interface of a management switch, you can enable an administrator to log into the management switch of a cluster to manage the devices in the cluster. Note that an administrator can only log into a management switch through the NM interface.



*Note:*

- The management VLAN interface is the default NM interface.
- You can configure only one NM interface, and the new configured one will override the original one.

# nssa

---

## Purpose

Using the **nssa** command, you can configure the type of an OSPF area as an NSSA area.

Using the **undo nssa** command, you can cancel the function.

## Syntax

```
nssa [default-route-advertise] [no-import-route] [no-summary]
undo nssa
```

## Parameters

|                                |                                                                   |
|--------------------------------|-------------------------------------------------------------------|
| <b>default-route-advertise</b> | Imports the default route to the NSSA area.                       |
| <b>no-import-route</b>         | Blocks the import of the default route to the NSSA area.          |
| <b>no-summary</b>              | Disables ABR from transmitting summary_net LSAs to the NSSA area. |

## Default

By default, NSSA area is not configured.

For all the routers connected to the NSSA area, the command **nssa** must be used to configure the area as the NSSA attribute.

## Example

To configure area 1 as an NSSA area, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]area 1
[SW5500-ospf-1-area-0.0.0.1]network 36.0.0.0 0.255.255.255
[SW5500-ospf-1-area-0.0.0.1]nssa
```

## View

This command can be used in the following views:

- OSPF Area view

## Description

The **default-route-advertise** parameter is used to generate a default type-7 LSA. No matter whether there is route 0.0.0.0 in the routing table on an ABR, type-7 LSA default route will always be generated. Only when there is route 0.0.0.0 in routing table on ASBR, will a type-7 LSA default route be generated.

On ASBR, the **no-import-route** parameter disables an external route that is imported by OSPF with the **import-route** command from being advertised to the NSSA area.

# ntdp enable

---

## Purpose

Use the **ntdp enable** command to enable NTDP on a system in system view, or to enable it on a port in Ethernet port view.

Use the **undo ntdp enable** command to disable NTDP on a system in system view, or to enable it on a port in Ethernet port view.

## Syntax

```
ntdp enable
```

```
undo ntdp enable
```

## Parameters

None

## Default

By default, NTDP is enabled on the switch and the ports supporting NDP. For a port that does not support NDP, NTDP cannot run even if NTDP is enabled on it.

## Example

Enable NTDP on the switch.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] ntdp enable
```

## View

This command can be used in the following views:

- System view
- Ethernet Port view



# ntdp explore

---

**Purpose** Use the **ntdp explore** command to start topology information collection.

**Syntax** `ntdp explore`

**Parameters** None

**Example** Start the topology collection.

```
<S5500> ntdp explore
```

**View** This command can be used in the following views:

- User view

**Description** Generally, NTDP collects network NDP information periodically. With the **ntdp explore** command, users can start topology information collection manually whenever needed. NTDP will collect the NDP information of every device and all of their neighboring connections in the specified network scope. The management device or network management system will learn the network topology according to the information to manage and monitor the devices.

# ntdp hop

---

**Purpose** Use the **ntdp hop** command to configure a limit to the hops for topology collection.

Use the **undo ntdp hop** command to restore the default hop limit for topology collection.

**Syntax**

```
ntdp hop hop-value
undo ntdp hop
```

**Parameters**

|                  |                                                                                                                                                           |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>hop-value</i> | Maximum hops that the device collected can be away from the topology collecting device. Valid values are 1 to 128.<br>If not specified, the default is 3. |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|

**Example** Set the hop number limit as 5.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] ntdp hop 5
```

**View** This command can be used in the following views:

- System view

**Description** With the **ntdp hop** command, you can collect the topology information of the devices among determined range, so that infinitive collection can be avoided. The limit is performed through controlling permitted hops from collection origination. For example, if you set the hop number limit as 2, only the switches less than 2 hops away from the switch originating the topology collection request will be collected.

This command is effective only on the topology-collecting device. The broader collection scope requires more memory of the topology-collecting device.

# ntdp timer

---

## Purpose

Use the **ntdp timer** command to configure the topology collection interval.

Use the **undo ntdp timer** command to restore the default topology collection interval.

## Syntax

```
ntdp timer interval-in-minutes
```

```
undo ntdp timer
```

## Parameters

*Interval-in-minutes* Interval of periodic topology information collection.  
Valid values are 0 to 65535 in minutes.

## Example

Set the periodic topology connection interval as 30 minutes.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] ntdp timer 30
```

## View

This command can be used in the following views:

- System view

## Description

The switch uses the interval as the periodic basis for topology collection.

# ntdp timer hop-delay

---

## Purpose

Use the **ntdp timer hop-delay** command to set delay for collected devices to forward topology collection requests.

Use the **undo ntdp timer hop-delay** command to restore the default delay value.

## Syntax

```
ntdp timer hop-delay time
```

```
undo ntdp timer hop-delay
```

## Parameters

*time*

Time that collected devices wait before forwarding the topology-collection request. Valid values are 1 to 1000 milliseconds.

If not specified, the default is 200 milliseconds.

## Example

Configure that collected devices delay for 300 ms after receiving NTDP requests and before transmitting the NTDP packet to the first port.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] ntdp timer hop-delay 300
```

## View

This command can be used in the following views:

- System view

## Description

To avoid network congestion that occurs because collecting devices receive large amount of responses simultaneously, you can set a delay with this command. Thus, each collected device waits for a period after it receives the topology request. Then, the first port will start to forward the topology request packet.

This command is executed on the collecting device. The topology request contains the hop-delay time, according to which the collected device decides how long it shall wait before the first port forwards the request.

# ntdp timer port-delay

---

## Purpose

Use the `ntdp timer port-delay` command to set the delay that a port waits to forward the topology collection request packet after the last port forwards it.

Use the `undo ntdp timer port-delay` command to restore the default port-delay.

## Syntax

```
ntdp timer port-delay time
```

```
undo ntdp timer port-delay
```

## Parameters

*time*

Time that a port waits before it forwards the topology request packet to the next port. Valid values are 1 to 100 in milliseconds.

If not specified, the default is 20 milliseconds.

## Example

Configure that collected devices delay for 40 ms after one port forwarding NTDP requests and before the next port forwarding the packet.

```
<S5500>system-view
System View: return to User View with Ctrl+Z.
[S5500] ntdp timer port-delay 40
```

## View

This command can be used in the following views:

- System view

## Description

To avoid network congestion that occurs because the collecting device receives large amount of responses simultaneously, you can set a delay with this command. Thus, each port of the device waits for a period after the last port forwards the topology request, and it then starts to forward the packet.

This command is executed on the collecting device. The topology request contains the port-delay time, according to which the collected device decides how long it shall wait before the next port forwards the request.

# ntp-service access

---

|                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                    |                                    |                              |                                   |                     |                                    |                   |                               |                         |                                                        |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|------------------------------------|------------------------------|-----------------------------------|---------------------|------------------------------------|-------------------|-------------------------------|-------------------------|--------------------------------------------------------|
| <b>Purpose</b>               | <p>Use the <code>ntp-service access</code> command to set the authority to access the local equipment.</p> <p>Use the <code>undo ntp-service access</code> command to cancel the access authority settings.</p>                                                                                                                                                                                                                                                                                                         |                    |                                    |                              |                                   |                     |                                    |                   |                               |                         |                                                        |
| <b>Syntax</b>                | <pre>ntp-service access { query   synchronization   server   peer } acl-number  undo ntp-service access { query   synchronization   server   peer }</pre>                                                                                                                                                                                                                                                                                                                                                               |                    |                                    |                              |                                   |                     |                                    |                   |                               |                         |                                                        |
| <b>Parameters</b>            | <table> <tr> <td><code>query</code></td> <td>Allows to control query authority.</td> </tr> <tr> <td><code>synchronization</code></td> <td>Allows only the server to access.</td> </tr> <tr> <td><code>server</code></td> <td>Allows query to server and access.</td> </tr> <tr> <td><code>peer</code></td> <td>Allows full access authority.</td> </tr> <tr> <td><code>acl-number</code></td> <td>IP address list number. Valid values are 2000 to 2999.</td> </tr> </table>                                            | <code>query</code> | Allows to control query authority. | <code>synchronization</code> | Allows only the server to access. | <code>server</code> | Allows query to server and access. | <code>peer</code> | Allows full access authority. | <code>acl-number</code> | IP address list number. Valid values are 2000 to 2999. |
| <code>query</code>           | Allows to control query authority.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                    |                                    |                              |                                   |                     |                                    |                   |                               |                         |                                                        |
| <code>synchronization</code> | Allows only the server to access.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                    |                                    |                              |                                   |                     |                                    |                   |                               |                         |                                                        |
| <code>server</code>          | Allows query to server and access.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                    |                                    |                              |                                   |                     |                                    |                   |                               |                         |                                                        |
| <code>peer</code>            | Allows full access authority.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                    |                                    |                              |                                   |                     |                                    |                   |                               |                         |                                                        |
| <code>acl-number</code>      | IP address list number. Valid values are 2000 to 2999.                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                    |                                    |                              |                                   |                     |                                    |                   |                               |                         |                                                        |
| <b>Default</b>               | By default, there is no limit to the access.                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                    |                                    |                              |                                   |                     |                                    |                   |                               |                         |                                                        |
| <b>Example</b>               | <p>Give the authority of time request, query control and synchronization with the local equipment to the peer in ACL 2076.</p> <pre>&lt;SW5500&gt;system-view System View: return to User View with Ctrl+Z. [SW5500]ntp-service access peer 2076 [SW5500]</pre> <p>Give the authority of time request and query control of the local equipment to the peer in ACL 2028.</p> <pre>&lt;SW5500&gt;system-view System View: return to User View with Ctrl+Z. [SW5500]ntp-service access synchronization 2028 [SW5500]</pre> |                    |                                    |                              |                                   |                     |                                    |                   |                               |                         |                                                        |
| <b>View</b>                  | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"> <li>■ System view</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                 |                    |                                    |                              |                                   |                     |                                    |                   |                               |                         |                                                        |
| <b>Description</b>           | <p>Set authority to access the NTP services on a local Switch. This is a basic and brief security measure, compared to authentication. An access request will be matched with <b>peer</b>, <b>serve</b>, <b>serve only</b>, and <b>query only</b> in an ascending order of the limitation. The first matched authority will be given.</p>                                                                                                                                                                               |                    |                                    |                              |                                   |                     |                                    |                   |                               |                         |                                                        |

# ntp-service authentication enable

---

## Purpose

Use the `ntp-service authentication enable` command to enable the NTP-service authentication function, if no IP address is specified, the switch automatically selects 224.0.1.1 as the multicast IP address.

Use the `undo ntp-service authentication enable` command to disable this function, if no IP address is specified, the switch will disable the configuration of the multicast IP address 224.0.1.1.

## Syntax

```
ntp-service authentication enable
undo ntp-service authentication enable
```

## Parameters

None

## Default

By default, the authentication is disabled.

## Example

Enable NTP authentication function.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]ntp-service authentication enable
[SW5500]
```

## View

This command can be used in the following views:

- System view

# ntp-service authentication-keyid

---

**Purpose** Use the `ntp-service authentication-keyid` command to set NTP authentication key.

Use the `undo ntp-service authentication-keyid` command to cancel the NTP authentication key.

**Syntax** `ntp-service authentication-keyid number authentication-mode md5 value`  
`undo ntp-service authentication-keyid number`

**Parameters**

|               |                                                                               |
|---------------|-------------------------------------------------------------------------------|
| <i>number</i> | Specifies the key number and range. Valid values are 1 to 4294967295.         |
| <i>value</i>  | Specifies the value of the key.<br>Valid values are 1 to 32 ASCII characters. |

**Default** By default, there is no authentication key.

Only MD5 authentication is supported for the NTP authentication key settings.

**Example** Set MD5 authentication key 10 as BetterKey.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
SW5500]ntp-service authentication-keyid 10 authentication-mode md5
BetterKey
[SW5500]
```

**View** This command can be used in the following views:

- System view



# ntp-service broadcast-client

---

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>     | <p>Use the <code>ntp-service broadcast-client</code> command to configure NTP broadcast client mode.</p> <p>Use the <code>undo ntp-service broadcast-client</code> command to disable the NTP broadcast client mode.</p>                                                                                                                                                                                                                                                                                                         |
| <b>Syntax</b>      | <pre>ntp-service broadcast-client<br/>undo ntp-service broadcast-client</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Parameters</b>  | None                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Default</b>     | By default, the NTP broadcast client mode is disabled.                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Example</b>     | <p>Configure to receive NTP broadcast packets via Vlan-Interface1.</p> <pre>&lt;SW5500&gt;system-view<br/>System View: return to User View with Ctrl+Z.<br/>[SW5500]interface vlan-interface1<br/>[SW5500-Vlan-Interface1]ntp-service broadcast-client<br/>[SW5500-Vlan-Interface1]</pre>                                                                                                                                                                                                                                        |
| <b>View</b>        | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ VLAN Interface view</li></ul>                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Description</b> | <p>Designate an interface on the local Switch to receive NTP broadcast messages and operate in broadcast client mode. The local Switch listens to the broadcast from the server. When it receives the first broadcast packet, it starts a brief client/server mode to switch messages with a remote server for estimating the network delay. Thereafter, the local Switch enters broadcast client mode and continues listening to the broadcast and synchronizes the local clock according to the arrived broadcast message.</p> |

# ntp-service broadcast-server

---

**Purpose** Use the `ntp-service broadcast-server` command to configure NTP broadcast server mode.

Use the `undo ntp-service broadcast-server` command to disable the NTP broadcast server mode.

**Syntax** `ntp-service broadcast-server [ authentication-keyid keyid ] [ version number ]`

`undo ntp-service broadcast-server`

|                   |                                   |                                                                                                 |
|-------------------|-----------------------------------|-------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | <code>authentication-keyid</code> | Specifies the authentication key.                                                               |
|                   | <code>keyid</code>                | Specifies the Key ID used in broadcast. Valid values are 1 to 4294967295.                       |
|                   | <code>version</code>              | Defines the NTP version.                                                                        |
|                   | <code>number</code>               | Defines the NTP version number. Valid values are 1 to 3.<br>If not specified, the default is 3. |

**Default** By default, the broadcast service is disabled.

**Example** Configure to broadcast NTP packets via Vlan-Interface1 and encrypt them with Key 4 and set the NTP version number as 3.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface vlan-interface1
[SW5500-Vlan-Interface1]ntp-service broadcast-server
authentication-key 4 version 3
[SW5500-Vlan-Interface1]
```

**View** This command can be used in the following views:

- VLAN Interface view

**Description** Designate an interface on the local equipment to broadcast NTP packets. The local equipment runs in broadcast-server mode and regularly broadcasts packets to its clients.

# ntp-service in-interface disable

---

## Purpose

Use the `ntp-service in-interface disable` command to disable an interface to receive NTP message.

Use the `undo ntp-service in-interface disable` command to enable an interface to receive NTP message.

## Syntax

```
ntp-service in-interface disable
```

```
undo ntp-service in-interface disable
```

## Parameters

None

## Default

By default, an interface is enabled to receive NTP message.

## Example

Disable Vlan-Interface1 to receive NTP message.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface vlan-interface1
[SW5500-Vlan-Interface1]ntp-service in-interface disable
[SW5500-Vlan-Interface1]
```

## View

This command can be used in the following views:

- VLAN Interface view

# ntp-service max-dynamic sessions

---

## Purpose

Use the `ntp-service max-dynamic-sessions` command to set how many sessions can be created locally.

Use the `undo ntp-service max-dynamic-sessions` command to resume the default maximum session number.

## Syntax

```
ntp-service max-dynamic-sessions number
```

```
undo ntp-service max-dynamic-sessions
```

## Parameters

*number* The maximum sessions that can be created locally.  
Valid values are 0 to 100.  
If not specified, the default is 100.

Set the local equipment to allow up to 50 sessions.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]ntp-service max-dynamic-sessions 50
[SW5500]
```

## View

This command can be used in the following views:

- System view

# ntp-service multicast-client

---

## Purpose

Use the `ntp-service multicast-client` command to configure the NTP multicast client mode.

Use the `undo ntp-service multicast-client` command to disable the NTP multicast client mode.

## Syntax

```
ntp-service multicast-client [ip-address]
undo ntp-service multicast-client [ip-address]
```

## Parameters

*ip-address* Specifies a multicast IP address of Class D.

## Default

By default, the multicast client service is disabled. *ip-address* defaults to 224.0.1.1.

## Example

Configure to receive NTP multicast packet via Vlan-Interface1 and the multicast group corresponding to these packets located at 224.0.1.1.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface vlan-interface 1
[SW5500-Vlan-Interface1]ntp-service multicast-client 224.0.1.1
[SW5500-Vlan-Interface1]
```

## View

This command can be used in the following views:

- VLAN Interface view

## Description

Designate an interface on the local Switch to receive NTP multicast messages and operate in multicast client mode. The local Switch listens to the multicast from the server. When it receives the first multicast packet, it starts a brief client/server mode to switch messages with a remote server for estimating the network delay. Thereafter, the local Switch enters multicast client mode and continues listening to the multicast and synchronizes the local clock according to the arrived multicast message.

# ntp-service multicast-server

---

## Purpose

Use the `ntp-service multicast-server` command to configure NTP multicast server mode.

Use the `undo ntp-service multicast-server` command to disable NTP multicast server mode.

## Syntax

```
ntp-service multicast-server [ip-address] [authentication-keyid
keyid] [ttl ttl-number] [version number]*
```

```
undo ntp-service multicast-server [ip-address]
```

## Parameters

|                             |                                                                                                |
|-----------------------------|------------------------------------------------------------------------------------------------|
| <i>ip-address</i>           | Specifies a multicast IP address of Class D. If not specified, the default is 224.0.1.1.       |
| <i>authentication-keyid</i> | Specifies authentication key.                                                                  |
| <i>keyid</i>                | Specifies Key ID used in multicast. Valid values are 1 to 4294967295.                          |
| <i>ttl</i>                  | Defines the time to live of a multicast packet.                                                |
| <i>ttl-number</i>           | Specifies the ttl of a multicast packet. Valid values are 1 to 255.                            |
| <i>version</i>              | Defines the NTP version.                                                                       |
| <i>number</i>               | Specifies the NTP version number. Valid values are 1 to 3. If not specified, the default is 3. |

## Example

Configure to transmit NTP multicast packets encrypted with Key 4 via Vlan-Interface1 at 224.0.1.1 and use NTP version 3.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface vlan-interface 1
[SW5500-Vlan-Interface1]ntp-service multicast-server 224.0.1.1
authentication-keyid 4 version 3
[SW5500-Vlan-Interface1]
```

## View

This command can be used in the following views:

- VLAN Interface view

## Description

Designate an interface on the local equipment to transmit NTP multicast packet. The local equipment operates in multicast-server mode and multicasts packets regularly to its clients.

# ntp-service reliable authentication-keyid

---

## Purpose

Use the `ntp-service reliable authentication-keyid` command to configure the key as reliable.

Use the `undo ntp-service reliable authentication-keyid` command to cancel the current setting.

## Syntax

```
ntp-service reliable authentication-keyid number
```

```
undo ntp-service reliable authentication-keyid number
```

## Parameters

*number* Specifies the key number. Valid values are 1 to 4294967295.

## Default

By default, no key is configured as reliable.

## Example

Enable NTP authentication, adopt MD5 encryption, and designate Key 37 BetterKey and configure it as reliable.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]ntp-service authentication enable
[SW5500]ntp-service authentication-keyid 37 authentication-mode md5
BetterKey
[SW5500]ntp-service reliable authentication-keyid 37
[SW5500]
```

## View

This command can be used in the following views:

- System view

## Description

When you enable the authentication to use this command to configure one or more than one key as reliable. In this case, a client will only get synchronized by a server whichever can provide a reliable key.

# ntp-service source-interface

---

## Purpose

Use the `ntp-service source-interface` command to designate an interface to transmit NTP message.

Use the `undo ntp-service source-interface` command to cancel the current setting.

## Syntax

```
ntp-service source-interface { interface-name | interface-type
interface-number }
```

```
undo ntp-service source-interface
```

## Parameters

|                         |                                                                                                               |
|-------------------------|---------------------------------------------------------------------------------------------------------------|
| <i>interface-name</i>   | Specifies an interface. The source IP address of the packets will be taken from the address of the interface. |
| <i>interface-type</i>   | Specifies the interface type and determine an interface with the interface-number parameter.                  |
| <i>interface-number</i> | Specifies the interface number and determine an interface with the interface-type parameter.                  |

## Example

Configure all the outgoing NTP packets to use the IP address of Vlan-Interface1 as their source IP address.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]ntp-service source-interface Vlan-Interface 1
[SW5500]
```

## View

This command can be used in the following views:

- System view

## Description

The source address specifies where the packets are transmitted from.

You can use this command to designate an interface to transmit all the NTP packets and take the source address of these packets from its IP address. If you do not want any other interface to receive the acknowledgement packets, use this command to specify one interface to send all the NTP packets.



# ntp-service unicast-peer

---

## Purpose

Use the `ntp-service unicast-peer` command to configure NTP peer mode.

Use the `undo ntp-service unicast-peer` command to cancel NTP peer mode.

## Syntax

```
ntp-service unicast-peer ip-address [version number |
authentication-key keyid | source-interface { interface-name |
interface-type interface-number } | priority]

undo ntp-service unicast-peer ip-address
```

## Parameters

|                                 |                                                                                                                                                                    |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>ip-address</code>         | Specifies the IP address of a remote server.                                                                                                                       |
| <code>version</code>            | Defines the NTP version.                                                                                                                                           |
| <code>number</code>             | Defines the NTP version number. Valid values are 1 to 3.<br>If not specified, the default is 3.                                                                    |
| <code>authentication-key</code> | Defines authentication key.                                                                                                                                        |
| <code>keyid</code>              | Defines the key ID used for transmitting messages to a remote server. Valid values are 1 to 4294967295.                                                            |
| <code>source-interface</code>   | Specifies the name of an interface.                                                                                                                                |
| <code>interface-name</code>     | Specifies the interface name. When a local device sends an NTP message to a peer, the source IP address of the message is taken from the address of the interface. |
| <code>interface-type</code>     | Specifies the interface type and determine an interface together with the interface-number parameter.                                                              |
| <code>interface-number</code>   | Specifies the interface number and determine an interface together with the interface-type parameter.                                                              |
| <code>priority</code>           | Designates a server as the first choice.                                                                                                                           |

## Default

By default, the authentication is disabled and the local server is not the first choice.

## Example

Configure the local equipment to synchronize or be synchronized by a peer at 128.108.22.44. Set the NTP version to 3. The IP address of the NTP packets are taken from that of Vlan-Interface1.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]ntp-service unicast-peer 131.108.22.33 version 3
source-interface Vlan-Interface 1
[SW5500]
```

**View**

This command can be used in the following views:

- System view

**Description**

This command sets the remote server at *ip-address* as a peer of the local equipment, which operates in symmetric active mode. *ip-address* specifies a host address other than an IP address of broadcast, multicast, or reference clock. By operating in this mode, a local device can synchronize and be synchronized by a remote server.

# ntp-service unicast-server

---

## Purpose

Use the `ntp-service unicast-server` command to configure NTP server mode.

Use the `undo ntp-service unicast-server` command to disable NTP server mode.

## Syntax

```
ntp-service unicast-server ip-address [version number |
authentication-keyid keyid | source-interface { interface-name |
interface-type interface-number } | priority]

undo ntp-service unicast-server ip-address
```

## Parameters

|                                   |                                                                                                                                                                    |
|-----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>ip-address</code>           | Specifies the IP address of a remote server.                                                                                                                       |
| <code>version</code>              | Defines the NTP version.                                                                                                                                           |
| <code>number</code>               | Defines the NTP version number. Valid values are 1 to 3.<br>If not specified, the default is 3.                                                                    |
| <code>authentication-keyid</code> | Defines authentication key.                                                                                                                                        |
| <code>keyid</code>                | Defines the key ID used for transmitting messages to a remote server. Valid values are 1 to 4294967295.                                                            |
| <code>source-interface</code>     | Specifies the name of an interface.                                                                                                                                |
| <code>interface-name</code>       | Specifies the interface name. When a local device sends an NTP message to a peer, the source IP address of the message is taken from the address of the interface. |
| <code>interface-type</code>       | Specifies the interface type and determine an interface together with the interface-number parameter.                                                              |
| <code>interface-number</code>     | Specifies the interface number and determine an interface together with the interface-type parameter.                                                              |
| <code>priority</code>             | Designates a server as the first choice.                                                                                                                           |

## Default

By default, the authentication is disabled and the local server is not the first choice.

## Example

Designate the server at 128.108.22.44 to synchronize the local device and use NTP version 3.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]ntp-service unicast-server 128.108.22.44 version 3
[SW5500]
```

## View

This command can be used in the following views:

- System view

**Description**

The command announces to use the remote server at *ip-address* as the local time server. *ip-address* specifies a host address other than an IP address of broadcast, multicast, or reference clock. By operating in client mode, a local device can be synchronized by a remote server, but not synchronize any remote server.

# option

---

## Purpose

Use the **option** command to specify the way to generate detecting results.

Use the **undo option** command to cancel the configured way to generate detecting results.

## Syntax

```
option [and | or]
```

```
undo option [and | or]
```

## Parameters

- |            |                                                                                                                                                                         |
|------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>and</b> | Specifies the detecting result is reachable only when all the IP addresses contained in the detecting group are reachable.<br>This value is set as the default keyword. |
| <b>or</b>  | Specifies the detecting result is reachable if only one of the IP address contained in the detecting group is reachable.                                                |

## Example

Specify the **or** keyword for detecting group 10.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] detect-group 10
[S5500-detect-group-10] option or
```

## View

This command can be used in the following views:

- Detecting Group view

## Description

When a detecting operation is being carried out, the switch detects each IP address contained in the detecting group in an ascending order by the list-number values of the IP addresses.

- If you specify the **and** keyword, the switch returns unreachable as the detecting result when the switch fails to ping an IP address contained in the detecting group and stops detecting.
- If you specify the **or** keyword, the switch returns reachable as the detecting result if the switch succeeds in pinging an IP address contained in the detecting group and stops detecting.



*This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

# originating-rp

---

## Purpose

Use the **originating-rp** command to allow MSDP peer to use the specified interface IP address as the RP address in the SA message when the MSDP peer creates SA messages.

Use the **undo originating-rp** command to cancel configuration.

## Syntax

```
originating-rp interface-type interface-number
```

```
undo originating-rp
```

## Parameters

*interface-type*                    Interface type.

*interface-number*                Interface number.

## Default

By default, the RP address in an SA message is the RP address configured by PIM.

## Example

Configure the IP address of the interface Vlan-interface 100 as the RP address of the created SA message.

```
<S5500> system-view
[S5500] msdp
[S5500-msdp] originating-rp Vlan-interface 100
```

## View

This command can be used in the following views:

- MSDP view

# ospf

---

## Purpose

Using the **ospf** command, you can enable the OSPF protocol.

Using the **undo ospf** command, you can disable the OSPF protocol.

## Syntax

```
ospf [process-id [router-id router-id]]
```

```
undo ospf
```

## Parameters

*process-id*

Specifies the ID of the OSPF process, which is locally significant. Valid values are 1 to 65535.  
If not specified, the default process ID is 1.

*router-id*

Specifies the router ID that is a 32-bit unsigned integer.

## Example

Enable the OSPF protocol.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]
```

Enable the OSPF protocol with a process ID of 120.

```
[SW5500]router id 10.110.1.8
[SW5500]ospf 120
[SW5500-ospf-120]
```

## View

This command can be used in the following views:

- System view

## Description

After enabling the OSPF protocol, you can configure OSPF operations using the commands described in the “OSPF Configuration Commands” section. By default, the system does not run the OSPF protocol.

## Related Command

**network**

# ospf authentication-mode

---

## Purpose

Using the `ospf authentication-mode` command, you can configure the authentication mode and key between adjacent routers.

Using the `undo ospf authentication-mode` command, you can cancel the set authentication key.

## Syntax

```
ospf authentication-mode { simple password | md5 key_id key }
undo ospf authentication-mode { simple | md5 }
```

## Parameters

|                                     |                                                                                                                                                                                                                                                                                                                                                                      |
|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>simple <i>password</i></code> | Specifies a password of up to 8 characters in length.                                                                                                                                                                                                                                                                                                                |
| <code><i>key_id</i></code>          | Specifies the ID of the MD5 authentication key. Valid values are 1 to 255.                                                                                                                                                                                                                                                                                           |
| <code><i>key</i></code>             | Specifies the MD5 authentication key. If it is input in a plain text form, MD5 key is a character string up to 16 characters in length. It will be displayed in a cipher text form in a length of 24 characters when the <b>display current-configuration</b> command is executed. Inputting the MD5 key in a cipher text form with 24 characters is also supported. |

## Example

Area 1 is where the network segment 131.119.0.0 of Interface Vlan-interface 1 is located. To set this area to support MD5 cipher text authentication, with an authentication key identifier of 15 and an authentication key of 3Com, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]
[SW5500-ospf-1]area 1
[SW5500-ospf-1-area-0.0.0.1]network 131.119.0.0 0.0.255.255
[SW5500-ospf-1-area-0.0.0.1]authentication-mode md5
[SW5500-ospf-1-area-0.0.0.1]quit
[SW5500-ospf-1]quit
[SW5500]interface vlan-interface 1
[SW5500-Vlan-interface1]ospf authentication-mode md5 15 3Com
```

## View

This command can be used in the following views:

- VLAN Interface view

## Description

The passwords for the authentication keys of routers on the same network segment must be identical. In addition, if you use this command with the



**authentication-mode** command, you can set the authentication type of an area (see Example). By default, the interface does not authenticate the OSPF packets.

## Related Command

**authentication-mode**

# ospf cost

---

## Purpose

Using the `ospf cost` command, you can configure the cost of sending traffic from each interface.

Using the `undo ospf cost` command, you can restore the default costs.

## Syntax

```
ospf cost value
```

```
undo ospf cost
```

## Parameters

*value*

Specifies the cost for running the OSPF protocol. Valid values are 1 to 65535.

## Default

For the Switch 5500-EI, the default cost for running OSPF protocol of on a VLAN interface is 10.

## Example

To specify a cost of 33 when the interface vlan-interface 1 runs OSPF, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface vlan-interface 1
[SW5500-Vlan-interface1]ospf cost 33
```

## View

This command can be used in the following views:

- VLAN Interface view

# ospf dr-priority

---

## Purpose

Using the `ospf dr-priority` command, you can configure the priority for electing the "designated router" on an interface.

Using the `undo ospf dr-priority` command, you can restore the default value.

## Syntax

```
ospf dr-priority value
```

```
undo ospf dr-priority
```

## Parameters

*value*

Specifies the interface priority for electing the "designated router". Valid values are 0 to 255. If not specified, the default value is 1.

## Example

To set a priority of 8 for Vlan-interface 1, when electing the DR, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface vlan-interface 1
[SW5500-Vlan-interface1]ospf dr-priority 8
```

## View

This command can be used in the following views:

- VLAN Interface view

## Description

The priority of the interface determines the qualification of the interface when the "designated router" (DR) is elected. The interface with the higher priority will be always be elected the DR. A priority of 0 will disallow the interface from participating in a DR election.

# ospf mib-binding

---

## Purpose

Using the **ospf mib-binding** command, you can bind the MIB operation to the specified OSPF process.

Using the **undo ospf mib-binding** command, you can restore the default settings.

## Syntax

```
ospf mib-binding process-id
```

```
undo ospf mib-binding
```

## Parameters

*process-id*

Specifies the process ID of OSPF. Valid values are 1 to 65535.

## Description

By default, MIB operation is bound to the first enabled OSPF process.

## Example

Bind MIB operation to OSPF process 100.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]ospf mib-binding 100
```

Bind MIB operation to OSPF process 200.

```
[SW5500]ospf mib-binding 200
Cancel the binding of MIB operation.
[SW5500]undo ospf mib-binding
```

## View

This command can be used in the following views:

- System view

## Description

When OSPF protocol enables the first process, it always binds MIB operation to this process. You can use this command to bind MIB operation to another OSPF process. Execute the **undo ospf mib-binding** command if you want to cancel the setting. OSPF will automatically re-bind MIB operation to the first process that it enables.

# ospf mtu-enable

---

## Purpose

Using the `ospf mtu-enable` command, you can enable the interface to write the MTU value when sending DD packets.

Using the `undo ospf mtu-enable` command, you can restore the default.

## Syntax

```
ospf mtu-enable
undo ospf mtu-enable
```

## Parameters

None

## Default

By default, the MTU value is 0 when sending DD packets, that is the MTU value of the interface is not written.

## Example

To set interface Vlan-interface 3 to write the MTU value when sending DD packets, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface Vlan-interface 3
[SW5500-Vlan-interface 3]ospf mtu-enable
```

## View

This command can be used in the following views:

- VLAN Interface view

## Description

DD packets (Database Description Packet) are sent by the router to describe its own LSDB when the router running OSPF protocol is synchronizing the database.

# ospf network-type

---

## Purpose

Use the `ospf network-type` command to configure the network type of OSPF interface.

Use the `undo ospf network-type` command to restore the default network type of the OSPF interface.

## Syntax

```
ospf network-type { broadcast | nbma | p2mp | p2p }
```

```
undo ospf network-type
```

## Parameters

|                  |                                                                     |
|------------------|---------------------------------------------------------------------|
| <b>broadcast</b> | Enables you to change the interface network type to broadcast.      |
| <b>nbma</b>      | Enables you to change the interface network type to NBMA.           |
| <b>p2mp</b>      | Enables you to change the interface network type to p2mp.           |
| <b>p2p</b>       | Enables you to change the interface network type to point-to-point. |

## Example

Set the interface Vlan-interface 1 to NBMA type.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface Vlan-interface 1
[SW5500-Vlan-interface1]ospf network-type nbma
```

## View

This command can be used in the following views:

- VLAN Interface view

## Description

OSPF divides networks into four types by link layer protocol:

- *Broadcast*: If Ethernet or FDDI is adopted, OSPF defaults the network type to broadcast.
- *Non-Broadcast Multi-access (nbma)*: If Frame Relay, ATM, HDLC or X.25 is adopted, OSPF defaults the network type to NBMA.
- *Point-to-Multipoint (p2mp)*: OSPF will not default the network type of any link layer protocol to p2mp. The general undertaking is to change a partially connected NBMA network to p2mp network if the NBMA network is not fully-meshed.
- *Point-to-point (p2p)*: If PPP, LAPB or POS is adopted, OSPF defaults the network type to p2p.

NBMA means that a network is non-broadcast and multi-accessible. ATM is a typical example. A user can configure the polling interval to specify the interval of sending polling hello packets before the adjacency of the neighboring routers is formed.

Configure the interface type to nonbroadcast on a broadcast network without multi-access capability.

Configure the interface type to p2mp if not all the routers are directly accessible on an NBMA network.

Change the interface type to p2p if the router has only one peer on the NBMA network.



*When the network type of an interface is NBMA or it is changed to NBMA manually, the peer command must be used to configure the neighboring point.*

## Related Command

`ospf dr-priority`

# ospf timer dead

---

## Purpose

Using the `ospf timer dead` command, you can configure the amount of dead time allowed to OSPF neighbors, in seconds.

Using the `undo ospf timer dead` command, you can restore the default value.

## Syntax

```
ospf timer dead seconds
```

```
undo ospf timer dead
```

## Parameters

*seconds*

Specifies the amount of dead time allowed (in seconds). Valid values are 1 to 65535. If not specified, the default dead time allowed to OSPF neighbors is 40 seconds

## Example

To set the dead time to 80 seconds on interface Vlan-interface 1, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface Vlan-interface 1
[SW5500-Vlan-interface1]ospf timer dead 80
```

## View

This command can be used in the following views:

- VLAN Interface view

## Description

If no Hello message is received from a neighbor in the specified time, the neighbor is considered unresponsive or down. The `timer dead` value should be at least four times that of the `timer hello` value. The `timer dead` value for routers on the same network segment must be identical.

## Related Command

```
ospf timer hello
```



# ospf timer hello

---

## Purpose

Using the `ospf timer hello` command, you can configure the Hello interval time allowed for an interface.

Using the `undo ospf timer hello` command, you can restore the interval to the default value.

## Syntax

```
ospf timer hello seconds
```

```
undo ospf timer hello
```

## Parameters

*seconds*

Enables you to enter the Hello interval time allowed (in seconds). Valid values are 1 to 255.  
If not specified, the default time allowed is 10 seconds for an interface of **p2p** or **broadcast** type, and 30 seconds for an interface of **nbma** or **p2mp** type.

## Example

To set a time interval of 20 seconds for transmitting Hello messages on the interface Vlan-interface 1, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface Vlan-interface 1
[SW5500-Vlan-interface1]ospf timer hello 20
```

## View

This command can be used in the following views:

- VLAN Interface view

## Related Command

`ospf timer dead`

# ospf timer poll

---

## Purpose

Using the `ospf timer poll` command, you can configure the Hello packet poll interval.

Using the `undo ospf timer poll` command, you can restore the default poll interval.

## Syntax

```
ospf timer poll seconds
```

```
undo ospf timer poll
```

## Parameters

*seconds*

Specifies the the poll Hello interval (in seconds). Valid values are 1 to 65535. If not specified, the default value is 120 seconds.

## Example

To set the transmit poll Hello packet interval to 130 seconds for interface Vlan-interface 2, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface Vlan-interface 2
[SW5500-Vlan-interface2]ospf timer poll 130
```

## View

This command can be used in the following views:

- VLAN Interface view

## Description

The Poll interval should be at least three times the Hello interval.

# ospf timer retransmit

---

## Purpose

Using the `ospf timer retransmit` command, you can configure the interval before LSA re-transmission on an interface.

Using the `undo ospf timer retransmit` command, you can restore the default interval value for LSA re-transmission on an interface.

## Syntax

```
ospf timer retransmit interval
```

```
undo ospf timer retransmit
```

## Parameters

*interval*

Specifies the interval allowed before LSA re-transmission (in seconds). Valid values are 1 to 65535.

If not specified, the default value is 5 seconds.

## Example

To set the retransmit interval between the interface Vlan-interface 1 and the adjacent routers to 12 seconds, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface Vlan-interface 1
[SW5500-Vlan-interface1]ospf timer retransmit 12
```

## View

This command can be used in the following views:

- VLAN Interface view

## Description

When a router transmits a Link State Advertisement (LSA) to the peer, it waits for the acknowledgement packet. If no acknowledgement is received from the neighbor within the time you set using this command, the LSA is re-transmitted.

According to RFC2328, the LSA retransmit between adjacent routers should not be set too short to avoid unexpected re-transmission.

# ospf trans-delay

---

## Purpose

Using the `ospf trans-delay` command, you can configure the LSA transmission delay on an interface.

Using the `undo ospf trans-delay` command, you can restore the default value of the LSA transmission delay.

## Syntax

```
ospf trans-delay value
```

```
undo ospf trans-delay
```

## Parameters

`value`

Specifies the LSA transmission delay (in seconds). Valid values are 1 to 3600. If not specified, the default is 1 second.

## Example

To set the LSA transmission delay to three seconds on interface Vlan-interface 1, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.

[SW5500]interface Vlan-interface 1
[SW5500-Vlan-interface1]ospf trans-delay 3
```

## View

This command can be used in the following views:

- VLAN Interface view

## Description

LSA will age in the "link state database" (LSDB) of the router as time goes by (add 1 for every second), but it will not age during network transmission. Therefore, it is necessary to add a period of time set by this command to the aging time of LSA before transmitting it.

# packet-filter

---

## Purpose

Use the `packet-filter` command to add packet filtering action to the QoS profile.

Use the `undo packet-filter` command, you can remove packet filtering action from the QoS profile.

## Syntax

```
packet-filter { inbound | outbound } { user-group acl-number [rule rule] | ip-group acl-number [rule rule [link-group acl-number rule rule]] | link-group acl-number [rule rule] }
```

```
undo packet-filter { inbound | outbound } { user-group acl-number [rule rule] | ip-group acl-number [rule rule [link-group acl-number rule rule]] | link-group acl-number [rule rule] }
```

## Parameters

|                                           |                                                                                                                                  |
|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| <code>inbound</code>                      | Filters the inbound packets on the port.                                                                                         |
| <code>outbound</code>                     | Filters the outbound packets on the port.                                                                                        |
| <code>user-group <i>acl-number</i></code> | Custom ACL, <i>acl-number</i> . Valid values are 5000 to 5999.                                                                   |
| <code>ip-group <i>acl-number</i></code>   | Basic or advanced ACL, <i>acl-number</i> . Valid values are 2000 to 3999                                                         |
| <code>link-group <i>acl-number</i></code> | Layer 2 ACL, <i>acl-number</i> . Valid values are 4000 to 4999                                                                   |
| <code>rule <i>rule</i></code>             | Specifies a match statement in the ACL. Valid values are 0 to 65534. All match statements are selected if you skip this keyword. |

## Example

To add the qos-profile student to this packet filtering action: Filters the inbound packets matching the ACL 4000, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]qos-profilestudent
[SW5500-qos-profilestudent]packet-filter inbound link-group 4000
[SW5500-qos-profilestudent]
```

## View

This command can be used in the following views:

- QoS Profile view

# packet-filter

---

## Purpose

Use the `packet-filter` command to activate the ACL on a specific interface.

Use the `undo packet-filter` command to disable the ACL on a specific interface.

## Syntax

```
packet-filter { inbound | outbound } { user-group acl-number [rule
rule] | ip-group acl-number [rule rule [link-group acl-number rule
rule]] | link-group acl-number [rule rule] }
```

```
undo packet-filter { inbound | outbound } { user-group acl-number [
rule rule] | ip-group acl-number [rule rule [link-group acl-number
rule rule]] | link-group acl-number [rule rule] }
```

## Parameters

|                                           |                                                                                                                                                                          |
|-------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>inbound</code>                      | Filters the traffic received by the Ethernet port.                                                                                                                       |
| <code>outbound</code>                     | Performs filtering to the packets sent by the interface.                                                                                                                 |
| <code>user-group <i>acl-number</i></code> | Activates user-defined ACLs. <i>acl-number</i> : Sequence number of the ACL. Valid values are 5000 to 5999.                                                              |
| <code>ip-group <i>acl-number</i></code>   | Activates the IP ACLs, including basic and advanced ACLs. <i>acl-number</i> specifies the sequence number of the ACL. Valid values are 2000 to 3999.                     |
| <code>link-group <i>acl-number</i></code> | Activates the Layer 2 ACLs. <i>acl-number</i> specifies the ACL number. Valid values are 4000 to 4999.                                                                   |
| <code>rule <i>rule</i></code>             | Specifies the rule of an ACL. Valid values are 0 to 65534.<br>if not specified, all sub-items of the ACL will be activated. An ACL can have many rules. They start at 0. |

## Example

Activate ACL 2000 for inbound traffic on interface Ethernet 1/0/1.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Ethernet 1/0/1
[SW5500-Ethernet1/0/1]packet-filter inbound ip-group 2000
[SW5500-Ethernet1/0/1]
```

## View

This command can be used in the following views:

- Ethernet Port view

# parity

---

## Purpose

Use the **parity** command to configure the parity mode on the AUX (Console) port.

Use the **undo parity** command to restore the default parity mode (no parity checking).

## Syntax

```
parity { even | mark | none | odd | space }
undo parity
```

## Parameters

|              |                                                |
|--------------|------------------------------------------------|
| <b>even</b>  | Sets the Switch to even parity.                |
| <b>mark</b>  | Sets the Switch to mark parity (1).            |
| <b>none</b>  | Sets the Switch to perform no parity checking. |
| <b>odd</b>   | Sets the Switch to odd parity.                 |
| <b>space</b> | Sets the Switch to zero parity (0).            |

## Example

To set mark parity on the AUX (Console) port, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]user-interface aux 0
[SW5500-ui-aux0]parity mark
```

## View

This command can be used in the following views:

- User Interface view

## Description

This command can only be performed in the AUX User interface view.

# passive

---

**Purpose** Use the `passive` command to set the data transmission mode to be passive mode.

Use the `undo passive` command to set the data transmission mode to be active mode.

**Syntax**

```
passive
undo passive
```

**Parameters** None

**Default** By default, the data transmission mode is passive mode

**Example** Set the data transmission to passive mode.

```
<SW5500>ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in
[ftp]passive
% Passive is on
[ftp]
```

**View** This command can be used in the following views:

- FTP Client view



# password

---

**Purpose** Use the **password** command to configure a password display mode for local users.  
Use the **undo password** command to cancel the specified password display mode.

**Syntax**

```
password { simple | cipher } password
undo password
```

**Parameters**

|                        |                                                                                                                                                    |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>simple</b>          | Specifies to display passwords in simple text.                                                                                                     |
| <b>cipher</b>          | Specifies to display passwords in cipher text.                                                                                                     |
| <b><i>password</i></b> | Defines a password, which is a character string of up to 16 characters if it is in simple text and of up to 24 characters if it is in cipher text. |

**Example** To set the user 3Com1 to display the password in simple text, given the password is 20030422, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]local-user 3Com1
[SW5500-luser-3Com1]password simple 20030422
```

**View** This command can be used in the following views:

- Local User View

**Related Command** **display local-user**

# password

---

**Purpose** Use the `password` command to configure or change the system login password for a user.

**Syntax** `password`

**Parameters** None

**Example** Configure the system login password for the user test to 9876543210.

```
S5500<S5500> system-view
System View: return to User View with Ctrl+Z.
S5500[S5500] local-user test
New local user added.
[S5500-luser-test] password
Password:*****
confirm:*****
```

Change the system login password for the user test to 0123456789.

```
[S5500-luser-test]password
Password:*****
Confirm :*****
Updating the password file ,please wait ...
```

**View** This command can be used in the following views:

- Local User view

# password-control

---

## Purpose

Use the **password-control** command to configure login passwords.

Use the **password-control aging *aging-time*** command to configure the aging time for system login passwords.

Use the **password-control length *length*** command to configure the minimum password length for the system login passwords.

Use the **password-control login-attempt *login-times*** command to configure the number of password attempts allowed for each user.

Use the **password-control history *max-record-num*** command to configure the maximum number of history password records allowed for each user.

Use the **password-control alert-before-expire *alert-time*** command to configure the alert time before password expiration, that is, specify the number of days before password expiration to start a daily alert.

Use the **password-control authentication-timeout *authentication-timeout*** command to configure the timeout time for user password authentication.

Use the **password-control exceed** command to configure the processing mode used after password attempt fails.

## Syntax

```
password-control aging aging-time
```

```
password-control length length
```

```
password-control login-attempt login-times [exceed { lock | unlock |
locktime time }]
```

```
password-control history max-record-num
```

```
password-control alert-before-expire alert-time
```

```
password-control authentication-timeout authentication-timeout
```

```
undo password-control { aging | length | login-attempt | exceed |
history | alert-before-expire | authentication-timeout }
```

## Parameters

***aging-time*** Specifies password aging time. Valid values are 1 day to 365 days. If not specified, the default is 90 days.

***length*** Specifies minimum password length. Valid values are any character string from 4 to 32 characters in length. If not specified, the default character string length is 10 characters.

***login-times*** Specifies the number of login attempts allowed for each user. Valid values are 2 to 10. If not specified, the default is 3.

|                                      |                                                                                                                                                                                                                                                                          |
|--------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b><i>max-record-num</i></b>         | Specifies the maximum number of history records allowed for each user. Valid values are 2 to 10. If not specified, the default is 4.                                                                                                                                     |
| <b><i>alert-time</i></b>             | Specifies alert-time period. When the remaining usable time of a password is no more than this time, the user is alerted to the forthcoming password expiration. Valid values are 1 to 30 days. If not specified, the default is 7 days.                                 |
| <b><i>authentication-timeout</i></b> | Specifies the timeout time for user authentication. Valid values are 30 seconds to 120 seconds. If not specified, the default is 60 seconds.                                                                                                                             |
| <b><i>exceed</i></b>                 | Configures the processing mode used after login fails.                                                                                                                                                                                                                   |
| <b><i>lock</i></b>                   | A processing mode. In lock mode, a user with a log-in failure is added to the blacklist and will be able to re-login only after the administrator manually removes this user from the blacklist.                                                                         |
| <b><i>locktime time</i></b>          | A processing mode. In locktime mode, a user with a log-in failure is inhibited from logging in a certain time period, which ranges from 3 to 360 (in minutes) and defaults to 120 minutes; the user is allowed to log into the device again only after this time passes. |
| <b><i>unlock</i></b>                 | A processing mode. In this mode, a login-failure user is allowed to log into the switch again and again without any inhibition.                                                                                                                                          |

**Default**

By default, the system operates in ***locktime*** mode after password authentication fails.

**Example**

Configure the aging time of the system login passwords to 100 days.

```
S5500<S5500>system-view
System View: return to User View with Ctrl+Z.
S5500[S5500] password-control aging 100
```

Configure the minimum password length of the system login passwords to eight characters.

```
S5500[S5500] password-control length 8
```

Configure the number of password attempts allowed for each user to five.

```
S5500[S5500] password-control login-attempt 5
```

Configure the maximum number of history password records allowed for each user to 10.

```
S5500[S5500] password-control history 10
```

Configure the alert time when users are alerted to their forthcoming expiration to seven days ahead of their expiration times.

```
S5500[S5500] password-control alert-before-expire 7
```

Configure the timeout time of the user password authentication to 100 seconds.

```
S5500 [S5500] password-control authentication-timeout 100
```

Configure the maximum number of password attempts to five, and configure the system to allow the attempt failure user to re-log into the device 360 minutes after the failure.

```
S5500 [S5500] password-control login-attempt 5 exceed locktime 360
```

## View

This command can be used in the following views:

- System view

# password-control enable

---

## Purpose

Use the **password-control enable** command to enable various password control functions of the system.

- Use the **password-control aging enable** command to enable password aging.
- Use the **password-control length enable** command to enable the limitation of the minimum password length.
- Use the **password-control history enable** command to enable the history password recording.
- Use the **undo password-control { aging | length | history } enable** command to disable password control.

## Syntax

```
password-control { aging | length | history } enable
undo password-control { aging | length | history } enable
```

## Parameters

None

## Default

By default, password aging, limitation of minimum password length, and history password recording are all enabled.

## Example

Enable password aging.

```
[<S5500>]system-view
System View: return to User View with Ctrl+Z.
S5500[S5500] password-control aging enable
Password aging enabled for all users. Default: 90 days.
```

Enable the limitation of the minimum password length.

```
S5500[S5500]password-control length enable
Password minimum length enabled for all users. Default: 10 characters.
```

Disable password aging.

```
S5500[S5500] undo password-control aging
Password aging disabled for all users.
```

Enable history password recording.

```
S5500[S5500] password-control history enable
Password history enabled for all users.
```

Disable history password recording.

```
S5500[S5500]undo password-control history
Password history disabled for all users.
Display the password control information of the specified user.
S5500[S5500]display local-user user-name test
```

The contents of local user test:

```
State: Active ServiceType Mask: T
Idle-cut: Disabled
Access-limit: Disabled Current AccessNum: 0
Bind location: Disabled
Vlan ID: Disabled
IP address: Disabled
MAC address: Disabled
User Privilege: 3
Password-Aging: Enabled (90 days)
Password-Length: Enabled (10 characters)
Password History was last reset 2 days ago.
```

## View

This command can be used in the following views:

- System view

## Description

When the password used to log into the switch expires, the switch requires the user to change the password, and automatically saves the history (old) password to a file in the flash memory. In this way, the switch can prevent any user from using one single password or the used password for a long time to enhance the security.

## Related Command

**password-control**

# password-control super

---

## Purpose

Use the **password-control super** command to configure the parameters related with the super passwords, including the password aging time and the minimum password length.

Use the **undo password-control super** command to restore the default settings for the super passwords.

## Syntax

```
password-control super { aging aging-time | length min-length }
undo password-control super { aging | length }
```

## Parameters

|                   |                                                                                                                             |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------|
| <i>aging-time</i> | Aging time for super passwords. Valid values are 1 to 365 days.<br>If not specified, the default is 90 days.                |
| <i>min-length</i> | Minimum length for super passwords. Valid values are 4 to 16 characters.<br>If not specified, the default is 10 characters. |

## Example

Configure the aging time of the super passwords to 10 days.

```
S5500<S5500> system-view
System View: return to User View with Ctrl+Z.
S5500[S5500] password-control super aging 10
```

## Description

The super passwords are used for the user who has logged into the device and wants to change from a lower privilege level to a higher privilege level.

## View

This command can be used in the following views:

- System view



# peer

---

## Purpose

Use the **peer** command to configure the neighboring point if a router is connected to a network of NBMA type.

Use the **undo peer** command to cancel the configured neighboring point.

## Syntax

```
peer ip_address [dr-priority dr_priority_number]
undo peer ip_address
```

## Parameters

|                           |                                                                                                                                                                             |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>ip_address</i>         | Specifies the IP address of the neighboring router.                                                                                                                         |
| <i>dr_priority_number</i> | Specifies the priority value that represents the corresponding priority value of the network neighbor. Valid values are 0 to 255. If not specified, the default value is 1. |

## Example

To configure the IP address of the neighboring router to 10.1.1.1, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]peer 10.1.1.1
```

## View

This command can be used in the following views:

- OSPF view

# peer

---

## Purpose

Use the **peer** command to configure the destination address of the peer device.

Use the **undo peer** command to cancel the set destination address. By default, there is no destination address.

## Syntax

```
peer ip_address
```

```
undo peer ip_address
```

## Parameters

*ip\_address*

Specifies the interface IP address of the peer router.

## Example

To specify the sending destination address as 202.38.165.1, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]rip
[SW5500-rip]peer 202.38.165.1
```

## View

This command can be used in the following views:

- RIP view

## Description

3Com recommends that you do not use this command. RIP can use unicast to exchange information with non-broadcasting networks. If required, you can use this command to specify the destination address of the peer device.

# peer connect-interface

---

## Purpose

Use the **peer connect-interface** command to configure MSDP peer.

Use the **undo peer connect-interface** command to cancel the configured MSDP peer.

## Syntax

```
peer peer-address connect-interface interface-type interface-number
undo peer peer-address
```

## Parameters

*peer-address*

IP address of the MSDP peer, in dotted decimal notation.

*interface-type*  
*interface-number*

Interface type and interface number. The local router uses the address of this interface as the source IP address to establish TCP connection with its remote MSDP peer.

## Example

Configure the router whose IP address is 125.10.7.6 as the MSDP peer of the local router.

```
<S5500> system-view
[S5500] msdp
[S5500-msdp] peer 125.10.7.6 connect-interface Vlan-interface 100
```

## View

This command can be used in the following views:

- MSDP view

## Related Command

**static-rpf-peer**

# peer description

---

## Purpose

Use the **peer description** command to configure the description text for an MSDP peer.

Use the **undo peer description** command to delete the configured description text.

## Syntax

```
peer peer-address description text
```

```
undo peer peer-address description
```

## Parameters

|                     |                                                                                 |
|---------------------|---------------------------------------------------------------------------------|
| <b>peer-address</b> | IP address of the MSDP peer, in the dotted decimal format.                      |
| <b>text</b>         | Description text, which is case sensitive. The maximum length is 80 characters. |

## Default

By default, an MSDP peer has no description text.

## Example

Add the description text “router CstmrA” for the router 125.10.7.6 to specify that the router is customer A.

```
<S5500> system-view
[S5500] msdp
[S5500-msdp] peer 125.10.7.6 description router CstmrA
```

## View

This command can be used in the following views:

- MSDP view

## Description

The administrator can distinguish MSDP peers by means of the description texts.

## Related Command

```
display msdp peer-status
```

# peer mesh-group

---

**Purpose** Use the `peer mesh-group` command to add an MSDP peer in a mesh group.  
Use the `undo peer mesh-group` command to cancel the configuration.

**Syntax**

```
peer peer-address mesh-group name
undo peer peer-address mesh-group name
```

**Parameters**

|                     |                                                                           |
|---------------------|---------------------------------------------------------------------------|
| <i>peer-address</i> | IP address of an MSDP peer in a mesh group, in the dotted decimal format. |
| <i>name</i>         | Name of a mesh group, case sensitive, containing 1 to 32 characters.      |

**Default** By default, an MSDP peer does not belong to any mesh group.

**Example** Configure the MSDP peer whose address is 125.10.7.6 as a member of the mesh group Grp1.

```
<S5500> system-view
[S5500] msdp
[S5500-msdp] peer 125.10.7.6 mesh-group Grp1
```

**View** This command can be used in the following views:

- MSDP view

# peer minimum-ttl

---

## Purpose

Use the `peer minimum-ttl` command to configure the minimum TTL value of the multicast data packets encapsulated in SA messages and to be sent to the specified MSDP peer.

Use the `undo peer minimum-ttl` command to restore the default TTL threshold.

## Syntax

```
peer peer-address minimum-ttl t1-value
```

```
undo peer peer-address minimum-ttl
```

## Parameters

*peer-address*

IP address of the MSDP peer to which the TTL threshold applies, in the dotted decimal format

*t1-value*

TTL threshold. Valid values are 0 to 255.  
If not specified, the default value of TTL threshold is 0.

## Example

Set the TTL threshold to 10, so that only those multicast data packets with a TTL value greater than or equal to 10 can be forwarded to the MSDP peer 110.10.10.1.

```
<S5500> system-view
[S5500] msdp
[S5500-msdp] peer 110.10.10.1 minimum-ttl 10
```

## View

This command can be used in the following views:

- MSDP view

## Related Command

`peer`

# peer-public-key end

---

|                         |                                                                                                                                                               |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>          | Use the <code>peer-public-key end</code> command to return to system view from public key view.                                                               |
| <b>Syntax</b>           | <code>peer-public-key end</code>                                                                                                                              |
| <b>Parameters</b>       | None                                                                                                                                                          |
| <b>Example</b>          | Exit from public key view.<br><br><pre>&lt;S5500&gt; system-view [S5500] rsa peer-public-key 3Com003 [S5500-rsa-public-key] peer-public-key end [S5500]</pre> |
| <b>View</b>             | This command can be used in the following views: <ul style="list-style-type: none"><li>■ Public Key view</li></ul>                                            |
| <b>Related Commands</b> | <ul style="list-style-type: none"><li>■ <code>public-key-code begin</code></li><li>■ <code>rsa peer-public-key</code></li></ul>                               |

# peer request-sa-enable

---

|                        |                                                                                                                                                                                                                                                                       |
|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>         | <p>Use the <code>peer request-sa-enable</code> command to enable the router to send an SA request message to the specified MSDP peer upon receipt of a Join message.</p> <p>Use the <code>undo peer request-sa-enable</code> command to remove the configuration.</p> |
| <b>Syntax</b>          | <pre>peer <i>peer-address</i> request-sa-enable<br/>undo peer <i>peer-address</i> request-sa-enable</pre>                                                                                                                                                             |
| <b>Parameters</b>      | <p><i>peer-address</i> IP address of the MSDP peer, in dotted decimal format.</p>                                                                                                                                                                                     |
| <b>Default</b>         | <p>By default, upon receipt of a Join message, the router sends no SA request message to the MSDP peer but waits for the next SA message.</p>                                                                                                                         |
| <b>Example</b>         | <p>Configure to send an SA request message to the MSDP peer 125.10.7.6.</p> <pre>&lt;S5500&gt; system-view<br/>[S5500] msdp<br/>[S5500-msdp] peer 125.10.7.6 request-sa-enable</pre>                                                                                  |
| <b>View</b>            | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ MSDP view</li></ul>                                                                                                                                                   |
| <b>Related Command</b> | <code>cache-sa-enable</code>                                                                                                                                                                                                                                          |



# peer sa-cache-maximum

---

## Purpose

Use the `peer sa-cache-maximum` command to set the maximum number of SA messages cached on the router.

Use the `undo peer sa-cache-maximum` command to restore the default configuration.

## Syntax

```
peer peer-address sa-cache-maximum sa-limit
```

```
undo peer peer-address sa-cache-maximum
```

## Parameters

|                     |                                                                                                                                                               |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>peer-address</i> | IP address of the MSDP peer, in the dotted decimal format.                                                                                                    |
| <i>sa-limit</i>     | Maximum number of SA messages cached. Valid values are 1 to 2,048.<br>If not specified, the default maximum number of SA messages cached on a router is 2,048 |

## Example

Configure the SA cache of the router so that it caches a maximum of 100 SA messages received from the MSDP peer 125.10.7.6.

```
<S5500> system-view
[S5500] msdp
[S5500-msdp] peer 125.10.7.6 sa-cache-maximum 100
```

## View

This command can be used in the following views:

- MSDP view

## Description

It is recommended to perform this configuration on all MSDP peers on a network that is vulnerable to DoS attacks.

## Related Commands

- `display msdp brief`
- `display msdp peer-status`
- `display msdp sa-count`

# peer sa-policy

---

## Purpose

Use the `peer sa-policy` command to configure the filtering list for receiving or forwarding the SA messages from the specified MSDP peer.

Use the `undo peer sa-policy` command to remove the configuration.

## Syntax

```
peer peer-address sa-policy { import | export } [acl acl-number]
undo peer peer-address sa-policy { import | export }
```

## Parameters

|                             |                                                                                                                        |
|-----------------------------|------------------------------------------------------------------------------------------------------------------------|
| <code>import</code>         | Specifies to receive the SA messages from the specified MSDP peer.                                                     |
| <code>export</code>         | Specifies to forward the SA messages from the specified MSDP peer.                                                     |
| <code>peer-address</code>   | IP address of the MSDP peer whose SA messages need to be filtered.                                                     |
| <code>acl acl-number</code> | Advanced IP ACL number. Valid values are 3000 to 3999.<br>If no ACL is specified, all (S, G) entries are filtered out. |

## Default

By default, no filtering is imposed on SA messages to be received or forwarded, namely all SA messages from MSDP peers are received or forwarded.

## Example

Configure a filtering list so that only those SA messages permitted by the advanced IP ACL 3100 are forwarded.

```
<S5500> system-view
[S5500] acl number 3100
[S5500-acl-adv-3100] rule permit ip source 170.15.0.0 0.0.255.255
destination 225.1.0.0 0.0.255.255
[S5500-acl-adv-3100] quit
[S5500] msdp
[S5500-msdp] peer 125.10.7.6 connect-interface Vlan-interface 100
[S5500-msdp] peer 125.10.7.6 sa-policy export acl 3100
```

## View

This command can be used in the following views:

- MSDP view

## Related Command

`peer`

# peer sa-request-policy

---

**Purpose** Use the `peer sa-request-policy` command to limit the SA request messages the router receives from an MSDP peer.

Use the `undo peer sa-request-policy` command to remove the limitation.

**Syntax**

```
peer peer-address sa-request-policy [acl acl-number]
undo peer peer-address sa-request-policy
```

**Parameters**

|                     |                                                                                                                                                               |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>peer-address</i> | IP address of an MSDP peer, the SA request messages sent from which will be filtered.                                                                         |
| <i>acl-number</i>   | Basic IP ACL number, describing a multicast group address. Valid values are 2000 to 2999.<br>If no ACL is specified, all SA request messages will be ignored. |

**Default** By default, the router receives all SA request messages from the MSDP peer.

**Example** Configure an ACL so that SA request messages from the group address range of 225.1.1.0/24 and from the MSDP peer 175.58.6.5 are received while other SA messages are ignored.

```
<S5500> system-view
[S5500] acl number 2001
[S5500-acl-basic-2001] rule permit source 225.1.1.0 0.0.0.255
[S5500-acl-basic-2001] quit
[S5500] msdp
[S5500-msdp] peer 175.58.6.5 sa-request-policy acl 2001
```

**View** This command can be used in the following views:

- MSDP view

**Description** If no ACL is specified, all SA requests will be ignored. If an ACL is specified, only those SA request messages from the groups that match the ACL rule will be processed while others are ignored.

**Related Command** `peer`

# pim

---

**Purpose**

Use the `pim` to enter the PIM View.

Use the `undo pim` to clear the configurations in PIM View.

**Syntax**

`pim`

`undo pim`

**Parameters**

None

**Example**

Enable multicast and enter the PIM View.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]multicast routing-enable
[SW5500]pim
[SW5500-pim]
```

**View**

This command can be used in the following views:

- System view

**Description**

The global parameters of PIM can only be configured in PIM View.

# pim bsr-boundary

---

**Purpose** Use the `pim bsr-boundary` to configure an interface to be the PIM domain border.

Use the `undo pim bsr-boundary` to remove the border.

**Syntax**

```
pim bsr-boundary
undo pim bsr-boundary
```

**Parameters** None

**Default** By default, no domain border is set.

**Example** Configure domain border on VLAN-interface10.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Vlan-interface-10
[SW5500-vlan-interface10]pim bsr-boundary
```

**View** This command can be used in the following views:

- Interface view

**Description** You can use this command to set a border for bootstrap messages, that is to say, bootstrap messages cannot pass interfaces that are configured with the `pim bsr-boundary` command while other PIM messages can. In this way, the network is divided into different BSR domains.

It should be noted that this command cannot set up multicast boundaries. It only sets up a PIM domain bootstrap message border.

**Related Command** `c-bsr`

# pim dm

---

|                    |                                                                                                                                                                                                                                                         |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>     | <p>Use the <code>pim dm</code> to enable PIM-DM (Dense Mode).</p> <p>Use the <code>undo pim dm</code> to disable PIM-DM.</p>                                                                                                                            |
| <b>Syntax</b>      | <pre>pim dm undo pim dm</pre>                                                                                                                                                                                                                           |
| <b>Parameters</b>  | None                                                                                                                                                                                                                                                    |
| <b>Default</b>     | By default, PIM-DM is disabled.                                                                                                                                                                                                                         |
| <b>Example</b>     | <p>Enable PIM DM on VLAN-interface10 of the Ethernet Switch.</p> <pre>&lt;SW5500&gt;system-view System View: return to User View with Ctrl+Z [SW5500]multicast routing-enable [SW5500]interface Vlan-interface-10 [SW5500-vlan-interface10]pim dm</pre> |
| <b>View</b>        | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ Interface view</li></ul>                                                                                                                                |
| <b>Description</b> | Once PIM-DM is enabled on an interface, PIM-SM cannot be enabled on the same interface and vice versa.                                                                                                                                                  |

# pim neighbor-limit

---

## Purpose

Use the `pim neighbor-limit` command to limit the PIM neighbors on an interface. No neighbor can be added when the limit is reached.

Use the `undo pim neighbor-limit` command to restore the default setting.

## Syntax

```
pim neighbor-limit limit
```

```
undo pim neighbor-limit
```

## Parameters

*limit*

Limits of PIM neighbors on the interface. Valid values are 0 to 128.

## Default

By default, the PIM neighbors on the interface are limited to 128.

## Example

Limit the PIM neighbors on the Vlan-interface10 to 50.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]multicast routing-enable
[SW5500]interface Vlan-interface-10
[SW5500-Vlan-interface10]pim neighbor-limit 50
```

## View

This command can be used in the following views:

- VLAN Interface view

## Description

If the existing PIM neighbors exceed the configured value during configuration, they will not be deleted.

# pim neighbor-policy

---

**Purpose** Use the `pim neighbor-policy` command to filter the PIM neighbors on the current interface.

Use the `undo pim neighbor-policy` command to remove the filter.

**Syntax**

```
pim neighbor-policy acl-number
undo pim neighbor-policy
```

**Parameters** *acl-number* Basic ACL number, in the range of 1 to 99.

**Example** Configure that 10.10.1.2 can serve as a PIM neighbor of the Vlan-interface10, but not 10.10.1.1.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]multicast routing-enable
[SW5500]interface Vlan-interface-10
[SW5500-Vlan-interface10]pim neighbor-policy 2000
[SW5500-Vlan-interface10]quit
[SW5500]acl number 2000
[SW5500-acl-basic-2000]rule permit source 10.10.1.2 0
[SW5500-acl-basic-2000]rule deny source 10.10.1.1 0
```

**View** This command can be used in the following views:

- VLAN Interface view

**Description** Only the routers that match the filtering rule in the ACL can serve as a PIM neighbor of the current interface.

The new configuration overwrites the old one if you run the command for a second time.



# pim sm

---

**Purpose** Use the `pim sm` to enable the PIM-SM protocol on an interface.

Use the `undo pim sm` to disable the PIM-SM protocol.

## Syntax

```
pim sm
```

```
undo pim sm
```

## Parameters

None

## Default

By default, PIM-SM is disabled.

## Example

Enable PIM-SM on VLAN-interface10.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]multicast routing-enable
[SW5500]interface Vlan-interface-10
[SW5500-vlan-interface10]pim sm
```

## View

This command can be used in the following views:

- Interface view

## Description

Once PIM-SM is enabled on an interface, PIM-DM cannot be enabled on the same interface and vice versa.

# pim timer hello

---

## Purpose

Use the `pim timer hello` to configure the interval of sending PIM router Hello messages.

Use the `undo pim timer hello` to restore the default interval value.

## Syntax

```
pim timer hello seconds
```

```
undo pim timer hello
```

## Parameters

*seconds*

Interval of sending Hello messages in seconds. Valid values are 1 to 18000.  
If not specified, the default is 30 seconds.

## Example

Configure to transmit Hello packet via VLAN-interface10 every 40 seconds.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]multicast routing-enable
[SW5500]interface Vlan-interface-10
[SW5500-vlan-interface10]pim timer hello 40
```

## View

This command can be used in the following views:

- Interface view

# ping

---

## Purpose

Use the **ping** command to check the IP network connection and the reachability of the host.

## Syntax

```
ping [-a ip-address] [-c count] [-d] [-h t11][-i {interface-type
interface-num | interface-name }][ip] [-n] [-p pattern] [-q]
[-r] [-s packetsize] [-t timeout] [-tos tos] [-v] string
```

## Parameters

|                                                                                     |                                                                                                                                                         |
|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>-a</b> <i>ip-address</i>                                                         | Specifies the source IP address to transmit ICMP ECHO-REQUEST.                                                                                          |
| <b>-c</b> <i>count</i>                                                              | Specifies how many times the ICMP ECHO-REQUEST packet will be transmitted, ranging from 1 to 4294967295.                                                |
| <b>-d</b>                                                                           | Configures the socket to be in DEBUGGING mode.                                                                                                          |
| <b>-h</b> <i>t11</i>                                                                | Configures TTL value for echo requests to be sent, range from 1 to 255.                                                                                 |
| <b>-i</b><br><i>interface-type</i><br><i>interface-num</i><br><i>interface-name</i> | Configures to choose packet sent on the interface.<br>Specifies the interface type.<br>Specifies the interface number.<br>Specifies the interface name. |
| <b>ip</b>                                                                           | Chooses IP ICMP packet.                                                                                                                                 |
| <b>-n</b>                                                                           | Configures to take the host parameter as IP address without domain name resolution.                                                                     |
| <b>-p</b>                                                                           | <i>pattern</i> is the hexadecimal padding of ICMP ECHO-REQUEST, for example, -p ff pads the packet completely with ff.                                  |
| <b>-q</b>                                                                           | Configure not to display any other detailed information except statistics.                                                                              |
| <b>-r</b>                                                                           | Record route.                                                                                                                                           |
| <b>-s</b> <i>packetsize</i>                                                         | Specifies the length of ECHO-REQUEST (excluding IP and ICMP packet header) in bytes.                                                                    |
| <b>-t</b> <i>timeout</i>                                                            | Maximum waiting time after sending the ECHO-REQUEST (measured in ms).                                                                                   |
| <b>-tos</b> <i>tos</i>                                                              | Specifies TOS value for echo requests to be sent, range from 0 to 255.                                                                                  |
| <b>-v</b>                                                                           | Shows other received ICMP packets (non ECHO-RESPONSE).                                                                                                  |
| <i>string</i>                                                                       | Destination host domain name or IP address.                                                                                                             |

## Default

By default, when the parameters are not specified:

- The ECHO-REQUEST message will be sent for 5 times.
- The socket is not in DEBUGGING mode.
- The TTL value for echo requests is 255.
- The host will be treated as IP address first. If it is not an IP address, perform domain name resolution.
- The default padding operation starts from 0x01 and ends on 0x09 (progressively), then performs again.
- All information, including statistics, is shown.
- Routes are not recorded.
- The ECHO-REQUEST is sent according to route selection.
- The default length of ECHO-REQUEST is 56 bytes.
- The default timeout of ECHO-RESPONSE is 2000 ms.
- Other ICMP packets (non ECHO-RESPONSE) do not display.
- The TOS value of echo requests is 0.

## Example

Check whether the host 202.38.160.244 is reachable.

```
<SW5500>ping 202.38.160.244
ping 202.38.160.244 : 56 data bytes
Reply from 202.38.160.244 : bytes=56 sequence=1 ttl=255 time = 1ms
Reply from 202.38.160.244 : bytes=56 sequence=2 ttl=255 time = 2ms
Reply from 202.38.160.244 : bytes=56 sequence=3 ttl=255 time = 1ms
Reply from 202.38.160.244 : bytes=56 sequence=4 ttl=255 time = 3ms
Reply from 202.38.160.244 : bytes=56 sequence=5 ttl=255 time = 2ms
--202.38.160.244 ping statistics--
5 packets transmitted
5 packets received
0% packet loss
round-trip min/avg/max = 1/2/3 ms
```

## View

This command can be used in the following views:

- User view

## Description

The **ping** command sends ICMP ECHO-REQUEST message to the destination. If the network to the destination works well, then the destination host will send ICMP ECHO-REPLY to the source host after receiving ICMP ECHO-REQUEST.

Perform the **ping** command to troubleshoot the network connection and line quality. The output information includes:

- Responses to each of the ECHO-REQUEST messages. If the response message is not received until timeout, output "Request time out". Or display response message bytes, packet sequence number, TTL and response time.
- The final statistics, including number of sent packets, number of response packets received, percentage of non-response packets and minimal/maximum/average value of response time.

If the network transmission rate is too low to increase the response message timeout.

## Related Command

`remote-ping`

`tracert`

# pki

---

**Purpose** Use the **pki** command to specify PKI module configuration information.

**Syntax** `pki [ certificate | delete-certificate | domain | entity | import-certificate | request-certificate | retrieval-crl | validate-certificate ]`

|                   |                             |                                                 |
|-------------------|-----------------------------|-------------------------------------------------|
| <b>Parameters</b> | <b>certificate</b>          | Specifies certificate.                          |
|                   | <b>delete-certificate</b>   | Specifies delete PKI certificates.              |
|                   | <b>domain</b>               | Specifies PKI domain configuration information. |
|                   | <b>entity</b>               | Specifies the PKI entity configuration.         |
|                   | <b>import-certificate</b>   | Specifies import certificate.                   |
|                   | <b>request-certificate</b>  | Specifies request certificate.                  |
|                   | <b>retrieval-crl</b>        | Specifies retrieval CRL operations.             |
|                   | <b>validate-certificate</b> | Validates certificate operations.               |

**View** This command can be used in the following views:

- System view

# poe enable

---

**Purpose** Use the `poe enable` command to enable the PoE feature on a port.  
Use the `undo poe enable` command to disable the PoE feature on a port.

**Syntax** `poe enable`  
`undo poe enable`

**Parameters** None

**Default** By default, the PoE feature on each port is enabled.

**Example** Enable the PoE feature on the current port.

```
[SW5500-Ethernet1/0/3]poe enable
Port power supply is enabled
```

Disable the PoE feature on the current port.

```
[SW5500-Ethernet1/0/3]undo poe enable
Port power supply is disabled
```

**View** This command can be used in the following views:

- Ethernet Port view

# poe legacy enable

---

|                    |                                                                                                                                                                                                                                              |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>     | <p>Use the <code>poe legacy enable</code> command to enable the nonstandard-PD detect function.</p> <p>Use the <code>undo poe legacy enable</code> command to disable the nonstandard-PD detect function.</p>                                |
| <b>Syntax</b>      | <pre>poe legacy enable undo poe legacy enable</pre>                                                                                                                                                                                          |
| <b>Parameters</b>  | None                                                                                                                                                                                                                                         |
| <b>Default</b>     | By default, the nonstandard-PD detect function is disabled.                                                                                                                                                                                  |
| <b>Example</b>     | <p>Enable the nonstandard-PD detect function.</p> <pre>[SW5500]poe legacy enable Legacy detection is enabled</pre> <p>Disable the nonstandard-PD detect function.</p> <pre>[SW5500]undo poe legacy enable Legacy detection is disabled</pre> |
| <b>View</b>        | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ System view</li></ul>                                                                                                                        |
| <b>Description</b> | PDs compliant with 802.3af standards are called standard PDs.                                                                                                                                                                                |



# po e max power

---

## Purpose

Use the `po e max-power` command to configure the maximum power that can be supplied by current port.

Use the `undo po e max-power` command to restore the maximum power supplied by current port to the default value.

## Syntax

```
po e max-power max-power
```

```
undo po e max-power
```

## Parameters

`max-power`

Maximum power distributed to the port. Valid values are 1000 to 15400 mW.

## Default

By default, the maximum power that a port can supply is 15400 mW.

## Example

Set the maximum power supplied by current port.

```
[SW5500-Ethernet1/0/3]po e max-power 15000
Set Port max power successfully
```

Restore the default maximum power on the current port.

```
[SW5500-Ethernet1/0/3]undo po e max-power
Set Port max power successfully
```

## View

This command can be used in the following views:

- Ethernet Port view

## Description



*The unit of power is mW. You can set the power in the granularity of 100 mW. The actual maximum power will be 5% larger than what you have set allowing for the effect of transient peak power.*

# poe mode

---

## Purpose

Use the `poe mode` command to configure the PoE mode on the current port.

Use the `undo poe mode` command to restore the PoE mode on the current port to the default mode.

## Syntax

```
poe mode { signal | spare }
```

```
undo poe mode
```

## Parameters

**signal**

Supply power through the signal line.

**spare**

Supply power through the spare line. Currently, the Switch 5500 Family does not support spare mode. If the subordinate PD only supports the spare mode, a conversion is needed.

## Default

By default, the port is powered through the signal cable.

## Example

Set the PoE mode on current port to *signal*.

```
[SW5500-Ethernet1/0/3]poe mode signal
Set PoE mode successfully
```

## View

This command can be used in the following views:

- Ethernet Port view

# poe power-management

---

## Purpose

Use the `poe power-management` command to configure the PoE management mode of port used in the case of power overloading.

Use the `undo poe power-management` command to restore the default mode.

## Syntax

```
poe power-management { auto | manual }
```

```
undo poe power-management
```

## Parameters

`auto` Adopt the auto mode, a PoE management mode based on port priority.

`manual` Adopt the manual mode.

## Default

By default, the PoE management mode on port is `auto`.

## Example

Configure the PoE management mode on port to auto.

```
[SW5500]poe power-management auto
Auto Power Management is enabled
```

Restore the default management mode.

```
[SW5500]undo poe power-management
Auto Power Management is enabled
```

## View

This command can be used in the following views:

- System view

# poe priority

---

**Purpose** Use the `poe priority` command to configure the power supply priority on a port.  
Use the `undo poe priority` command to restore the default priority.

**Syntax**

```
poe priority { critical | high | low }
undo poe priority
```

**Parameters**

|                 |                                             |
|-----------------|---------------------------------------------|
| <i>critical</i> | Sets the port priority to <i>critical</i> . |
| <i>high</i>     | Sets the port priority to <i>high</i> .     |
| <i>low</i>      | Sets the port priority to <i>low</i> .      |

**Default** By default, the port priority is `low`.

**Example** Set the port priority to `critical`.

```
[SW5500-Ethernet1/0/3]poe priority critical
Set Port PSE priority successfully
```

Restore the default priority.

```
[SW5500-Ethernet1/0/3]undo poe priority
Set Port PSE priority successfully
```

**View** This command can be used in the following views:

- Ethernet Port view

**Description**



*If there are too many ports with critical priority, the total power these ports need might exceed the maximum power supplied by the equipment, that is, 300W. In this case, no new PD can be added to the switch.*

When the remaining power of the whole equipment is below 18.8 W, no new PD can be added to the Switch.

# poe-profile

---

## Purpose

Use the **poe-profile** command to create a PoE Profile.

Use the **undo poe-profile** command to delete an existing PoE Profile.

## Syntax

```
poe-profile profilename
```

```
undo poe-profile profilename
```

## Parameters

*profilename*

Name of PoE Profile, consisting of a string from 1 to 15 characters long, beginning with English letters (in upper- or lowercase letters), and cannot be reserved keywords like all, interface, user, undo, and mode.

## Example

Create a PoE Profile by the name of profile-test.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] poe-profile profile-test
```

## View

This command can be used in the following views:

- System view

## Description

The maximum number of PoE Profiles that can be configured for an SWITCH 5500 switch is 256.

# poe update

---

**Purpose** Use the `poe update` command to update the PSE processing software online

**Syntax** `poe update { refresh | full } filename`

**Parameters**

|                       |                                                                             |
|-----------------------|-----------------------------------------------------------------------------|
| <code>refresh</code>  | The refresh update mode is used when the PSE processing software is valid.  |
| <code>full</code>     | The full update mode is used when the PSE has no valid processing software. |
| <code>filename</code> | Update file name, with a length of 1 to 64 characters.                      |

**Example** Update the PSE processing software online.

```
[SW5500]poe update refresh 0290_021.s19
.....
.....
.....
.....
.....
.....
.....
.....
Update PoE board successfully
```

**View** This command can be used in the following views:

- System view

**Description** 

- Note:*
- The full mode is used only when you cannot use the `refresh` mode.
  - When the update procedure in `refresh` mode is interrupted for some unexpected reason (for example, power-off) or some errors occur, you can use the `full` mode to re-update.
  - When the PSE processing software is damaged (that is, all the PoE commands cannot be successfully executed), you can use the full mode to update and restore the software.

# port

---

## Purpose

Using the **port** command, you can add one port or one group of ports to a VLAN.

Using the **undo port** command, you can cancel one port or one group of ports from a VLAN.

## Syntax

```
port interface_list
```

```
undo port interface_list
```

## Parameters

*interface\_list*

List of Ethernet ports to be added to or deleted from a certain VLAN, expressed as *interface\_list*= {{ *interface\_type interface\_num* | *interface\_name* } [ to { *interface\_type interface\_num* | *interface\_name* } ] }&<1-10>.

*interface\_type* is the interface type, *interface\_num* is the interface number and *interface\_name* is the interface name. For their meanings and value range, see the parameter of Port in this document. The interface number after keyword to must be larger than or equal to the port number before to.

&<1-10>

Represents the repeatable times of parameters. A value of 1 is the minimum and 10 is the maximum.

## Example

Add Ethernet1/0/2 through Ethernet1/0/4 to VLAN 2.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]vlan 2
[SW5500-vlan2]port ethernet1/0/2 to ethernet1/0/4
```

## View

This command can be used in the following views:

- VLAN view

## Description



You can add/delete trunk port and hybrid ports to/from a VLAN by **port** and **undo port** commands in Ethernet Port View, but not in VLAN View.

## Related Command

**display vlan**

# port access vlan

---

**Purpose** Use the `port access vlan` command to assign the access port to a specified VLAN.

Use the `undo port access vlan` command to remove the access port from the VLAN.

**Syntax**

```
port access vlan vlan_id
undo port access vlan
```

**Parameters**

|                      |                                                                             |
|----------------------|-----------------------------------------------------------------------------|
| <code>vlan_id</code> | Specifies a VLAN ID. Valid values are 2 to 4094, as defined in IEEE 802.1Q. |
|----------------------|-----------------------------------------------------------------------------|

**Example** To assign Ethernet port 1/0/1 to VLAN3, enter the following.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]vlan 3
[SW5500-vlan3]quit
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]port access vlan 3
[SW5500-Ethernet1/0/1]
```

**View** This command can be used in the following views:

- Ethernet Port view



# port hybrid protocol-vlan vlan

---

## Purpose

Use the **port hybrid protocol-vlan vlan** command to deliver specified protocol VLANs to a port.

Use the **undo port hybrid protocol-vlan vlan** command to remove the associations between specified protocol-based VLANs and a port.

## Syntax

```
port hybrid protocol-vlan vlan vlan-id { protocol-index [to
protocol-end] | all }
```

```
undo port hybrid protocol-vlan vlan vlan-id { protocol-index [to
protocol-end] | all }
```

## Parameters

|                       |                                                                                                                    |
|-----------------------|--------------------------------------------------------------------------------------------------------------------|
| <i>vlan-id</i>        | Specifies a VLAN ID. Valid values are 1 to 4,094.                                                                  |
| <i>protocol-index</i> | Beginning protocol index. Valid values are 0 to 4 and must not be bigger than the end value of the protocol index. |
| <i>protocol-end</i>   | End protocol index. Valid values are 0 to 4 and must not be smaller than the start value of the protocol index.    |
| all                   | Specifies all protocols.                                                                                           |

## Example

Associate Ethernet1/0/1 port with protocols 0 through 4 of VLAN 3 (assuming that VLAN 3 is a protocol-based VLAN).

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface ethernet1/0/1
[S5500-Ethernet1/0/1] port hybrid protocol-vlan vlan 3 0 t
```

## View

This command can be used in the following views:

- Ethernet Port view

## Description



*You can only associate Hybrid ports with protocol-based VLANs at present. Before associate a port with a protocol-based VLAN, make sure the port belongs to the VLAN.*

## Related Command

**display protocol-vlan interface**

# port hybrid pvid vlan

---

|                        |                                                                                                                                                                                                                                                                                                                                                                                              |                |                                                                                                                    |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|--------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>         | <p>Use the <code>port hybrid pvid vlan</code> command to configure the default VLAN ID of the hybrid port.</p> <p>Use the <code>undo port hybrid pvid</code> command to restore the default VLAN ID of the hybrid port.</p>                                                                                                                                                                  |                |                                                                                                                    |
| <b>Syntax</b>          | <pre>port hybrid pvid vlan <i>vlan_id</i> undo port hybrid pvid</pre>                                                                                                                                                                                                                                                                                                                        |                |                                                                                                                    |
| <b>Parameters</b>      | <table><tr><td><i>vlan_id</i></td><td>Specifies a VLAN ID. Valid values are 2 to 4094, as defined in IEEE 802.1Q.<br/>If not specified, the default is 1.</td></tr></table>                                                                                                                                                                                                                  | <i>vlan_id</i> | Specifies a VLAN ID. Valid values are 2 to 4094, as defined in IEEE 802.1Q.<br>If not specified, the default is 1. |
| <i>vlan_id</i>         | Specifies a VLAN ID. Valid values are 2 to 4094, as defined in IEEE 802.1Q.<br>If not specified, the default is 1.                                                                                                                                                                                                                                                                           |                |                                                                                                                    |
| <b>Example</b>         | <p>To configure the default VLAN of the hybrid port Ethernet1/0/1 to VLAN100, enter the following.</p> <pre>&lt;SW5500&gt;system-view System View: return to User View with Ctrl+Z. [SW5500]interface ethernet 1/0/1 [SW5500-Ethernet1/0/1]port link-type hybrid [SW5500-Ethernet1/0/1]port hybrid pvid vlan 100 [SW5500-Ethernet1/0/1]</pre>                                                |                |                                                                                                                    |
| <b>View</b>            | <p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ Ethernet Port view</li></ul>                                                                                                                                                                                                                                                                 |                |                                                                                                                    |
| <b>Description</b>     | <p>Hybrid port can be configured together with the isolate-user-vlan. But if the default VLAN has set mapping in the isolate-user-vlan, the default VLAN ID cannot be modified. If you want to modify it, cancel the mapping first.</p> <p>The default VLAN ID of local hybrid port must be consistent with that of the peer one, otherwise, the packets cannot be properly transmitted.</p> |                |                                                                                                                    |
| <b>Related Command</b> | <pre>port link-type</pre>                                                                                                                                                                                                                                                                                                                                                                    |                |                                                                                                                    |

# port hybrid vlan

---

## Purpose

Use the `port hybrid vlan` command to add the port to the specified VLAN(s). The port needs to have been made a hybrid port before you can do this. See the related command below.

Use the `undo port hybrid vlan` command to remove the port from the specified VLAN(s).

## Syntax

```
port hybrid vlan vlan_id_list { tagged | untagged }
```

```
undo port hybrid vlan vlan_id_list
```

## Parameters

`vlan_id_list`

Specifies a VLAN ID, or more than one VLAN ID, in the range 2 to 4094. The hybrid port will be added to the specified VLANs. This can be a single VLAN, a series of individual VLANs separated by a space, or the first VLAN in a range of VLANs (*vlan\_id* to *last\_vlan\_id*).



*You can enter up to ten `vlan_id` parameters in one `port hybrid vlan` command.*

`tagged`

Specifies to tag the port for the specified VLAN.

`untagged`

Specifies to leave the port untagged for the specified VLAN.

## Example

To add the port Ethernet1/0/1 to VLAN 2, VLAN 4 and all VLANs in the range 50 to 100 as a tagged port, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]port link-type hybrid
[SW5500-Ethernet1/0/1]quit
[SW5500]vlan 2
[SW5500-vlan2]quit
[SW5500]interface e1/0/1
[SW5500-Ethernet1/0/1]port hybrid vlan 2 4 50 to 100 tagged
[SW5500-Ethernet1/0/1]
```

## View

This command can be used in the following views:

- Ethernet Port view

## Description

A hybrid port can belong to multiple VLANs. A port can only be added to a VLAN if the VLAN has already been created. See the `vlan vlan-vid` command.

## Related Command

`port link-type`

# port isolate

---

## Purpose

Use the `port isolate` command to add a port to an isolation group using the following commands, and achieves port-to-port isolation between this port and other ports of this group, that is, Layer 2 forwarding between the isolated ports is not available.

Use the `undo port isolate` command to remove a port from an isolation group.

## Syntax

```
port isolate
```

```
undo port isolate
```

## Parameters

None

## Default

By default, a port is not in an isolation group, namely Layer 2 forwarding is achievable between this port and other ports.

## Example

To add Ethernet1/0/1 and Ethernet1/0/2 to isolation group, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]port isolate
[SW5500-Ethernet1/0/1]quit
[SW5500]interface ethernet 1/0/2
[SW5500-Ethernet1/0/2]port isolate
```

## View

This command can be used in the following views:

- Ethernet Port view

# port link-aggregation group

---

## Purpose

Use the `port link-aggregation group agg_id` command to add an Ethernet port into a manual or static aggregation group.

Use the `undo port link-aggregation group` command to delete an Ethernet port from a manual or static aggregation group

## Syntax

```
port link-aggregation group agg_id
```

```
undo port link-aggregation group
```

## Parameters

*agg\_id* Aggregation group ID. Valid values are 1 to 416.

## Example

To add Ethernet1/0/1 into aggregation group 22, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]link-aggregation group 22 mode manual
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]port link-aggregation group 22
#Apr 2 03:29:48:954 2000 SW5500 LAGG/2/AggPortInactive:- 1 -Trap
1.3.6.1.4.1.2
011.5.25.25.2.2: TrapIndex 31465473 Aggregation Group 22: port member
Ethernet1/
0/1 becomes INACTIVE!
[SW5500-Ethernet1/0/1]
```

## View

This command can be used in the following views:

- Ethernet Port view

## Related Command

```
display link-aggregation verbose
```

# port link-type

---

**Purpose** Use the `port link-type` command to configure the link type of the Ethernet port.

Use the `undo port link-type` command to restore the port as default status.

**Syntax**

```
port link-type { access | hybrid | trunk | xrn-fabric }
undo port link-type
```

|                   |                         |                                                    |
|-------------------|-------------------------|----------------------------------------------------|
| <b>Parameters</b> | <code>access</code>     | Specifies to configure the port as an access port. |
|                   | <code>hybrid</code>     | Specifies to configure the port as a hybrid port   |
|                   | <code>trunk</code>      | Specifies to configure the port as a trunk port.   |
|                   | <code>xrn-fabric</code> | Specifies to configure the port as a Fabric port.  |

**Default** By default, a port is an access port.

**Example** To configure the Ethernet port Ethernet1/0/1 as a trunk port, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]port link-type trunk
[SW5500-Ethernet1/0/1]
```

**View** This command can be used in the following views:

- Ethernet Port view

## Description



*A port on a Switch can be configured as an access port, a hybrid port, a trunk port or a fabric port. However, to reconfigure between hybrid and trunk link types, you must first restore the default, or access, link type.*

*For a Switch 5500 28-port unit, Ethernet1/0/27 and Ethernet1/0/28 ports can be configured as fabric ports; For a Switch 5500 52-port unit, Ethernet1/0/51 and Ethernet1/0/52 ports can be configured as fabric ports, that is, they are used for stacking the Switch 5500.*

# port-security enable

---

## Purpose

Use the **port-security enable** command to enable port security.

Use the **undo port-security enable** command to disable port security.

## Syntax

```
port-security enable
undo port-security enable
```

## Parameters

None

## Default

By default, port security is disabled.

## Example

Enter system view.

```
<S5500> system-view
```

Enable port security.

```
[S5500] port-security enable
```

Notice: the port-control of 802.1x will be restricted to auto when port-security enabled.

Please wait... Done.

## View

This command can be used in the following views:

- System view

## Description



**CAUTION:** To avoid confliction, the following limitation on the 802.1x and the MAC address authentication will be taken after port security is enabled:

- The access control mode (set by the dot1x port-control command) automatically changes to auto.
- The dot1x port-method command can be successfully executed only when no user is online.
- The dot1x, dot1x port-method, dot1x port-control and mac-authentication commands cannot be used.

# port-security intrusion-mode

---

**Purpose** Use the `port-security intrusion-mode` command to set the action mode of the Intrusion Protection feature.

Use the `undo port-security intrusion-mode` command to cancel the set action mode.

**Syntax**

```
port-security intrusion-mode { disableport | disableport-temporarily |
blockmac }
```

```
undo port-security intrusion-mode
```

**Parameters**

|                                      |                                                                                                            |
|--------------------------------------|------------------------------------------------------------------------------------------------------------|
| <code>disableport</code>             | Represents permanently disabling the port and sending trap message.                                        |
| <code>disableport-temporarily</code> | Represents temporarily disabling the port, re-enabling the port after 20 seconds and sending trap message. |
| <code>blockmac</code>                | Represents discarding the packets with illegal source MAC addresses, and sending trap messages.            |

**Default** By default, no action mode is set.

**Example**

Enter system view.

```
<S5500> system-view
```

Enable port security.

```
[S5500] port-security enable
```

Enter Ethernet1/0/1 port view.

```
[S5500] interface ethernet1/0/1
```

Set the action mode of the Intrusion Protection feature on Ethernet1/0/1 port to disableport.

```
[S5500-Ethernet1/0/1] port-security intrusion-mode disableport
```

**View** This command can be used in the following views:

- Ethernet Port view

## Description



*By way of checking the source MAC addresses of the data frames received on a port, the Intrusion Protection feature discovers illegal packets and takes appropriate action (temporarily/permanently disabling the port, or filtering out the packets with these source MAC addresses) to guarantees the security on the port.*



*The illegal packets include:*

- *Packets with unknown source MAC addresses received when MAC address learning is disabled on the port*
- *Packets with unknown source MAC addresses received when the number of MAC addresses on the port has reached the set maximum number of MAC addresses allowed to access the port.*
- *Packets received from users who fail the authentication.*

The action mode of the Intrusion Protection feature can be set to **disableport**, **disableport-temporarily** or **blockmac**. For the **disableport-temporarily** mode, you can set the time during which the system temporarily disables a port by using the **port-security timer disableport** command.

## Related Command

**port-security timer disableport**

# port-security max-mac-count

---

## Purpose

Use the **port-security max-mac-count** command to set the maximum number of MAC addresses allowed to access the port.

Use the **undo port-security max-mac-count** command to cancel this limit.

## Syntax

```
port-security max-mac-count count-value
```

```
undo port-security max-mac-count
```

## Parameters

*count-value*

Maximum number of MAC addresses. This argument is 0 by default, which represents there is no limit on the number of MAC addresses.

## Default

By default, there is no limit on the number of MAC addresses allowed to access the port.

## Example

Enter system view

```
<S5500> system-view
```

Enable port security.

```
[S5500] port-security enable
```

Enter ethernet1/0/1 port view.

```
[S5500] interface ethernet1/0/1
```

Set the maximum number of MAC addresses allowed to access the port to 100.

```
[S5500-Ethernet1/0/1] port-security max-mac-count 100
```

## View

This command can be used in the following views:

- Ethernet Port view

## Description



**CAUTION:** The maximum number of MAC addresses set by this command does not include the number of the static MAC address entries set manually.

## Related Commands

- **port-security enable**
- **port-security port-mode**

# port-security ntk-mode

---

## Purpose

Use the **port-security ntk-mode** command to set the packet transmission mode of the Need to Know (NTK) feature.

Use the **undo port-security ntk-mode** command to cancel the setting.

## Syntax

```
port-security ntk-mode { ntkonly | ntk-withbroadcasts |
ntk-withmulticasts }
```

```
undo port-security ntk-mode
```

## Parameters

|                           |                                                                                                                                                           |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>ntkonly</b>            | Allows the system to transmit only unicast packets with successfully authenticated destination MAC addresses.                                             |
| <b>ntk-withbroadcasts</b> | Allows the system to transmit the broadcast packets and the unicast packets with successfully authenticated destination MAC addresses.                    |
| <b>ntk-withmulticasts</b> | Allows the system to transmit the multicast packets, broadcast packets and the unicast packets with successfully authenticated destination MAC addresses. |

## Default

By default, no packet transmission mode of the NTK feature is set on the port.

## Example

Enter system view.

```
<S5500> system-view
```

Enable port security.

```
[S5500] port-security enable
```

Enter ethernet1/0/1 port view.

```
[S5500] interface ethernet1/0/1
```

Set the packet transmission mode of the NTK feature to ntkonly on the current port.

```
[S5500-Ethernet1/0/1] port-security ntk-mode ntkonly
```

## View

This command can be used in the following views:

- Ethernet Port view

## Description



*By way of checking the destination MAC addresses of the data frames to be sent from a port, this feature ensures that only successfully authenticated devices can*

*obtain data frames from the port so as to prevent illegal devices from filching network data.*

The packet transmission mode of the NTK feature can be set to ***ntkonly***, ***ntk-withbroadcasts*** or ***ntk-withmulticasts***.



**CAUTION:** *The port-security ntk-mode command and the unknown-multicast drop enable command (which enables the unknown multicast packet drop function), cannot be used together. Or else, the system prompts a failure.*

# port-security OUI

---

**Purpose** Use the `port-security OUI command` to set an OUI value for authentication.  
Use the `undo port-security OUI` command to cancel an OUI value setting.

**Syntax**

```
port-security OUI OUI-value index index-value
undo port-security OUI index id-value
```

**Parameters**

|                    |                                                                                                                                                 |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>OUI-value</i>   | OUI value. You can input a complete MAC address (in hexadecimal) for this argument and the system will calculate the OUI value from your input. |
| <i>index-value</i> | OUI index. Valid values are 1 to 16.                                                                                                            |



*The organizationally unique identifiers (OUIs) are assigned by IEEE to different equipment providers. Each OUI uniquely identifies an equipment provider in the world and is the higher 24 bits of MAC address.*

*You need only to input a complete hexadecimal MAC address in this command, and the system will automatically convert the address to binary format and then take the higher 24 bits of the resulting binary data as the OUI value.*

**Example** Enter system view.


```
<S5500> system-view
```

Set an OUI value by specifying the MAC address 00ef-ec00-0000, and set the OUI index to five.

```
[S5500] port-security oui 00ef-ec00-0000 index 5
```

**View** This command can be used in the following views:

- System view

**Description**  **CAUTION:** *The OUI value set by this command takes effect only when the security mode of the port is set to userlogin-withoui (by the port-security port-mode command).*

**Related Command** `port-security port-mode`

# port-security port-mode

---

- Purpose** Use the `port-security port-mode` command to set the security mode of the port.
- Use the `undo port-security port-mode` command to restore the normal operating mode of the port.
- Syntax**
- ```
port-security port-mode mode
undo port-security port-mode
```
- Parameters**
- mode* Security mode of the port. See Table 95 for the values of this argument.
- Default** By default, no security mode is set on the port.
- Example**
- Enter system view.
- ```
<S5500> system-view
```
- Enable port security.
- ```
[S5500] port-security enable
```
- Enter ethernet1/0/1 port view.
- ```
[S5500] interface ethernet1/0/1
```
- Set the security mode on Ethernet1/0/1 port to userlogin.
- ```
[S5500-Ethernet1/0/1] port-security port-mode userlogin
```
- View** This command can be used in the following views:
- Ethernet Port view
- Description** Table 95 describes the available security modes in details:

Table 95 Description of the port security modes

Security mode	Description	Feature
autolearn	This security mode will automatically change to the secure mode after the system has learned a certain number of MAC addresses from this port; at the same time, the learned MAC addresses will be changed to static MAC addresses.	In this mode, only the NTK and Intrusion Protection features take effect.

Table 95 Description of the port security modes (continued)

Security mode	Description	Feature
secure	In this mode, the system is disabled from learning MAC addresses from this port.	In this mode, the NTK and Intrusion Protection features do not take effect.
userlogin	In this mode, 802.1x authentication is performed for access users.	In this mode, the NTK and Intrusion Protection features do not take effect.
userlogin-secure	The port opens only after the access user passes the 802.1x authentication. Even after the port opens, only the packets of the successfully authenticated user can pass through the port.	In this mode, the NTK and Intrusion Protection features do not take effect.
In this mode, only one 802.1x-authenticated user is allowed to access the port.	In these modes, only the NTK and Intrusion Protection features take effect.	In this mode, the NTK and Intrusion Protection features do not take effect.
When the port changes from the normal mode to this security mode, the system automatically removes the already existing dynamic MAC address entries and authenticated MAC address entries on the port.	In these modes, only the NTK and Intrusion Protection features take effect.	In this mode, the NTK and Intrusion Protection features do not take effect.
userlogin-withoui	This mode is similar to the userlogin-secure mode, except that there can be one OUI-carried MAC address being successfully authenticated in addition to the single 802.1x-authenticated user who is allowed to access the port.	In this mode, the NTK and Intrusion Protection features do not take effect.
When the port changes from the normal mode to this security mode, the system automatically removes the already existing dynamic/authenticated MAC address entries on the port.	This mode is similar to the userlogin-secure mode, except that there can be one OUI-carried MAC address being successfully authenticated in addition to the single 802.1x-authenticated user who is allowed to access the port.	In this mode, the NTK and Intrusion Protection features do not take effect.
mac-authentication	In this mode, MAC address-based authentication is performed for access users.	In this mode, the NTK and Intrusion Protection features do not take effect.
userlogin-secure-or-mac	In this mode, the two kinds of authentication in mac-authentication and userlogin-secure modes can be performed simultaneously. If both kinds of authentication succeed, the userlogin-secure mode takes precedence over the mac-authentication mode.	In this mode, the NTK and Intrusion Protection features do not take effect.
userlogin-secure-else-mac	In this mode, first the MAC-based authentication is performed. If this authentication succeeds, the mac-authentication mode is adopted, or else, the authentication in userlogin-secure mode is performed.	In this mode, the NTK and Intrusion Protection features do not take effect.
userlogin-secure-ext	This mode is similar to the userlogin-secure mode, except that there can be more than one 802.1x-authenticated user on the port.	In this mode, the NTK and Intrusion Protection features do not take effect.

Table 95 Description of the port security modes (continued)

Security mode	Description	Feature
userlogin-secure-or-mac-ext	This mode is similar to the userlogin-secure-or-mac mode, except that there can be more than one 802.1x-authenticated user on the port.	
userlogin-secure-else-mac-ext	This mode is similar to the userlogin-secure-else-mac mode, except that there can be more than one 802.1x-authenticated user on the port.	

port-security timer disableport

Purpose

Use the `port-security timer disableport` command to set the time during which the system temporarily disables a port.

Use `undo port-security timer disableport` command restore the default time.

Syntax

```
port-security timer disableport timer
```

```
undo port-security timer disableport
```

Parameters

timer

Valid values for this argument are 20 to 300.
If not specified, the default is 20 seconds.

Example

Set the time during which the system temporarily disables a port to 50 seconds.

```
<S5500> system-view  
[S5500] port-security timer disableport 50
```

View

This command can be used in the following views:

- System view

Description



The time set by the port-security timer disableport command takes effect when the disableport-temporarily mode is set by the port-security intrusion-mode command.

port-security trap

Purpose

Use the **port-security trap** command to enable the sending of the specified type(s) of trap messages.

Use the **undo port-security trap** command to disable the sending of the specified type(s) of trap messages.

Syntax

```
port-security trap { addresslearned | intrusion | dot1xlogon |
dot1xlogoff | dot1xlogfailure | ralmlogon | ralmlogoff | ralmlogfailure
}*

```

```
undo port-security trap { addresslearned | intrusion | dot1xlogon |
dot1xlogoff | dot1xlogfailure | ralmlogon | ralmlogoff | ralmlogfailure
}*

```

Parameters

addresslearned	Enables/disables the sending of MAC address learning trap messages.
intrusion	Enables/disables the sending of intrusion packet discovery trap messages.
dot1xlogon	Enables/disables the sending of 802.1x user logon trap messages.
dot1xlogoff	Enables/disables the sending of 802.1x user logoff trap messages.
dot1xlogfailure	Enables/disables the sending of 802.1x user authentication failure trap messages.
ralmlogon	Enables/disables the sending of RALM user logon trap messages.
ralmlogoff	Enables/disables the sending of RALM user logoff trap messages.
ralmlogfailure	Enables/disables the sending of RALM user authentication failure trap messages.



RADIUS authenticated login using MAC-address (RALM) refers to MAC address-based RADIUS authentication.

Default

By default, the system disables the sending of any types of trap messages.

Example

Enter system view.

```
<S5500> system-view
```

Allow the sending of the intrusion packet discovery trap messages.

```
[S5500] port-security trap intrusion
```

View

This command can be used in the following views:

- System view

Description



This command is designed based on the Device Tracking feature. The Device Tracking feature enables the switch to send trap messages in case special data packets (generated by special actions such as illegal intrusion, and abnormal user logon/logoff) pass through a port for the convenience of network administrator to monitor these special actions.

port-tagged

Purpose

Use the **port-tagged** command to configure VLAN check on the management device for the communication inside a cluster.

Use the **undo port-tagged** command to cancel VLAN check on the management device for the communication inside a cluster.

Syntax

```
port-tagged management-vlan
```

```
undo port-tagged
```

Parameters

None

Default

By default, VLAN check is performed.

Example

Configure VLAN check for the communication inside a cluster.

```
<aaa_0.S5500>system-view
System View: return to User View with Ctrl+Z.
[aaa_0.S5500]cluster
[aaa_0.S5500-cluster] port-tagged management-vlan
```

View

This command can be used in the following views:

- Cluster view

Description

Cluster packets are often forwarded inside the management VLAN only. Any configuration error (for example, the member port connected to the management device is set as a port outside the management VLAN) will cause communication failure between the management and member devices. To avoid such problem, you can configure VLAN check on the management device. This enables member devices to automatically add the connection port into the management VLAN, thus guarantees normal communication between the management and member devices.

port trunk permit vlan

Purpose

Use the `port trunk permit vlan` command to add a trunk port to one VLAN, a selection of VLANs or all VLANs.

Use the `undo port trunk permit vlan` command to remove a trunk port from one VLAN, a selection of VLANs or all VLANs.

Syntax

```
port trunk permit vlan {vlan_id_list | all}
undo port trunk permit vlan {vlan_id_list | all}
```

Parameters

`vlan_id`

Specifies a VLAN ID, or more than one VLAN ID. Valid values are 2 to 4094. The trunk port will be added to the specified VLANs. This can be a single VLAN, a series of individual VLANs separated by a space, or the first VLAN in a range of VLANs. If this is the first VLAN in a range use the `last_vlan_id` parameter to indicate the last VLAN in the range (`vlan_id` to `last_vlan_id`).



You can enter up to ten `vlan_id` parameters at one `port trunk permit vlan` command.

`all`

Adds the trunk port to all VLANs.

Example

To add the trunk port Ethernet1/0/1 to VLAN 2, VLAN 4 and all VLANs in the range 50-100, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface ethernet 1/0/1
[SW5500-Ethernet1/0/1]port link-type trunk
[SW5500-Ethernet1/0/1]port trunk permit vlan 2 4 50 to 100
Please wait... Done.
[SW5500-Ethernet1/0/1]
```

View

This command can be used in the following views:

- Ethernet Port view

Description

A trunk port can belong to multiple VLANs. If the `port trunk permit vlan` command is used many times, then the VLAN enabled to pass on trunk port is the set of these `vlan_id_list`.

Related Command

`port link-type`

port trunk pvid vlan

Purpose	<p>Use the <code>port trunk pvid vlan</code> command to configure the default VLAN ID for a trunk port.</p> <p>Use the <code>undo port trunk pvid</code> command to restore the default VLAN ID for a trunk port.</p>		
Syntax	<pre>port trunk pvid vlan <i>vlan_id</i> undo port trunk pvid</pre>		
Parameters	<table><tr><td><i>vlan_id</i></td><td>Specifies a VLAN ID. Valid values are 2 to 4094, as defined in IEEE802.1Q. This is the VLAN that you want to be the default VLAN for a trunk port. If not specified, the default is 1.</td></tr></table>	<i>vlan_id</i>	Specifies a VLAN ID. Valid values are 2 to 4094, as defined in IEEE802.1Q. This is the VLAN that you want to be the default VLAN for a trunk port. If not specified, the default is 1.
<i>vlan_id</i>	Specifies a VLAN ID. Valid values are 2 to 4094, as defined in IEEE802.1Q. This is the VLAN that you want to be the default VLAN for a trunk port. If not specified, the default is 1.		
Default	The default VLAN ID of local trunk port should be consistent with that of the peer one, otherwise packets cannot be properly transmitted.		
Example	<p>To configure the trunk port Ethernet1/0/1 to the default VLAN of 100, enter the following:</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]interface ethernet 1/0/1 [SW5500-Ethernet1/0/1]port link-type trunk [SW5500-Ethernet1/0/1]port trunk pvid vlan 100 [SW5500-Ethernet1/0/1]</pre>		
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ Ethernet Port view		
Related Command	<code>port link-type</code>		

preference

Purpose

Using the **preference** command, you can configure the OSPF protocol route preference.

Using the **undo preference** command, you can restore the default value of the OSPF protocol route.

Syntax

```
preference [ ase ] value
```

```
undo preference [ ase ]
```

Parameters

value	Specifies the OSPF protocol route preference. Valid values are 1 to 255.
ase	Indicates the preference of an imported external route of the AS.

Default

By default, the preference of an OSPF protocol internal route is 10 and the preference of an external route is 150.

Example

To set the preference of an imported external route of the AS to 160, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]router id 1.1.1.1  
[SW5500]ospf  
[SW5500-ospf-1]preference ase 160
```

View

This command can be used in the following views:

- OSPF view

Description

Because multiple dynamic routing protocols could be running on a router at any one time, priority needs to be assigned to each protocol. Using this command, you can set a default preference for each routing protocol. The protocol with the higher preference has priority.

preference

Purpose	Use the preference command to configure the route preference of RIP. Use the undo preference command to restore the default preference.
Syntax	preference value undo preference
Parameters	value Specifies the preference level. Valid values are 1 to 255. If not specified, the value is 100.
Default	The default value of each routing protocol is determined by the specific routing policy. This “preference” determines the optimal route in the IP routing table. You can use this command to modify the RIP preference.
Example	To specify an RIP preference of 20, enter the following: <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]rip [SW5500-rip]preference 20</pre>
View	This command can be used in the following views: ■ RIP view

primary accounting

Purpose

Use the **primary accounting** command to configure a primary TACACS accounting server.

Use the **undo primary accounting** command to delete the configured primary TACACS accounting server.

Syntax

```
primary accounting ip-address [ port ]
```

```
undo primary accounting
```

Parameters

ip-address IP address of the server, a valid unicast address in dotted decimal format.

port Port number of the server. Valid values are 1 to 65535. If not specified, the default is 49.

Example

Configure a primary accounting server.

```
[S5500] hwtacacs scheme test1  
[S5500-hwtacacs-test1] primary accounting 10.163.155.12 49
```

View

This command can be used in the following views:

- HWTACACS view

Description

You are not allowed to assign the same IP address to both primary and secondary accounting servers.

You can configure only one primary accounting server in a HWTACACS scheme. If you repeatedly use this command, the latest configuration replaces the previous one.

You can remove an accounting server only when it is not being used by any active TCP connections, and the removal impacts only packets forwarded afterwards.

primary authentication

Purpose

Use the **primary authentication** command to configure a primary TACACS authentication server.

Use the **undo primary authentication** command to delete the configured authentication server.

Syntax

```
primary authentication ip-address [ port ]
```

```
undo primary authentication
```

Parameters

<i>ip-address</i>	IP address of the server, a valid unicast address in dotted decimal format.
<i>port</i>	Port number of the server. Valid values are 1 to 65535. If not specified, the default is 49.

Example

Configure a primary authentication server.

```
[S5500] hwtacacs scheme test1  
[S5500-hwtacacs-test1] primary authentication 10.163.155.13 49
```

View

This command can be used in the following views:

- HWTACACS view

Description

You are not allowed to assign the same IP address to both primary and secondary authentication servers.

You can configure only one primary authentication server in a HWTACACS scheme. If you repeatedly use this command, the latest configuration replaces the previous one.

You can remove an authentication server only when it is not being used by any active TCP connections, and the removal impacts only packets forwarded afterwards.

Related Command

```
display hwtacacs
```

primary authorization

Purpose

Use the **primary authorization** command to configure a primary TACACS authorization server.

Use the **undo primary authorization** command to delete the configured primary authorization server.

Syntax

```
primary authorization ip-address [ port ]
```

```
undo primary authorization
```

Parameters

ip-address

IP address of the server, a valid unicast address in dotted decimal format.

port

Port number of the server. Valid values are 1 to 65535. If not specified, the default is 49.

Example

Configure a primary authorization server.

```
[S5500] hwtacacs scheme test1  
[S5500-hwtacacs-test1] primary authorization 10.163.155.13 49
```

View

This command can be used in the following views:

- HWTACACS view

Description

You are not allowed to assign the same IP address to both primary and secondary authorization servers.

You can configure only one primary authorization server in a HWTACACS scheme. If you repeatedly use this command, the latest configuration replaces the previous one.

You can remove an authorization server only when it is not being used by any active TCP connections, and the removal impacts only packets forwarded afterwards.

Related Command

```
display hwtacacs
```

priority

Purpose

Use the **priority** command to configure the priority of Ethernet port.

Use the **undo priority** command to restore the default port priority.

Syntax

```
priority priority-level
```

```
undo priority
```

Parameters

priority-level

Specifies the priority level of the port. Valid values are 0 to 7.

If not specified, the default priority level of the port is 0.

Example

Set the priority of Ethernet1/0/1 port to 7.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]interface Ethernet 1/0/1  
[SW5500-Ethernet1/0/1]priority 7  
[SW5500-Ethernet1/0/1]
```

View

This command can be used in the following views:

- Ethernet Port view

Description

The Switch replaces the 802.1p priority carried by a packet with the port priority that is defined.

Every port on the Switch supports eight packet egress queues. The Switch puts the packets into different egress queues according to their priorities.

When transmitting a packet, the Switch replaces the packet's 802.1p priority with the priority of the received port, according to which the packet will be put into the corresponding egress queue.

priority trust

Purpose

Use the **priority trust** command to configure the system to trust the packet's 802.1p priority and not replace the 802.1p priorities carried by the packets with the port priority.

Use **undo priority** command to configure the system not to trust the packet 802.1p priority.

Syntax

```
priority trust
```

```
undo priority
```

Parameters

None

Default

By default, the system replaces the 802.1p priority carried by a packet with the port priority.

Example

Configure the system to trust the packet 802.1p priority and not replace the 802.1p priorities carried by the packets with the port priority.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]interface Ethernet 1/0/1  
[SW5500-Ethernet1/0/1]priority trust  
[SW5500-Ethernet1/0/1]
```

View

This command can be used in the following views:

- Ethernet Port view

Related Command

```
priority
```

protocol inbound

Purpose Use the `protocol inbound` command to configure the protocols supported in the current user interface.

Syntax `protocol inbound { all | ssh | telnet }`

Parameters

<code>all</code>	Supports all protocols, including Telnet and SSH.
<code>ssh</code>	Supports only SSH.
<code>telnet</code>	Supports only Telnet.

Default By default, both SSH and Telnet are supported.

Example Configure vty0 through vty4 to support SSH only.

```
<S5500> system-view
[S5500] user-interface vty 0 4
[S5500-ui-vty0-4] protocol inbound ssh
```

View This command can be used in the following views:

- VTY User Interface view

Description After you use this command with SSH enabled, your configuration cannot take effect till next login if no RSA key pair is configured.



CAUTION:

- When SSH protocol is specified, to ensure a successful login, you must configure the AAA authentication using the `authentication-mode scheme` command.
- The `protocol inbound ssh` configuration fails if you configured `authentication-mode password` and `authentication-mode none`. When you configured SSH protocol successfully for the user interface, then you cannot configure authentication-mode password and authentication-mode none any more.

protocol-priority protocol-type

Purpose

Use the **protocol-priority** command to set the global traffic priority that applies to a given protocol.

Use the **undo protocol-priority** command to remove such a configuration.

Syntax

```
protocol-priority protocol-type protocol-type { ip-precedence  
ip-precedence | dscp dscp-value }
```

```
undo protocol-priority protocol-type protocol-type
```

Parameters

protocol-type
protocol-type

Represents the protocol type, currently only supports OSPF, TELNET, SNMP, ICMP (to be input in the form of strings in the command line).

ip-precedence
ip-precedence

IP priority. Valid values are 0 to 7.

dscp dscp-value

DSCP priority. Valid values are 0 to 63.

Example

Set the IP priority of OSPF protocol to be 3.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] protocol-priority protocol-type OSPF ip-precedence 3
```

View

This command can be used in the following views:

- System view

protocol-vlan

Purpose

Use the **protocol-vlan** command to specify a VLAN is a specified type of protocol-based VLAN.

Use the **undo protocol-vlan** command to cancel the configuration.

Syntax

```
protocol-vlan [ protocol-index ] { at | ip | ipx { ethernetii | llc | raw | snap } | mode { ethernetii etype etype-id | llc { dsap dsap-id [ ssap ssap-id ] | ssap ssap-id } | snap etype etype-id }
```

```
undo protocol-vlan { protocol-index [ to protocol-end ] | all }
```

Parameters

at	Specifies the VLAN is an AT-based VLAN. (AT stands for AppleTalk.)
ip	Specifies the VLAN is an IP-based VLAN.
ipx	Specifies the VLAN is an IPX-based VLAN. The <i>ethernetii</i> , <i>llc</i> , <i>raw</i> and <i>snap</i> keywords specify the four IPX encapsulation types.
mode	Specifies the VLAN is based on other protocols.
ethernetii	Specifies the VLAN is an EthernetII-based VLAN.
etype-id	The Ethernet type of the inbound packets. Valid values for this argument are from 600 to FFFF.
llc	Specifies the VLAN is based on logic link control protocols.
dsap-id	Destination service access point. Valid values for this argument are from 0 to FF.
ssap-id	Source service access point. Valid values for this argument are from 0 to FF.
snap	Specifies that the VLAN is a SNAP-based VLAN. (SNAP is short for sub-network access protocol.)
etype-id	The Ethernet type of inbound packets. Valid values for this argument are from 600 to FFFF.
protocol-index	Beginning protocol index. Valid values are from 0 to 4. This argument needs to be less than or equal to the end protocol index. If you do not specify this argument, the beginning protocol index will be determined by the system.
protocol-end	End protocol index. Valid values are from 0 to 4. This argument needs to be larger than or equal to the protocol-index argument.
all	Specifies all protocol indexes.

Example

Specify VLAN3 is an IP-based VLAN.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] vlan 3
[S5500-vlan3] protocol-vlan ip
```

View

This command can be used in the following views:

- VLAN view

Related Command

display protocol-vlan vlan

public-key-code begin

Purpose Use the **public-key-code begin** command to enter public key edit view and input the client public key.

Syntax `public-key-code begin`

Parameters None

Example Enter public key edit view and input client public keys.

```
<S5500> system-view
[S5500] rsa peer-public-key 3Com003
[S5500-rsa-public-key] public-key-code begin
[S5500-key-code] 308186028180739A291ABDA704F5D93DC8FDF84C427463
[S5500-key-code] 1991C164B0DF178C55FA833591C7D47D5381D09CE82913
[S5500-key-code] D7EDF9C08511D83CA4ED2B30B809808EB0D1F52D045DE4
[S5500-key-code] 0861B74A0E135523CCD74CAC61F8E58C452B2F3F2DA0DC
[S5500-key-code] C48E3306367FE187BDD944018B3B69F3CBB0A573202C16
[S5500-key-code] BB2FC1ACF3EC8F828D55A36F1CDDC4BB45504F020125
[S5500-key-code] public-key-code end
[S5500-rsa-public-key]
```

View This command can be used in the following views:

- Public Key Edit view

Description You can key in a blank space between characters (since the system can remove the blank space automatically), or press <Enter> to continue your input at the next line. But the public key, which is generated randomly by the SSH 2.0-supported client software, should be composed of hexadecimal characters.

Related Commands

- `public-key-code end`
- `rsa peer-public-key`

public-key-code begin

Purpose Use the **public-key-code begin** command to enter public key edit view and set server public keys.

Syntax `public-key-code begin`

Parameters None

Example Enter public key edit view and set server public keys.

```
<S5500> system-view
[S5500] rsa peer-public-key 3Com003
[S5500-rsa-public-key] public-key-code begin
[S5500-key-code] 308186028180739A291ABDA704F5D93DC8FDF84C427463
[S5500-key-code] 1991C164B0DF178C55FA833591C7D47D5381D09CE82913
[S5500-key-code] D7EDF9C08511D83CA4ED2B30B809808EB0D1F52D045DE4
[S5500-key-code] 0861B74A0E135523CCD74CAC61F8E58C452B2F3F2DA0DC
[S5500-key-code] C48E3306367FE187BDD944018B3B69F3CBB0A573202C16
[S5500-key-code] BB2FC1ACF3EC8F828D55A36F1CDDC4BB45504F020125
[S5500-key-code] public-key-code end
[S5500-rsa-public-key]
```

View This command can be used in the following views:

- Public Key Edit view

Description You can key in a blank space between characters (since the system can remove the blank space automatically), or press <Enter> to continue your input at the next line. But the public key, which are generated randomly after you use the **rsa local-key-pair create** command on the server, should be composed of hexadecimal characters.

Related Commands

- `public-key-code end`
- `rsa local-key-pair create`
- `rsa peer-public-key`

public-key-code end

Purpose	Use the public-key-code end command to return from public key edit view to public key view and save the public keys you set.
Syntax	<code>public-key-code end</code>
Parameters	None
Example	Exit from public key edit view and save the public keys. <pre><S5500> system-view [S5500]rsa peer-public-key zhangshan [S5500-rsa-public-key]public-key-code begin [S5500-rsa-key-code] public-key-code end [S5500-rsa-public-key]</pre>
View	This command can be used in the following views: <ul style="list-style-type: none">■ Public Key Edit view
Description	After you use this command to terminate the public key editing, public key validity will be checked before the keys are saved. If there are illegal characters in the keys, the prompt will be given and the keys will be discarded. Your configuration this time fails. If the keys are valid, they will be saved in the public key list of the client.
Related Command	<ul style="list-style-type: none">■ <code>public-key-code begin</code>■ <code>rsa peer-public-key</code>

put

Purpose

Use the **put** command to upload a local file to the remote SFTP server.

If no name is specified for the file to be saved on the remote SFTP server, the name of the source file is used.

Syntax

```
put local-file [ remote-file ]
```

Parameters

<i>local-file</i>	Name of the source file at the local end.
<i>remote-file</i>	Name assigned to the file to be saved on the remote SFTP server.

Example

Upload local file temp.c to the remote SFTP server and save it with the name temp1.c.

```
sftp-client> put temp.c temp1.c
```

View

This command can be used in the following views:

- SFTP Client view

pwd

Purpose Use the **pwd** command to display the current directory on the SFTP server.

Syntax `pwd`

Parameters None

Example Display the current directory on the SFTP server.

```
sftp-client> pwd  
flash:/
```

View This command can be used in the following views:

- SFTP Client view

queue-scheduler

Purpose

Use the `queue-scheduler` command to configure queue scheduling mode.

Use the `undo queue-scheduler` command to restore the default value.

Syntax

```
queue-scheduler { wfq queue1-width queue2-width queue3-width queue4-width queue5-width queue6-width queue7-width queue8-width | wrr queue1-weight queue2-weight queue3-weight queue4-weight queue5-weight queue6-weight queue7-weight queue8-weight }
```

```
undo queue-scheduler
```

Parameters

```
wfq queue1-width queue2-width queue3-width queue4-width queue5-width queue6-width queue7-width queue8-width
```

Indicates that the queue uses Weighted Fair Queue scheduling. `queue1-weight`: the weight of queue 1, the percentage allocated by bandwidth; `queue2-weight`: the weight of queue 2, and so on.

```
wrr queue1-weight queue2-weight queue3-weight queue4-weight queue5-weight queue6-weight queue7-weight queue8-weight
```

Indicates that the queue uses weight round robin (WRR) scheduling. `queue1-weight`: the weight of queue 1, the percentage allocated by bandwidth; `queue2-weight`: the weight of queue 2, and so on.

```
queue-scheduler strict priority
```

SP divides the queue of port into up to 8, from high-priority queue to low-priority queue. During the progress of packet delivery from the queues, packets are picked up from each queue strictly following the priority order from high to low. When the higher-priority queue is empty it will send the packets in the lower-priority group. SP has the drawback that when congestion occurs, if there are many packets queuing in the higher-priority queue, it will require a long time to transmit these packets of higher service priority while the messages in the lower-priority queue are continuously set aside without delivery.

Default

By default, WRR algorithm is selected for all outbound queues at a port.

Example

To set WRR as the port queue scheduling mode, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Ethernet 1/0/1
[SW5500-Ethernet1/0/1]queue-scheduler wrr 1 2 3 4 5 6 7 8
[SW5500-Ethernet1/0/1]
```

View

This command can be used in the following views:

- Ethernet Port view

Description

The queue weight is based on bytes. For example, if the weight of queues 1, 2, 3, 4, 5, 6, 7, 8 is respectively as 1, 2, 3, 4, 5, 6, 7, 8, then among every 36 bytes in process, 1 bytes from queue 1, 2 bytes from queue 2, 3 bytes from queue 3 and 4 bytes from queue 4, 5 bytes from queue 5, 6 bytes from queue 6, 7 bytes from queue 7 and 8 bytes from queue 8.

Related Command

`display queue-scheduler`

quit

Purpose Use the `quit` command to terminate the connection to the remote SSH server.

Syntax `quit`

Parameters None

Example Terminate the connection to the remote SSH server.

```
<S5500> quit
```

View This command can be used in the following views:

- User view

quit

Purpose	Use the quit command to terminate the connection to the remote SFTP server and exit to system view.
Syntax	<code>quit</code>
Parameters	None
Example	Terminate the connection to the remote SFTP server. <pre>sftp-client> quit [S5500]</pre>
View	This command can be used in the following views: <ul style="list-style-type: none">■ SFTP Client view
Description	This command has the same function as the bye and exit commands.

qos cos-local-precedence-map

Purpose

Use the `qos cos-local-precedence-map` command to configure “CoS Local-precedence” mapping table

Use the `undo qos cos-local-precedence-map` command to restore its default values.

Syntax

```
qos cos-local-precedence-map cos0-map-local-prec cos1-map-local-prec  
cos2-map-local-prec cos3-map-local-prec cos4-map-local-prec  
cos5-map-local-prec cos6-map-local-prec cos7-map-local-prec  
  
undo qos cos-local-precedence-map
```

Parameters

<i>cos0-map-local-prec</i>	CoS 0 -> Local precedence (queue) mapping value, in the range of 0~7.
<i>cos1-map-local-prec</i>	CoS 1 -> Local precedence (queue) mapping value, in the range of 0~7.
<i>cos2-map-local-prec</i>	CoS 2 -> Local precedence (queue) mapping value, in the range of 0~7.
<i>cos3-map-local-prec</i>	CoS 3 -> Local precedence (queue) mapping value, in the range of 0~7.
<i>cos4-map-local-prec</i>	CoS 4 -> Local precedence (queue) mapping value, in the range of 0~7.
<i>cos5-map-local-prec</i>	CoS 5 -> Local precedence (queue) mapping value, in the range of 0~7.
<i>cos6-map-local-prec</i>	CoS 6 -> Local precedence (queue) mapping value, in the range of 0~7.
<i>cos7-map-local-prec</i>	CoS 7 -> Local precedence (queue) mapping value, in the range of 0~7.

Example

Configure CoS and Local Precedence table.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]qos cos-local-precedence-map 0 1 2 3 4 5 6 7  
[SW5500]
```

The following is the configured "CoS Local-precedence" mapping table.

Table 96 Default configure CoS and Local-precedence table

CoS and Local Precedence Value	Local Precedence Queue
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7

View

This command can be used in the following views:

- System view

Description

This will map a CoS value to a specific local precedence (queue). Note that traffic which has been assigned a local precedence via QOS will also be assigned to the same queue.

The following is the default CoS and Local Precedence table.

Table 97 Default CoS and Local-precedence table

CoS and Local Precedence Value	Local Precedence Queue
0	2
1	0
2	1
3	3
4	4
5	5
6	6
7	7

qos-profile

Purpose

Use the `qos-profile` command to create a QoS profile and enter the corresponding view. For an existing profile, you can directly enter the corresponding view.

Use the `undo qos-profile` command to delete a QoS profile.

Syntax

```
qos-profile profile-name
```

```
undo qos-profile profile-name
```

Parameters

profile-name

QoS profile name, consisting of a string of one to 32 characters, starting with letters [a-z, A-Z] and excluding all, interface, and user which are reserved as keywords.

Example

To create QoS profile student, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500] qos-profile student  
[SW5500-qos-profilestudent]
```

View

This command can be used in the following views:

- System view

Description

You cannot delete the specific QoS profile that has been applied to the port.

radius nas-ip

Purpose

Use the `radius nas-ip` command to specify the source address of the RADIUS packet sent from NAS.

Use the `undo radius nas-ip` command to restore the default setting.

Syntax

```
radius nas-ip ip-address
```

```
undo radius nas-ip
```

Parameters

ip-address IP address in dotted decimal format.

Default

By default, the source address is not specified, that is, the address of the interface sending the packet serves as the source address.

Example

To configure the Switch to send RADIUS packets from 129.10.10.1, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]radius nas-ip 129.10.10.1
```

View

This command can be used in the following views:

- System view

Description

By specifying the source address of the RADIUS packet, you can avoid unreachable packets as returned from the server upon interface failure. The source address is normally recommended to be a loopback interface address.

This command specifies only one source address; therefore, the newly configured source address may overwrite the original one.

radius-scheme

- Purpose** Use the `radius-scheme` command to configure the RADIUS scheme used by the current ISP domain.
- Syntax** `radius-scheme radius-scheme-name`
- Parameters** `radius-scheme-name` Specifies a RADIUS scheme, consisting of a character string not exceeding 32 characters.
- Example** The following example designates the current ISP domain, marlboro.net, to use the RADIUS server, Radserver.
- ```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]domain marlboro.net
[SW5500-isp-marlboro.net]radius-scheme Radserver
```
- View** This command can be used in the following views:
- ISP Domain view
- Description** This command is used to specify the RADIUS scheme for the current ISP domain. The specified RADIUS scheme shall have been created.
- Related Commands**
- `display radius`

# radius scheme

---

## Purpose

Use the **radius scheme** command to configure a RADIUS scheme group and enter its view.

Use the **undo radius scheme** command to delete the specified RADIUS scheme.

## Syntax

```
radius scheme radius-scheme-name
```

```
undo radius scheme radius-scheme-name
```

## Parameters

**radius-scheme-name** Specifies the Radius server name, consisting of a character string not exceeding 32 characters.

## Default

A default RADIUS scheme named *system* has been created in the system. The attributes of *system* are all default values.

## Example

To create a RADIUS scheme named "3Com" and enter its view, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]radius scheme 3Com
New Radius scheme
[SW5500-radius-3Com]
```

## View

This command can be used in the following views:

- System view

## Description

RADIUS protocol configuration is performed on a per-RADIUS-scheme basis. Every RADIUS scheme shall at least have the specified IP address and UDP port number of the RADIUS authentication/authorization/accounting server and some necessary parameters exchanged with the RADIUS client end (Switch). It is necessary to create the RADIUS scheme and enter its view before performing other RADIUS protocol configurations.

A RADIUS scheme can be used by several ISP domains at the same time. You can configure up to 16 RADIUS schemes, including the default RADIUS scheme named as System.

Although **undo radius scheme** can remove a specified RADIUS scheme, the default one cannot be removed. Note that a scheme currently in use by the online user cannot be removed.

## Related Commands

- **key**
- **display radius**



- radius-scheme
- retry
- retry realtime-accounting
- retry stop-accounting
- server-type
- state
- stop-accounting-buffer enable
- timer realtime-accounting
- user-name-format

# reboot

---

**Purpose** Use the **reboot** command to restart an Ethernet switch.

**Syntax** `reboot [ unit unit-id ]`

**Parameters** `unit-id` Unit ID of a switch.

**Example** Directly restart the switch without saving the current configuration.

```
<S5500> reboot
This will reboot device. Continue? [Y/N] y
Start to check configuration with next startup configuration file,
please wait.....
This command will reboot the device. Current configuration may be lost
in next
startup if you continue. Continue? [Y/N] y
#Apr 2 00:05:57:155 2000 S5500 COMMONSY/5/REBOOT:- 1 -
Reboot Fabric by command.

<S5500>
%Apr 2 00:06:01:148 2000 S5500 DEV/5/DEV_LOG:- 1 -
Switch is rebooted.
Starting.....
```

**Description**



*The system will check whether there is any configuration change before it restarts, and will ask whether you want to proceed or not if there is any change, to prevent you from losing your original configuration due to forgetting after the restart.*

**View**

This command can be used in the following views:

- User view

# reboot member

---

**Purpose** Use the **reboot member** command to reset a specified member device on the management device.

**Syntax** `reboot member { member-number | mac-address H-H-H } [ eraseflash ]`

<b>Parameters</b>	<i>member-number</i>	Cluster member number.
	mac-address <i>H-H-H</i>	MAC address of the member device to be reset.
	eraseflash	Deletes the configuration file when resetting the member device.

**Example** Reset cluster member 2.

```
<aaa_0.S5500>system-view
System View: return to User View with Ctrl+Z.
[aaa_0.S5500]cluster
[aaa_0.S5500-cluster] reboot member 2
```

**View** This command can be used in the following views:

- Cluster view

**Description** Communication between the management and member devices may be interrupted due to some configuration errors. Through the remote control function of member devices, you can control them remotely on the management device. For example, you can delete the booting configuration file and reset the member device, and thus restore normal communication between the management and member devices.

When using the **reboot member** command, you can decide whether to delete the configuration file when the member device is resetting with argument **eraseflash**.

# region-name

---

## Purpose

Use the **region-name** command to assign an MST region name to a switch.

Use the **undo region-name** command to restore the default MST region name.

## Syntax

```
region-name name
```

```
undo region-name
```

## Parameters

*name*

MST region name for a switch, consisting of a string from 1 to 32 characters long.

## Default

The default MST region name of a switch is its MAC address.

MST region name, along with MST region VLAN mapping table and MSTP revision level, determines the MST region to which a switch belongs.

## Example

Configure the MST region name of the switch to be hello.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] stp region-configuration
[S5500-mst-region] region-name hello
```

## View

This command can be used in the following views:

- MST Region view

## Related Commands

- **active region-configuration**
- **check region-configuration**
- **instance**
- **revision-level**
- **vlan-mapping modulo**

# register-policy

---

## Purpose

Use the **register-policy** command to configure a RP to filter the register messages sent by the DR in the PIM-SM network and to accept the specified messages only.

Use the **undo register-policy** command to remove the configured message filtering.

## Syntax

```
register-policy acl-number
```

```
undo register-policy
```

## Parameters

*acl-number*

Number of IP advanced ACL, defining the rule of filtering the source and group addresses. Valid values are 3000 to 3999.

## Example

If the local device is the RP in the network, use the following command to only accept multicast message register of the source sending multicast address in the range of 225.1.0.0/16 on network segment 10.10.0.0/16.

```
<SW5500> system-view
System View: return to User View with Ctrl+Z
[SW5500] acl number 3010
[SW5500-acl-adv-3010] rule permit ip source 10.10.0.0 0.0.255.255
destination 225.1.0.0 0.0.255.255
[SW5500-acl-adv-3010] quit
[SW5500] pim
[SW5500-pim] register-policy 3010
```

## View

This command can be used in the following views:

- PIM view

# remote-ping

---

**Purpose** Use the **remote-ping** command to specify remote-ping test class.

**Syntax** `remote-ping [ count | destination-ip | display | frequency | msdp-tracert | mtracert | ping | quit ]`

<b>Parameters</b>	<b>count</b>	Specifies remote-ping probe number in one test.
	<b>destination-ip</b>	Specifies remote-ping class destination ip address.
	<b>display</b>	Displays current system information.
	<b>frequency</b>	Specifies remote-ping interval time between two remote-ping tests.
	<b>msdp-tracert</b>	Specifies MSDP trace route to source RP.
	<b>mtracert</b>	Traces route to multicast source.
	<b>ping</b>	Ping function.
	<b>quit</b>	Exits from current command view.

**Example** `[5500-EI] remote-ping`

**View** This command can be used in the following views:

- System view

**Description** Remote-ping is a network diagnostic tool used to test the performance of protocols (only ICMP by far) operating on network. It is an enhanced alternative to the ping command.

Remote-ping test group is a set of remote-ping test parameters. A test group contains several test parameters and is uniquely identified by an administrator name plus a test tag.

You can perform an remote-ping test after creating a test group and configuring the test parameters.

Different from the ping command, remote-ping does not display the round trip time (RTT) and timeout status of each packet on the console terminal in real time. You need to execute the display remote-ping command to view the statistic results of your remote-ping test operation. remote-ping allows administrators to set the parameters of remote-ping test groups and start remote-ping test operations.

## Related Command

`display remote-ping`

`ping`

`tracert`

# remote-ping-agent enable

---

<b>Purpose</b>	<p>Use the <code>remote-ping-agent enable</code> command to enable remote-ping client.</p> <p>Use the <code>undo remote-ping-agent enable</code> command to disable remote-ping client.</p>
<b>Syntax</b>	<pre>remote-ping-agent enable undo remote-ping-agent enable</pre>
<b>Parameters</b>	None
<b>Example</b>	<p>Enable remote-ping client.</p> <pre>[S5500] remote-ping-agent enable</pre>
<b>View</b>	<p>This command can be used in the following views:</p> <ul style="list-style-type: none"><li>■ System view</li></ul>
<b>Description</b>	You can perform a test only after the remote-ping client function is enabled.



# remote-probe vlan

---

## Purpose

Use the **remote-probe vlan enable** command to enable the remote-probe port mirroring on the VLAN of a switch.

Use the **undo remote-probe vlan enable** command to disable the remote-probe port mirroring.

## Syntax

```
remote-probe vlan enable
undo remote-probe vlan enable
```

## Parameters

None

## Example

Configure VLAN 5 to be remote-probe VLAN.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] vlan 5
[S5500-vlan5] remote-probe vlan enable
```

## View

This command can be used in the following views:

- VLAN view

# remotehelp

---

**Purpose** Use the **remotehelp** command to display help information about the FTP protocol command.

**Syntax** `remotehelp [ protocol-command ]`

**Parameters** `protocol-command` FTP protocol command.

**Example** Show the syntax of the protocol command `user`.

```
<SW5500>ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in
[ftp]remotehelp user
214 Syntax: USER <sp> <username>
[ftp]
```

**View** This command can be used in the following views:

- FTP Client view

# remove

---

**Purpose** Use the **remove** command to delete the specified file from the server.

**Syntax** `remove remote-file`

**Parameters** `remote-file` Name of a file on the server.

**Example** Delete file temp.c from the server.  

```
sftp-client> remove temp.c
```

**View** This command can be used in the following views:

- SFTP Client view

**Description** This command has the same function as the **delete** command.

# rename

---

**Purpose** Use the **rename** command to change the name of the specified file on the SFTP server.

**Syntax** `rename old name new name`

**Parameters**

<code>old name</code>	Original file name.
<code>new name</code>	New file name.

**Example** Change the name of file temp1 on the SFTP server to temp2.

```
sftp-client> rename temp1 temp2
```

**View** This command can be used in the following views:

- SFTP Client view

# reset

---

**Purpose** Use the `reset` command to reset the system configuration parameters of RIP.

**Syntax** `reset`

**Parameters** None

**Example** Reset the RIP system.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]rip
[SW5500-rip]reset
```

**View** This command can be used in the following views:

- RIP view

**Description** When you need to re-configure parameters of RIP, this command can be used to restore to the default setting.

# reset acl counter

---

**Purpose** Use the `reset acl counters` command to reset the ACL statistics information to zero.

**Syntax** `reset acl counter { all | acl-number }`

**Parameters**

<code>all</code>	All ACLs.
<code><i>acl-number</i></code>	Specifies the sequence number of an ACL.

**Example** Clear the statistics information of ACL 2000.

```
<SW5500>reset acl counters 2000
```

**View** This command can be used in the following views:

- User view

# reset arp

---

## Purpose

Use the `reset arp` command to remove information that is no longer required from the ARP mapping table.

Use the `reset arp` command to clear all ARP entries. You are asked to confirm this entry.

Use the `reset arp dynamic` command to clear all dynamic ARP entries.

Use the `reset arp static` command to clear all static ARP entries.

Use the `display arp interface` command to clear all entries for the specified port.

## Syntax

```
reset arp [dynamic | static | interface { interface_type interface_num
| interface_name }]
```

## Parameters

<i>dynamic</i>	Clears the dynamic ARP mapping entries. Note that dynamic ARP entries start re-learning immediately.
<i>static</i>	Clears the static ARP mapping entries. Note that static ARP entries are deleted permanently.
<i>interface interface_type interface_num interface_name</i>	Clears the ARP mapping entries for the specified port.

## Example

To clear static ARP entries, enter the following:

```
<SW5500>reset arp static
```

## View

This command can be used in the following views:

- User view

## Description

You can remove entries of a specified type, or from a specified port.

## Related Command

- `arp static`
- `display arp`

# reset counters interface

---

**Purpose** Use the `reset counters interface` command to reset the statistical information on the port and count the related information again on the port for the user.

**Syntax**

```
reset counters interface [interface_type | interface_type
interface_num | interface_name]
```

**Parameters**

<i>interface_type</i>	Specifies the port type.
<i>interface_num</i>	Specifies the port number.
<i>interface_name</i>	Specifies the port name in the <i>interface_name=interface_type interface_num</i> format.

For parameter description, refer to the `interface` command.

**Example** To reset statistical information on Ethernet1/0/1, enter the following:

```
<SW5500>reset counters interface ethernet1/0/1
<SW5500>
```

**View** This command can be used in the following views:


- User view

**Description** If you do not enter a port type, or port type and port number, information is cleared from all ports on the Switch. If only the port type is specified, all the information on ports of this type will be cleared. If both port type and port number are specified, the information on the dpecified port will be cleared. After 802.1x is enabled, the port information cannot be reset.



# reset dhcp server conflict

---

<b>Purpose</b>	Use the <code>reset dhcp server conflict</code> command to clear address conflict statistics.	
<b>Syntax</b>	<code>reset dhcp server conflict { all   ip <i>ip-address</i> }</code>	
<b>Parameters</b>	<code>ip <i>ip-address</i></code>	Specifies an IP address, whose conflict statistics will be cleared.
	<code>all</code>	Clears all address conflict statistics.
<b>Example</b>	Clear all address conflict statistics.  <S5500> reset dhcp server conflict all	
<b>View</b>	This command can be used in the following views: <ul style="list-style-type: none"><li>■ User view</li></ul>	
<b>Description</b>		<i>This command applies only to the S5500-EI series among Switch 5500-Series Switches.</i>
<b>Related Command</b>	<code>display dhcp server conflict</code>	

# reset dhcp server ip-in-use

---

**Purpose** Use the **reset dhcp server ip-in-use** command to clear the specified or all dynamic address binding information.

**Syntax**

```
reset dhcp server ip-in-use { ip ip-address | pool [pool-name] |
interface [interface-type interface-number] | all }
```

**Parameters**


<b>all</b>	Clears the dynamic address binding information about all IP addresses.
<b>ip <i>ip-address</i></b>	Clears the dynamic address binding information about a specified IP address.
<b>pool [ <i>pool-name</i> ]</b>	Clears the dynamic address binding information about a specified address pool. The <i>pool-name</i> argument consists of a string from 1 to 35 characters long and is the name of an address pool. If you do not provide this argument, this command clears the dynamic address binding information about all global address pools.
<b>interface [ <i>interface-type interface-number</i> ]</b>	Clears the dynamic address binding information about a specified interface address pool. If you do not specify the <i>interface-number</i> argument, this command clears the dynamic address binding information about all interface address pools.

**Example** Clear the dynamic address binding information about the IP address 10.110.1.1.

```
<S5500> reset dhcp server ip-in-use ip 10.110.1.1
```

**View** This command can be used in the following views:

- User view

**Description**  *This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

**Related Command** `display dhcp server ip-in-use`

# reset dhcp server statistics

---

**Purpose** Use the `reset dhcp server statistics` command to clear the statistics on a DHCP server, such as the number of global/interface address pools, the number of manually/automatically-bound or expired IP addresses, the number of DHCP unrecognized packets/request packets/response packets.

**Syntax** `reset dhcp server statistics`


**Parameters** None

**Example** Clear the statistics on a DHCP server.

```
<S5500> reset dhcp server statistics
```

**View** This command can be used in the following views:

- User view

**Description**  *This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

**Related Command** `display dhcp server statistics`

# reset dot1x statistics

---

<b>Purpose</b>	Use the <code>reset dot1x statistics</code> command to reset the statistics of 802.1x.
<b>Syntax</b>	<code>reset dot1x statistics [ interface <i>interface-list</i> ]</code>
<b>Parameters</b>	<code>interface <i>interface-list</i></code> Ethernet port list including several Ethernet ports. <code><i>interface-list</i> = { <i>interface-num</i> [ to <i>interface-num</i> ] }</code> & < 1-10 >. <code><i>interface-num</i></code> specifies a single Ethernet port in the format <code><i>port-num</i> = { <i>interface-type interface-num</i>   <i>interface-name</i> }</code> , where <code><i>interface-type</i></code> specifies the port type, <code><i>interface-num</i></code> specifies the port number and <code><i>interface-name</i></code> specifies the port name. For the respective meanings and value ranges, read the parameter of the Port Configuration section.
<b>Example</b>	Clear the 802.1x statistics on Ethernet 1/0/2.  <pre>&lt;SW5500&gt;reset dot1x statistics interface ethernet 1/0/2</pre>
<b>View</b>	This command can be used in the following views: <ul style="list-style-type: none"><li>■ User view</li></ul>
<b>Description</b>	This command can be used to re-perform statistics if the user wants to delete the former statistics of 802.1x.  When the original statistics are cleared, if no port type or port number is specified, the global 802.1x statistics of the Switch and 802.1x statistics on all the ports will be cleared. If the port type and port number are specified, the 802.1x statistics on the specified port will be cleared.
<b>Related Command</b>	<code>display dot1x</code>

# reset garp statistics

---

## Purpose

Use the **reset garp statistics** command to clear the GARP statistics (such as the information about the packets received/sent/discarded by GVRP/GMRP).

Use the **reset garp statistics** command without parameters to clear the GARP statistics on all ports.

## Syntax

```
reset garp statistics [interface interface-list]
```

## Parameters

*interface-list*

Ethernet port list, in the format of *interface-list* = { *interface-type interface-number* [ to *interface-type interface-number* ] }&<1-10>. Where, *interface-type* is the port type, *interface-number* is the port number (refer to the parameter description of the port part in this document for the meanings and ranges of the two parameters), and &<1-10> is the repeatable times of the expression (from 1 to 10).

## Example

Clear GARP statistics about all ports.

```
<S5500> reset garp statistics
```

## View

This command can be used in the following views:

- User view

## Related Command

```
display garp statistics
```

# reset hwtacacs statistics

---

<b>Purpose</b>	Use the <code>reset hwtacacs statistics</code> command to clear HWTACACS protocol statistics.	
<b>Syntax</b>	<code>reset hwtacacs statistics { accounting   authentication   authorization   all }</code>	
<b>Parameters</b>	<code>accounting</code>	Clears all the HWTACACS accounting statistics.
	<code>authentication</code>	Clears all the HWTACACS authentication statistics.
	<code>authorization</code>	Clears all the HWTACACS authorization statistics.
	<code>all</code>	Clears all statistics.
<b>Example</b>	Clear all HWTACACS protocol statistics.  <code>&lt;S5500&gt;reset hwtacacs statistics</code>	
<b>View</b>	This command can be used in the following views: <ul style="list-style-type: none"><li>■ User view</li></ul>	
<b>Related Command</b>	<code>display hwtacacs</code>	

# reset igmp group

---

**Purpose** Use the `reset igmp group` command to delete an existing IGMP group from the interface. The deleted group can added again on the interface.

**Syntax**

```
reset igmp group { all | interface interface-type interface-number {
all | group-address [group-mask] } }
```

<b>Parameters</b>	<code>all</code>	All IGMP groups.
	<code>interface <i>interface-type</i> <i>interface-number</i></code>	Interface type and interface number.
	<code><i>group-address</i></code>	IGMP group address.
	<code><i>group-mask</i></code>	Mask of IGMP group address.

**Example** Delete all IGMP groups on all the interfaces.

```
<SW5500>reset igmp group all
```

Delete all IGMP groups on the Vlan-interface10.

```
<SW5500>reset igmp group interface Vlan-interface10 all
```

Delete the group 225.0.0.1 from the Vlan-interface10.

```
<SW5500>reset igmp group interface Vlan-interface10 225.0.0.1
```

Delete the IGMP groups ranging from 225.1.1.0 to 225.1.1.255 on the Vlan-interface10.

```
<SW5500>reset igmp group interface Vlan-interface10 225.1.1.0
255.255.255.0
```

**View** This command can be used in the following views:

- User view

# reset igmp-snooping statistics

---

<b>Purpose</b>	Use the <code>reset igmp-snooping statistics</code> command to clear the IGMP Snooping statistics.
<b>Syntax</b>	<code>reset igmp-snooping statistics</code>
<b>Parameters</b>	None
<b>Example</b>	Clear the IGMP Snooping statistics.  <pre>&lt;S5500&gt; reset igmp-snooping statistics</pre>
<b>View</b>	This command can be used in the following views: <ul style="list-style-type: none"><li>■ User view</li></ul>
<b>Related Command</b>	<code>igmp-snooping</code>



# reset ip statistics

---

**Purpose** Use the `reset ip statistics` command to clear the IP statistics information.

**Syntax** `reset ip statistics`

**Parameters** None

**Example** To clear the IP statistics information, enter the following:  
  
`<SW5500>reset ip statistics`

**View** This command can be used in the following views:

- User view

**Related Commands**

- `display ip interface vlan-interface`
- `display ip statistics`

# reset lacp statistics

---

## Purpose

Use the `reset lacp statistics` command to clear LACP statistics at a designated port. If no port is specified, then LACP statistics at all ports shall be cleared.

## Syntax

```
reset lacp statistics [interface { interface_type interface_number |
interface_name } [to { interface_type interface_num | interface_name }
]]
```

## Parameters

```
interface { interface_type
interface_num |
interface_name } [to {
interface_type interface_
num | interface_name }]
```

Specifies ports. You can specify multiple sequential ports with the `to` parameter, instead of specifying only one port.

***interface\_name*** Specifies port name, in the format of ***interface\_name = interface\_type interface\_num***.

***interface\_type*** Specifies port type and ***interface\_num*** port number.

For more information, see the parameter item for the `interface` command.

## Example

To clear LACP statistics at all Ethernet ports, enter the following:

```
<SW5500>reset lacp statistics
```

## View

This command can be used in the following views:

- User view

## Related Command

`display link-aggregation interface`

# reset logbuffer

---

**Purpose** Use the `reset logbuffer` command to clear information in log buffer.

**Syntax** `reset logbuffer`

**Parameters** None

**Example** Clear information in log buffer.

```
<SW5500>reset logbuffer
```

**View** This command can be used in the following views:

- User view

# reset msdp peer

---

<b>Purpose</b>	Use the <code>reset msdp peer</code> command to reset the TCP connection with the specified MSDP peer and clear all statistics information of that MSDP peer.	
<b>Syntax</b>	<code>reset msdp peer <i>peer-address</i></code>	
<b>Parameters</b>	<i>peer-address</i>	IP address of the MSDP peer, in the dotted decimal format
<b>Example</b>	Reset the TCP connection with the MSDP peer 125.10.7.6 and the statistics of the MSDP peer.  <pre>&lt;S5500&gt; reset msdp peer 125.10.7.6</pre>	
<b>View</b>	This command can be used in the following views: <ul style="list-style-type: none"><li>■ User view</li></ul>	
<b>Related Command</b>	<code>peer</code>	

# reset msdp sa-cache

---

<b>Purpose</b>	Use the <code>reset msdp sa-cache</code> command to clear cached SA entries of the MSDP peer.
<b>Syntax</b>	<code>reset msdp sa-cache [ <i>group-address</i> ]</code>
<b>Parameters</b>	<i>group-address</i> Group address; the cached (S, G) entries matching this address are to be deleted from the SA cache. If no multicast group address is specified, all cached SA entries will be cleared.
<b>Example</b>	Clear the cached entries whose group address is 225.5.4.3 from the SA cache. <pre>&lt;S5500&gt; reset msdp sa-cache 225.5.4.3</pre>
<b>View</b>	This command can be used in the following views: <ul style="list-style-type: none"><li>■ User view</li></ul>
<b>Related Commands</b>	<ul style="list-style-type: none"><li>■ <code>cache-sa-enable</code></li><li>■ <code>display msdp sa-cache</code></li></ul>

# reset msdp statistics

---

- Purpose** Use the `reset msdp statistics` command to clear the statistics information of one or more MSDP peers without resetting the MSDP peer(s).
- Syntax** `reset msdp statistics [ peer-address ]`
- Parameters** *peer-address* Address of the MSDP peer whose statistics, reset information and input/output information will be cleared. If no MSDP peer address is specified, the statistics information of all MSDP peers will be cleared.
- Example** Clear the statistics information of the MSDP peer 125.10.7.6.
- ```
<S5500> reset msdp statistics 125.10.7.6
```
- View** This command can be used in the following views:
- User view

reset multicast forwarding-table

Purpose Use the `reset multicast forwarding-table` command to clear MFC forwarding entries or statistic information of MFC forwarding entries.

Syntax

```
reset multicast forwarding-table [ statistics ] { all | { group-address [ mask { group-mask / group-mask-length } ] | source-address [ mask { source-mask / source-mask-length } ] | incoming-interface interface-type interface-number } * }
```

Parameters

| | |
|--|--|
| <code>statistics</code> | If it is selected, the system clears the statistic information of MFC forward entries. Otherwise, the system clears MFC forward entries. |
| <code>all</code> | All MFC forward entries. |
| <code>group-address</code> | Specifies group address. |
| <code>group-mask</code> | Specifies Mask of group address |
| <code>group-mask-length</code> | Specifies mask length of group address. |
| <code>source-address</code> | Specifies source address. |
| <code>source-mask</code> | Specifies mask of source address. |
| <code>source-mask-length</code> | Specifies mask length of source address. |
| <code>incoming-interface</code> | Specifies incoming interface for the forward entry. |
| <code>interface-type</code>
<code>interface-number</code> | Interface type and interface number. |

Example Clear the forwarding entry with address of 225.5.4.3 from the MFC forwarding table.

```
<SW5500>reset multicast forwarding-table 225.5.4.3
```

Clear statistic information of the forwarding entry with address of 225.5.4.3 from the MFC forwarding table.

```
<SW5500>reset multicast forwarding-table statistics 225.5.4.3
```

View This command can be used in the following views:

- User view

Description Type in the source address first and group address after in the command, ensuring that both addresses are valid. The system prompts error information if invalid addresses are entered.

Related Command

- `display multicast forwarding-table`
- `reset pim routing-table`
- `reset multicast routing-table`

reset multicast routing-table

Purpose

Use the `reset multicast routing-table` command to clear route entries from the core multicast routing table, as well as MFC forwarding entries.

Syntax

```
reset multicast routing-table { all | { group-address [ mask {  
group-mask / group-mask-length } ] | source-address [ mask {  
source-mask / source-mask-length } ] | { incoming-interface  
interface-type interface-number } } * }
```

Parameters

| | |
|--|--|
| <code>all</code> | All route entries in the core multicast routing table. |
| <code><i>group-address</i></code> | Specifies group address. |
| <code><i>group-mask</i></code> | Specifies Mask of group address. |
| <code><i>group-mask-length</i></code> | Specifies mask length of group address. |
| <code><i>source-address</i></code> | Specifies source address. |
| <code><i>source-mask</i></code> | Specifies mask of source address. |
| <code><i>source-mask-length</i></code> | Specifies mask length of source address. |
| <code><i>incoming-interface</i></code> | Specifies incoming interface for the forward entry. |
| <code><i>interface-type</i></code>
<code><i>interface-number</i></code> | Interface type and interface number. |

Example

Clear the route entry with address of 225.5.4.3 from the core multicast routing table.

```
<SW5500>reset multicast routing-table 225.5.4.3
```

Clear statistic information of the forward entry with address of 225.5.4.3 from the MFC forwarding table.

```
<SW5500>reset multicast forwarding-table statistics 225.5.4.3
```

View

This command can be used in the following views:

- User view

Description

Type in the source address first and group address after in the command, ensure that both addresses are valid. The system prompts error information if invalid addresses are entered.

Related Commands

- `display multicast forwarding-table`
- `reset pim routing-table`
- `reset multicast forwarding-table`

reset ndp statistics

Purpose Use the `reset ndp statistics` command to reset the NDP counters to clear the NDP statistics.

Syntax `reset ndp statistics [interface port-list]`

Parameters *port-list* Specifies a list of ports connected with the specified port. A list may contain consecutive or separated ports, or the combination of consecutive and separated ports. The argument is expressed as { *interface-type interface-number* / *interface-name* } [to { *interface-type interface-number* / *interface-name* }] } &<1-10>. *interface-type* specifies the port type. *interface-number* specifies the port number, expressed as slot number/port number. Key word to helps specify a port range.

Example Clear NDP statistics.

```
<S5500> reset ndp statistics
```

View This command can be used in the following views:

- User view

reset ospf all

Purpose

Using the `reset ospf all` command, you can reset the OSPF process, as follows:

- Invalid LSAs are cleared immediately without waiting for LSA timeout.
- If the Router ID changes, a new Router ID takes effect to execute the command.
- Re-elect DR and BDR.
- OSPF configuration before the restart will not be lost.

Syntax

```
reset ospf [ statistics ] { all | process-id }
```

Parameters

| | |
|-------------------------|---|
| <code>all</code> | Resets all OSPF processes. |
| <code>process-id</code> | The process ID of OSPF. Valid values are 1 to 65535. If not specified, the default process ID is 1. |
| <code>statistics</code> | Enter to reset OSPF statistics. |

Example

Reset all the OSPF processes:

```
<SW5500>reset ospf all
```

View

This command can be used in the following views:

- User view

Description

After you enter the command, you are asked to confirm that the OSPF protocol should be re-enabled.

reset password-control blacklist

Purpose

Use the **reset password-control blacklist** command to delete all the user entries in the blacklist.

Use the **reset password-control blacklist username *username*** command to delete specified user entries in the blacklist.

Syntax

```
reset password-control blacklist [ username username ]
```

Parameters

username *username* Specifies a user name.

Example

Check the user information in the blacklist; as you can see, the blacklist contains three users: test, tes, and test2.

```
S5500<S5500> display password-control blacklist
USERNAME                               IP
test                                   192.168.30.25
tes                                    192.168.30.24
test2                                  192.168.30.23
```

Delete the user test from the blacklist.

```
S5500<S5500> reset password-control blacklist user-name test
Are you sure to delete the blacklist-users ?[Y/N]y
All the blacklist users have been cleared.
```

Check the current user information in the blacklist; as you can see, the user test has been deleted.

```
<S5500] > display password-control blacklist
USERNAME                               IP
tes                                    192.168.30.24
test2                                  192.168.30.23
```

View

This command can be used in the following views:

- User view

reset password-control history-record

Purpose

Use the **reset password-control history-record** command to delete the history password records of all users.

Use the **reset password-control history-record username *username*** command to delete the history password record of a specific user.

Syntax

```
reset password-control history-record [ username username ]
```

Parameters

username Name of the user whose history password record will be deleted.

Example

Delete the history password records of all users

```
S5500<S5500> reset password-control history-record  
Are you sure to delete all the history record?[Y/N]
```

If you input "Y", the system deletes all the history password records of all users and gives the following prompt:

```
All historical passwords have been cleared for all users.
```

Delete the history password records of the user test.

```
S5500<S5500> reset password-control history-record username test  
Are you sure to delete all the history record of user test ?[Y/N]
```

If you input "Y", the system deletes all the history password records of the specified user and gives the following prompt:

```
All historical passwords have been cleared for user test.
```

View

This command can be used in the following views:

- User view

reset password-control history-record super

Purpose

Use the `reset password-control history-record super level` command to delete the history records of the super password for the users at the specified level.

Use the `reset password-control history-record super` command to delete the history records of all super passwords.

Syntax

```
reset password-control history-record super [ level level-value ]
```

Parameters

level-value Privilege level, the history records of the super password for the users at this level will be deleted. Valid values are 1 to 3.

Example

Delete the history records of the super password for the users at level 2.

```
S5500<S5500> reset password-control history-record super level 2
Are you sure to clear the specified-level super password history
records? [Y/N]
```

If you input "Y", the system deletes the history records of the super password for the users at level 2.

View

This command can be used in the following views:

- User view

reset pim neighbor

Purpose Use the `reset pim neighbor` command to clear a PIM neighbor

Syntax `reset pim neighbor { all | { neighbor-address | interface interface-type interface-number } * }`

Parameters

| | |
|--|-----------------------------|
| <code>all</code> | All PIM neighbors. |
| <code><i>neighbor-address</i></code> | Specifies neighbor address. |
| <code>interface <i>interface-type</i>
<i>interface-number</i></code> | Specifies interface. |

Example Clear the PIM neighbor 25.5.4.3.

```
<SW5500>reset pim neighbor 25.5.4.3
```

View This command can be used in the following views:

- User view

Related Command `display pim neighbor`

reset pim routing-table

Purpose Use the `reset pim routing-table` command to clear a PIM route entry.

Syntax

```
reset pim routing-table { all | { group-address [ mask { group-mask | group-mask-length } ] | source-address [ mask { source-mask | source-mask-length } ] | { incoming-interface { interface-type interface-number | null } } } * }
```

| | | |
|-------------------|--|--|
| Parameters | <code>all</code> | All PIM neighbors. |
| | <code><i>group-address</i></code> | Specifies group address. |
| | <code>mask <i>group-mask</i></code> | Specifies group mask. |
| | <code>mask-length <i>group-mask-length</i></code> | Specifies mask length of the group address. |
| | <code><i>source-address</i></code> | Specifies source address. |
| | <code>mask <i>source-mask</i></code> | Specifies source mask. |
| | <code>mask-length <i>source-mask-length</i></code> | Specifies mask length of the group address. |
| | <code>incoming-interface</code> | Specifies incoming interface for the route entry in PIM routing table. |
| | <code><i>interface-type</i> <i>interface-number</i></code> | Specifies the interface. |
| | <code>null</code> | Specifies the incoming interface of the route entry as null. |

Example Clear the route entries with group address 225.5.4.3 from the PIM routing table.

```
<SW5500>reset pim routing-table 225.5.4.3
```

View This command can be used in the following views:

- User view

Description You can type in `source-address` first and `group-address` after in the command, as long as they are valid. Error information will be given if you type in invalid addresses.

If in this command, the `group-address` is 224.0.0.0/24 and `source-address` is the RP address (where group address can have a mask, but the resulted IP address must be 224.0.0.0, and source address has no mask), then it means only the (*, *, RP) item will be cleared.

If in this command, the `group-address` is any a group address, and `source-address` is 0 (where group address can have a mask, and source address has no mask), then only the (*, G) item will be cleared.

This command clears multicast route entries from PIM routing table, as well as the corresponding route entries and forward entries in the multicast core routing table and MFC.

Related Commands

- **display pim routing-table**
- **reset multicast routing-table**
- **reset multicast forwarding-table**

reset radius statistics

| | |
|------------------------|---|
| Purpose | Use the reset radius statistics command to clear the statistic information related to the RADIUS protocol. |
| Syntax | <code>reset radius statistics</code> |
| Parameters | None |
| Example | To clear the RADIUS protocol statistics, enter the following:

<code><SW5500>reset radius statistics</code> |
| View | This command can be used in the following views: <ul style="list-style-type: none">■ User view |
| Related Command | <code>display radius</code> |

reset recycle-bin

Purpose Use the **reset recycle-bin** command to completely delete file(s) in the recycle bin.

Syntax

```
reset recycle-bin [ file-url ] [ /force ]  
reset recycle-bin [ /fabric ]
```

Parameters

| | |
|-----------------------|---|
| <code>file-url</code> | Path name or file name of the file in the flash memory, consisting of a character string from 1 to 142 characters long. This argument supports the wildcard "*" . |
| <code>/force</code> | Gives no prompt for the delete operation. |
| <code>/fabric</code> | Operates on the whole fabric. |

Example Clear recycle bin on all units in the fabric.

```
<S5500> reset recycle-bin /fabric  
Squeeze the recycle bins in fabric ? [Y/N]:y  
Unit1 reset success!  
Unit2 reset success!  
%Apr 4 11:42:57:160 2000 S5500 VFS/6/OPLOG:- 1 - Unit1 reset success!  
%Apr 4 11:42:57:236 2000 S5500 VFS/6/OPLOG:- 1 - Unit2 reset success!
```

View This command can be used in the following views:

- User view

Description The files that are deleted using the **delete** command are still stored in the recycle bin. To delete them completely, you can use the **reset recycle-bin** command.



*When you execute the **reset recycle-bin /fabric** command, the system does not prompt you to give a confirmation for each file you want to delete.*

reset saved-configuration

Purpose Use the **reset saved-configuration** command to delete the main or backup configuration files on the Ethernet switches in the fabric.

Syntax `reset saved-configuration [backup | main]`

Parameters

| | |
|---------------|----------------------------|
| main | Main configuration file. |
| backup | Backup configuration file. |

Example Delete the main configuration file to be used for next startup.

```
<S5500>reset saved-configuration main
The saved configuration will be erased.
Are you sure? [Y/N]y
Configuration in flash is being cleared.
Please wait ...
...
Configuration in flash is cleared.
```

View This command can be used in the following views:

- User view

Description Executing the **reset saved-configuration** command with neither **backup** nor **main** keyword will delete the main configuration files in the fabric.

Generally, the **reset saved-configuration** command is used in the following cases:

- After the software on an Ethernet switch is updated, the configuration files in the flash memory are not compatible with the new software version. In this case, you can use the command to delete the old configuration files.
- It is expected to apply an Ethernet switch that has ever been used to a new environment, but the old configuration files cannot adapt to the new environment. In this case, you can use the command to delete the old configuration files and then reconfigure the Ethernet switch.



CAUTION:

- Use the **reset saved-configuration** command with caution. You are recommended to use this command under the guidance of technical support personnel.
- When the Ethernet switch is powered on and initialized, if no configuration file is found in the flash memory, the default parameters are used for the initialization.
- If the file to be deleted does not exist, the system will report error message.

Related Command

`save`

reset stop-accounting-buffer

| | |
|-------------------------|--|
| Purpose | Use the reset stop-accounting-buffer command to clear the stop-accounting requests that have no response and are buffered on the switch. |
| Syntax | reset stop-accounting-buffer hwtacacs-scheme <i>hwtacacs-scheme-name</i> |
| Parameters | <p><i>hwtacacs-scheme</i>
<i>hwtacacs-scheme-name</i></p> <p>Configures to delete the stop-accounting requests from the buffer according to the specified HWTACACS scheme name. The <i>hwtacacs-scheme-name</i> specifies the HWTACACS scheme name with a character string not exceeding 32 characters, excluding "?".</p> |
| Example | <p>Delete the buffered stop-accounting requests that are related to the HWTACACS scheme "3Com".</p> <pre><S5500> reset stop-accounting-buffer hwtacacs-scheme 3Com</pre> |
| View | <p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ User view |
| Related Commands | <ul style="list-style-type: none">■ display stop-accounting buffer■ retry stop-accounting■ stop-accounting-buffer enable |

reset stp

Purpose Use the **reset stp** command to clear the STP statistics of specified Ethernet ports.

Syntax `reset stp [interface interface-list]`

Parameters *interface-list* List of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of *interface-list* = { *interface-type interface-number* [to *interface-type interface-number*] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.

Example Clear the STP statistics of ports Ethernet1/0/1 through Ethernet1/0/3.

```
<S5500> reset stp interface Ethernet 1/0/1 to Ethernet 1/0/3
```

View This command can be used in the following views:

- User view

Description Statistics about spanning trees includes the number of the TCN BPDUs, Configuration BPDUs, RST BPDUs, and MST BPDUs sent and received through a port or specific ports. Note that statistics about STP BPDUs and TCN BPDUs are collected only for the CIST..

This command clears the STP statistics about the specified ports if you specify the *interface-list* argument. If you do not specify the *interface-list* argument, this command clears the STP statistics about all ports.

Related Command `display stp`

reset tcp statistics

| | |
|------------------------|--|
| Purpose | Use the <code>reset tcp statistics</code> command to clear the TCP statistics information. |
| Syntax | <code>reset tcp statistics</code> |
| Parameters | None |
| Example | To clear the TCP statistics information, enter the following:

<pre><SW5500>reset tcp statistics</pre> |
| View | This command can be used in the following views: <ul style="list-style-type: none">■ User view |
| Related Command | <code>display tcp statistics</code> |

reset traffic-statistic

Purpose Use the `reset traffic-statistic` command to reset the traffic statistics information.

Syntax

```
reset traffic-statistic inbound { user-group acl-number [ rule rule ] |
ip-group acl-number [ rule rule ] | link-group acl-number [ rule rule ]
}
```

| | | |
|-------------------|---|--|
| Parameters | <code>inbound</code> | Specifies the traffic received by the Ethernet port. |
| | <code>user-group <i>acl-number</i></code> | Activates user-defined ACLs. <i>acl-number</i> : Sequence number of ACL, ranging from 5000 to 5999. |
| | <code>ip-group <i>acl-number</i></code> | Activates IP ACLs, including basic and advanced ACLs. <i>acl-number</i> : Sequence number of ACL, ranging from 2000 to 3999. |
| | <code>link-group <i>acl-number</i></code> | Activates Layer 2 ACLs. <i>acl-number</i> : Sequence number of ACL, ranging from 4000 to 4999. |
| | <code>rule <i>rule</i></code> | Specifies the sub-item of an active ACL, ranging from 0 to 65534; if not specified, all sub-items of the ACL will be activated. If only an IP ACL or a Layer 2 ACL is activated, this parameter can be omitted. If both IP and Layer 2 ACLs are activated at the same time, the <i>rule</i> parameter cannot be omitted. |

Example Clear the statistics information about ACL 2000.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Ethernet 1/0/1
[SW5500-Ethernet1/0/1]reset traffic-statistic inbound ip-group 2000
[SW5500-Ethernet1/0/1]
```

View This command can be used in the following views:

- Ethernet Port view

Description This command is used for clearing the statistics information about all the traffic or a specified one.

Table 98 Comparison of Statistics Information reset commands

| Command | Function |
|--------------------------------|--|
| <code>reset acl counter</code> | Reset the statistics information of the ACL which is used in the case of filtering or classifying the data treated by the software of the Switch. The case includes: ACL cited by route policy function and ACL used for control logon user. |

Table 98 Comparison of Statistics Information reset commands (continued)

| Command | Function |
|--------------------------------|--|
| reset traffic-statistic | Reset statistic information of traffic. This command is used in the case of filtering or classifying the data transmitted by the hardware of the Switch. Commonly, this command is used to reset the statistics information of the traffic-statistic command. |

reset trapbuffer

Purpose Use the `reset trapbuffer` command to clear information in trap buffer.

Syntax `reset trapbuffer`

Parameters None

Example Clear information in trap buffer.

```
<SW5500>reset trapbuffer
```

View This command can be used in the following views:

- User view

reset udp statistics

Purpose Use the `reset udp statistics` command to clear the UDP statistics information.

Syntax `reset udp statistics`

Parameters None

Example To clear the UDP traffic statistics information, enter the following:

```
<SW5500>reset udp statistics
```

View This command can be used in the following views:

- User view

reset vrrp statistics

Purpose Use the **reset vrrp** command to clear the statistics information about VRRP.

Syntax `reset vrrp statistics [vlan-interface vlan-id] [virtual-router-ID]`

Parameters

| | |
|--|--|
| <code>statistics</code> | Displays VRRP statistics. |
| <code>vlan-interface <i>vlan-id</i></code> | Specifies a VLAN interface ID. |
| <code><i>virtual-router-ID</i></code> | VRRP virtual router ID. Valid values are 1 to 255. |

Example Clear the VRRP statistics on the switch.

```
<S5500> reset vrrp statistics
```

View This command can be used in the following views:

- User view

Description When you execute this command,

- If the interface index and backup group ID are not specified, the statistics information about all the backup groups on the switch is cleared.
- If only the interface index is specified, the statistics information about all the backup groups on the interface will be cleared.
- If both the interface index and backup group ID are specified, the statistics information about the specified backup group on the interface is cleared.



The VRRP feature is supported by Switch 5500-EI series switches but is not supported by Switch 5500-SI series switches.

resilient-arp enable

| | |
|------------------------|---|
| Purpose | <p>Use the <code>resilient-arp enable</code> command to enable the resilient ARP function.</p> <p>Use the <code>undo resilient-arp enable</code> command to disable the resilient ARP function.</p> |
| Syntax | <pre>resilient-arp enable undo resilient-arp enable</pre> |
| Parameters | None |
| Default | By default, resilient ARP function is enabled. |
| Example | <p>To enable the resilient ARP function, enter the following:</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]resilient-arp enable</pre> |
| View | <p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view |
| Related Command | <code>display resilient-arp</code> |

resilient-arp interface vlan-interface

Purpose

Use the **resilient-arp interface vlan-interface** command to configure the Switch to send resilient ARP packets out the specified VLAN interface.

Use the **undo resilient-arp interface vlan-interface** command to stop the Switch from sending ARP packets out of the specified VLAN interface.

Syntax

```
resilient-arp interface vlan-interface vlan_id
```

```
undo resilient-arp interface vlan-interface vlan_id
```

Parameters

vlan_id

Enter the VLAN interface ID.

If no interface ID is specified, the system sends resilient ARP packets out of VLAN interface 1.

Example

To set VLAN interface 2 to send resilient ARP packets., enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]resilient-arp interface vlan-interface 2
```

View

This command can be used in the following views:

- System view

Related Command

```
display resilient-arp
```

restore startup-configuration from

Purpose

Use the **restore startup-configuration from** command to download or restore the startup configuration of either a specified switch from a file on a TFTP server or the whole fabric.

Syntax

```
restore { unit unit-id | fabric } startup-configuration from source-addr filename.cfg
```

Parameters

| | |
|---------------------|---|
| <i>unit-id</i> | Unit ID of a switch. |
| <i>fabric</i> | Specifies the whole fabric system. |
| <i>source-addr</i> | Host name or IP address of an TFTP server. |
| <i>filename.cfg</i> | Name of the configuration file to be downloaded. This file name is suffixed with <i>cfg</i> . |

Example

Restore the backupstartup configuration of unit 7 from the file u2aaa.cfg from on the TFTP server with the IP address 1.1.1.253.

```
<S5500> restore unit 7 startup-configuration from 1.1.1.253 aaa.cfg
Restore startup configuration from 1.1.1.253. Please wait...
File will be transferred in binary mode.
Downloading file from remote tftp server, please wait.....
TFTP: 20291958 bytes receivedsent in 0 second(s).
File downloaded successfully.
```

```
Unit 27: Restore startup current configuration finished!
```

```
Unit 27: Restore startup current configuration finished!
```

Restore the startup configuration of the whole fabric from the file bbb.cfg on the TFTP server with the IP address 1.1.1.253.

```
<S5500> restore fabric startup-configuration from 1.1.1.253 bbb.cfg
Restore startup configuration from 1.1.1.253. Please wait...
File will be transferred in binary mode.
Downloading file from remote tftp server, please wait...
TFTP:      2029 bytes sent in 0 second(s).
```

```
File downloaded successfully.
```

```
Unit 7: Restore startup current configuration finished!
```

```
Unit 8: Restore startup current configuration finished!
```

View

This command can be used in the following views:

- User view

retry

Purpose Use the **retry** command to set the maximum retry times during a detect operation.

Syntax `retry retry-times`

Parameters `retry-times` Retry times during a detect operation. Valid values are 0 to 10.
If not specified, the default is 2.

Example Specify the maximum number of retries to 3 for detecting group 10.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] detect-group 10
[S5500-detect-group-10] retry 3
```

View This command can be used in the following views:

- Detecting Group view

retry realtime-accounting

Purpose

Use the `retry realtime-accounting` command to configure the maximum number of retries for real-time accounting requests.

Use the `undo retry realtime-accounting` command to restore the maximum number of retries for real-time accounting requests to the default value.

Syntax

```
retry realtime-accounting retry-times
```

```
undo retry realtime-accounting
```

Parameters

retry-times

Specifies the maximum times of real-time accounting request failing to be responded. Valid values are 1 to 255.

If not specified, the accounting request can fail to be responded up to 5 times.

Example

To allow the real-time accounting request failing to be responded for up to 10 times, enter the following:

```
<SW5500> system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]radius scheme 3Com  
[SW5500-radius-3Com]retry realtime-accounting 10
```

View

This command can be used in the following views:

- RADIUS Scheme view

Description

RADIUS server usually checks if a user is online with timeout timer. If the RADIUS server has not received the real-time accounting packet from NAS, it will consider that there is line or device failure and stop accounting. Therefore, it is necessary to disconnect the user at the NAS end and on the RADIUS server synchronously when unexpected failure occurs. The Switch 5500 Series supports a maximum number of times that real-time accounting requests can fail to be responded to. NAS will disconnect the user if it has not received a real-time accounting response from the RADIUS server for the number of specified times.

How is the value of *count* calculated? Suppose RADIUS server connection will timeout in *T* and the real-time accounting interval of NAS is *t*, then the integer part of the result from dividing *T* by *t* is the value of *count*. Therefore, when applied, *T* is suggested the numbers which can be divided exactly by *t*.

Related Command

`radius-scheme`

retry stop-accounting

Purpose

Use the `retry stop-accounting` command to configure the maximal retransmission times after stopping accounting request.

Use the `undo retry stop-accounting` command to restore the retransmission times to the default value.

Syntax

```
retry stop-accounting retry-times
```

```
undo retry stop-accounting
```

Parameters

retry-times

Specifies the maximal retransmission times after stopping accounting request. Valid values are 10 to 65535.

If not specified, the default value is 500.

Example

To indicate that, when stopping accounting request for the server "3Com" in the RADIUS server group, the Switch will retransmit the packets for up to 1000 times, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]radius scheme 3Com
[SW5500-radius-3Com]retry stop-accounting 1000
```

View

This command can be used in the following views:

- RADIUS Scheme view

Description

Because the stopping accounting request concerns account balance and will affect the amount of charge, which is very important for both the user and ISP, NAS shall make its best effort to send the message to RADIUS accounting server. Accordingly, if the message from the Switch to RADIUS accounting server has not been responded, the Switch shall save it in the local buffer and retransmit it until the server responds or discard the messages after transmitting for specified times.

Related Commands

- `display stop-accounting buffer`
- `radius-scheme`
- `reset stop-accounting-buffer`

return

| | |
|--------------------|---|
| Purpose | Use the return command to return to user view from any other view. |
| Syntax | return |
| Parameters | None |
| Example | <p>To return to user view from any other view (the example below shows the command entered from the system view), enter the following.</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]return <SW5500></pre> |
| Description | <p><i>Performs the same function as Ctrl+Z.</i></p> <p><i>To return to the next highest level of view, use quit.</i></p> |
| View | <p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view or higher |

revision-level

| | | | |
|-------------------------|---|--------------|---|
| Purpose | Use the revision-level command to set the MSTP revision level for a switch.

Use the undo revision-level command to restore the default revision level. | | |
| Syntax | <pre>revision-level level

undo revision-level</pre> | | |
| Parameters | <table><tr><td><i>level</i></td><td>MSTP revision level for the switch. Valid values are 0 to 65535.
If not specified, the default is 0.</td></tr></table> | <i>level</i> | MSTP revision level for the switch. Valid values are 0 to 65535.
If not specified, the default is 0. |
| <i>level</i> | MSTP revision level for the switch. Valid values are 0 to 65535.
If not specified, the default is 0. | | |
| Example | Set the MSTP revision level of the MST region where the switch resides to 5.

<pre><S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] stp region-configuration
[S5500-mst-region] revision-level 5</pre> | | |
| View | This command can be used in the following views: <ul style="list-style-type: none">■ MST Region view | | |
| Description | MSTP revision level, along with MST region name and VLAN mapping table, determines the MST region to which a switch belongs. | | |
| Related Commands | <ul style="list-style-type: none">■ active region-configuration■ check region-configuration■ instance■ region-name■ vlan-mapping modulo | | |

rip

Purpose Use the `rip` command to enable RIP and enter the RIP command view.

Use the `undo rip` command to disable RIP.

Syntax

```
rip
```

```
undo rip
```

Parameters

None

Default

By default, RIP is disabled.

Example

To enable RIP, and enter RIP view, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]rip
[SW5500-rip]
```

View

This command can be used in the following views:

- System view

Description

Enabling RIP does not affect interface configurations.

rip authentication-mode

Purpose

Use the `rip authentication-mode` command to configure the RIP-2 authentication mode and its parameters for the Switch 5500.

Use the `rip authentication-mode simple` command to configure the RIP-2 simple text authentication key.

Use the `rip authentication-mode md5 usual key-string` to configure the MD5 cipher text authentication key for RIP-2.

Use the `rip authentication-mode md5 nonstandard key-string key-id` command to configure the MD5 cipher text authentication ID for RIP-2.

Use the `undo rip authentication-mode` command to cancel RIP-2 authentication.

Syntax

```
rip authentication-mode { simple password | md5 { usual key-string |  
nonstandard key-string key-id } }
```

```
undo rip authentication-mode
```

Parameters

| | |
|--------------------------|--|
| <code>simple</code> | Specifies simple text authentication mode. |
| <code>password</code> | Specifies the simple text authentication key. |
| <code>md5</code> | Specifies MD5 cipher text authentication mode. |
| <code>usual</code> | Specifies the MD5 cipher text authentication packet to use the general packet format (RFC 1723 standard format). |
| <code>key-string</code> | Specifies the MD5 cipher text authentication key. If it is entered in plain text, the MD5 key is a character string not exceeding 16 characters. This key is displayed in a cipher text form in a length of 24 characters when display current-configuration command is executed. Inputting the MD5 key in cipher text form with 24 characters long is also supported. |
| <code>nonstandard</code> | Sets the MD5 cipher text authentication packet to use a nonstandard packet format (as described in RFC2082). |
| <code>key-id</code> | Specifies an MD5 cipher text authentication identifier, ranging from 1 to 255. |

Example

To specify the interface "Vlan-interface 1" to use simple authentication with the key set to "aaa", enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface Vlan-interface 1  
[SW5500-Vlan-interface1]rip version 2  
[SW5500-Vlan-interface1]rip authentication-mode simple aaa
```

To specify the interface Vlan-interface 1 to use MD5 authentication with the key string as “aaa” and the packet type set to usual, enter the following:

```
[SW5500]interface Vlan-interface 1
[SW5500-Vlan-interface1]rip version 2
[SW5500-Vlan-interface1]rip authentication-mode md5 key-string aaa
[SW5500-Vlan-interface1]rip authentication-mode md5 type nonstandard
```

To set MD5 authentication on Vlan-interface 1 with the key string set to “aaa” and the packet type set to usual, enter the following:

```
[SW5500]interface Vlan-interface 1
[SW5500-Vlan-interface1]rip version 2
[SW5500-Vlan-interface1]rip authentication-mode md5 usual aaa
```

View

This command can be used in the following views:

- Interface view

Description

There are two RIP-2 authentication modes: simple authentication and MD5 cipher text authentication. When you use MD5 cipher text authentication mode, two types of packet formats are available. The standard format (set using the **usual** parameter), is described in RFC 1723. The non-standard format (set using the **nonstandard** parameter), is described in RFC 2082.



RIP-1 does not support authentication.

Related Command

rip version

rip input

| | |
|-------------------------|---|
| Purpose | <p>Use the <code>rip input</code> command to allow an interface to receive RIP packets.</p> <p>Use the <code>undo rip input</code> command to block an interface from receiving RIP packets.</p> |
| Syntax | <pre>rip input undo rip input</pre> |
| Parameters | None |
| Default | By default, all interfaces except loopback interfaces are able to receive RIP packets. |
| Example | <p>To set the interface Vlan-interface 1 not to receive RIP packets, enter the following:</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]interface Vlan-interface 1 [SW5500-Vlan-interface1]undo rip input</pre> |
| View | <p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ Interface view |
| Description | <p>This command is used in conjunction with two other two commands: <code>rip output</code> and <code>rip work</code>. The <code>rip input</code> and <code>rip output</code> commands control, respectively, the receipt and the transmission of RIP packets on an interface. The <code>rip work</code> command allows both receipt and transmission of RIP packets.</p> |
| Related Commands | <ul style="list-style-type: none">■ <code>rip output</code>■ <code>rip work</code> |

rip metricin

| | | | |
|------------------------|--|--------------|---|
| Purpose | <p>Use the <code>rip metricin</code> command to configure an additional route metric to be added to the route when an interface receives RIP packets.</p> <p>Use the <code>undo rip metricin</code> command to restore the default value of this additional route metric.</p> | | |
| Syntax | <pre>rip metricin value undo rip metricin</pre> | | |
| Parameters | <table><tr><td>value</td><td>Specifies an additional route metric to be added when receiving a packet. Valid values are 0 to 16. If not specified, the default value is 0.</td></tr></table> | value | Specifies an additional route metric to be added when receiving a packet. Valid values are 0 to 16. If not specified, the default value is 0. |
| value | Specifies an additional route metric to be added when receiving a packet. Valid values are 0 to 16. If not specified, the default value is 0. | | |
| Example | <p>To set the additional route metric to 2 when the interface Vlan-interface 1 receives RIP packets, enter the following:</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]interface Vlan-interface 1 [SW5500-Vlan-interface1]rip metricin 2</pre> | | |
| View | <p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ Interface view | | |
| Related Command | <pre>rip metricout</pre> | | |

rip metricout

Purpose

Use the `rip metricout` command to configure an additional route metric to be added to a route when an interface transmits RIP packets.

Use the `undo rip metricout` command to restore the default value of the additional route metric.

Syntax

```
rip metricout value
```

```
undo rip metricout
```

Parameters

`value`

Specifies an additional route metric added when transmitting a packet. Valid values are 1 to 16. If not specified, the default is 1.

Example

To set the additional route metric to 2 when the interface Vlan-interface 1 transmits RIP packets, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface Vlan-interface 1
[SW5500-Vlan-interface1]rip metricout 2
```

View

This command can be used in the following views:

- Interface view

Related Command

```
rip metricin
```

rip output

| | |
|-------------------------|---|
| Purpose | <p>Use the <code>rip output</code> command to allow an interface to transmit RIP packets.</p> <p>Use the <code>undo rip output</code> command to disable an interface from transmitting RIP packets.</p> |
| Syntax | <pre>rip output undo rip output</pre> |
| Parameters | None |
| Default | By default, all interfaces except loopback interfaces are able to transmit RIP packets. |
| Example | <p>To prevent the interface Vlan-interface 1 from transmitting RIP packets, enter the following:</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]interface Vlan-interface 1 [SW5500-Vlan-interface1]undo rip output</pre> |
| View | <p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ Interface view |
| Description | <p>This command is used in conjunction with two other commands: <code>rip input</code> and <code>rip work</code>. <code>rip input</code> and <code>rip output</code> control, respectively, the receipt and the transmission of RIP packets on an interface. <code>rip work</code> allows both receipt and transmission of RIP packets.</p> |
| Related Commands | <ul style="list-style-type: none">■ <code>rip input</code>■ <code>rip work</code> |

rip split-horizon

Purpose

Use the `rip split-horizon` command to configure an interface to use split horizon when transmitting RIP packets. This is the default.

Use the `undo rip split-horizon` command to configure an interface not to use split horizon when transmitting RIP packets.

Syntax

```
rip split-horizon
```

```
undo rip split-horizon
```

Parameters

None

Example

To set the interface Vlan-interface 1 not to use split horizon when processing RIP packets, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface Vlan-interface 1  
[SW5500-Vlan-interface1]undo rip split-horizon
```

View

This command can be used in the following views:

- Interface view

Description

Normally, split horizon is necessary for preventing router loops. You may need to disable split horizon to ensure proper operation of protocols.

rip version

Purpose

Use the `rip version` command to configure the version number of RIP packets on an interface.

Use the `undo rip version` command to restore the default RIP packet version on the interface. The interface RIP version is RIP-1.

Syntax

```
rip version 1
rip version 2 [ broadcast | multicast ]
undo rip version
```

Parameters

| | |
|------------------------|---|
| <code>1</code> | Sets the interface version to RIP-1. |
| <code>2</code> | Sets the interface version to RIP-2. |
| <code>broadcast</code> | Sets the transmission mode of an RIP-2 packet to broadcast. |
| <code>multicast</code> | Sets the transmission mode of an RIP-2 packet to multicast. |

Default

By default, RIP-1 transmits packets in broadcast mode, while RIP-2 transmits packets in multicast mode.

Example

To configure the interface Vlan-interface 1 to RIP-2 broadcast mode, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface Vlan-interface 1
[SW5500-Vlan-interface1]rip version 2 broadcast
```

View

This command can be used in the following views:

- Interface view

Description

When running RIP-1, the interface receives and transmits RIP-1 packets, and can also receive RIP-2 broadcast packets.

When running RIP-2 in broadcast mode, the interface receives and transmits RIP-2 broadcast packets, and can also receive both RIP-1 packets and RIP-2 multicast packets.

When running RIP-2 in multicast mode, the interface receives and transmits RIP-2 multicast packets, and can also receive RIP-2 broadcast packets. The interface can not receive RIP-1 packets.

rip work

Purpose Use the `rip work` command to enable the RIP on an interface. This is the default.

Use the `undo rip work` command to disable RIP on an interface.

Syntax

```
rip work
```

```
undo rip work
```

Parameters

None

Example

To disable the running of RIP on interface Vlan-interface 1, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface Vlan-interface 1  
[SW5500-Vlan-interface1]undo rip work
```

View

This command can be used in the following views:

- Interface view

Description

This command is used in conjunction with the `rip input`, `rip output` and `network` commands. Refer to the descriptions of these commands for details.

Related Commands

- `network`
- `rip input`
- `rip output`

rmdir

- Purpose** Use the **rmdir** command to delete the specified directory from the remote SFTP server.
- Syntax** `rmdir remote-path`
- Parameters** `remote-path` Name of a directory on the remote SFTP server.
- Example** Delete directory D:/temp1 from the remote SFTP server.
- ```
sftp-client> rmdir D:/temp1
```
- View** This command can be used in the following views:
- SFTP Client view



# rmon alarm

---

## Purpose

Use the **rmon alarm** command to add an entry to the alarm table.

Use the **undo rmon alarm** command to delete an entry from this table.

## Syntax

```
rmon alarm entry-number alarm-variable sampling-time { delta | absolute
} rising-threshold threshold-value1 event-entry1 falling-threshold
threshold-value2 event-entry2 [owner text]

undo rmon alarm entry-number
```

## Parameters

<b>entry-number</b>	Number of the entry to be added/deleted. Valid values are 1 to 65535.
<b>alarm-variable</b>	Specifies the alarm variable with a character string, ranging from 1 to 256 characters, in the OID dotted format, like 1.3.6.1.2.1.2.1.10.1 (or ifInOctets.1).
<b>sampling-time</b>	Specifies the sampling interval. Valid values are 5 to 65535 (measured in seconds).
<b>delta</b>	Sampling type is delta.
<b>absolute</b>	Sampling type is absolute.
<b>rising-threshold</b> <b>threshold-value1</b>	Rising threshold. Valid values are 0 to 2147483647.
<b>event-entry1</b>	Event number corresponding to the upper limit of threshold. Valid values are 0 to 65535.
<b>falling-threshold</b> <b>threshold-value2</b>	Falling threshold. Valid values are 0 to 2147483647.
<b>event-entry2</b>	Event number corresponding to the falling threshold. Valid values are 0 to 65535.
<b>owner text</b>	Specifies the creator of the alarm. Length of the character string can be from 1 to 127 characters long.

## Example

Delete the information of entry 15 from the alarm table.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]undo rmon alarm 15
[SW5500]
```

In this way, the alarm event can be triggered in the abnormal situations and then decides to log and send trap to the NM station.

## View

This command can be used in the following views:

- System view

# rmon event

---

## Purpose

Use the `rmon event` command to add an entry to the event table.

Use the `undo rmon event` command to delete an entry from this table.

## Syntax

```
rmon event event-entry [description string] { log | trap
trap-community | log-trap log-trapcommunity | none } [owner
rmon-station]
```

```
undo rmon event event-entry
```

## Parameters

<b>event-entry</b>	Number of the entry to be added/deleted. Valid values are 1 to 65535.
<b>description string</b>	Event description. The length of the character string can be from 1 to 255 characters long.
<b>log</b>	Log event.
<b>trap</b>	Trap event.
<b>trap-community</b>	The community of the Network Management station that the trap message is sent to.
<b>log-trap</b>	Log and trap event.
<b>log-trapcommunity</b>	The community of the Network Management station that the trap message is sent to.
<b>none</b>	Neither log nor trap event.
<b>owner rmon-station</b>	Name of the network management station that creates this entry. The length of the character string can be from 1 to 127 characters long.

## Example

Add the entry 10 to the event table and mark it as log event.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]rmon event 10 log
[SW5500]
```

## View

This command can be used in the following views:

- System view

## Description

Event management of RMON defines the way to deal with event number and event-log, send trap message or log while sending trap message. In this way, alarm events may obtain corresponding treatment

# rmon history

---

## Purpose

Use the `rmon history` command to add an entry to the history control table.

Use the `undo rmon history` command to delete an entry from history control table.

## Syntax

```
rmon history entry-number buckets number interval sampling-interval [owner text-string]
```

```
undo rmon history entry-number
```

## Parameters

<code>entry-number</code>	Number of the entry to be added/deleted. Valid values are from 1 to 65535.
<code>buckets number</code>	Capacity of the history table corresponding to the control line.
<code>interval sampling-interval</code>	Sampling interval. Valid values are from 5 to 3600 (measured in seconds).
<code>owner text-string</code>	Creator of the line. Length of the character string. Valid values are from 1 to 127.

## Example

Delete the entry 15 from the history control table.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface Ethernet1/0/1
[SW5500-Ethernet1/0/1]undo rmon history 15
[SW5500-Ethernet1/0/1]
```

## View

This command can be used in the following views:

- Ethernet Port view

## Description

Perform this command to sample, set sample parameter (sample time interval) and storage amounts for a port. RMON will periodically perform data collection and save for query on this port. Sample information includes utility, error number and total packet number.

# rmon prialarm

---

## Purpose

Use the `rmon prialarm` command to add an entry to the extended RMON alarm table.

Use the `undo rmon prialarm` command to delete an entry from the extended RMON alarm table.

## Syntax

```
rmon prialarm entry-number alarm-var [alarm-des] sampling-timer {
delta | absolute | changeratio } rising-threshold threshold-value1
event-entry1 falling-threshold threshold-value2 event-entry2 entrytype
{ forever | cycle cycle-period } [owner text]
```

```
undo rmon prialarm entry-number
```

## Parameters

<code>entry-number</code>	Specifies the entry number. Valid values are from 1 to 65535.
<code>alarm-var</code>	Specifies the alarm variable, which can be an arithmetic expression of several integer MIB node instances. The node can be OID in dotted notation.
<code>alarm-des</code>	Specifies the alarm description with a length ranging from 0 to 127 characters.
<code>sampling-timer</code>	Sets the sampling interval (in seconds). Valid values are 10 to 65535 seconds.
<code>delta   absolute   changeratio</code>	Specifies the sampling type as delta ratio or absolute ratio.
<code>threshold-value1</code>	Rising threshold value, specified with a number greater than 0.
<code>event-entry1</code>	Corresponding event number to the upper limit threshold value, ranging from 0 to 65535.
<code>threshold-value2</code>	Falling threshold value, specified with a number greater than 0.
<code>event-entry2</code>	Event number corresponding to the falling threshold, ranging from 0 to 65535.
<code>forever   cycle cycle-period</code>	Specifies the type of the alarm instance line.  <code>cycle-period</code> specifies the functional cycle of the instance.
<code>owner text</code>	Specifies the creator of the line. The length of the character string can be from 1 to 127 characters.

## Example

Delete line 10 from the extended RMON alarm table.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]undo rmon prialarm 10
[SW5500]
```

## View

This command can be used in the following views:

- System view

## Description

The number of instances can be created in the table depends on the hardware resource of the product.

# rmon statistics

---

- Purpose** Use the `rmon statistics` command to add an entry to the statistic table.
- Use the `undo rmon statistics` command to delete an entry from statistic table.
- Syntax**
- ```
rmon statistics entry-number [ owner text-string ]
```
- ```
undo rmon statistics entry-number
```
- Parameters**
- |                          |                                                                                           |
|--------------------------|-------------------------------------------------------------------------------------------|
| <i>entry-number</i>      | Number of the entry to be added/deleted. Valid values are 1 to 65535.                     |
| <i>owner text-string</i> | Creator of the entry. The length of the character string can be from 1 to 127 characters. |
- Example** Add the statistics of Ethernet 1/0/1 to entry 20 of the statistics table.
- ```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface Ethernet1/0/1
[SW5500-ethernet1/0/1]rmon statistics 20
[SW5500-ethernet1/0/1]
```
- View** This command can be used in the following views:
- Ethernet Port view
- Description** RMON statistic management concerns the statistics and monitoring of the usage and error on a port. Statistics includes collision, CRC (Cyclic Redundancy Check) and queue, undersized or oversized packet, timeout, fragment, broadcast, multicast, unicast, and bandwidth utility.

route-policy

Purpose

Use the `route-policy` command to create and enter the Route-policy view.

Use the `undo route-policy` command to delete the established Route-policy.

Syntax

```
route-policy route_policy_name { permit | deny } node { node_number }  
undo route-policy route_policy_name [ permit | deny | node node_number ]
```

Parameters

| | |
|--------------------------------|---|
| <code>route_policy_name</code> | Specifies a Route-policy name to identify one Route-policy uniquely. |
| <code>permit</code> | Specifies the match mode of the defined Route-policy node as permit mode. |
| <code>deny</code> | Specifies the match mode of the defined Route-policy node as deny mode. |
| <code>node</code> | Specifies the node of the route policy. |
| <code>node_number</code> | Specifies the index of the node in the route-policy. When this route-policy is used for routing information filtration, the node with smaller node-number will be tested first. |

Default

By default, no Route-policy is defined.

Example

Configured one Route-policy policy1, whose node number is 10 and if-match mode is permit, and enter Route policy view.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]route-policy policy permit node 10  
    % New sequence of this list  
[SW5500-route-policy]
```

View

This command can be used in the following views:

- System view

Description

The `route-policy` command is used for route information filtration or route policy. One Route-policy comprises some nodes and each node comprises some match and apply sub-statements. The match sub-statement defines the match rules of this node and the apply sub-statement defines the actions after passing the filtration of this node. The filtering relationship between the match sub-statements of the node is "and", that is, all match sub-statements that meet the node. The filtering relation between Route-policy nodes is "OR", that is, passing the filtering of one node means

passing the filtering of this Route-policy. If the information does not pass the filtration of any nodes, it cannot pass the filtration of this Route-policy.

Related Commands

- `if-match interface`
- `if-match { acl | ip-prefix }`
- `if-match ip next-hop`
- `if-match cost`
- `if-match tag`
- `apply cost`
- `apply tag`

router id

Purpose

Using the `router id` command, you can configure the ID of a router running the OSPF protocol.

Using the `undo router id` command, you can cancel the router ID that has been set.

Syntax

```
router id router_id
```

```
undo router id
```

Parameters

`router_id` Enter the router ID as a 32-bit unsigned integer.

Default

By default, if the LoopBack interface address exists, the system chooses the LoopBack address with the greatest IP address value as the router ID; if no LoopBack interface is configured, then the address of the physical interface with the greatest IP address value will be the router ID.

Example

To set the router ID to 10.1.1.3., enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]router id 10.1.1.3
```

View

This command can be used in the following views:

- System view

Description

The router ID is a 32-bit unsigned integer that uniquely identifies a router in an OSPF system. You can specify the ID for a router. If a router ID isn't specified, the router automatically selects one of the configured IP address as the router ID. If an IP address is not configured for any interface, the router ID must be configured in OSPF view. Otherwise, OSPF protocol cannot be enabled.

When the router ID is configured manually, the IDs of any two routers cannot be the same in the autonomous system. So, the IP address of one interface can be selected as the router ID.



The modified router ID will not be valid unless OSPF is re-enabled.

Related Command

`ospf`

rsa local-key-pair create

Purpose Use the **rsa local-key-pair create** command to generate RSA key pairs, whose names are in the format of switch name plus `_host`, `S5500_host` for example.

Syntax `rsa local-key-pair create`

Parameters None

Example Generate a local RSA key pair.

```
<S5500> system-view
[S5500] rsa local-key-pair create
The local-key-pair will be created.
The range of public key size is (512 ~ 2048).
NOTES: If the key modulus is greater than 512,
        It will take a few minutes.
Input the bits in the modulus[default = 512]:
Generating keys...
.....+++++++
.....+++++++
.....+++++++
.....+++++++
```

View This command can be used in the following views:

- System view

Description After you use the command, the system prompts you to define the key length.

- In SSH1.x, the key length is in the range of 512 to 2,048 (bits).
- In SSH 2.0, the key length is in the range of 1024 to 2048 (bits). To make SSH 1.x compatible, 512- to 2,048-bit keys are allowed on clients, but the length of server keys must be more than 1,024 bits. Otherwise, clients cannot be authenticated.



CAUTION:

- If you use this command to generate an RSA key provided an old one exists, the system will prompt you to replace the previous one or not.
- As a fabric contains multiple devices, you need to execute the **rsa local-key-pair create** command first to make sure all the devices in the fabric share one RSA local-key pair.

For a successful SSH login, you must generate the local RSA key pairs first. You just need to execute the command once, with no further action required even after the system is rebooted.

Related Commands ■ `display rsa local-key-pair public`

- `rsa local-key-pair destroy`

rsa local-key-pair destroy

| | |
|------------------------|---|
| Purpose | Use the rsa local-key-pair destroy command to destroy all existing RSA key pairs at the server end. |
| Syntax | rsa local-key-pair destroy |
| Parameters | None |
| Example | Destroy all existing RSA key pairs at the server end.

<pre><S5500> system-view [S5500] rsa local-key-pair destroy % The local-key-pair will be destroyed. % Confirm to destroy these keys? [Y/N]:Y</pre> |
| View | This command can be used in the following views: <ul style="list-style-type: none">■ System view |
| Related Command | rsa local-key-pair create |

rsa peer-public-key

Purpose Use the `rsa peer-public-key` command to enter the public key view.

Syntax `rsa peer-public-key key-name`

Parameters `key-name` Public key name.

Example To enter the public key view, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]rsa peer-public-key 3COM002
[SW5500-rsa-public-key]
```

View This command can be used in the following views:

- System view

Description When using this command together with the `public-key-code begin` command to configure the public key at the client, which is generated randomly by the client program supporting SSH1.5.

Related Commands

- `public-key-code begin`
- `public-key-code end`

rule

Purpose

Use the **rule** command to add a sub-rule to an ACL.

Use the **undo rule** command to cancel a sub-rule from an ACL.

Syntax

Define or delete the sub-rules of a basic ACL:

```
rule [ rule-id ] { permit | deny } [ source { source-addr wildcard | any }
fragment | time-range name ]*
```

```
undo rule rule-id [ source | fragment | time-range ]*
```

Define or delete the sub-rules of an advanced ACL:

```
rule [ rule-id ] { permit | deny } protocol [ source { source-addr
wildcard | any } ] [ destination { dest-addr wildcard | any } ] [
source-port operator port1 [ port2 ] ] [ destination-port operator
port1 [ port2 ] ] [ icmp-type type code ] [ established ] [ [ {
precedence precedence tos tos | dscp dscp ] [ vpn-instance instance |
fragment | time-range name ]*
```

```
undo rule rule-id [ source | destination | source-port |
destination-port | icmp-type | precedence | tos | dscp | fragment |
time-range | vpn-instance ]*
```

Define or delete the sub-rules of a Layer 2 ACL:

```
rule [ rule-id ] { permit | deny } [ [ type protocol-type type-mask |
lsap lsap-type type-mask ] | format-type | cos cos | source {
source-vlan-id | source-mac-addr source-mac-wildcard }* | dest {
dest-mac-addr dest-mac-wildcard } | time-range name ]*
```

```
undo rule rule-id
```

Define or cancel the sub-rules of user-defined ACL

```
rule [ rule-id ] { permit | deny } { rule-string rule-mask offset
}&<1-8> [ time-range name ]
```

```
undo rule rule-id
```

Parameters

| | |
|------------------------|---|
| rule-id | Specifies the sub-items of an ACL. Valid values are 0 to 65534. |
| permit | Permits packets that meet the requirements. |
| deny | Denies packets that meet the requirements. |
| time-range name | Name of a time range, during which a rule takes effect. |



The following parameters are various property parameters carried by packets. The ACL sets rules according to this parameter.

Parameters specific to basic ACLs:

| | |
|--|---|
| source { <i>source-addr</i>
<i>wildcard</i> <i>any</i> } | <i>source-addr wildcard</i> represents the source IP address and the wildcard digit represented in dotted decimal notation. <i>any</i> represents all source addresses. |
| fragment | Means this rule is only effective fragment packets and is ignored for non-fragment packets. |

Parameters specific to advanced ACLs:

| | |
|-----------------|--|
| protocol | Specifies the protocol type that is represented by a name or a number. When it is a name, this parameter can be any of the following: icmp, igmp, tcp, udp, ip, gre, ospf, or ipinip. If the adopted value is IP, that means all the Internet Protocols. When it is a number, it ranges from 1 to 225. |
|-----------------|--|

| | |
|--|---|
| source { <i>source-addr</i>
<i>wildcard</i> <i>any</i> } | <i>source-addr wildcard</i> means the source IP address and the wildcard digit represented in dotted decimal notation. <i>any</i> means all source addresses. |
|--|---|

| | |
|---|---|
| destination { <i>dest-addr</i>
<i>wildcard</i> <i>any</i> } | <i>dest-addr wildcard</i> means the destination IP address and the wildcard digit represented in dotted decimal notation. <i>any</i> means all destination addresses. |
|---|---|

| | |
|---|--|
| source-port operator port1
<i>[port2]</i> | Source port number of TCP or UDP used by the packet. <i>operator</i> is port operator, including eq (equal), gt (greater than), lt (less than), neq (not-equal), range (within this range). Note that this parameter is only available when the parameter <i>protocol</i> is TCP or UDP. <i>port1 [port2]</i> : Source port number of TCP or UDP used by the packet, notated by a character or a number which ranges from 0 to 65535 inclusive. For the value of the character, please refer to mnemonic symbol table. The two parameters <i>port1</i> and <i>port2</i> appear at the same time only when the operator is "range", but other operators need " <i>port1</i> " only. |
|---|--|

| | |
|--|--|
| destination-port operator
<i>port1 [port2]</i> | Destination port number of TCP or UDP used by packets. For detailed description, please refer to source-port operator <i>port1 [port2]</i> . |
|--|--|

| | |
|----------------------------|--|
| icmp-type type code | Appears when <i>protocol</i> is icmp. <i>type code</i> specifies an ICMP packet. <i>type</i> represents the type of ICMP packet, notated by a character or a number which ranges from 0 to 255; <i>code</i> represents ICMP code, which appears when the protocol is "icmp" and the type of packet is not notated by a character, ranging from 0 to 255. |
|----------------------------|--|

| | |
|--------------------|--|
| established | Means that it is only effective to the first SYN packet established by TCP, appears when <i>protocol</i> is TCP. |
|--------------------|--|

| | |
|-------------------------------------|---|
| precedence <i>precedence</i> | IP precedence. Valid values are any name or a number ranging from 0 to 7. |
| tos <i>tos</i> | ToS (Type of Service) value. Valid values are any name or a number ranging from 0 to 15. Packets can be classified according to TOS value. |
| dscp <i>dscp</i> | DSCP (Differentiated Services Code Point) value. Valid values are any name or a number ranging from 0 to 63. Packets can be classified according to DSCP value. |
| fragment | Means this rule is only effective for fragment packets and is ignored for non-fragment packets. |

Parameters specific to Layer 2 ACL:

| | |
|--|--|
| source { <i>source-vlan-id</i>
<i>source-mac-addr</i>
<i>source-mac-wildcard</i> }* | The source information of a packet, <i>source-vlan-id</i> represents source VLAN of the packet, <i>source-mac-addr</i> <i>source-mac-wildcard</i> represents source MAC address of the packet. For example, if you set <i>source-mac-wildcard</i> to 0-0-ffff, it means that you will take the last 16 bits of source MAC address as the rule of traffic classification. |
| dest { <i>dest-vlan-id</i>
<i>dest-mac-addr</i>
<i>dest-mac-wildcard</i> }* | The destination information of a packet: <i>dest-mac-addr</i> <i>dest-mac-wildcard</i> represents the packet's destination MAC address. For example, if you set <i>source-mac-wildcard</i> to 0-0-ffff, it means that you will take the last 16 bits of source MAC address as the rule of traffic classification. |
| type <i>protocol-type</i>
<i>protocol-type-mask</i> | Protocol type carried by the Ethernet frame. |
| lsap <i>lsap-type</i>
<i>lsap-type-mask</i> | Lsap type carried by the Ethernet frame. |

The parameter for user-defined ACL:

| | |
|---|---|
| { <i>rule-string</i> <i>rule-mask</i>
<i>offset</i> }&<1-8> | <i>rule-string</i> is a character string of a rule defined by a user ranging from 2 to 80 characters. It is a hexadecimal string with even digits. <i>rule-mask</i> <i>offset</i> is used to extract the packet information. Here, <i>rule-mask</i> is <i>rule mask</i> , used for logical AND operation with data packets, and <i>offset</i> determines to perform AND operation from which bytes apart from the packet header. <i>rule-mask</i> <i>offset</i> extracts a character string from the packet and compares it with the user-defined rule-string to get and process the matched packets. &<1-8> indicates that you can define up to 8 such rules at a time. This parameter is used for the user-defined ACL. |
|---|---|

Example

Add a sub-rule to an advanced ACL:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]acl number 3000
[SW5500-acl-adv-3000]rule 1 permit tcp established source 1.1.1.1 0
destination 2.2.2.2 0
```

Add a sub-rule to a basic ACL:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]acl number 2000
[SW5500-acl- basic-2000]rule 1 permit source 1.1.1.1 0 fragment
```

Add a sub-rule to a Layer 2 ACL:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]acl number 4000
[SW5500-acl-ethernetframe-4000] rule 1 permit source 1
```

Add a rule to a user-defined ACL:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]acl number 5000
[SW5500-acl-user-5000] rule 1 permit 88 ff 18
```

View

This command can be used in the following views:

- Corresponding ACL view

Description

You can define several sub-rules for an ACL. If you include parameters when using the **undo rule** command, the system only deletes the corresponding content of the sub-rule.

Related Command

acl

save

Purpose Use the **save** command to save the current configurations to a file in the flash memory.

Syntax `save [cfgfile | [safely] [backup | main]]`

| | | |
|-------------------|-----------------------|--|
| Parameters | <i>cfgfile</i> | Path name or file name of the configuration file in the flash memory to which the current configurations will be saved. Valid values are a character string from 5 to 56 characters long. |
| | <i>safely</i> | Safe mode. Saving the current configurations in this mode is relatively slow, but the configuration file still remains in the flash without being lost even if the switch restarts or powers down during the saving. |
| | <i>main</i> | Assigns the main attribute to the file. |
| | <i>backup</i> | Assigns the backup attribute to the file. |

Example Save the currently running configurations to the main configuration file to be used for next startup.

```
<S5500> save main
The configuration will be written to the device.
Are you sure? [Y/N] y
Please input the file name (*.cfg) (To leave the existing filename
unchanged press the enter key): 123.cfg
```

```
Now saving current configuration to the device.
Saving configuration. Please wait...
.....
Unit1 save configuration flash:/123.cfg successfully
Unit2 save configuration flash:/123.cfg successfully
```

```
<S5500>
%Apr 2 02:58:01:682 2000 S5500 CFM/3/CFM_LOG:- 1 -Unit1 save
configuration successfully.
%Apr 2 02:58:01:783 2000 S5500 CFM/3/CFM_LOG:- 1 -Unit2 save
configuration successfully.
```

Save the currently running configurations to the configuration file 234.cfg on unit 1.

```
<S5500> save unit1>flash:/234.cfg
The current configuration will be saved to unit1>flash:/234.cfg [Y/N]: y
Now saving current configuration to the device.
Saving configuration. Please wait...
.....
Unit1 save configuration unit1>flash:/234.cfg successfully
<S5500>
%Apr 2 04:07:21:805 2000 5500-EI CFM/3/CFM_LOG:- 1 -Unit1 save
configuration successfully.
```

View

This command can be used in the following views:

- Any view

Description

Executing the **save** command with neither **backup** nor **main** will assign the main attribute to the file to which the current configurations are saved.

The system provides two methods to save the current configurations.

- If the **safely** keyword is not used, the system saves the current configurations in fast mode. This mode is fast, but the configuration file may be lost if the switch restarts or powers down.
- If the **safely** keyword is used, the system saves the current configurations in safe mode. This mode is relatively slow, but the configuration file still remains in the flash memory without being lost even if the switch restarts or powers down during the saving.

The fast mode is recommended under the circumstances with stable power system, while the safe mode is recommended under the circumstances with bad power system or in the case of remote maintenance.



- *If the **cfgfile** argument is not specified, the system saves the current configurations to the configuration file used in this startup, or saves the current configurations with the default configuration file name if the default configurations are used in this startup.*
- *If multiple switches compose one fabric, executing the **save** command will make each unit in the fabric save its own current configurations.*
- *To ensure that the switch can use the current configurations after it restarts, you are recommended to save the current configurations by using the **save** command before restarting the switch.*
- *The current configurations will be saved in the same format as the display format.*

schedule reboot at

Purpose

Use the `schedule reboot at` command to enable the timing reboot function of the switch and set the specific reboot time and date.

Use the `undo schedule reboot` command to disable the timing reboot function.

Syntax

```
schedule reboot at hh:mm [ yyyy/mm/dd ]
```

```
undo schedule reboot
```

Parameters

hh:mm

Reboot time of the switch, in the format of "hour:minute." Valid values for hh are 0 to 23. Valid values for mm are 0 to 59.

yyyy/mm/dd

Reboot date of the switch, in the format of "year/month/day. Valid values for yyyy are 2000 to 2099. Valid values for mm are 1 to 12. The value of dd is related to the specific month.

Default

By default, the timing reboot switch function is disabled.

Example

Set the switch to be restarted at 22:00 that night (the current time is 15:50).

```
<SW5500>schedule reboot at 22:00
Reboot system at 22:00:00 2000/04/02 (in 19 hours and 47 minutes)
confirm? [Y/N]:y
%Apr  2 02:12:20:72 2000 3Com CMD/5/REBOOT:- 1 -
aux0: schedule reboot parameters at 02:12:20 2000/04/02. And system
will reboot at 22:00 2000/04/02.
<SW5500>
```

View

This command can be used in the following views:

- User view

Description

If the `schedule reboot at` command sets specified date parameters, which represents a data in the future, the switch will be restarted in specified time, with error not more than 1 minute.

If no specified date parameters are configured, two cases are involved: If the configured time is after the current time, the switch will be restarted at the time point of that day; if the configured time is before the current time, the switch will be restarted at the time point of the next day.

It should be noted that the configured date should not exceed the current date more than 30 days. In addition, after the command is configured, the system will prompt you to input confirmation information. Only after the "Y" or the "y" is entered can

the configuration be valid. If there is related configuration before, it will be covered directly.

After the **schedule reboot at** command is configured and the system time is adjusted by the **clock** command, the former configured **schedule reboot at** parameter will go invalid.

Related Commands

- **reboot**
- **display schedule reboot**
- **schedule reboot delay**

schedule reboot delay

Purpose

Use the `schedule reboot delay` command to enable the timing reboot switch function and set the waiting time.

Use the `undo schedule reboot` command to disable the timing reboot function.

Syntax

```
schedule reboot delay { hhh:mm | mmm }
```

```
undo schedule reboot
```

Parameters

hhh:mm

Waiting time for rebooting a switch, in the format of "hour: minute". Valid values for hhh are 0 to 720. Valid values for mm are 0 to 59.

mmm

Waiting delay for rebooting a switch, in the format of "absolute minutes". Valid values are 0 to 43200.

Default

By default, the timing reboot switch function is disabled.

Example

Configure the switch to be restarted after 88 minutes (the current time is 21:32).

```
<SW5500>schedule reboot delay 88
Reboot system at 03:41 2000/04/02 (in 1 hours and 28 minutes)
Confirm? [Y/N]:y
%Apr 2 02:13:10:09 2000 3Com CMD/5/REBOOT:- 1 -
aux0: schedule reboot parameters at 02:13:10 2000/04/02. And system
will reboot at 03:41 2000/04/02.
<SW5500>
```

View

This command can be used in the following views:

- User view

Description

Two formats can be used to set the waiting delay of timing reboot switch, namely the format of "hour: minute" and the format of "absolute minutes". But the total minutes should be no more than 30×24×60 minutes, or 30 days.

After this command is configured, the system will prompt you to input confirmation information. Only after the "Y" or the "y" is entered can the configuration be valid. If there is related configuration before, it will be covered directly.

After the `schedule reboot at` command is configured, and the system time is adjusted by the `clock` command, the original `schedule reboot at` parameter will become invalid.

Related Commands

- `display schedule reboot`

- `reboot`
- `schedule reboot at`
- `undo schedule reboot`

scheme

Purpose

Use the **scheme** command to configure the AAA scheme to be referenced by the current ISP domain.

Use the **undo scheme** command to restore the default AAA scheme.

Syntax

```
scheme { radius-scheme radius-scheme-name [ local ] | local | none }
undo scheme { radius-scheme | none }
```

Parameters

<i>radius-scheme-name</i>	RADIUS scheme, consisting of a character string from 1 to 32 characters long.
local	Local authentication.
none	No authentication.

Default

The default AAA scheme in the system is local.

Example

To specify the current ISP domain, 3Com163.net, to use the RADIUS scheme 3Com, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]domain marlboro.net
[SW5500-isp-marlboro.net]scheme radius-scheme 3Com
```

View

This command can be used in the following views:

- ISP Domain view

Description

With this command, the current ISP domain can reference a RADIUS scheme that has been configured. If the local or none scheme applies, no RADIUS scheme can be adopted.



*You can use either the **scheme** or **radius-scheme** command to specify the RADIUS scheme for an ISP domain. If both of these two commands are used, the latest configuration will take effect.*

Related Command

radius-scheme

screen-length

Purpose

Use the command **screen-length** to configure how many information lines (maximum) will be displayed on the screen of a terminal.

Use the command **undo screen-length** to restore the default of 24 lines.

Syntax

```
screen-length screen-length
```

```
undo screen-length
```

Parameters

screen-length

The maximum number of information lines that you can display on a terminal screen. Valid values are 0 to 512.

If not specified, the default is 24.

Example

To configure a terminal to display 20 lines of information, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]user-interface aux 0  
[SW5500-ui-aux0]screen-length 20
```

View

This command can be used in the following views:

- User Interface view

Description

To disable this function, that is to allow an unlimited number of information lines, enter the parameter as 0.

secondary accounting

Purpose	<p>Use the secondary accounting command to configure a secondary TACACS accounting server.</p> <p>Use the undo secondary accounting command to delete the configured secondary TACACS accounting server.</p>				
Syntax	<pre>secondary accounting ip-address [port] undo secondary accounting</pre>				
Parameters	<table><tr><td><i>ip-address</i></td><td>IP address of the server, a valid unicast address in dotted decimal format.</td></tr><tr><td><i>port</i></td><td>Port number of the server. Valid values are 1 to 65535. If not specified, the default is 49.</td></tr></table>	<i>ip-address</i>	IP address of the server, a valid unicast address in dotted decimal format.	<i>port</i>	Port number of the server. Valid values are 1 to 65535. If not specified, the default is 49.
<i>ip-address</i>	IP address of the server, a valid unicast address in dotted decimal format.				
<i>port</i>	Port number of the server. Valid values are 1 to 65535. If not specified, the default is 49.				
Default	By default, IP address of TACACS accounting server is all zeros.				
Example	<p>Configure a secondary accounting server.</p> <pre>[S5500] hwtacacs scheme test1 [S5500-hwtacacs-test1] secondary accounting 10.163.155.12 49</pre>				
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ HWTACACS view				
Description	<p>You are not allowed to assign the same IP address to both primary and secondary accounting servers.</p> <p>You can configure only one secondary accounting server in a HWTACACS scheme. If you repeatedly use this command, the latest configuration replaces the previous one.</p> <p>You can remove an accounting server only when it is not being used by any active TCP connections, and the removal impacts only packets forwarded afterwards.</p>				

secondary authentication

Purpose	<p>Use the secondary authentication command to configure a secondary TACACS authentication server.</p> <p>Use the undo secondary authentication command to delete the configured secondary authentication server.</p>				
Syntax	<pre>secondary authentication ip-address [port] undo secondary authentication</pre>				
Parameters	<table><tr><td><i>ip-address</i></td><td>IP address of the server, a valid unicast address in dotted decimal format.</td></tr><tr><td><i>port</i></td><td>Port number of the server. Valid values are 1 to 65535. If not specified, the default is 49.</td></tr></table>	<i>ip-address</i>	IP address of the server, a valid unicast address in dotted decimal format.	<i>port</i>	Port number of the server. Valid values are 1 to 65535. If not specified, the default is 49.
<i>ip-address</i>	IP address of the server, a valid unicast address in dotted decimal format.				
<i>port</i>	Port number of the server. Valid values are 1 to 65535. If not specified, the default is 49.				
Default	By default, IP address of TACACS authentication server is all zeros.				
Example	<p>Configure a secondary authentication server.</p> <pre>[S5500] hwtacacs scheme test1 [S5500-hwtacacs-test1] secondary authentication 10.163.155.13 49</pre>				
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ HWTACACS view				
Description	<p>You are not allowed to assign the same IP address to both primary and secondary authentication servers.</p> <p>You can configure only one primary authentication server in a HWTACACS scheme. If you repeatedly use this command, the latest configuration replaces the previous one.</p> <p>You can remove an authentication server only when it is not being used by any active TCP connections, and the removal impacts only packets forwarded afterwards.</p>				
Related Command	display hwtacacs				

secondary authorization

Purpose	Use the <code>secondary authorization</code> command to configure a secondary TACACS authorization server. Use the <code>undo secondary authorization</code> command to delete the configured secondary authorization server.				
Syntax	<pre>secondary authorization ip-address [port] undo secondary authorization</pre>				
Parameters	<table><tr><td><i>ip-address</i></td><td>IP address of the server, a legal unicast address in dotted decimal format.</td></tr><tr><td><i>port</i></td><td>Port number of the server. Valid values are 1 to 65535. If not specified, the default is 49.</td></tr></table>	<i>ip-address</i>	IP address of the server, a legal unicast address in dotted decimal format.	<i>port</i>	Port number of the server. Valid values are 1 to 65535. If not specified, the default is 49.
<i>ip-address</i>	IP address of the server, a legal unicast address in dotted decimal format.				
<i>port</i>	Port number of the server. Valid values are 1 to 65535. If not specified, the default is 49.				
Default	By default, IP address of TACACS authorization server is all zeros.				
Example	Configure the secondary authorization server. <pre>[S5500] hwtacacs scheme test1 [S5500-hwtacacs-test1] secondary authorization 10.163.155.13 49</pre>				
View	This command can be used in the following views: <ul style="list-style-type: none">■ HWTACACS view				
Description	<p>You are not allowed to assign the same IP address to both primary and secondary authorization servers.</p> <p>You can configure only one primary authorization server in a HWTACACS scheme. If you repeatedly use this command, the latest configuration replaces the previous one.</p> <p>You can remove an authorization server only when it is not being used by any active TCP connections, and the removal impacts only packets forwarded afterwards.</p>				
Related Command	<code>display hwtacacs</code>				

security-policy-server

Purpose Use the **security-policy-server** command to configure the IP address of a security policy server.

Use the **undo security-policy-server** command to remove the IP address configuration of a security policy server.

Syntax

```
security-policy-server ip-address  
undo security-policy-server [ ip-address | all ]
```

Parameters

<i>ip-address</i>	The IP address of security policy server.
<i>all</i>	The IP addresses of all the security policy servers.

Example Configure the IP address of the security policy server to be 192.168.0.1.

```
<S5500>system-view  
System View: return to User View with Ctrl+Z.  
[S5500] radius scheme S5500  
[S5500-radius-S5500] security-policy-server 192.168.0.1  
[S5500-radius-S5500] display current-configuration  
  
...  
  
radius scheme S5500  
primary authentication 1.1.11.29 1812  
secondary authentication 127.0.0.1 1645  
user-name-format without-domain  
security-policy-server 192.168.0.1
```

View This command can be used in the following views:

- RADIUS Scheme view

Description For each RADIUS scheme, a maximum of eight security policy servers with different IP addresses can be configured. While users are surfing the Internet, the switch will only respond to the session control packets sent from the authentication server and the security policy server.

self-service-url

Purpose Use the `self-service-url` command to either configure the self-service server URL or remove the self-service URL.

Syntax

```
self-service-url enable url-string
self-service-url disable
```

Parameters

`url-string` The URL address of the page used to change the user password on the self-service server, consisting of a string from 1 to 64 characters long. The string cannot contain "?" character. If "?" is contained in the URL address, you must replace it with "|" when inputting the URL address in the command line.

Default By default, self-service server URL is not configured on the Switch.

Example In the ISP domain "marlboro.net", configure the URL address of the page used to change the user password on the self-service server to `http://10.153.89.94/selfservice/modPasswd1x.jsp|userName`.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]domain marlboro.net
[SW5500-isp-marlboro.net] self-service-url enable
http://10.153.89.94/selfservice/modPasswd1x.jsp|userName
```

View This command can be used in the following views:

- ISP Domain view

Description This command must be incorporated with a RADIUS server (such as a CAMS server) that supports self-service. Self-service means that users can manage their accounts and card numbers by themselves. And a server with the self-service software is called a self-service server.

Once this function is enabled on the Switch, users can locate the self-service server and perform self-management through the following operations:

- Select "Change user password" on the 802.1x client.
- After the client opens the default explorer (IE or NetScape), locate the specified URL page used to change the user password on the self-service server.
- Change user password on this page.

The "Change user password" option is available only after the user passed the authentication; otherwise, this option is in grey and unavailable.

send

Purpose Use the **send** command to send messages to other user interfaces.

Syntax `send { all | number | type }`

Parameters	all	Sends a message to all user interfaces.
	number	Specifies the absolute/relative number of the interface that you want to send a message to.
	type	Specifies the type and type number of the user interface that you want to send a message to.

Example To send a message to all the user interfaces, enter the following:

```
<SW5500>send all
```

View This command can be used in the following views:

- User view

server-type

Purpose Use the **server-type** command to configure the RADIUS server type supported by the Switch.

Use the **undo server-type** to restore the RADIUS server type to the default value.

Syntax

```
server-type { 3com | standard }  
undo server-type
```

Parameters

3Com	Configures the Switch to support the extended RADIUS server type, which requires the RADIUS client end (Switch) and RADIUS server to interact according RADIUS extensions.
standard	Configures the Switch to support the RADIUS server of Standard type, which requires the RADIUS client end (Switch) and RADIUS server to interact according to the regulation and packet format of standard RADIUS protocol (RFC 2138/2139 or newer).

Default By default, the newly created RADIUS scheme supports the server of standard. type, while the "system" RADIUS scheme created by the system supports the server of 3Com type.

Example To set the RADIUS server type of RADIUS scheme, "3Com" to 3Com, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]radius scheme 3Com  
[SW5500-radius-3Com]server-type 3Com
```

View This command can be used in the following views:

- RADIUS Scheme view

Description The Switch 5500 supports standard RADIUS protocol and the extended RADIUS service platform independently developed by 3Com.

Related Command **radius-scheme**

service-type

Purpose

Use the command **service-type** to configure which level of command a user can access after login.

Use the command **undo service-type** to restore the default level of command (level 1).

Syntax

```
service-type { ftp [ ftp-directory directory ] | lan-access | {ssh | telnet | terminal }* [ level level ] }
```

```
undo service-type { ftp [ ftp-directory directory ] | lan-access | {ssh | telnet | terminal }* [ level level ] }
```

Parameters

telnet	Specifies user type as Telnet.
ssh	Specifies user type as SSH.
level level	Specifies the level of Telnet, SSH, or terminal users. Valid values for this argument are an integer from 0 to 3. If no value is specified, the default is 0.
ftp	Specifies the user type as ftp.
ftp-directory directory	Specifies the directory of ftp users. Valid values for directory are a character string up to 64 characters long.
lan-access	Specifies user type to lan-access, which mainly refers to Ethernet accessing users, 802.1x supplicants for example.
terminal	Authorizes the user to use the terminal service (login from the Console port).

Example

To allow a user **zbr** to configure commands a level 0 after login, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]local-user zbr
[SW5500-luser-zbr]service-type telnet level 0
```

To activate these settings, quit the system and login with the username **zbr**. Now only the commands at level 0 are listed on the terminal.

```
[SW5500]quit
<SW5500>?
User view commands:
  debugging      Debugging functions
  language-mode  Specify the language environment
  ping           Ping function
  quit           Exit from current command view
  super          Privilege current user a specified priority level
  telnet         Establish one TELNET connection
```

tracert	Trace route function
undo	Negate a command or set its default

View

This command can be used in the following views:

- Local User view

Description

Commands are classified into four levels, as follows:

- *0 - Visit level.* Users at this level have access to network diagnosis tools (such as ping and tracert), and the Telnet commands. A user at this level cannot save the configuration file.
- *1 - Monitoring level.* Users at this level can perform system maintenance, service fault diagnosis, and so on. A user at this level cannot save the configuration file.
- *2 - System level.* Users at this level can perform service configuration operations, including routing, and can enter commands that affect each network layer. Configuration level commands are used to provide direct network service to the user.
- *3 - Management level.* Users at this level can perform basic system operations, and can use file system commands, FTP commands, TFTP commands, XModem downloading commands, user management commands and level setting commands.

service-type

Purpose

Use the **service-type** command to configure a service type for a particular user.

Use the **undo service-type** command to cancel the specified service type for the user.

Syntax

```
service-type { ftp [ ftp-directory directory ] | lan-access | ssh |  
terminal | telnet [ level level ] ] | telnet [ level level ] ] }  
  
undo service-type { ftp [ ftp-directory ] | lan-access | telnet }
```

Parameters

telnet	Specifies user type as Telnet.
level level	Specifies the level of Telnet or SSH users. Valid values for the argument level are an integer in the range of 0 to 3. If not value is specified, the default is 0.
ftp	Specifies user type as ftp.
ftp-directory directory	Specifies the directory of ftp users, directory is a character string of up to 64 characters.
lan-access	Specifies user type to lan-access, which mainly refers to Ethernet accessing users, 802.1x supplicants for example.
ssh	Specifies user type as ssh.
terminal	Specifies user type as terminal, which refers to users who use the terminal service (login from the console port).

Example

To set to provide the lan-access service for the user JohnQ, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]local-user JohnQ  
[SW5500-luser-JohnQ]service-type lan-access
```

View

This command can be used in the following views:

- Local User view

Description

When you configure the service type ssh, Telnet or Terminal, note the following:

- When you configure a new service type for a user, the system adds the new service type to the existing one.

- You can set a user level when you configure a service type. If you set multiple service types and specify the user levels, only the last configured user level is valid. Service types do not have individual user levels.



*You can use either **level** or **service-type** commands to specify the level for a local user. If both of these commands are used, the latest configuration takes effect.*

service-type multicast

Purpose

Use the **service-type multicast** command to set the current VLAN as a multicast VLAN.

Use the **undo service-type multicast** command to cancel the multicast VLAN setting.

Syntax

```
service-type multicast
```

```
undo service-type multicast
```

Parameters

None

Default

By default, no VLAN is a multicast VLAN.

Example

Configure VLAN 2 as a multicast VLAN.

```
<S5500> system-view  
[S5500] vlan 2  
[S5500-vlan2] service-type multicast
```

View

This command can be used in the following views:

- VLAN view

Description

By configuring a multicast VLAN, adding corresponding switch ports to the multicast VLAN and enabling IGMP Snooping, you can make users in different VLANs share the same multicast VLAN. This saves bandwidth since multicast stream is transmitted only within the multicast VLAN, and also guarantees the security because the multicast VLAN is completely isolated from the user VLANs.



Note:

- You cannot set the isolate VLAN as a multicast VLAN.
- One user port can belong to only one multicast VLAN.
- The port connected to a user end can only be set as a hybrid port.
- A multicast member port must belong to the same multicast VLAN with the router port. Or else, it cannot receive multicast packets.
- When setting a multicast VLAN ID on the router port, you must define the port as a trunk port or a tag-carried hybrid port, or else no multicast member port in this multicast VLAN can receive multicast packets.
- If a multicast member port needs to receive multicast packets forwarded by the router port but the router port does not belong to any multicast VLAN, you should remove the multicast member port from its multicast VLAN, or else it cannot receive multicast packets.

set authentication password

Purpose

Use the `set authentication password` command to configure the password for local authentication.

Use the `undo set authentication password` command to cancel local authentication password.

Syntax

```
set authentication password { cipher | simple } password  
undo set authentication password
```

Parameters

<code>cipher</code>	Displays the password in encrypted text.
<code>simple</code>	Displays the password in plain text.
<code>password</code>	If the authentication is in the simple mode, the password must be in plain text. If the authentication is in the cipher mode, the password can be either in encrypted text or in plain text. If a plain text password is entered when cipher mode has been selected, the password will be displayed in the configuration settings as encrypted. A plain text password is a sequential character string of no more than 16 digits, for example, 3Com918. The length of an encrypted password must be 24 digits and in encrypted text, for example, _(TT8F]Y\5SQ=^Q'MAF4<1!!.

Default

The password in plain text is required when performing authentication, regardless of whether the configuration is plain text or cipher text.

By default, a password is required for users connecting over Modem or Telnet. If a password has not been set, the following prompt is displayed: `Login password has not been set!`

Example

To configure the local authentication password on VTY 0 to 3Com, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]user-interface vty 0  
[SW5500-ui-vty0]set authentication password simple 3com
```

View

This command can be used in the following views:

- User Interface view

set unit name

Purpose You can use this command to set a name for a device.

Syntax `set unit unit-id name unit-name`

Parameters

<code><i>unit-id</i></code>	Unit ID of a device.
<code><i>unit-name</i></code>	Unit name of a device, consisting of a string 0 to 64 characters long.

Example To set the name "hello" for the device with unit ID 1, enter the following:

```
<SW5500>display xrn-fabric
Fabric name is SW5500, system mode is L3.
Fabric authentication: no authentication, unit number: 1.
Unit Name      Unit ID
First          1(*)
Second         2
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]set unit 1 name hello
Changing unit name! Please wait.....
[SW5500]quit
<SW5500>
<SW5500>display xrn-fabric
Fabric name is SW5500, system mode is L3.
Fabric authentication: no authentication, unit number: 1.
Unit Name      Unit ID
Hello          1(*)
Second         2
```

View This command can be used in the following views:

- System view

sftp

Purpose

Use the **sftp** command to establish a connection to the SFTP server and enter SFTP client view.

Syntax

```
sftp { host-ip | host-name } [ port-num ] [ prefer_kex { dh_group1 |
dh_exchange_group } ] [ prefer_ctos_cipher { des | aes128 } ] [
prefer_stoc_cipher { des | aes128 } ] [ prefer_ctos_hmac { sha1 |
sha1_96 | md5 | md5_96 } ] [ prefer_stoc_hmac { sha1 | sha1_96 | md5 |
md5_96 } ]
```

Parameters

<i>host-ip</i>	IP address of the server.
<i>host-name</i>	Name of the server, consisting of a string from 1 to 20 characters long.
<i>port-num</i>	Port number of the server. Valid values are 0 to 65,535. If not specified, the default port number is 22.
<i>prefer_kex</i>	Key exchange algorithm preference. Choose one of the two algorithms available.
<i>dh_group1</i>	Diffie-Hellman-group1-sha1 key exchange algorithm. It is the default key exchange algorithm.
<i>dh_exchange_group</i>	Diffie-Hellman-group-exchange-sha1 key exchange algorithm.
<i>prefer_ctos_cipher</i>	Encryption algorithm preference from the client to server. It defaults to AES128.
<i>prefer_stoc_cipher</i>	Encryption algorithm preference from the server to client. It defaults to AES128.
<i>des</i>	DES_cbc encryption algorithm.
<i>aes128</i>	AES_128 encryption algorithm.
<i>prefer_ctos_hmac</i>	HMAC algorithm preference from the client to server. It defaults to SHA1_96.
<i>prefer_stoc_hmac</i>	HMAC algorithm preference from the server to client. It defaults to SHA1_96.
<i>sha1</i>	HMAC-SHA1 algorithm.
<i>sha1_96</i>	HMAC-SHA1_96 algorithm.
<i>md5</i>	HMAC-MD5 algorithm.
<i>md5_96</i>	HMAC-MD5-96 algorithm.

Example

Establish a connection to the SFTP server with IP address 10.1.1.2 and use the default encryption algorithms.

```
[S5500] sftp 10.1.1.2
```


View

This command can be used in the following views:

- System view

sftp server enable

Purpose Use the `sftp server enable` command to enable the secure FTP (SFTP) server.
Use the `undo sftp server enable` command to disable the SFTP server.

Syntax

```
sftp server enable
undo sftp server
```

Parameters None

Default By default, the SFTP server is disabled.

Example Enable the SFTP server.

```
<S5500> system-view
[S5500] sftp server enable
```

Disable the SFTP server.

```
[S5500] undo sftp server
```

View This command can be used in the following views:

- System view

sftp source-interface

Purpose

Use the **sftp source-interface** command to specify source interface for the SFTP client.

Use the **undo sftp source-interface** command to clear the source interface configuration. After that, the source address in the packets sent to the SFTP server is determined by the system.

Syntax

```
sftp source-interface interface-type interface-number
```

```
undo sftp source-interface
```

Parameters

interface-type Source interface type. If you specify a nonexistent interface in the command, your configuration fails.

interface-number Source interface number.

Example

Specify source interface for the SFTP client.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] sftp source-interface Vlan-interface 2
```

View

This command can be used in the following views:

- System view

sftp source-ip

Purpose

Use the **sftp source-ip** command to specify source IP address for the SFTP client.

Use the **undo sftp source-ip** command to clear the source IP address configuration. After that, the source address in the packets sent to the SFTP server is determined by the system.

Syntax

```
sftp source-ip ip-addr
```

```
undo sftp source-ip
```

Parameters

ip-addr

Source IP address. If the *ip-addr* in the command is not an address of the device, your configuration fails.

Example

Specify source IP address for the SFTP client.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] sftp source-ip 192.168.0.1
```

View

This command can be used in the following views:

- System view

sftp time-out

Purpose

Use the **sftp time-out** command to set the timeout time for the SFTP user connection.

Use the **undo sftp time-out** command to restore the default timeout time.

Syntax

```
sftp time-out time-out-value
```

```
undo sftp time-out
```

Parameters

time-out-value

Timeout time. Valid values are 1 to 35,791 minutes.
If not specified, the default is 0 minutes.

Example

Set the timeout time for the SFTP user connection to 500 minutes.

```
<S5500> system-view  
[S5500] sftp time-out 500
```

View

This command can be used in the following views:

- System view

Description

After you set the timeout time for the SFTP user connection, the system will automatically release the connection when the time is up.

shell

Purpose

Use the **shell** command to enable the terminal service for a user interface. The terminal service is enabled by default.

Use the **undo shell** command to disable the terminal service for a user interface.

Syntax

```
shell
```

```
undo shell
```

Parameters

None

Example

To disable the terminal service on the VTY user interfaces 0 to 4, enter the following from another user interface:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]user-interface vty 0 4  
[SW5500-ui-vty0-4]undo shell
```

View

This command can be used in the following views:

- User Interface view

Description

When using the **undo shell** command, note the following points.

- For reasons of security, the **undo shell** command can only be used on user interfaces other than the AUX User Interface.
- You cannot use this command on the current user interface.

You are asked to confirm the command.

shutdown

Purpose Use the **shutdown** command to shut down the specified MSDP peer.

Use the **undo shutdown** command to remove the configuration.

Syntax `shutdown peer-address`

`undo shutdown peer-address`

Parameters `peer-address` IP address of an MSDP peer.

Default By default, no MSDP peer is shut down.

Example Shut down the MSDP peer 125.10.7.6.

```
<S5500> system-view
[S5500] msdp
[S5500-msdp] shutdown 125.10.7.6
```

View This command can be used in the following views:

- MSDP view

Related Command `peer`

silent-interface

Purpose

Using the **silent-interface** command, you can prevent an interface from transmitting OSPF packets.

Using the **undo silent-interface** command, you can restore the default setting. By default, the interface transmits OSPF packets.

Syntax

```
silent-interface silent-interface_type silent-interface_number
```

```
undo silent-interface silent-interface_type silent-interface_number
```

Parameters

silent-interface_type Specifies the interface type.

silent-interface_number Specifies the interface number.

Example

To stop interface Vlan-interface 2 from transmitting OSPF packets, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]silent-interface Vlan-interface 2
```

View

This command can be used in the following views:

- OSPF view

Description

You can use this command to stop the transmission of OSPF packets on an interface. This prevents the router on some network from receiving the OSPF routing information. On a Switch, this command can disable/enable the specified VLAN interface to send OSPF packets.

snmp-agent community

Purpose

Use the `snmp-agent community` command to set the community access name and enable access to SNMP.

Use the `undo snmp-agent community` command to cancel the settings of community access name.

Syntax

```
snmp-agent community { read | write } community-name [ mib-view  
view-name ] [ acl acl-list ] ]
```

```
undo snmp-agent community community-name
```

Parameters

<code>read</code>	Indicates that MIB object can only be read.
<code>write</code>	Indicates that MIB object can be read and written.
<code>community-name</code>	Community name character string.
<code>view-name</code>	MIB view name.
<code>acl acl-list</code>	Sets access control list for specified community.

Example

Configure community name as `comaccess` and with read-only access permission.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]snmp-agent community read comaccess  
[SW5500]
```

Configure community name as `mgr` and read-write access permission.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]snmp-agent community write mgr  
[SW5500]
```

Delete the community name `comaccess`.

```
[SW5500]undo snmp-agent community comaccess
```

View

This command can be used in the following views:

- System view

snmp-agent group

Purpose

Using the `snmp-agent group` command, you can configure a new SNMP group and reference the ACL to perform ACL control to the network management users by `acl acl-number`.

Using the `undo snmp-agent group` command, you can remove a specified SNMP group.

Syntax

```
snmp-agent group { v1 | v2c } group-name [ read-view read-view ] [
write-view write-view ] [ notify-view notify-view ] [acl acl-number]
```

```
undo snmp-agent group { v1 | v2c } group-name
```

```
snmp-agent group v3 group-name [ authentication | privacy ] [ read-view
read-view ] [ write-view write-view ] [ notify-view notify-view ] [ acl
acl-number ]
```

```
undo snmp-agent group v3 group-name [ authentication | privacy ]
```

Parameters

<code>v1</code>	V1 security mode.
<code>v2c</code>	V2c security mode.
<code>v3</code>	V3 security mode.
<code>groupname</code>	Group name. Valid values are 1 to 32 bytes.
<code>authentication</code>	If this parameter is added to configuration command, the system will authenticate but not encrypt SNMP data packets.
<code>privacy</code>	Authenticates and encrypts the packets.
<code>read-view</code>	Sets read-only view.
<code>read-view</code>	Read-only view name. Valid values are 1 to 32 bytes.
<code>write-view</code>	Sets read-write view.
<code>write-view</code>	Read-write view name. Valid values are 1 to 32 bytes.
<code>notify-view</code>	Sets notify view.
<code>notify-view</code>	Notify view name. Valid values are 1 to 32 bytes.
<code>acl acl-number</code>	The number identifier of basic number-based ACLs. Valid values are 2000 to 2999.

Example

Creates a new SNMP group: MyCompany, and reference the ACL 2001 to perform ACL control to the network management users (basic ACL 2001 has already been defined).

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]snmp-agent group v1 MyCompany acl 2001
[SW5500]
```

View

This command can be used in the following views:

- System view

snmp-agent group

Purpose

Use the `snmp-agent group` command to configure a new SNMP group, that is, map an SNMP user to SNMP view.

Use the `undo snmp-agent group` command to delete a specified SNMP group.

Syntax

```
snmp-agent group { v1 | v2c } group-name [ read-view read-view ] [
write-view write-view ] [ notify-view notify-view ] [ acl acl-list ]

undo snmp-agent group { v1 | v2c } group-name

snmp-agent group v3 group-name [ authentication | privacy ] [ read-view
read-view ] [ write-view write-view ] [ notify-view notify-view ] [ acl
acl-list ]

undo snmp-agent group v3 group-name [ authentication | privacy ]
```

Parameters

<i>group-name</i>	A group name, up to 32 characters in length.
<i>authentication</i>	Specifies that the packet is authenticated without encryption.
<i>privacy</i>	Specifies that the packet is authenticated and encrypted.
<i>read-view</i>	Configures read-only view settings.
<i>read-view</i>	A read-only view name, up to 32 characters in length.
<i>write-view</i>	Configures read and write view settings.
<i>write-view</i>	A read and write view name, up to 32 characters in length.
<i>notify-view</i>	Configures notify view settings.
<i>notify-view</i>	A notify view name, up to 32 characters in length.
<i>acl acl-list</i>	The access control list for this group name.
<i>v3</i>	Configures SNMP version 3.

Example

To create an SNMP group named 3Com, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]snmp-agent group v3 3Com
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

3Com recommends that you do not use the **notify-view** parameter when configuring an SNMP group, for the following reasons:

- The **snmp-agent target-host** command automatically generates a *notify-view* for a user, and adds it to the corresponding group.
- Any change of the SNMP group *notify-view* will affect all the users related to this group.

snmp-agent local-engineid

Purpose

Use the `snmp-agent local-engineid` command to configure a name for a local or remote SNMP engine on the Switch.

Use the `undo snmp-agent local-engineid` command to restore the default setting of engine ID.

Syntax

```
snmp-agent local-engineid engineid
```

```
undo snmp-agent local-engineid
```

Parameters

`local-engineid`

Specifies an engineID for the local SNMPv3 entity.

`engineid`

Specifies the engine ID with a character string, only composed of hexadecimal numbers between 5 and 32 inclusive. The default value is "Enterprise Number + device information".

Example

Configure the ID of a local or remote device as 1234512345.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
<SW5500>snmp-agent local-engineid 1234512345
<SW5500>
```

View

This command can be used in the following views:

- System view

Description

Device information is determined according to different products. It can be IP address, MAC address or user defined text. However, you must use numbers in hexadecimal form.

snmp-agent log

Purpose

Use the **snmp-agent log** command to enable the network management operation logging function.

Use the **undo snmp-agent log** command to disable the network management operation logging function.

Syntax

```
snmp-agent log { set-operation | get-operation | all }
```

```
undo snmp-agent log { set-operation | get-operation | all }
```

Parameters

set-operation	Logs the set operations performed by the network administrator.
get-operation	Logs the get operations performed by the network administrator.
all	Logs both the get and set operations performed by the network administrator.

Default

By default, the network management operation logging function is disabled.

Example

Enable the network management operation logging function.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] snmp-agent log all
```

View

This command can be used in the following views:

- System view

Description



- *In a network that contains no fabric, you can use the **display logbuffer** command to view the logs of the **get** and **set** operations performed by the network administrator.*
- *As for a fabric, you can execute the **display logbuffer** command on the master device to view the logs of the **set** operations performed by the network administrator, and execute the **display logbuffer** command on the devices to which the **get** operations are performed to view the logs of corresponding **get** operations.*

snmp-agent mib-view

Purpose Use the `snmp-agent mib-view` command to create or update the view information.

Use the `undo snmp-agent mib-view` command to delete the view information

Syntax

```
snmp-agent mib-view { included | excluded } view-name oid-tree
undo snmp-agent mib-view view-name
```

Parameters	<code>included</code>	Includes this MIB subtree.
	<code>excluded</code>	Excludes this MIB subtree.
	<code>view-name</code>	Specifies the view name, consisting of a character string from 1 to 32 characters long.
	<code>oid-tree</code>	MIB object subtree. It can be a character string of the variable OID, or a variable name, consisting of a character string from 1 to 255 characters long.

Default By default, the view name is v1default. OID is 1.3.6.1.

Example Create a view that consists of all the objects of MIB-II.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]snmp-agent mib-view included mib2 1.3.6.1.3
[SW5500]
```

View This command can be used in the following views:

- System view

Description Both the character string of OID and the node name can be input as parameter.

snmp-agent packet max-size

Purpose

Use the `snmp-agent packet max-size` command to configure the size of SNMP packet that the Agent can send/receive.

Use the `undo snmp-agent packet max-size` command to restore the default size of SNMP packet.

Syntax

```
snmp-agent packet max-size byte-count
```

```
undo snmp-agent packet max-size
```

Parameters

byte-count

Specifies the size of SNMP packet (measured in bytes).
Valid values are 484 to 17940 bytes.
If not specified, the default size is 1500 bytes.

Example

Set the size of SNMP packet to 1042 bytes.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]snmp-agent packet max-size 1042  
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

The sizes of the SNMP packets received/sent by the Agent are different in different network environments.

snmp-agent sys-info

Purpose

Use the `snmp-agent sys-info` command to set system information such as geographical location of the device, contact information for system maintenance and version information of running SNMP.

Use the `undo snmp-agent sys-info location` command to restore the default value.

Syntax

```
snmp-agent sys-info { contact sysContact | location sysLocation |
version { { v1 | v2c | v3 } * | all } }
```

```
undo snmp-agent sys-info [ { contact | location } * | version { { v1 |
v2c | v3 } * | all } ]
```

Parameters

<i>sysContact</i>	A character string describing the system maintenance contact. Valid values are 1 to 255 characters long. If not specified, the default contact information is "3Com Marlborough USA".
<i>sysLocation</i>	A character string to describe the system location. If not specified, the default character string is "Marlborough USA".
<i>version</i>	Version of running SNMP.
<i>v1</i>	SNMP V1.
<i>v2c</i>	SNMP V2C.
<i>v3</i>	SNMP V3.
<i>all</i>	All SNMP version (includes SNMP V1, SNMP V2C, SNMP V3).

Example

Set system location as Building 3/Room 214.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]snmp-agent sys-info location Building 3/Room 214
[SW5500]
```

View

This command can be used in the following views:

- System view

snmp-agent target-host

Purpose

Use the `snmp-agent target-host` command to select and configure the host that you want to receive SNMP notification.

Use the `undo snmp-agent target-host` command to cancel the host currently configured to receive SNMP notification.

Syntax

```
snmp-agent target-host trap address udp-domain host-addr [ udp-port  
udp-port-number ] params securityname community-string [ v1 | v2c | v3  
[ authentication | privacy ] ]
```

```
undo snmp-agent target-host host-addr securityname community-string
```

Parameters

<code>trap</code>	Specifies the host to receive traps or notifications.
<code>address</code>	Specifies the transport address to be used in the generation of SNMP messages.
<code>udp-domain</code>	Specifies the transport domain over UDP for the target address.
<code>host-addr</code>	Specifies the IP address of the destination host.
<code>udp-port udp-port-number</code>	Specifies the UDP port number of the host to receive the SNMP notification.
<code>params</code>	Specifies the SNMP target information to be used in the generation of SNMP messages.
<code>community-string</code>	Specifies the community name, up to 32 characters in length.
<code>v1</code>	Specifies SNMP version 1.
<code>v2c</code>	Specifies SNMP version 2C.
<code>v3</code>	Specifies SNMP version 3.
<code>authentication</code>	Specifies that the packet is authenticated without encryption.
<code>privacy</code>	Specifies that the packet is authenticated and encrypted.

Example

To enable Trap messages to be sent to 2.2.2.2 with a community name of `comaccess`, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]snmp-agent trap enable  
[SW5500]snmp-agent target-host trap address udp-domain 2.2.2.2 params  
securityname comaccess  
[SW5500]
```

To enable Trap messages to be sent to 2.2.2.2 with a community name of **public**, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]snmp-agent trap enable
[SW5500]snmp-agent target-host trap address udp-domain 2.2.2.2 params
securityname public
[SW5500]
```

View

This command can be used in the following views:

- System view

Related Command

snmp-agent trap enable

snmp-agent trap enable

Purpose

Use the `snmp-agent trap enable` command to enable the device to send Trap message.

Use the `undo snmp-agent trap enable` command to disable Trap message sending.

Syntax

```
snmp-agent trap enable [ configuration | flash | ospf [ process-id ] [ ospf-trap-list ] | standard [ authentication | coldstart | linkdown | linkup | warmstart ]* | system ]
```

```
undo snmp-agent trap enable [ bgp [ backwardtransition ] [ established ] | configuration | flash | ospf [ process-id ] [ ospf-trap-list ] | standard [ authentication | coldstart | linkdown | linkup | warmstart ]* | system ]
```

Parameters

<code>configuration</code>	Configure to send SNMP configuration Trap packets.
<code>flash</code>	Configure to send SNMP flash Trap packets.
<code>ospf [<i>process-id</i>] [<i>ospf-trap-list</i>]</code>	Configure to send the OSPF trap packets. <i>process-id</i> is the ID of the OSPF process, ranging from 1 to 65535. <i>ospf-trap-list</i> is the list of OSPF trap information.
<code>standard [authentication coldstart linkdown linkup warmstart]*</code>	Configure to send standard Trap messages.
<code>authentication</code>	Configure to send SNMP authentication Trap messages when authentication fails.
<code>coldstart</code>	Configure to send SNMP cold start Trap messages when switch is rebooted.
<code>linkdown</code>	Configure to send SNMP link down Trap messages when switch port turns down.
<code>linkup</code>	Configure to send SNMP link up Trap messages when switch port turns up.
<code>warmstart</code>	Configure to send SNMP warm start Trap messages when snmp is re-enabled.
<code>system</code>	Configure to send SysMib trap messages.

Default

By default, Trap message sending is disabled.

Example

Enable to send the trap packet of SNMP authentication failure to 10.1.1.1. The community name is 3Com.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]snmp-agent trap enable standard authentication
[SW5500]snmp-agent target-host trap address udp-domain 10.1.1.1 param
securityname 3Com
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

The **snmp-agent trap enable** command and the **snmp-agent target-host** command should be used at the same time. The **snmp-agent target-host** command specifies which hosts can receive Trap message. To send Trap messages, at least one **snmp-agent target-host** command should be configured.

snmp-agent trap enable ospf

Purpose

Use the `snmp-agent trap enable ospf` command to enable the OSPF TRAP function.

Use the `undo snmp-agent trap enable ospf` command to disable the OSPF TRAP function.

Syntax

```
snmp-agent trap enable ospf [ process-id ] [ ifstatechange |  
virifstatechange | nbrstatechange | virnbrstatechange | ifcfgerror |  
virifcfgerror | ifauthfail | virifauthfail | ifrxbadpkt | virifrxbadpkt  
| txretransmit | viriftxretransmit | originatelsa | maxagelsa |  
lsdoverflow | lsdapproachoverflow ]
```

```
undo snmp-agent trap enable ospf [ process-id ] [ ifstatechange |  
virifstatechange | nbrstatechange | virnbrstatechange | ifcfgerror |  
virifcfgerror | ifauthfail | virifauthfail | ifrxbadpkt | virifrxbadpkt  
| txretransmit | viriftxretransmit | originatelsa | maxagelsa |  
lsdoverflow | lsdapproachoverflow ]
```

Parameters

process-id

The process ID of OSPF. The command is applied to all current OSPF processes if you do not specify a process ID.

ifstatechange,
virifstatechange,
nbrstatechange,
virnbrstatechange,
ifcfgerror, virifcfgerror,
ifauthfail, virifauthfail,
ifrxbadpkt, virifrxbadpkt,
txretransmit,
viriftxretransmit,
originatelsa, maxagelsa,
lsdoverflow,
lsdapproachoverflow

Types of TRAP packets that the switch produces in case of OSPF anomalies.

Default

By default, the switch does not send TRAP packets in case of OSPF anomalies.

Example

Enable the TRAP function for OSPF process 100.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]snmp-agent trap enable ospf 100
```

View

This command can be used in the following views:

- System view

Description

This command cannot be applied to the OSPF processes that are started after the command is executed.

snmp-agent trap life

Purpose

Use the `snmp-agent trap life` command to set the timeout of Trap packets.

Use the `undo snmp-agent trap life` command to restore the default value.

Syntax

```
snmp-agent trap life seconds
```

```
undo snmp-agent trap life
```

Parameters

seconds

Specifies the timeouts. Valid values are 1 to 2592000 seconds.

If not specified, the default timeout interval is 120 seconds.

Example

Configure the timeout interval of Trap packet as 60 seconds.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]snmp-agent trap life 60  
[SW5500]
```

View

This command can be used in the following views:

- System view

Description

The set timeout of Trap packet is represented by *seconds*. If time exceeds *seconds*, this Trap packet will be discarded.

Related Commands

- `snmp-agent trap enable`
- `snmp-agent target-host`

snmp-agent trap queue-size

Purpose

Use the `snmp-agent trap queue-size` command to configure the information queue length of Trap packet sent to destination host.

Use the `undo snmp-agent trap queue-size` command to restore the default value.

Syntax

```
snmp-agent trap queue-size length
```

```
undo snmp-agent trap queue-size
```

Parameters

length

Length of queue. Valid values are 1 to 1000.
If not specified, the default length is 100.

Example

Configure the queue length to 200.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]snmp-agent trap queue-size 200
[SW5500]
```

View

This command can be used in the following views:

- System view

Related Commands

- `snmp-agent trap enable`
- `snmp-agent trap life`

snmp-agent trap source

Purpose

Use the `snmp-agent trap source` command to specify the source address for sending Traps.

Use the `undo snmp-agent trap source` command to cancel the source address for sending Traps.

Syntax

```
snmp-agent trap source vlan-interface vlan-id
```

```
undo snmp-agent trap source
```

Parameters

vlan-id

Specifies the VLAN interface ID. Valid values are 1 to 4094.

Example

Configure the IP address of the VLAN interface 1 as the source address for transmitting the Trap packets.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]snmp-agent trap source vlan-interface 1  
[SW5500]
```

View

This command can be used in the following views:

- System view

snmp-agent usm-user

Purpose

Use the `snmp-agent usm-user` command to add a new user to an SNMP group, and reference the ACL to perform ACL control to the network management users by acl-number.

Use the `undo snmp-agent usm-user` command to remove the user from the related SNMP group as well as the configuration of the ACL control of the user.

Syntax

For Versions V1 and V2C:

```
snmp-agent usm-user { v1 | v2c } user-name group-name [ acl acl-number ]
```

```
undo snmp-agent usm-user { v1 | v2c } user-name group-name
```

For Version V3:

```
snmp-agent usm-user v3 user-name group-name [ authentication-mode { md5 | sha } auth-password ] [ acl acl-number ]
```

```
undo snmp-agent usm-user v3 user-name group-name { local | engineid engineid-string }
```

Parameters

<code>v1</code>	V 1 security mode.
<code>v2c</code>	V 2 security mode.
<code>v3</code>	V 3 security mode.
<code>user-name</code>	The user name. Valid values are from 1 to 32 bytes.
<code>group-name</code>	The corresponding group name of the user. Valid values are from 1 to 32 bytes.
<code>authentication-mode</code>	Specifies the security level to "to be authenticated"
<code>md5</code>	Specifies the authentication protocol as HMAC-MD5-96.
<code>sha</code>	Specifies the authentication protocol as HMAC-SHA-96.
<code>auth-password</code>	Authentication password, consisting of a character string from 1 to 64 bytes.
<code>privacy</code>	Specifies the security level as encryption.
<code>des56</code>	Specifies the DES encryption protocol.
<code>priv-password</code>	Encryption password, character string, ranging from 1 to 64 bytes.
<code>acl acl-number</code>	The number identifier of basic number-based ACLs, ranging from 2000 to 2999.
<code>local</code>	Local entity user.

engineid	Specifies the engine ID related to the user.
engineid-string	Engine ID character string.

Example

Add a user "John" to the SNMP group "Mygroup". Specify the security level to "to be authenticated", the authentication protocol to HMAC-MD5-96 and the authentication password to "hello", and reference the ACL 2002 to perform ACL control to the network management users (basic ACL 2002 has already been defined).

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500] snmp-agent usm-user v3 John Mygroup authentication-mode md5
hello acl 2002
```

View

This command can be used in the following views:

- System view

snmp-agent usm-user

Purpose

Use the `snmp-agent usm-user` command to add a new community name or, if you use the V3 parameter, a new user to an SNMP group.

Use the `undo snmp-agent usm-user` command to delete a user from an SNMP group.

Syntax

```
snmp-agent usm-user { v1 | v2c } username groupname [ acl acl-list ]
undo snmp-agent usm-user { v1 | v2c } username groupname

snmp-agent usm-user v3 username groupname [ authentication-mode { md5 | sha } authpassstring [ privacy-mode { des56 privpassstring }]]
[ acl acl-list ]

undo snmp-agent usm-user v3 username groupname { local | engineid engine-id }
```

Parameters

username	Specifies the user name, consisting of a character string from 1 to 32 characters in length.
groupname	Specifies the group name corresponding to that user, consisting of a character string from 1 to 32 characters in length.
v1	Specifies the use of V1 safe mode.
v2c	Specifies the use of V2c safe mode.
v3	Specifies the use of V3 safe mode.
authentication-mode	Specifies the use of authentication.
md5	Specifies that the MD5 algorithm is used in authentication. MD5 authentication uses a 128-bit password. The computation speed of MD5 is faster than that of SHA.
sha	Specifies that the SHA algorithm is used in authentication. SHA authentication uses a 160-bit password. The computation speed of SHA is slower than that of MD5, but SHA offers higher security.
authpassstring	Enter the authentication password, up to 64 characters in length.
privacy-mode	Specifies the use of authentication and encryption.
des 56	Specifies that the DES encryption algorithm is used. Must be entered if you enter the privacy-mode parameter.
privpassstring	Specifies the encryption password with a character string from 1 to 64 bytes.
acl acl-list	Specifies the access control list for this user, based on USM name.

Example

To add a user named "JohnQ" to the SNMP group "3Com", then configure the use of MD5, and set the authentication password to "pass", enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]snmp-agent usm-user v3 JohnQ 3Com authentication-mode md5 pass
[SW5500]
```

View

This command can be used in the following views:

- System view

Description



SNMP engineID (for authentication) is required when configuring remote users. This command will not be effective if engineID is not configured.

For V1 and V2C, this command will add a new community name. For V3, it will add a new user for an SNMP group. See Related Commands below.

Related Commands

- `display snmp-agent`
- `snmp-agent usm-user`

snmp-host

Purpose

Use the **snmp-host** command to configure the public SNMP host for members inside a cluster on the management device.

Use the **undo snmp-host** command to cancel the public SNMP host configuration.

Syntax

```
snmp-host ip-address
```

```
undo snmp-host
```

Parameters

ip-address

IP address of the SNMP host configured for the cluster.

Default

By default, no public SNMP host is configured.

Example

Configure the IP address of SNMP host for the cluster on the management device.

```
<aaa_0.S5500>system-view  
System View: return to User View with Ctrl+Z.  
[aaa_0.S5500]cluster  
[aaa_0.S5500-cluster] snmp-host 1.0.0.9
```

View

This command can be used in the following views:

- Cluster view

Description

Only after you configure the IP address of the network management site for the cluster, cluster members can send the trap information to the site through the management device.

These commands can only be executed on the management device.

source-policy

Purpose

Use the `source-policy` command to filter the source (and group) address of multicast data packets.

Use the `undo source-policy` command to remove the configuration.

Syntax

```
source-policy acl-number
```

```
undo source-policy
```

Parameters

`acl-number`

Basic or advanced ACL. Valid values are 2000 to 3999.

Example

Set to receive the multicast data packets from source address 10.10.1.2, but discard those from 10.10.1.1.

```
<SW5500> system-view
System View: return to User View with Ctrl+Z
[SW5500]multicast routing-enable
[SW5500]pim
[SW5500-pim]source-policy 1
[SW5500-pim]quit
[SW5500]acl number 1
[SW5500-acl-basic-1]rule permit source 10.10.1.2 0
[SW5500-acl-basic-1]rule deny source 10.10.1.1 0
```

View

This command can be used in the following views:

- PIM view

Description

If resource address filtering is configured, as well as basic ACLs, then the router filters the resource addresses of all multicast data packets received. Those not matched will be discarded.

If resource address filtering is configured, as well as advanced ACLs, then the router filters the resource and group addresses of all multicast data packets received. Those not matched will be discarded.

When this feature is configured, the router filters not only multicast data, but the multicast data encapsulated in the registration packets.

The new configuration overwrites the old one if you run the command for a second time.

speed

Purpose

Use the **speed** command to configure the transmission rate on the AUX (Console) port.

Use the **undo speed** command to restore the default rate.

Syntax

```
speed speed-value
```

```
undo speed
```

Parameters

speed-value

Specifies the transmission rate on the AUX (Console) port in bits per second (bps). Valid values are any of the following: 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 or 4096000.

If not specified, the default rate is 19200 bps.

Example

To configure the transmission speed on the AUX (Console) port as 9600 b/s, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]user-interface aux 0  
[SW5500-ui-aux0]speed 9600
```

View

This command can be used in the following views:

- User Interface view

Description



This command can only be performed in AUX User Interface view

speed

Purpose

Use the **speed** command to configure the port speed.

Use the **undo speed** command to restore the default speed. By default, the speed is **auto**.

Syntax

For a 100 Mbps Ethernet port, the parameters for this command are as follows:

```
speed { 10 | 100 | auto }
```

For a 1000 Mbps Ethernet port, the parameters for this command are as follows:

```
speed { 10 | 100 | 1000 | auto }
```

The undo form of this command is:

```
undo speed
```

Parameters

10	Sets the port speed to 10 Mbps.
100	Sets the port speed to 100 Mbps.
1000	Sets the port speed to 1000 Mbps. (Only available on Gigabit ports).
auto	Sets the port speed to auto-negotiation.

Example

To configure the port speed of port Ethernet1/0/1 to 10 Mbps, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface ethernet 1/0/1  
[SW5500-Ethernet1/0/1]speed 10  
[SW5500-Ethernet1/0/1]
```

View

This command can be used in the following views:

- Ethernet Port view

Related Command

duplex

spf-schedule-interval

Purpose

Using the `spf-schedule-interval` command, you can configure the route calculation interval of OSPF.

Using the `undo spf-schedule-interval` command, you can restore the default setting.

Syntax

```
spf-schedule-interval interval
```

```
undo spf-schedule-interval
```

Parameters

interval

Specifies the SPF route calculation interval for OSPF, in seconds. Valid values are 1 to 10. If not specified, the default value is 5 seconds.

Example

To set the OSPF route calculation interval of the Switch 5500 to 6 seconds, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf]spf-schedule-interval 6
```

View

This command can be used in the following views:

- OSPF view

Description

According to the Link State Database (LSDB), the router running OSPF can calculate the shortest path tree, with itself as the root, and determine the next hop to the destination network according to the shortest path tree. By adjusting the SPF calculation interval, you can decrease the frequency of network changes and unnecessary consumption of bandwidth and router resources.

ssh client assign rsa-key

Purpose

Use the **ssh client assign rsa-key** command to specify on the client the public key for the server to be connected to guarantee the client can be connected to a reliable server.

Use the **undo ssh client assign rsa-key** command to remove the association between the public keys and servers.

Syntax

```
ssh client { server-ip | server-name } assign rsa-key keyname  
undo ssh client server-ip assign rsa-key
```

Parameters

<i>server-ip</i>	Server IP address.
<i>server-name</i>	Server name, consisting of a string from 1 to 80 characters long.
<i>keyname</i>	Server public key name, consisting of a string from 1 to 64 characters long.

Example

Specify on the client the public key of the server (with IP address 192.168.0.1) as abc.

```
<S5500> system-view  
[S5500] ssh client 192.168.0.1 assign rsa-key abc
```

View

This command can be used in the following views:

- System view

ssh client first-time enable

Purpose	<p>Use the <code>ssh client first-time enable</code> command to configure the client to run the initial authentication.</p> <p>Use the <code>undo ssh client first-time</code> command to remove the configuration.</p>
Syntax	<pre>ssh client first-time enable undo ssh client first-time</pre>
Parameters	None
Default	By default, the client runs the initial authentication.
Example	<p>Configure the client to run the initial authentication.</p> <pre><S5500> system-view [S5500] ssh client first-time enable</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view
Description	<p>In the initial authentication, if the SSH client does not have the public key for the server which it accesses for the first time, the client continues to access the server and save locally the public key of the server. Then at the next access, the client can authenticate the server with the public key saved locally.</p> <p>When the initial authentication function is not available, the client does not access the server if it does not have the public key of the server locally. In this case, you need first to save the public key of the target server to the client in other ways.</p>

ssh server authentication-retries

Purpose

Use the **ssh server authentication-retries** command to set authentication retry number for SSH connections.

Use the **undo ssh server authentication-retries** command to restore the default authentication retry number. The default value takes effect at next login.

Syntax

```
ssh server authentication-retries times
```

```
undo ssh server authentication-retries
```

Parameters

times

Authentication retry number. Valid values are 1 to 5. If not specified, the default is 3.

Example

Set the authentication retry number to 4.

```
<S5500> system-view  
[S5500] ssh server authentication-retries 4
```

View

This command can be used in the following views:

- System view

Description



*As the authentication retry number increases by one when a client sends a public key to the server, configure a value larger than two for the times argument if you specify the password-public authentication type using the **ssh user authentication-type** command.*

Related Command

```
display ssh server
```

ssh-server source-interface

Purpose

Use the **ssh-server source-interface** command to specify source interface for the SSH server. If you specify a nonexistent interface in the command, your configuration fails.

Use the **undo ssh-server source-interface** command to clear the source interface configuration. After that, the source address in the packets sent to the SSH2 client is determined by the system.

Syntax

```
ssh-server source-interface interface-type interface-number
```

```
undo ssh-server source-interface
```

Parameters

<i>interface-type</i>	Source interface type.
<i>interface-number</i>	Source interface number.

Example

Specify source interface for the SSH server.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] ssh-server source-interface Vlan-interface 2
```

View

This command can be used in the following views:

- System view

ssh server rekey-interval

Purpose

Use the `ssh server rekey-interval` command to define update interval of server key pair.

Use the `undo ssh server rekey-interval` command to cancel the current setting.

Syntax

```
ssh server rekey-interval hours
```

```
undo ssh server rekey-interval
```

Parameters

hours

Defines key update interval (in hours). Valid values are 1 to 24.

Default

By default, system doesn't update the server key.

Example

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]ssh server rekey-interval 3  
[SW5500]
```

View

This command can be used in the following views:

- System view

Related Command

```
display ssh server
```

ssh-server source-ip

Purpose

Use the **ssh-server source-ip *ip-addr*** command to specify source IP address for the SSH server.

Use the **undo ssh-server source-ip** command to clear the source IP address configuration. After that, the source address in the packets sent to the SSH client is determined by the system.

Syntax

```
ssh-server source-ip ip-addr
```

```
undo ssh-server source-ip
```

Parameters

ip-addr

Source IP address. If the ***ip-addr*** in the command is not an address of the device, your configuration fails.

Example

Specify source IP address for the SSH server.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] ssh-server source-ip 192.168.0.1
```

View

This command can be used in the following views:

- System view

ssh server timeout

Purpose

Use the **ssh server timeout** command to set authentication timeout time for SSH connections.

Use the **undo ssh server timeout** command to restore the default timeout time. The default value takes effect at next login.

Syntax

```
ssh server timeout seconds
```

```
undo ssh server timeout
```

Parameters

seconds

Authentication timeout time (in seconds). Valid values are 1 to 120.
If not specified, the default is 60 seconds.

Example

Set the authentication timeout time to 80 seconds.

```
<S5500> system-view  
[S5500] ssh server timeout 80
```

View

This command can be used in the following views:

- System view

Related Command

```
display ssh server
```

ssh user assign rsa-key

Purpose

Use the **ssh user assign rsa-key** command to allocate public keys to SSH users.

Use the **undo ssh user assign rsa-key** command to remove the association between the public keys and SSH users. The configuration takes effect at the next login.

Syntax

```
ssh user username assign rsa-key keyname
```

```
undo ssh user username assign rsa-key
```

Parameters

<i>username</i>	SSH user name, consisting of a string from 1 to 80 characters long.
<i>keyname</i>	Client public key name, consisting of a string from 1 to 64 characters long.

Example

Set the client public key for the zhangsan user to key1.

```
<S5500> system-view
[S5500] ssh user zhangsan assign rsa-key key1
[S5500]
```

View

This command can be used in the following views:

- System view

Description

If the user already has a public key, the new public key overrides the old one.

Related Command

```
display ssh user-information
```

ssh user authentication-type

Purpose

Use the **ssh user authentication-type** command to define on the server the available authentication type for an SSH user.

Use the **undo ssh user authentication-type** command to restore the default setting.

Syntax

```
ssh user username authentication-type { password | rsa |  
password-publickey | all }
```

```
undo ssh user username authentication-type
```

Parameters

username	Valid SSH user name, consisting of a string from 1 to 80 characters long.
password	Specifies the authentication type as password.
rsa	Specifies the authentication type as RSA public key.
password-publickey	Specifies the authentication type as both password and RSA public key. That is, the user can pass the authentication only if both the password and RSA public key are correct. For the authentication type specified by the password-publickey keyword, <ul style="list-style-type: none">■ Users using SSHv1 can log onto a switch if they pass one of the authentications.■ Users using SSHv2 need to pass both of the authentications to log onto a switch.
all	Specifies the authentication type as either password or RSA public key. That is, the user can pass the authentication if either the password or RSA public key is correct.

Default

By default, no authentication type is specified for new users, so they cannot access the switch.

New users must specify authentication type. Otherwise, they cannot access the switch. The new authentication type configured takes effect at the next login.

Example

Set the authentication type for the zhangsan user as password.

```
<S5500> system-view  
[S5500] ssh user zhangsan authentication-type password
```

View

This command can be used in the following views:

- System view

Description

This command defines available authentication type on the server. The actual authentication type, however, is determined by the client.

Related Command

`display ssh user-information`

ssh user service-type

Purpose

Use the **ssh user service-type** command to specify service type for a user.

Use the **undo ssh user service-type** command to restore the default service type for the SSH user in the system.

Syntax

```
ssh user username service-type { stelnet | sftp | all }
```

```
undo ssh user username service-type
```

Parameters

username	Local user name or the user name defined on the remote RADIUS server, consisting of a string from 1 to 80 characters long.
stelnet	Sets the service type to Telnet. If no service type is specified, Telnet is used as the default.
sftp	Sets the service type to SFTP.
all	Includes Telnet and SFTP two services types.

Example

Specify SFTP service for SSH user zhangsan.

```
<S5500> system-view  
[S5500] ssh user zhangsan service-type sftp
```

View

This command can be used in the following views:

- System view

Related Command

```
display ssh user-information
```

ssh user username authentication-type

Purpose

Use the `ssh user username authentication-type` command to define authentication type for a designated user.

Use the `undo ssh user username authentication-type` command to restore the default mode in which logon fails.

Syntax

```
ssh user username authentication-type { all | password | rsa }  
undo ssh user username authentication-type
```

Parameters

<code>username</code>	Valid local user name or user name defined by remote RADIUS system.
<code>all</code>	Specifies authentication type as password and RSA.
<code>password</code>	Specifies authentication type as password.
<code>rsa</code>	Specifies authentication type as RSA.

Default

By default, user can't logon the switch through SSH or TELNET, so you have to specify authentication type for a new user. The new configuration takes effects at the next logon.

Example

To specify jsmith's authentication type as password, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]ssh user jsmith authentication-type password  
[SW5500]
```

View

This command can be used in the following views:

- System view

Related Command

```
display ssh user-information
```


ssh2

Purpose

Use the **ssh2** command to enable the connection between SSH client and server, define key exchange algorithm preference, encryption algorithm preference and HMAC algorithm preference on the server and client.

Syntax

```
ssh2 { host-ip | host-name } [ port-num ] [ prefer_kex { dh_group1 |  
dh_exchange_group } ] [ prefer_ctos_cipher { des | aes128 } ] [  
prefer_stoc_cipher { des | aes128 } ] [ prefer_ctos_hmac { sha1 |  
sha1_96 | md5 | md5_96 } ] [ prefer_stoc_hmac { sha1 | sha1_96 | md5 |  
md5_96 } ]
```

Parameters

<i>host-ip</i>	Server IP address.
<i>host-name</i>	Server name, consisting of a string from 1 to 20 characters long.
<i>port-num</i>	Server port number. Valid values are 0 to 65,535. If not specified, the default is 22.
<i>prefer_kex</i>	Key exchange algorithm preference. Choose one of the two algorithms available.
<i>dh_group1</i>	Diffie-Hellman-group1-sha1 key exchange algorithm. If not specified, Diffie-Hellman-group1-sha1 key exchange is the default algorithm.
<i>dh_exchange_group</i>	Diffie-Hellman-group-exchange-sha1 key exchange algorithm.
<i>prefer_ctos_cipher</i>	Encryption algorithm preference from the client to server. If not specified, the default is AES128.
<i>prefer_stoc_cipher</i>	Encryption algorithm preference from the server to client. If not specified, the default is AES128.
<i>des</i>	DES_cbc encryption algorithm.
<i>aes128</i>	AES_128 encryption algorithm.
<i>prefer_ctos_hmac</i>	HMAC algorithm preference from the client to server. If not specified, the default is SHA1_96.
<i>prefer_stoc_hmac</i>	HMAC algorithm preference from the server to client. If not specified, the default is SHA1_96.
<i>sha1</i>	HMAC-SHA1 algorithm.
<i>sha1_96</i>	HMAC-SHA1_96 algorithm.
<i>md5</i>	HMAC-MD5 algorithm.
<i>md5_96</i>	HMAC-MD5-96 algorithm.

Example

Log into the SSH 2.0 server with IP address 10.214.50.51 and make these settings:

- Key exchange algorithm preference as dh_exchange_group
- encryption algorithm preference from the server to client as aes128
- HMAC algorithm preference from the client to server as md5
- HMAC algorithm preference from the server to client as sha1_96

```
<S5500> system-view
[S5500] ssh2 10.214.50.51 prefer_kex dh_exchange_group
prefer_stoc_cipher aes128 prefer_ctos_hmac md5 prefer_stoc_hmac sha1_96
```

View

This command can be used in the following views:

- System view

ssh2 source-interface

Purpose

Use the **ssh2 source-interface** command to specify source interface for the SSH2 client.

Use the **undo ssh2 source-interface** command to clear the source interface configuration. After that, the source address in the packets sent to the SSH2 server is determined by the system.

Syntax

```
ssh2 source-interface interface-type interface-number
```

```
undo ssh2 source-interface
```

Parameters

interface-type Source interface type. If you specify a nonexistent interface in the command, your configuration fails.

interface-number Source interface number.

Example

Specify source interface for the SSH2 client.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] ssh2 source-interface Vlan-interface 1
```

View

This command can be used in the following views:

- System view

ssh2 source-ip

Purpose

Use the **ssh2 source-ip** command to specify source IP address for the SSH2 client.

Use the **undo ssh2 source-ip** command to clear the source IP address configuration. After that, the source address in the packets sent to the SSH2 server is determined by the system.

Syntax

```
ssh2 source-ip ip-addr
```

```
undo ssh2 source-ip
```

Parameters

ip-addr

Source IP address. If the *ip-addr* in the command is not an address of the device, your configuration fails.

Example

Specify source IP address for the SSH2 client.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] ssh2 source-ip 192.168.1.1
```

View

This command can be used in the following views:

- System view

standby detect-group

Purpose

Use the **standby detect-group** command to specify to enable the VLAN interface backup function by using the auto detect function.

Use the **undo standby detect-group** command to disable the VLAN interface backup function.

Syntax

```
standby detect-group group-number
```

```
undo standby detect-group group-number
```

Parameters

group-number Detecting group number. Valid values are 1 to 50.

Example

Specify to enable VLAN interface 2 when the result of detecting group 10 is unreachable.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] interface vlan-interface 2  
[S5500-vlan-interface2] standby detect-group 10
```

View

This command can be used in the following views:

- VLAN Interface view

Description

You can enable VLAN interface backup function by auto detecting results in the following ways:

- Enable the primary interface when the result of the detecting group is reachable.
- Enable the secondary interface when the result of the detecting group is unreachable.
- When the link between the primary VLAN interface and the destination comes back up, that is, the result of the detecting group is reachable again, the system enables the primary VLAN interface and shuts down the secondary.

state

Purpose	Use the state command to configure the state of the current ISP domain/current user.
Syntax	state { active block }
Parameters	<p>active Configures the current ISP domain (ISP Domain View)/current user (Local User View) as being in active state, that is, the system allows the users in the domain (ISP Domain View) or the current user (Local User View) to request network service.</p> <p>block Configures the current ISP domain (ISP Domain View)/current user (Local User View) as being in block state, that is, the system does not allow the users in the domain (ISP Domain View) or the current user (Local User View) to request network service.</p>
Default	<p>By default, after an ISP domain is created, it is in the active state (in ISP Domain View).</p> <p>A local user will be active (in Local User View) upon its creation.</p>
Example	<p>To set the current ISP domain marlboro.net to be in the block state. The supplicants in this domain cannot request for the network service, enter the following:</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]domain marlboro.net [SW5500-isp-marlboro.net]state block [SW5500-isp-marlboro.net]quit To set the user 3Com1 to be in the block state, enter the following: [SW5500-user-3Com1]state block</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none"> ■ ISP Domain view ■ Local User view
Description	In ISP Domain View, every ISP can either be in active or block state. If an ISP domain is configured to be active, the users in it can request for network service, while in block state, its users cannot request for any network service, which will not affect the users currently online.
Related Command	domain

state

Purpose

Use the **state** command to configure the state of RADIUS server.

Syntax

```
state { primary | secondary } { accounting | authentication } { block | active }
```

Parameters

primary	Configures to set the state of the primary RADIUS server.
secondary	Configures to set the state of the second RADIUS server.
accounting	Configures to set the state of RADIUS accounting server.
authentication	Configures to set the state of RADIUS authentication/authorization.
block	Configures the RADIUS server to be in the state of block.
active	Configures the RADIUS server to be active, namely the normal operation state.

Default

By default, as for the newly created RADIUS scheme, the primary and secondary accounting/authentication servers are in the state of **block**; as for the "system" RADIUS scheme created by the system, the primary accounting/authentication servers are in the state of **active**, and the secondary accounting/authentication servers are in the state of **block**.

Example

To set the second authentication server of RADIUS scheme, "3Com", to be active, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]radius scheme 3Com  
[SW5500-radius-3Com]state secondary authentication active
```

View

This command can be used in the following views:

- RADIUS Scheme view

Description

For the primary and second servers (no matter an authentication/authorization or an accounting server), if the primary server is disconnected to NAS for some fault, NAS will automatically turn to exchange packets with the second server. However, after the primary one recovers, NAS will not resume the communication with it at once, instead, it continues communicating with the second one. When the second one fails to communicate, NAS will turn to the primary one again. This command is used to set

the primary server to be **active** manually, in order that NAS can communicate with it right after the troubleshooting.

When the primary and second servers are all **active** or **block**, NAS will send the packets to the primary server only.

Related Commands

- **primary accounting**
- **primary authentication**
- **radius-scheme**
- **secondary accounting**
- **secondary authentication**

static-bind ip-address

Purpose

Use the **static-bind ip-address** command to specify an IP address which will be bound statically to a MAC address.

Use the **undo static-bind ip-address** command to remove a statically bound IP address.

Syntax

```
static-bind ip-address ip-address [ mask-length | mask mask ]
```

```
undo static-bind ip-address
```

Parameters

<i>ip-address</i>	IP address to be bound. If you do not specify the mask-length or mask argument, the default subnet mask is used.
<i>mask-length</i>	Length of the subnet mask of the specified IP address. Valid values are 1 to 31.
<i>mask mask</i>	Subnet mask of the specified IP address.

Default

By default, no IP address is statically bound.

Example

Enter system view.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.
```

Bind the IP address 10.1.1.1 (with the subnet mask 255.255.255.0) to the MAC address 0000-e03f-0305.

```
[S5500] dhcp server ip-pool 0  
[S5500-dhcp-pool-0] static-bind ip-address 10.1.1.1 mask 255.255.255.0  
[S5500-dhcp-pool-0] static-bind mac-address 0000-e03f-0305
```

View

This command can be used in the following views:

- DHCP Address Pool view

Description



- *The static-bind ip-address command must be used together with the static-bind mac-address command, to respectively specify a statically bound IP address and MAC address.*
- *If you execute the static-bind ip-address command repeatedly, the new configuration overwrites the previous one.*
- *This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

Related Commands

- `dhcp server ip-pool`
- `static-bind mac-address`

static-bind mac-address

Purpose

Use the **static-bind mac-address** command to specify a MAC address to which an IP address will be bound statically.

Use the **undo static-bind mac-address** command to remove such a MAC address.

Syntax

```
static-bind mac-address mac-address
```

```
undo static-bind mac-address
```

Parameters

mac-address

MAC address of the host to which the IP address is to be bound. You need to provide this argument in the form of H-H-H.

Default

By default, no such MAC address is specified.

Example

Enter system view.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.
```

Bind the IP address 10.1.1.1 (with the subnet mask 255.255.255.0) to the MAC address 0000-e03f-0305.

```
[S5500] dhcp server ip-pool 0  
[S5500-dhcp-pool-0] static-bind ip-address 10.1.1.1 mask 255.255.255.0  
[S5500-dhcp-pool-0] static-bind mac-address 0000-e03f-0305
```

View

This command can be used in the following views:

- DHCP Address Pool view

Description



- *The static-bind ip-address command must be used together with the static-bind mac-address command, to respectively specify a statically bound IP address and MAC address.*
- *If you execute the static-bind ip-address command repeatedly, the new configuration overwrites the previous one.*
- *This command applies only to the S5500-EI series among Switch 5500-Series Switches.*

Related Commands

- **dhcp server ip-pool**
- **static-bind ip-address**

static-rp

Purpose

Use the `static-rp` command to configure static RP.

Use the `undo static-rp` command to remove the configuration.

Syntax

```
static-rp rp-address [ acl-number ]
```

```
undo static-rp
```

Parameters

rp-address

Static RP address, a legal unicast IP address.

acl-number

Basic ACL, used to control the range of the multicast group served by the static RP, which ranges from 2000 to 2999. If an ACL is not specified at configuration, static RP will serve all multicast groups; if an ACL is specified, static RP will only serve the multicast group passing the ACL.

Example

Configure 10.110.0.6 as a static RP.

```
<SW5500> system-view
System View: return to User View with Ctrl+Z
[SW5500]multicast routing-enable
[SW5500]pim
[SW5500-pim]static-rp 10.110.0.6
```

View

This command can be used in the following views:

- PIM view

Description

The Static RP functions as the backup for a dynamic RP so as to improve the network robustness. If the RP is elected by the BSR mechanism, static RP will not work.

All routers in the PIM domain should be configured with this command and be specified with the same RP address.

The new configuration overwrites the old one if you run the command for a second time.

Related Command

```
display pim rp-info
```

static-rpf-peer

Purpose Use the `static-rpf-peer` command to configure a static RPF peer.
Use the `undo static-rpf-peer` command to remove a static RPF peer.

Syntax `static-rpf-peer peer-address [rp-policy ip-prefix-name]`
`undo static-rpf-peer peer-address`

Parameters

<code>peer-address</code>	Address of the static RPF peer receiving SA messages.
<code>rp-policy ip-prefix-name</code>	Specifies a filtering policy based on RP addresses to filter RPs in SA messages. <code>ip-prefix-name</code> is the IP address prefix list, consisting of 1 to 19 characters.

Default By default, no static RPF peer is configured.

Example Configure a static RPF peer.

```
<S5500> system-view
[S5500] ip ip-prefix list1 permit 130.10.0.0 16 greater-equal 16
less-equal 32
[S5500] msdp
[S5500-msdp] peer 130.10.7.6 connect-interface Vlan-interface 100
[S5500-msdp] static-rpf-peer 130.10.7.6 rp-policy list
```

View This command can be used in the following views:

- MSDP view

Description If only one MSDP peer is configured with the peer command, the MSDP peer will be regarded as a static RPF peer. When configuring multiple static RPF peers for the same router, you must follow the following two configuration methods:

- In the case that all the peers use the rp-policy keyword: Multiple static RPF peers take effect at the same time. RPs in SA messages are filtered according to the prefix list configured; only SA messages whose RP addresses pass the filtering are received. If multiple static RPF peers using the same rp-policy keyword are configured, when any of the peers receives an SA message, it will forward the SA message to the other peers.
- In the case that none of the peers use the rp-policy keyword: According to the configuration sequence, only the first static RPF peer whose connection state is UP is active. All the SA messages from this peer will be received and those from other static RPF peers will be discarded. Once the active static RPF peer fails (because the configuration is removed or the connection is terminated), based on the configuration sequence, the subsequent first static RPF peer whose connection is in the UP state will be selected as the active static RPF peer.

Related Commands

- `peer`
- `ip ip-prefix`

startup bootrom-access enable

Purpose

Use the **startup bootrom-access enable** command to enable the user to enter the main Boot Menu with customized password.

Use the **undo startup bootrom-access enable** to disable the user from entering the main Boot Menu with customized password.

Syntax

```
startup bootrom-access enable
```

```
undo startup bootrom-access enable
```

Parameters

None

Default

By default, the user is disabled from entering the main Boot Menu with customized password.

Example

Enable the user to enter the main Boot Menu with customized password.

```
<S5500> startup bootrom-access enable
```

View

This command can be used in the following views:

- User view

Description

You can use the **display startup** command to check the executing results of the above commands.

startup saved-configuration

Purpose

Use the **startup saved-configuration** command to assign the main or backup attribute to a configuration file on one switch or all switches in the fabric so as to use this file as the main or backup startup configuration file of the switch(es) upon next startup.

Use the **undo startup saved-configuration** command to configure the switch(es) to use null configuration upon next startup.

Syntax

```
startup saved-configuration cfgfile [ backup | main ]
```

```
undo startup saved-configuration [ unit unit-id ]
```

Parameters

<i>cfgfile</i>	Path name or file name of a configuration file in the flash memory, consisting of a character string from 5 to 56 characters long.
main	Assigns the main attribute to the file.
backup	Assigns the backup attribute to the file.
unit <i>unit-id</i>	Unit ID of a switch.

Example

Set the file vrpcfg.cfg as the main startup configuration file of the whole fabric.

```
<S5500> startup saved-configuration vrpcfg.cfg main
Please wait.....Done!
%Apr 2 02:55:10:025 2000 S5500 CFM/3/CFM_LOG:- 1 -Unit1 set the
configuration
successfully.
<S5500>
%Apr 2 02:55:10:134 2000 S5500 CFM/3/CFM_LOG:- 1 -Unit2 set the
configuration
successfully.
```

Set the file 123.cfg as the backup startup configuration file of unit1.

```
<S5500> startup saved-configuration unit1>flash:/123.cfg backup
Please wait.....Done!
%Apr 2 02:55:54:797 2000 S5500 CFM/3/CFM_LOG:- 1 -Unit1 set the
configuration
successfully.
```

View

This command can be used in the following views:

- User view

Description

Executing the **startup saved-configuration** command with neither **backup** nor **main** parameter will assign the main attribute to the file.

Executing the **undo startup saved-configuration** command without the **unit** keyword will specify that all the switches in the stack fabric system will use null configuration when starting up. From the local unit, you can specify another unit in the fabric to use null configuration when starting up.

Currently, the configuration files have an extension name of ".cfg" and are stored in the root directory.

Related Command

display startup

stop-accounting-buffer enable

Purpose	<p>Use the <code>stop-accounting-buffer enable</code> command to configure to save the stopping accounting requests without response in the Switch buffer.</p> <p>Use the <code>undo stop-accounting-buffer enable</code> command to cancel the function of saving the stopping accounting requests without response in the Switch buffer.</p>
Syntax	<pre>stop-accounting-buffer enable undo stop-accounting-buffer enable</pre>
Parameters	None
Default	By default, enable to save the stopping accounting requests in the buffer.
Example	<p>To indicate that, for the server “3Com” in the RADIUS scheme, the Switch will save the stopping accounting request packets in the buffer, enter the following:</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]radius scheme 3Com [SW5500-radius-3Com]stop-accounting-buffer enable</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ RADIUS Scheme view
Description	<p>Because the stopping accounting request concerns the account balance and will affect the amount of charge, which is very important for both the user and ISP, NAS shall make its best effort to send the message to the RADIUS accounting server. Accordingly, if the message from the Switch to the RADIUS accounting server has not been responded to, the Switch shall save it in the local buffer and retransmit it until the server responds or discard the messages after transmitting for a specified number of times.</p>
Related Commands	<ul style="list-style-type: none">■ <code>display stop-accounting buffer</code>■ <code>radius-scheme</code>■ <code>reset stop-accounting-buffer</code>

stopbits

Purpose

Use the **stopbits** command to configure the stop bits on the AUX (Console) port.
Use the **undo stopbits** command to restore the default stop bits (the default is 1).

Syntax

```
stopbits { 1 | 1.5 | 2 }  
undo stopbits
```

Parameters

1	Sets the stop bits to 1.
1.5	Sets the stop bits to 1.5.
2	Sets the stop bits to 2.

Example

To configure the stop bits to 2, enter the following from the AUX (Console) port:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]user-interface aux 0  
[SW5500-ui-aux0]stopbits 2
```

View

This command can be used in the following views:

- User Interface view

Description



This command can only be performed in AUX User Interface view.

stp

Purpose	<p>Use the stp command to enable/disable MSTP globally or for a port.</p> <p>Use the undo stp command to restore the default MSTP status globally or for a port.</p>				
Syntax	<pre>stp { enable disable } undo stp</pre>				
Parameters	<table><tr><td>enable</td><td>Enables MSTP globally or for a port.</td></tr><tr><td>disable</td><td>Disables MSTP globally or for a port.</td></tr></table>	enable	Enables MSTP globally or for a port.	disable	Disables MSTP globally or for a port.
enable	Enables MSTP globally or for a port.				
disable	Disables MSTP globally or for a port.				
Default	By default, MSTP is disabled.				
Example	<p>Enable MSTP globally.</p> <pre><S5500> system-view System View: return to User View with Ctrl+Z. [S5500] stp enable</pre> <p>Disable MSTP for port Ethernet1/0/1.</p> <pre><S5500> system-view System View: return to User View with Ctrl+Z. [S5500] interface ethernet 1/0/1 [S5500-Ethernet1/0/1] stp disable</pre>				
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view■ Ethernet Port view				
Description	<p>With MSTP enable, a switch determines whether to operate in STP mode, RSTP mode, or MSTP mode according to your configuration. A switch becomes a transparent bridge if you disable MSTP.</p> <p>With MSTP enabled, a switch dynamically maintains the status of spanning trees by processing BPDUs of the corresponding VLANs. After MSTP is disabled, the switch stops doing so.</p>				
Related Commands	<ul style="list-style-type: none">■ stp interface■ stp mode				

stp bpdu-protection

Purpose

Use the **stp bpdu-protection** command to enable the BPDU protection function.

Use the **undo stp bpdu-protection** command to restore the default operation mode of the BPDU protection function.

Syntax

```
stp bpdu-protection
```

```
undo stp bpdu-protection
```

Parameters

None

Default

By default, the BPDU protection function is disabled.

Example

Enable the BPDU protection function.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp bpdu-protection
```

View

This command can be used in the following views:

- System view

Description

Normally, access ports of access layer devices have terminals (such as PCs) or file servers directly connected to them. These ports are usually configured to be edge ports to achieve rapid transition. When they receive BPDUs, however, they are set as non-edge ports automatically, which causes MSTP to recalculate the spanning trees, resulting in network topology jitters.

In normal cases, edge ports are free of BPDUs. But malicious users may attack the switches by sending forged BPDUs to the edge ports to create network jitters. You can prevent this type of attack by utilizing the BPDU protection function. With this function enabled on a switch, once an edge port receives a BPDU, the system automatically shut it down and notifies the network administrator of the situation. Only the administrator can restore edge ports that are shut down.



CAUTION:

As 1000 Mbps ports of a 3Com Switch 5500 Family switch cannot be shut down, the BPDU protection function is not applicable to these ports even you enable the BPDU protection function and specify these ports to be MSTP edge ports.

stp bridge-diameter

Purpose

Use the **stp bridge-diameter** command to set the network diameter of a switched network, which is represented in terms of the maximum number of switches between any two terminals in a switched network.

Use the **undo stp bridge-diameter** command to restore the default network diameter.

Syntax

```
stp bridge-diameter bridgenum
```

```
undo stp bridge-diameter
```

Parameters

bridgenum Network diameter for the switched network. Valid values are 2 to 7. If not specified, the default is 7.

Example

Set the network diameter to 5.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] stp bridge-diameter 5
```

View

This command can be used in the following views:

- System view

Description

An MSTP-enabled switch adjusts its Hello time, Forward delay, and Max age settings accordingly after you configure the network diameter on the switch. With the network diameter set to 7 (the default), the three time settings are set to their defaults as well.

The **stp bridge-diameter** command applies to CISTs only.

Related Commands

- **stp timer forward-delay**
- **stp timer hello**
- **stp timer max-age**

stp cost

Purpose

Use the **stp cost** command to set the path cost of a port in a spanning tree instance.

Use the **undo stp cost** command to restore the default.

Syntax

```
stp [ instance instance-id ] cost cost
```

```
undo stp [ instance instance-id ] cost
```

Parameters

instance-id ID of a spanning tree instance. Valid values are 0 to 16. A value of 0 specifies the CIST.

cost Path cost for the port. Valid values are 1 to 200,000,000.

Default

By default, a switch calculates the path costs of ports in each spanning tree instance automatically according to the specified standard.

If you specify the *instance-id* argument to be 0 or do not specify this argument, the **stp cost** command sets the path cost of the port in the CIST.

Example

Set the path cost of port Ethernet1/0/3 in spanning tree instance 2 to 200.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface ethernet1/0/3
[S5500-Ethernet1/0/3] stp instance 2 cost 200
```

View

This command can be used in the following views:

- Ethernet Port view

Description

The path cost of a port affects the role of the port. By configuring the same ports to have different path costs in different MSTIs, you can enable flows of different VLANs to travel along different physical links, implementing VLAN-based load balancing. Path cost changes for ports of an MSTP-enabled switch can cause MSTP to redetermine the roles of the ports and to perform state transitions.

Related Command

stp interface cost

stp edged-port

Purpose

Use the **stp edged-port** command to configure the current Ethernet port to be either an edge port or a non-edge port.

Use the **undo stp edged-port** command to restore the current Ethernet port to its default state.

Syntax

```
stp edged-port { enable | disable }
```

```
undo stp edged-port
```

Parameters

enable	Configures the current Ethernet port to be an edge port.
disable	Configures the current Ethernet port to be a non-edge port.

Default

By default, all Ethernet ports of a switch are non-edge ports.

Example

Configure port Ethernet1/0/1 to be a non-edge port.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface ethernet1/0/1
[S5500-Ethernet1/0/1] stp edged-port disable
```

View

This command can be used in the following views:

- Ethernet Port view

Description

A port is an edge port if it has terminals directly connected and is not connected to any other switches or shared network segments. As edge ports do not result in loops when the network topology changes, you can enable a port to transit to the forwarding state rapidly by making it an edge port. It is recommended that you set the Ethernet ports with terminals directly connected as edge ports to enable them to transit to the forwarding state rapidly.

As an edge port is not connected to any switch, it normally does not receive any BPDUs. But once it receives a BPDU when the BPDU protection function is not enabled, it becomes a non-edge port even if it is configured to be an edge port.



CAUTION:

Only one function among loop prevention, root protection, and edge port can be valid at a time.

Related Command

`stp interface edged-port`

stp ignored vlan

Purpose

Use the `stp ignored vlan` command to configure a STP-Ignored VLAN.

Use the `undo stp ignored vlan` command to cancel the configuration.

Syntax

```
stp ignored vlan vlan-list
```

```
undo stp ignored vlan vlan-list
```

Parameters

vlan-list List of VLANs, and *vlan-list*={ *vlan-id* [to *vlan-id*] }&<1-10>.

&<1-10> Indicates that *vlan-id* can be specified for 10 times at most. The value of VLAN ID ranges from 1 to 4094.

Default

By default, no VLAN is considered STP-Ignored when STP is enabled on the Switch.

Example

To specify VLAN 10 to VLAN 20 as an STP-Ignored VLANs, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]stp ignored vlan 10 to 20
To cancel the configuration of VLAN 10 to VLAN 20 as an STP-Ignored
VLANs, enter the following:
[SW5500]undo stp ignored vlan 10 to 20
```

View

This command can be used in the following views:

- System view

Description

Once an STP-Ignored VLAN is configured, the packets of the VLAN will be forwarded on any Switch port, with no restriction from the calculated STP path.

stp interface

Purpose Use the **stp interface** command in system view to enable or disable MSTP for specified ports.

Syntax `stp interface interface-list { enable | disable }`

Parameters

<code><i>interface-list</i></code>	List of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of <code><i>interface-list</i> = { <i>interface-type interface-number</i> [to <i>interface-type interface-number</i>] } &<1-10></code> , where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.
<code>enable</code>	Enables MSTP.
<code>disable</code>	Disables MSTP.

Default By default, MSTP is enabled on ports of a switch if MSTP is globally enabled; and MSTP is disabled on ports of a switch if MSTP is disabled globally.

An MSTP-disabled port does not participate in any calculation of spanning trees and is always in forwarding state.

Example Enable MSTP for Ethernet1/0/1 port in system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] stp interface Ethernet 1/0/1 enable
```

View This command can be used in the following views:

- System view

Description



CAUTION:

Disabling MSTP on ports may result in loops.

Related Command

- `stp`
- `stp mode`

stp interface cost

Purpose

Use the **stp interface cost** command in system view to set the path cost of specified ports in a specified spanning tree instance.

Use the **undo stp interface cost** command in system view to restore the default path cost.

Syntax

```
stp interface interface-list [ instance instance-id ] cost cost
```

```
undo stp interface interface-list [ instance instance-id ] cost
```

Parameters

<i>interface-list</i>	List of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of <i>interface-list</i> = { <i>interface-type interface-number</i> [to <i>interface-type interface-number</i>] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.
<i>instance-id</i>	Spanning tree instance ID. Valid values are 0 to 16. A value of 0 specifies the CIST.
<i>cost</i>	Path cost for the ports. Valid values are 1 to 200,000,000.

Default

By default, a switch calculates the path costs of ports in each spanning tree instance automatically according to the specified standard.

If you specify the *instance-id* argument to be 0 or do not specify this argument, the **stp interface cost** command sets the path cost of the port in the CIST.

Example

Set the path cost of port Ethernet1/0/3 in spanning tree instance 2 to 400 in system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] stp instance 2 interface Ethernet 1/0/3 cost 400
```

View

This command can be used in the following views:

- System view

Description

The path cost of a port affects the role of the port. By configuring the same ports to have different path costs in different MSTIs, you can enable flows of different VLANs to travel along different physical links, implementing VLAN-based load balancing.

Path cost changes for ports of an MSTP-enabled switch can cause MSTP to recalculate the roles of the ports and to perform state transitions.

The default path cost of a port varies with the port speed.

Related Command

stp cost

stp interface edged-port

Purpose

Use the **stp interface edged-port** command to configure the specified Ethernet ports to be either edge ports or non-edge ports.

Use the **undo stp interface edged-port** command in system view to restore the specified Ethernet ports to their default states.

Syntax

```
stp interface interface-list edged-port { enable | disable }  
undo stp interface interface-list edged-port
```

Parameters

<i>interface-list</i>	List of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of <i>interface-list</i> = { <i>interface-type interface-number</i> [to <i>interface-type interface-number</i>] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.
enable	Configures the specified Ethernet ports to be edge ports.
disable	Configures the specified Ethernet ports to be non-edge ports.

Default

By default, all Ethernet ports of a switch are non-edge ports.

Example

Configure Ethernet1/0/3 port to be an edge port in system view.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp interface Ethernet 1/0/3 edged-port enable
```

View

This command can be used in the following views:

- System view

Description

A port is an edge port if it has terminals directly connected and is not connected to any other switches or shared network segments. As edge ports do not result in loops when the network topology changes, you can enable a port to transit to the forwarding state rapidly by making it an edge port. It is recommended that you set the Ethernet ports with terminals directly connected as edge ports to enable them to transit to the forwarding state rapidly.

As an edge port is not connected to any switch, it normally does not receive any BPDUs. But once it receives a BPDU when the BPDU protection function is not enabled, it becomes a non-edge port even if it is configured to be an edge port.



CAUTION:

Only one function among loop prevention, root protection, and edge port can be valid at a time.

Related Command

`stp edged-port`

stp interface loop protection

Purpose

Use the **stp interface loop-protection** command to enable the loop prevention function in system view.

Use the **undo stp interface loop-protection** command to restore the default state of the loop prevention function in system view.

Syntax

```
stp interface interface-list loop-protection
```

```
undo stp interface interface-list loop-protection
```

Parameters

interface-list

List of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of *interface-list* = { *interface-type interface-number* [to *interface-type interface-number*] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.

Default

The loop prevention function is disabled by default.

Example

Enable the loop prevention function for port Ethernet1/0/1.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp interface Ethernet 1/0/1 loop-protection
```

View

This command can be used in the following views:

- System view

Description



CAUTION:

Only one function among loop prevention, root protection, and edge port can be valid at a given time.

Related Command

stp loop-protection

stp interface mcheck

Purpose Use the **stp interface mcheck** command in system view to perform the mCheck operation for specified ports.

Syntax `stp [interface interface-list] mcheck`

Parameters *interface-list* List of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of *interface-list* = { *interface-type interface-number* [to *interface-type interface-number*] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.

Example Perform the mCheck operation for port Ethernet1/0/3 in system view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] stp interface Ethernet 1/0/3 mcheck
net1/0/1 no-agreement-check
```

View This command can be used in the following views:

- System view

Description On a switched network, if a port on a switch running MSTP is connected to a switch running STP or RSTP, it automatically transits to STP or RSTP mode. But when the switch running STP or RSTP is disconnected, the port cannot transit back to MSTP mode automatically; it remains in STP or RSTP mode. In this case, you can force the port to operate in MSTP mode by performing the mCheck operation.

Related Commands

- `stp mcheck`
- `stp mode`

stp interface point-to-point

Purpose

Use the **stp interface point-to-point** command in system view to specify whether the specified ports connect to point-to-point links.

Use the **undo stp interface point-to-point** command in system view to restore the default setting.

Syntax

```
stp interface interface-list point-to-point { force-true | force-false  
| auto }
```

```
undo stp interface interface-list point-to-point
```

Parameters

<i>interface-list</i>	List of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of <i>interface-list</i> = { <i>interface-type interface-number</i> [to <i>interface-type interface-number</i>] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.
<i>force-true</i>	Specifies the specified Ethernet ports connect to point-to-point links.
<i>force-false</i>	Specifies the specified Ethernet ports connect to links that are not point-to-point.
<i>auto</i>	Specifies that MSTP automatically determines whether the ports must connect to point-to-point links.

Default

By default, the auto mode is used, that is, the switch automatically determines whether the ports connect to point-to-point links.

Example

Specify port Ethernet1/0/3 to connect to point-to-point link in system view.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp interface Ethernet 1/0/3 point-to-point force-true
```

View

This command can be used in the following views:

- System view

Description

The rapid transition feature is not applicable to ports that are connected to non-point-to-point links.

If an Ethernet port is the master port of an aggregation port or operates in full-duplex mode, the link to which the port is connected is a point-to-point link. It is recommended that you specify the **auto** keyword in the **stp interface**

point-to-point command for links of this kind to enable the type of the link being automatically determined by MSTP.

These two commands only apply to CISTs and MSTIs. If you configure the link to which a port is connected to be a point-to-point link (or a non-point-to-point link), the configuration applies to all spanning tree instances (that is, the port is configured to connect to a point-to-point link [or a non-point-to-point link] in all spanning tree instances). If the actual physical link is not a point-to-point link and you configure the link to which the port is connected to be a point-to-point link, loops may temporarily occur.

Related Command

stp point-to-point

stp interface port priority

Purpose

Use the **stp interface port priority** command in system view to set the port priority of specified ports in a spanning tree instance.

Use the **undo stp interface port priority** command in system view to restore the default port priority of specified ports in the spanning tree instance.

Syntax

```
stp interface interface-list instance instance-id port priority  
priority
```

```
undo stp interface interface-list instance instance-id port priority
```

Parameters

<i>interface-list</i>	List of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of <i>interface-list</i> = { <i>interface-type interface-number</i> [to <i>interface-type interface-number</i>] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.
<i>instance-id</i>	Spanning tree instance ID. Valid values are 0 to 16. A value of 0 specifies the CIST.
<i>priority</i>	Priority for the ports. Valid values are 0 to 240 but must be a multiple of 16, such as 0, 16, and 32. If not specified, the default port priority is 128.

Example

Set the priority of port Ethernet1/0/3 in spanning tree instance 2 to 16.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp interface Ethernet 1/0/3 instance 2 port priority 16
```

View

This command can be used in the following views:

- System view

Description

If you specify the *instance-id* argument to be 0, the configured priorities apply to the CIST. The role a port plays in a spanning tree instance can be affected by its priority. A port on an MSTP-enabled switch can have different port priorities and play different roles in different MSTIs. This enables packets of different VLANs to be forwarded along different physical paths, implementing VLAN-based load balancing. Changes of port priorities can cause MSTP to redetermine the roles of ports, resulting in state transition of ports.

Related Command

stp port priority

stp interface root-protection

Purpose

Use the **stp interface root-protection** command to enable the root protection function for specified ports in system view.

Use the **undo stp interface root-protection** command to restore the default operation state of the root protection function in system view.

Syntax

```
stp interface interface-list root-protection
```

```
undo stp interface interface-list root-protection
```

Parameters

interface-list

List of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of *interface-list* = { *interface-type interface-number* [*to interface-type interface-number*] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.

Default

By default, the root protection function is disabled.

Example

Enable the root protection function for port Ethernet1/0/1.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp interface Ethernet 1/0/1 root-protection
```

View

This command can be used in the following views:

- System view

Description

Configuration errors and malicious attacks may cause legal root bridges to receive BPDUs of higher priorities, and give up their roles as root bridges, which means network topology jitters. In this case, flows that should travel along high-speed links may be led to low-speed links, and network congestions may occur.

You can avoid this problem by utilizing the root protection function. Ports with this function enabled can retain their roles in all spanning tree instances. When such a port receives BPDUs of higher priorities, its state is set to discarding and it stops forwarding any packets as if the connected link were down. Only when it receives no BPDUs of higher priorities in a specified period, does it resumes its normal state.



CAUTION:

Only one function among loop prevention, root protection, and edge port can be valid at a time.

Related Command `stp root-protection`

stp interface transmit-limit

Purpose

Use the **stp interface transmit-limit** command to set the maximum number of BPDUs that specified ports can send within a Hello time interval.

Use the **undo stp interface transmit-limit** command to restore the default.

Syntax

```
stp interface interface-list transmit-limit packetnum
```

```
undo stp interface interface-list transmit-limit
```

Parameters

interface-list

List of Ethernet ports. You can specify multiple Ethernet ports by providing this argument in the form of *interface-list* = { *interface-type interface-number* [to *interface-type interface-number*] } &<1-10>, where &<1-10> means that you can provide up to 10 port indexes/port index lists for this argument.

packetnum

Maximum number of BPDUs that the ports can send within a Hello time interval, also known as maximum transmission speed. Valid values are 1 to 255. If not specified, the default is 3.

Example

Set the maximum transmission speed of port Ethernet1/0/3 to 5.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp interface Ethernet 1/0/3 transmit-limit 5
```

View

This command can be used in the following views:

- System view

Description

A larger *packetnum* value means a greater number of packets can be transmitted in each Hello time interval and more switch resources will be consumed. Configure the *packetnum* argument to a proper value to limit the number of BPDUs sent in each Hello time interval, preventing MSTP from occupying too much network resources when network topology jitters occur.

Related Command

stp transmit-limit

stp loop-protection

Purpose	<p>Use the stp loop-protection command to enable the loop prevention function for the current port.</p> <p>Use the undo stp loop-protection command to restore the default operation state of the loop prevention function. By default, the loop prevention function is disabled.</p>
Syntax	<pre>stp loop-protection undo stp loop-protection</pre>
Parameters	None
Example	<p>Enable the loop prevention function for port Ethernet1/0/1.</p> <pre><S5500> system-view System View: return to User View with Ctrl+Z. [S5500] interface Ethernet1/0/1 [S5500-Ethernet1/0/1] stp loop-protection</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ Ethernet Port view

stp max-hops

Purpose

Use the **stp max-hops** command to set the maximum hop count of the MST region to which the switch belongs.

Use the **undo stp max-hops** command to restore the default maximum hop count.

Syntax

```
stp max-hops hops
```

```
undo stp max-hops
```

Parameters

hops

Maximum hop count. Valid values are 1 to 40.
If not specified, the default is 20.

Example

Set the maximum hop count of the current MST region to 35.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp max-hops 35
```

View

This command can be used in the following views:

- System view

Description

The maximum hop count configured on the region root for an MST region is used to limit the size of the MST region.

A BPDU contains a hop counter field. In a MST region, after a BPDU leaves the root bridge, its hop counter decreases by 1 whenever it is forwarded by a switch; once its hop counter reaches 0, it is dropped. Such a mechanism disables the switches that are beyond the maximum hop count from participating in spanning tree calculation, and thus limits the size of an MST region.

With such a mechanism, once a switch becomes the root bridge of a CIST or MSTI, the maximum hop count configured on it determines the network diameter of the spanning tree and limits the size of the spanning tree. The switches that are not the root bridge in an MST region adopts the maximum hop count configured on the root bridge.

stp mcheck

Purpose Use the **stp mcheck** command to perform the mCheck operation for the current port.

Syntax `stp mcheck`

Parameters None

Example Perform the mCheck operation for port Ethernet1/0/1.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface Ethernet1/0/1
[S5500-Ethernet1/0/1] stp mcheck
```

View This command can be used in the following views:

- Ethernet Port view

Description On a switched network, if a port on a switch running MSTP is connected to a switch running STP or RSTP, it automatically transits to STP or RSTP mode. But when the switch running STP or RSTP is disconnected, the port cannot transit back to MSTP mode automatically; it remains in STP or RSTP mode. In this case, you can force the port to operate in MSTP mode by performing the mCheck operation.

Related Commands

- `stp interface mcheck`
- `stp mode`

stp mode

Purpose

Use the **stp mode** command to set the MSTP operation mode of the switch.

Use the **undo stp mode** command to restore the default MSTP operation mode.

Syntax

```
stp mode { stp | rstp | mstp }
```

```
undo stp mode
```

Parameters

stp Specifies MSTP to operate in STP mode.

mstp Specifies MSTP to operate in MSTP mode.

rstp Specifies MSTP to operate in RSTP mode.

Default

By default, a switch operates in MSTP mode.

Example

Configure the switch to operate in STP mode.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp mode stp
```

View

This command can be used in the following views:

- System view

Description

MSTP provides the following three operation modes to be compatible with STP/RSTP:

- STP mode. A switch operating in STP mode sends STP BPDUs.
- RSTP mode. A switch operating in RSTP mode sends RSTP BPDUs.
- MSTP mode. A switch operating in MSTP mode sends MSTP BPDUs.

Once MSTP finds that a port is connected with a switch running STP or RSTP, it automatically transit the port to operate in STP or RSTP mode.

Related Commands

- **stp**
- **stp interface**
- **stp interface mcheck**
- **stp mcheck**

stp pathcost-standard

Purpose

Use the **stp pathcost-standard** command to set the standard for calculating the default path costs of the links to which the switch is connected to.

Use the **undo stp pathcost-standard** command to specify to use the default standard.

Syntax

```
stp pathcost-standard { dot1d-1998 | dot1t | legacy }
```

```
undo stp pathcost-standard
```

Parameters

dot1d-1998

Adopts the IEEE 802.1D-1998 standard to calculate the default path costs for ports.

dot1t

Adopts the IEEE 802.1t standard to calculate the default path costs for ports.

legacy

Adopts the standard defined by 3Com Corporation to calculate the default path costs for ports.

Default

By default, the IEEE 802.1t standard is used to calculate the default path costs for ports.

Example

Configure the switch to use the IEEE 802.1D-1998 standard to calculate the default path costs of its ports.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp pathcost-standard dot1d-1998
```

Configure the switch to use the IEEE 802.1t standard to calculate the default path costs of its ports.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp pathcost-standard dot1t
```

View

This command can be used in the following views:

- System view

Description

The following table lists transmission speeds and their corresponding path costs.

Table 99 Transmission speeds and the corresponding path costs

Transmission speed	Operation mode (half-/full-duplex)	IEEE 802.1t	3Com-3Com standard
		802.1D-1998	
0	-	65,535	200,000
10 Mbps	Half-Duplex	100	2,000
	Full-Duplex	99	2,000
	Aggregated Link 2 Ports	95	1,800
	Aggregated Link 3 Ports	95	1,600
	Aggregated Link 4 Ports	95	1,400
100 Mbps	Half-Duplex	19	200
	Full-Duplex	18	200
	Aggregated Link 2 Ports	15	180
	Aggregated Link 3 Ports	15	160
	Aggregated Link 4 Ports	15	140
1,000 Mbps	Full-Duplex	4	20
	Aggregated Link 2 Ports	3	18
	Aggregated Link 3 Ports	3	16
	Aggregated Link 4 Ports	3	14
10 Gbps	Full-Duplex	2	2
	Aggregated Link 2 Ports	1	1
	Aggregated Link 3 Ports	1	1
	Aggregated Link 4 Ports	1	1

Normally, the path cost of a port in full-duplex mode is slightly less than that of the port in half-duplex mode.

When calculating the path cost of an aggregate link, the 802.1D-1998 standard does not take the number of the aggregated links into account, whereas the 802.1T standard does so by using the following equation:

$$\text{Path cost} = 200,000,000 / \text{link transmission speed}$$

Where, the link transmission speed is the sum of the speeds of the unblocked ports for the aggregate link measured in 100 kbps units.

stp point-to-point

Purpose

Use the **stp point-to-point** command to specify whether the port must connect to point-to-point link.

Use the **undo stp point-to-point** command to restore the default setting.

Syntax

```
stp point-to-point { force-true | force-false | auto }
```

```
undo stp point-to-point
```

Parameters

force-true	Specifies the current Ethernet port to connect to point-to-point link.
force-false	Specifies the current Ethernet port to connect to a link that is not point-to-point.
auto	Specifies that MSTP automatically determines whether the current Ethernet port must connect to a point-to-point link.

Default

By default, the auto mode is used, that is, the switch automatically determines whether the port must connect to point-to-point link.

Example

Specify port Ethernet1/0/3 to connect to point-to-point link.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface Ethernet1/0/3
[S5500-Ethernet1/0/3] stp point-to-point force-true
```

View

This command can be used in the following views:

- Ethernet Port view

Description

The rapid transition feature is not applicable to ports that are connected to non-point-to-point links.

If an Ethernet port is the master port of an aggregation port or operates in full-duplex mode, then the link to which the port is connected is a point-to-point link. It is recommended that you specify the **auto** keyword in the **stp interface point-to-point** command for links of this kind to enable the type of the links being automatically determined by MSTP.

These two commands only apply to CISTs and MSTIs. If you configure the link to which a port is connected is a point-to-point link (or a non-point-to-point link), the configuration applies to all spanning tree instances (that is, the port is configured to connect to a point-to-point link [or a non-point-to-point link] in all spanning tree instances). If the actual physical link is not a point-to-point link and you configure the

link to which the port is connected to be a point-to-point link, loops may temporarily occur.

Related Command

stp interface point-to-point

stp port priority

Purpose

Use the **stp port priority** command to set the priority of the current port in a specified spanning tree instance.

Use the **undo stp port priority** command to restore the default priority of the current port in the specified spanning tree instance.

Syntax

```
stp [ instance instance-id ] port priority priority
```

```
undo stp [ instance instance-id ] port priority
```

Parameters

<i>instance-id</i>	Spanning tree instance ID. Valid values are 0 to 16. A value of 0 specifies the CIST.
port priority <i>priority</i>	Priority for the port. Valid values are 0 to 240 but must be a multiple of 16 (such as 0, 16, and 32). If not specified, the default port priority is 128.

Example

Set the priority of port Ethernet1/0/3 in spanning tree instance 2 to 16.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface Ethernet1/0/3
[S5500-Ethernet1/0/3] stp instance 2 port priority 16
```

View

This command can be used in the following views:

- Ethernet Port view

Description

If you specify the *instance-id* argument to be 0 or do not specify the argument, the configured priority applies to the CIST. The role a port plays in a spanning tree instance can be affected by its priority. A port on an MSTP-enabled switch can have different port priorities and play different roles in different MSTIs. This enables packets of different VLANs to be forwarded along different physical paths, implementing VLAN-based load balancing. Changes of port priorities can cause MSTP to redetermine the roles of ports, resulting in state transition of ports.

Related Command

```
stp interface port priority
```


stp priority

Purpose

Use the **stp priority** command to set the priority of a switch in a spanning tree instance.

Use the **undo stp priority** command to restore the default priority of a switch.

Syntax

```
stp [ instance instance-id ] priority priority
```

```
undo stp [ instance instance-id ] priority
```

Parameters

<i>instance-id</i>	Spanning tree instance ID. Valid values are 0 to 16. A value of 0 specifies the CIST.
<i>priority</i>	Priority for the switch. Valid values are 0 to 61,440 but must be a multiple of 4,096 (such as 0, 4096, and 8192). The total number of switch priorities is 16. If not specified, the default priority of a switch is 32,768.

Example

Set the priority of the switch in spanning tree instance 1 to 4,096.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp instance 1 priority 4096
```

View

This command can be used in the following views:

- System view

Description

Switch priorities are used for spanning tree generation and are spanning tree-specific. That is, a switch can be assigned different priorities in different spanning tree instances.

If you do not specify the *instance-id* argument, the configuration applies to the CIST.

stp region-configuration

Purpose Use the **stp region-configuration** command to enter MST region view.

Use the **undo stp region-configuration** command to restore the default MST region settings.

Syntax

```
stp region-configuration
undo stp region-configuration
```

Parameters None

Default The three MST region settings default to:

- MST region name: the first MAC address of the switch.
- All VLANs are mapped to the CIST.
- MSTP revision level: 0.

Example Enter MST region view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] stp region-configuration
[S5500-mst-region]
```

View This command can be used in the following views:

- System view

Description You can modify the three MST region settings (that is, the region name, revision level, and VLAN mapping table) in MST region view.

stp root primary

Purpose

Use the **stp root primary** command to configure the current switch to be the root bridge of a specified spanning tree instance.

Use the **undo stp root** command to cancel the configuration.

Syntax

```
stp [ instance instance-id ] root primary [ bridge-diameter bridgenum ]  
[ hello-time centi-seconds ]
```

```
undo stp [ instance instance-id ] root
```

Parameters

<i>instance-id</i>	Spanning tree instance ID. Valid values are 0 to 16. A value of 0 specifies the CIST.
<i>bridgenum</i>	Network diameter of the specified spanning tree. Valid values are 2 to 7. If not specified, the default is 7.
<i>centi-seconds</i>	Hello time of the specified spanning tree in centiseconds. Valid values are 100 to 1,000. If not specified, the default is 200.

Default

By default, a switch does not operate as a root bridge.

If you do not specify the *instance-id* argument, the configuration applies to the CIST.

Example

Configure the current switch to be the root bridge of spanning tree instance 1, setting the network diameter of the switched network to 4, and the Hello time to 500 centiseconds.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp instance 1 root primary bridge-diameter 4 hello-time 500
```

View

This command can be used in the following views:

- System view

Description

You can specify a root bridge for each spanning tree instance, leaving out the priority of the switch. If you also specify the network diameter, the switch will then figure out the three correlated parameters (that is, the Hello time, Forward delay, and Max age). As the Hello time calculated from the network diameter is not always the optimal one, you can set it manually by using the hello-time keyword. Normally, it is recommended that the Forward delay and Max age parameters be left automatically determined according to the network diameter setting.

**CAUTION:**

- *You can configure only one root bridge for a spanning tree instance and can configure one or more secondary root bridges for a spanning tree instance. Configuring multiple root bridges for a spanning tree instance causes unpredictable results.*
- *Once a switch is configured to be the root bridge or a secondary root bridge, its priority cannot be modified.*

stp root-protection

Purpose	<p>Use the stp root-protection command to enable the root protection function for the current port.</p> <p>Use the undo stp root-protection command to restore the default operation state of the root protection function.</p>
Syntax	<pre>stp root-protection undo stp root-protection</pre>
Parameters	None
Default	By default, the root protection function is disabled.
Example	<p>Enable the root protection function for port Ethernet1/0/1.</p> <pre><S5500> system-view System View: return to User View with Ctrl+Z. [S5500] interface Ethernet1/0/1 [S5500-Ethernet1/0/1] stp root-protection</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ Ethernet Port view
Description	<p>Configuration errors and malicious attacks may cause legal root bridges to receive BPDUs of higher priorities, and give up their roles as root bridges, which means network topology jitters. In this case, flows that should travel along high-speed links may be led to low-speed links, and network congestions may occur.</p> <p>You can avoid this problem by utilizing the root protection function. Ports with this function enabled can retain their roles in all spanning tree instances. When such a port receives BPDUs of higher priorities, its state is set to discarding and it stops forwarding any packets as if the connected link were down. Only when it receives no BPDUs of higher priorities in a specified period, does it resumes its normal state.</p>
Related Command	<pre>stp interface root-protection</pre>

stp root secondary

Purpose

Use the **stp root secondary** command to configure the current switch to be a secondary root bridge of a specified spanning tree instance.

Use the **undo stp root** command to cancel the configuration.

Syntax

```
stp [ instance instance-id ] root secondary [ bridge-diameter bridgenum ] [ hello-time centi-seconds ]
```

```
undo stp [ instance instance-id ] root
```

Parameters

<i>instance-id</i>	Spanning tree instance ID. Valid values are 0 to 16. A value of 0 specifies the CIST.
<i>bridgenum</i>	Network diameter of the specified spanning tree. Valid values are 2 to 7. If not specified, the default is 7.
<i>centi-seconds</i>	Hello time of the specified spanning tree in centiseconds. Valid values are 100 to 1,000. If not specified, the default is 200.

Default

By default, a switch does not operate as a secondary root bridge.

If you do not specify the *instance-id* argument, the configuration applies to the CIST.

Example

Configure the current switch to be a secondary root bridge of spanning tree instance 4, setting the network diameter of the switched network to 5 and the Hello time to 300 centiseconds.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] stp instance 4 root secondary bridge-diameter 5 hello-time 300
```

View

This command can be used in the following views:

- System view

Description

You can configure one or more secondary root bridges for a spanning tree instance. If the switch operating as the root bridge fails or is turned off, the secondary root bridge with the smallest MAC address becomes the root bridge.

You can also specify the network diameter and the Hello time of the switch while specifying a switch to be a secondary root bridge. The switch will then figures out the other two correlated settings (that is, the Forward delay and Max age). You can configure only one root bridge for a spanning tree instance and can configure one or more secondary root bridges for a spanning tree instance.

Once a switch is configured to be the root bridge or a secondary root bridge, its priority cannot be modified.

stp tc-protection

Purpose	Use the stp tc-protection command to enable or disable the TC-BPDU attack prevention function for the switch.
Syntax	<pre>stp tc-protection enable stp tc-protection disable</pre>
Parameters	None
Default	By default, the TC-BPDU attack prevention function is enabled.
Example	Enable the TC-BPDU attack prevention function for the switch. <pre><S5500> system-view System View: return to User View with Ctrl+Z. [S5500] stp tc-protection enable</pre>
View	This command can be used in the following views: <ul style="list-style-type: none">■ System view
Description	<p>A switch removes MAC address entries and ARP entries upon receiving TC-BPDUs. If a malicious user sends large amounts of TC-BPDUs to a switch in a short period, the switch may be busy removing MAC address entries and ARP entries, which may decrease the performance of the switch and introduce potential stability risks.</p> <p>With the TC-BPDU attack prevention function enabled, a switch performs removing operation only once in a specified period (10 seconds by default) after it receives a TC-BPDU. The switch also checks to see if other TC-BPDUs arrive and performs another removing operation in the next period if a TC-BPDU is received. Such a mechanism prevents a switch from being busy removing address entries and ARP entries.</p>

stp timeout-factor

Purpose

Use the `stp timeout-factor` command to configure the multiple of hello time for the Switch.

Use the `undo stp timeout-factor` command to restore the default multiple value.

Syntax

```
stp timeout-factor number
```

```
undo stp timeout-factor
```

Parameters

number

Specifies the multiple of hello time. Valid values are 3 to 7.

If not specified, the default multiple is 3.

Example

To set the multiple value of hello time to 7, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]stp timeout-factor 7
```

View

This command can be used in the following views:

- System view

Description

The Ethernet Switch transmits RSTP packets every hello time seconds. By default, if the Switch does not receive RSTP packets from the upstream Switch for 3 x hello time seconds, the Switch will decide the upstream Switch is dead and will recalculate the topology of the network. In a congested network, a system administrator may want to increase the timeout interval to prevent an unnecessary network topology change. This can be accomplished by using the timeout-factor command to set the multiplier to the desired value. The higher the multiplier the greater the timeout interval. It is recommended to set 5, 6 or 7 as the value of multiple in the steady network.

stp timer-factor

Purpose

Use the **stp timer-factor** command to set the timeout time of a switch in terms of the multiple of the Hello time. For example, with the number argument set to 3, the timeout time is three times of the Hello time.

Use the **undo stp timer-factor** command to restore the default Hello time factor.

Syntax

```
stp timer-factor number
```

```
undo stp timer-factor
```

Parameters

number

Timeout time factor. Valid values are 1 to 10. If not specified, the default is 3.

Example

Set the Hello time factor to 7.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp timer-factor 7
```

View

This command can be used in the following views:

- System view

Description

A switch sends protocol packets to its neighboring devices in the specified Hello time interval to test the connectivity of links. Normally, if a switch does not receive any protocol packets from its upstream switch in a period three times of the Hello time, it assumes that the upstream switch is down and recalculates the spanning trees.

Spanning tree recalculation may also occur in a very stable network where certain upstream switches are busy. In this case, you can increase the timeout time to four or more times of the Hello time. For stable networks, a timeout time of five to seven times of the Hello time is recommended.

stp timer forward-delay

Purpose

Use the **stp timer forward-delay** command to set the Forward delay for a switch.

Use the **undo stp timer forward-delay** command to revert to the default Forward delay.

Syntax

```
stp timer forward-delay centi-seconds
```

```
undo stp timer forward-delay
```

Parameters

centi-seconds

Forward delay in centiseconds. Valid values are 400 to 3,000.

If not specified, the default is 1,500.

Example

Set the Forward delay to 2,000 centiseconds.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp timer forward-delay 2000
```

View

This command can be used in the following views:

- System view

Description

To prevent temporary loops while ports change their states, each port undergoes an intermediate period when it changes from the discarding state to the forwarding state to allow for synchronizing with the remote switches. This intermediate period is determined by the Forward delay configured on the root bridge.

The Forward delay setting configured for a root bridge applies to all switches operating in the spanning tree instance, including the root bridge.

As for the configuration of the three time-related parameters (that is, the Hello time, Forward delay, and Max age parameters), you can refer to the following expressions to prevent networks from jittering frequently.

$2 * (\text{Forward delay} - 1 \text{ second}) \geq \text{Max age}$,

$\text{Max age} \geq 2 * (\text{Hello time} + 1 \text{ second})$.

It is recommended that you specify the network diameter and the Hello time parameter by using the **stp root primary** or **stp root secondary** command in a network with MSTP employed, after which the three optimized time-related parameters are automatically determined.

Related Commands

- `stp bridge-diameter`
- `stp timer hello`
- `stp timer max-age`

stp timer hello

Purpose

Use the **stp timer hello** command to set the Hello time for a switch.

Use the **undo stp timer hello** command to restore the default Hello time.

Syntax

```
stp timer hello centi-seconds
```

```
undo stp timer hello
```

Parameters

centi-seconds

Integer for the Hello time in centiseconds. Valid values are 100 to 1,000.
If not specified, the default is 200.

Example

Set the Hello time to 400 centiseconds.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp timer hello 400
```

View

This command can be used in the following views:

- System view

Description

MSTP sends BPDUs regularly to maintain the spanning trees. The Hello time argument controls the interval for sending BPDUs. If a switch does not receive any BPDU for a specific period, that is, a BPDU timeout occurs, the switch initiates the spanning tree recalculation process. All switches in a spanning tree use the Hello time configured for the root bridge.

The settings of the three MSTP time parameters must satisfy the following expressions to prevent frequent network jitters:

$$2 * (\text{Forward delay} - 1 \text{ second}) \geq \text{Max age}$$
$$\text{Max age} \geq 2 * (\text{Hello time} + 1 \text{ second})$$

It is recommended that you specify the network diameter and the Hello time by using the **stp root primary** or **stp root secondary** command. MSTP will then automatically calculate the optimal values of the three parameters.

Related Commands

- **stp bridge-diameter**
- **stp timer forward-delay**
- **stp timer max-age**

stp timer max-age

Purpose

Use the **stp timer max-age** command to set the Max age for a switch.

Use the **undo stp timer max-age** command to restore the default Max age.

Syntax

```
stp timer max-age centi-seconds
```

```
undo stp timer max-age
```

Parameters

centi-seconds

Max age in centiseconds. Valid values are 600 to 4,000.

If not specified, the default is 2,000.

Example

Set the Max age to 1,000 centiseconds.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] stp timer max-age 1000
```

View

This command can be used in the following views:

- System view

Description

MSTP is capable of detecting link problems and automatically setting redundant links to forwarding state. In a CIST, the Max age is the criterion for switches to judge whether or not a received BPDU is timed out. And spanning trees will be regenerated if a BPDU received by a port is timed out.

The Max age argument is meaningless to MSTIs. All switches in a CIST uses the Max age configured for the root bridge of the CIST to judge whether a BPDU is timed out.

The settings of the three MSTP time parameters must satisfy the following expressions to prevent frequent network jitters:

$$2 * (\text{Forward delay} - 1 \text{ second}) \geq \text{Max age}$$
$$\text{Max age} \geq 2 * (\text{Hello time} + 1 \text{ second})$$

It is recommended that you specify the network diameter and the Hello time by using the **stp root primary** or **stp root secondary** command. MSTP will then automatically calculate the optimal values of the three parameters.

Related Commands

- **stp bridge-diameter**
- **stp timer forward-delay**
- **stp timer hello**

stp transmit-limit

Purpose

Use the **stp transmit-limit** command to set the maximum number of BPDUs the current port can transmit within a Hello time interval.

Use the **undo stp transmit-limit** command to restore the default.

Syntax

```
stp transmit-limit packetnum
```

```
undo stp transmit-limit
```

Parameters

packetnum

Maximum number of BPDUs that the port can transmit within a Hello time interval. Valid values are 1 to 255. If not specified, the default is 3.

Example

Set the maximum number of BPDUs that port Ethernet1/0/1 can transmit in a Hello time interval to 5.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface Ethernet1/0/1
[S5500-Ethernet1/0/1] stp transmit-limit 5
```

View

This command can be used in the following views:

- Ethernet Port view

Description

A larger *packetnum* value means a greater number of packets can be transmitted in each Hello time interval and more switch resources will be consumed. Configure the *packetnum* argument to a proper value to limit the number of BPDUs sent in each Hello time interval, preventing MSTP from occupying too much network resources when network topology jitters occur.

Related Command

```
stp interface transmit-limit
```

stub

Purpose

Using the **stub** command, you can configure the type of an OSPF area as “stub”.

Using the **undo stub** command, you can cancel the setting. By default, no OSPF areas are set as Stub areas.

Using the **default-cost** command, you can configure the default route cost.

Syntax

```
stub [ no-summary ]
```

```
undo stub
```

Parameters

no-summary

Enter to prevent the transmission of Summary LSAs to the Stub area.

Default

If the router is an ABR, it will send a default route to the connected stub area.

Example

To set the type of OSPF area 1 to Stub, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf]area 1
[SW5500-ospf-1-area-0.0.0.1]stub
```

View

This command can be used in the following views:

- OSPF Area view

Related Command

default cost

summary

Purpose

Use the **summary** command to activate RIP-2 automatic route summarization. This is the default.

Use the **undo summary** command to disable RIP-2 automatic route summarization.

Syntax

summary

undo summary

Parameters

None

Example

To set the RIP version on the interface Vlan-interface 1 to RIP-2, and then disable the route aggregation, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]interface Vlan-interface 1
[SW5500-Vlan-interface1]rip version 2
[SW5500-Vlan-interface1]quit
[SW5500]rip
[SW5500-rip]undo summary
```

View

This command can be used in the following views:

- RIP view

Description

Route aggregation can be performed to reduce the routing traffic on the network as well as to reduce the size of the routing table. RIP-1 does not support subnet masks. Forwarding sub-netted routes may cause ambiguity. Networks that use RIP-1 should always use the natural mask. Therefore, RIP-1 uses route summarization all the time. If RIP-2 is used, route summarization function can be disabled with the **undo summary** command, when it is necessary to broadcast the subnet route.

Related Command

rip version

super

Purpose	Use the super command to give users access to a higher level than their currently assigned user level.
Syntax	<code>super level</code>
Parameters	<code>level</code> Specifies a user level. Valid values are 0 to 3. If not specified, the default is 3.
Example	<p>To change to user level 3 from the current user level.</p> <pre><SW5500>super 3 Password:</pre> <p>The password prompt displays only if you set a password using the super password command.</p>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ Any view
Description	<p>Login users are classified into four levels that correspond to the four command levels. A user can only use commands at the levels that are equal to or lower than their user level.</p> <p>To ensure that only an authorized user can access the higher level, use the super password command to set a password for the higher level. If the user does not enter a valid password, the user level does not change.</p>
Related Command	<ul style="list-style-type: none">■ <code>quit</code>■ <code>super password</code>

super password

Purpose

Use the **super password** command to configure the password for changing the user from a lower level to a higher level.

Use the undo **super password** command to cancel the password settings.

Syntax

```
super password [ level level ] { simple | cipher } password  
undo super password [ level level ]
```

Parameters

<i>level</i>	Specifies a user level. Valid values are 1 to 3. The password you enter is set for the specified level. If not specified, the default is 3.
<i>cipher</i>	Displays the password in encrypted text.
<i>simple</i>	Displays the password in plain text.
<i>password</i>	If the authentication is in the simple mode, the password must be in plain text. If the authentication is in the cipher mode, the password can be either in encrypted text or in plain text. If a plain text password is entered when cipher mode has been selected, the password will be displayed in the configuration settings as encrypted. A plain text password is a sequential character string of no more than 16 digits, for example, 3Com918. The length of an encrypted password must be 24 digits and in encrypted text, for example, _(TT8F]Y\5SQ=^Q'MAF4<1!!.

Example

To set the password for level 3 to **zbr**, type the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]super password level 3 simple zbr
```

View

This command can be used in the following views:

- System view

Description

To prevent unauthorized users from illegal intrusion, user ID authentication is performed when users switch from a lower level to a higher level. For the sake of confidentiality, on the screen the user cannot see the password that he entered. The user has three chances to input valid password, and then switch to the higher level. Otherwise, the original user level will remain unchanged. The password in plain text is required when performing authentication, regardless of whether the configuration is plain text or encrypted text.

sysname

Purpose

Use the **sysname** command to configure the host name of the Switch.

Use the **undo sysname** command to restore the host name to the default of SW5500.

Syntax

```
sysname text
```

```
undo sysname
```

Parameters

text

Specifies the host name of the Switch. The host name must be no more than 30 characters long. If not specified, the default host name is SW5500.

Example

To configure the hostname of the Switch to 3Com, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]sysname 3Com  
[3Com]
```

View

This command can be used in the following views:

- System view

Description

Changing the hostname of the Ethernet switch will affect the prompt of command line interface. For example, if the hostname of the Ethernet switch is *MyHost*, the prompt in user view will be *<MyHost>*.

sysname

Purpose

Use the `sysname` command to change the name of the fabric.

Use the `undo sysname` command to restore the default fabric name.

Syntax

```
sysname sysname
```

```
undo sysname
```

Parameters

sysname

A string comprised of 1 to 30 characters.
If not specified, the default Fabric name of Ethernet Switch is SW5500.

Example

To change the fabric name of the device to "hello", enter the following:

```
<SW5500>display xrn-fabric
Fabric name is SW5500, system mode is L3.
Fabric authentication: no authentication, unit number: 1.
Unit Name      Unit ID
First          1(*)
Second         2
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]sysname hello
[hello]display xrn-fabric
Fabric name is SW5500, system mode is L3.
Fabric authentication: no authentication, unit number: 1.
Unit Name      Unit ID
First          1(*)
Second         2
```

View

This command can be used in the following views:

- System view

Description

The modification will affect the prompt character in the command line interface. For example, if the fabric name of the Switch is SW5500, the prompt character in user view is `<SW5500>`.

sysname

Purpose

Use the **sysname** command to set the system name of the Switch.

Use the **undo sysname** command to restore the default value of the system name.

Syntax

```
sysname sysname
```

```
undo sysname
```

Parameters

sysname

Specifies the hostname, comprised of a character string from 1 to 30 characters long.

Default

By default, the system name of the Switch is SW5500.

Example

Set the hostname of the Switch to be LANSwitch.

```
<5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]sysname LANSwitch  
[LANSwitch]
```

View

This command can be used in the following views:

- System view

Description

Changing the system name of the Switch will affect the prompt of the command line interface. For example, the system name of the Switch is SW5500, and the prompt in user view is <SW5500>.

system-view

Purpose Enter `system-view` to enter the system view from the user view.

Syntax `system-view`

Parameters None

Example To enter system view from user view, enter the following:

```
<SW5500>system-view
System view: return to User View with Ctrl+Z.
[SW5500]
```

View This command can be used in the following views:

- User view

Related Commands

- `quit`
- `return`

tcp timer fin-timeout

Purpose

Use the `tcp timer fin-timeout` command to configure the TCP finwait timer.

Use the `undo tcp timer fin-timeout` command to restore the default value of the TCP finwait timer.

Syntax

```
tcp timer fin-timeout time-value
```

```
undo tcp timer fin-timeout
```

Parameters

time-value

Specifies the TCP finwait timer value in seconds. Valid values are 76 to 3600.

If not specified, the default is 675 seconds.

Example

To configure the TCP finwait timer value as 800 seconds, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]tcp timer fin-timeout 800
```

View

This command can be used in the following views:

- System view

Description

When the TCP connection state changes from FIN_WATI_1 to FIN_WAIT_2, the finwait timer is enabled. If the switch does not receive FIN packet before finwait timer timeouts, the TCP connection will be terminated.

Related Commands

- `tcp timer syn-timeout`
- `tcp window`

tcp timer syn-timeout

Purpose

Use the `tcp timer syn-timeout` command to configure the TCP synwait timer.

Use the `undo tcp timer syn-timeout` command to restore the default value of the timer.

Syntax

```
tcp timer syn-timeout time-value
```

```
undo tcp timer syn-timeout
```

Parameters

time-value

Specifies the TCP synwait timer value measured in seconds. Valid values are 2 to 600.
If not specified, the default time-value is 75 seconds.

Example

To configure the TCP synwait timer value as 80 seconds, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]tcp timer syn-timeout 80
```

View

This command can be used in the following views:

- System view

Description

TCP will enable the synwait timer, if a SYN packet is sent. The TCP connection will be terminated if the response packet is not received.

Related Commands

- `tcp timer fin-timeout`
- `tcp window`

tcp window

Purpose

Use the `tcp window` command to configure the size of the transmission and receiving buffers of the connection-oriented Socket.

Use the `undo tcp window` command to restore the default size of the buffer.

Syntax

```
tcp window window-size
```

```
undo tcp window
```

Parameters

window-size

Specifies the size of the transmission and receiving buffers measured in kilobytes (KB). Valid values are 1 to 32.

If not specified, the default window-size is 4KB.

Example

To configure the size of the transmission and receiving buffers as 3KB, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]tcp window 3
```

View

This command can be used in the following views:

- System view

Related Commands

- `tcp timer fin-timeout`
- `tcp timer syn-timeout`

telnet

Purpose Use the `telnet` command to log in to another Ethernet switch from the current switch via Telnet for remote management.

Syntax `telnet { hostname | ip_address } [service_port]`

Parameters

<i>hostname</i>	Specifies the host name of the remote Switch. It is configured using the <code>ip host</code> command.
<i>ip_address</i>	Specifies the IP address or the host name of the remote Switch. If you enter the host name, the Switch must be set to static resolution.
<i>service_port</i>	Designates the management port on the remote Switch, in the range 0 to 65535. If not specified, the default Telnet port number of 23 is used.

Example To log in to the Ethernet switch Switch32 at IP address 10.1.1.1 from the current Switch (Switch01), enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]user-interface vty 0 4
[SW5500-ui-vty0-4]authentication-mode none
<Switch01>telnet 10.1.1.1
Trying 10.1.1.1....
Press CTRL+K to abort
Connected to 10.1.1.1...
*****
*           All rights reserved (1997-2004)           *
*           Without the owner's prior written consent, *
*no decompiling or reverse-engineering shall be allowed.*
*****
<Switch32>
```

View This command can be used in the following views:

- User view

Description To terminate the Telnet logon, press `<Ctrl+K>` or `<Ctrl+]>`.

Related Command `display tcp status`

telnet-server source-interface

Purpose

Use the **telnet-server source-interface** command to specify source interface for the Telnet server.

Use the **undo telnet-server source-interface** command to clear the source interface configuration. After that, the source address in the packets sent to the Telnet client is determined by the system.

Syntax

```
telnet-server source-interface interface-type interface-number
```

```
undo telnet-server source-interface
```

Parameters

interface-type

Source interface type. If you specify a nonexistent interface in the command, your configuration fails.

interface-number

Source interface number. If you specify a nonexistent interface in the command, your configuration fails.

Example

Specify source interface for the Telnet server.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] telnet-server source-interface NULL 0
```

View

This command can be used in the following views:

- System view

telnet-server source-ip

Purpose

Use the **telnet-server source-ip** command to specify source IP address for the Telnet server.

Use the **undo telnet-server source-ip** command to clear the source IP address configuration. After that, the source address in the packets sent to the Telnet client is determined by the system.

Syntax

```
telnet-server source-ip ip-addr
```

```
undo telnet-server source-ip
```

Parameters

ip-addr

Source IP address. If the *ip-addr* in the command is not an address of the device, your configuration fails.

Example

Specify source IP address for the Telnet server.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] telnet-server source-ip 192.168.1.1
```

View

This command can be used in the following views:

- System view

telnet source-interface

Purpose

Use the **telnet source-interface** command to specify source interface for the Telnet client.

Use the **undo telnet source-interface** command to clear the source interface configuration. After that, the source address in the packets sent to the Telnet server is determined by the system.

Syntax

```
telnet source-interface interface-type interface-number
```

```
undo telnet source-interface
```

Parameters

interface-type Source interface type. If you specify a nonexistent interface in the command, your configuration fails.

interface-number Source interface number.

Example

Specify source interface for the Telnet client.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] telnet source-interface Vlan-interface 2
```

View

This command can be used in the following views:

- System view

telnet source-ip

Purpose

Use the **telnet source-ip** command to specify source IP address for the Telnet client.

Use the **undo telnet source-ip** command to clear the source IP address configuration. After that, the source address in the packets sent to the Telnet server is determined by the system.

Syntax

```
telnet source-ip ip-addr
```

```
undo telnet source-ip
```

Parameters

ip-addr

Source IP address. If the *ip-addr* in the command is not an address of the device, your configuration fails.

Example

Specify source IP address for the Telnet client.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] telnet source-ip 192.168.1.1
```

View

This command can be used in the following views:

- System view

terminal debugging

Purpose	<p>Use the <code>terminal debugging</code> command to configure to display the debugging information on the terminal.</p> <p>Use the <code>undo terminal debugging</code> command to configure not to display the debugging information on the terminal.</p>
Syntax	<pre>terminal debugging undo terminal debugging</pre>
Parameters	None
Default	By default, the displaying function is disabled.
Example	<p>Enable the terminal display debugging.</p> <pre><SW5500>terminal debugging % Current terminal debugging is on <SW5500></pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ User view
Related Command	<code>debugging</code>

terminal logging

Purpose	<p>Use the <code>terminal logging</code> command to start logging the information displayed on the terminal.</p> <p>Use the <code>undo terminal logging</code> command to disable terminal log information display.</p>
Syntax	<pre>terminal logging undo terminal logging</pre>
Parameters	None
Default	By default, this function is enabled.
Example	<p>Disable the terminal log display.</p> <pre><SW5500>undo terminal logging % Current terminal logging is off <SW5500></pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ User view

terminal monitor

Purpose Use the `terminal monitor` command to enable the log debugging/log/trap on the terminal monitor.

Use the `undo terminal monitor` command to disable these functions.

Syntax

```
terminal monitor
undo terminal monitor
```

Parameters None

Default By default, enable these functions for the console user and disable them for the terminal user.

Example Disable the terminal monitor.

```
<SW5500>undo terminal monitor
% Current terminal monitor is off
<SW5500>
```

View This command can be used in the following views:

- User view

Description This command only takes effect on the current terminal where the commands are input. The debugging/log/trap information can be output to the current terminal, beginning in user view. When the terminal monitor is shut down, no debugging/log/trap information will be displayed in local terminal, which is equals to having performed the `undo terminal debugging`, `undo terminal logging`, `undo terminal trapping` commands. When the terminal monitor is enabled to use `terminal debugging / undo terminal debugging`, `terminal logging / terminal logging and terminal trapping / undo terminal trapping` respectively to enable or disable the corresponding functions.

terminal trapping

Purpose Use the `terminal trapping` command to enable terminal trap information display.

Use the `undo terminal trapping` command to disable this function.

Syntax `terminal trapping`

`undo terminal trapping`

Parameters None

Default By default, this function is enabled.

Example Enable trap information display.

```
<SW5500>terminal trapping
% Current terminal trapping is on
<SW5500>
```

View This command can be used in the following views:

- User view

test-enable

Purpose Use the **test-enable** command to execute the current remote-ping test.

Use the **undo test-enable** command to stop the remote-ping test.

Syntax

```
test-enable  
undo test-enable
```


Parameters None

Example Execute the remote-ping test defined by the test group administrator icmp.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] remote-ping administrator icmp  
[S5500-remote-ping-administrator-icmp] test-enable
```

View This command can be used in the following views:

- Remote-Ping Test Group view

Description  After you execute the **test-enable** command, the system does not display the test results automatically. You can view the test results by executing the **display remote-ping** command.

Related Command **display remote-ping**

test-type

Purpose Use the **test-type** command to configure the type of the test.

Syntax `test-type type`

Parameters `type` Test type.

Example Set the test type to ICMP.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] remote-ping administrator icmp
[S5500-remote-ping-administrator-icmp] test-type icmp
```

View This command can be used in the following views:

- Remote-Ping Test Group view

Description Currently the system only supports ICMP test.

tftp cluster get

Purpose Use the **tftp cluster get** command to download a specified file from a cluster TFTP server.

Syntax `tftp cluster get source-file [destination-file]`

Parameters

<i>source-file:</i>	Directory and the name of the file to be downloaded on the cluster TFTP server.
<i>destination-file:</i>	Local directory and the file name which the downloaded file is to be saved as.

Example Download the file named LANSwitch.app from the cluster TFTP server and save it as vs.app.

```
<123_1.S5500> tftp cluster get LANSwitch.app vs.app
```

View This command can be used in the following views:

- User view

Related Command `tftp cluster put`

tftp cluster put

Purpose Use the **tftp put** command to upload a specified file to a specified directory of a cluster TFTP server.

Syntax `tftp cluster put source-file [destination-file]`

Parameters

<i>source-file</i>	Directory and the name of the file to be uploaded.
<i>destination-file</i>	Remote directory and the file name which the uploaded file is to be saved as.

Example Upload the local file named vrpcfg.txt to the cluster TFTP server and save it as Temp.txt.

```
<123_1.S5500> tftp cluster put vrpcfg.txt temp.txt
```

View This command can be used in the following views:

- User view

Related Command `tftp cluster get`

tftp get

- Purpose** Use the **tftp get** command to download a file from a TFTP server to this switch.
- Syntax** `tftp tftp-server get source-file [dest-file]`
- Parameters**
- | | |
|--------------------|--|
| <i>tftp-server</i> | IP address or host name of a TFTP server. |
| <i>source-file</i> | Name of the file which will be downloaded from the TFTP server. |
| <i>dest-file</i> | Name of the file to which the downloaded file will be saved on the switch. |
- Example** Download the file LANSwitch.bin from the TFTP server with the IP address of 1.1.3.214 to this switch and save it to the file vs.bin.
- ```
<S5500> tftp 1.1.3.214 get LANSwitch.bin vs.bin
```
- View** This command can be used in the following views:
- User view



# tftp put

---

**Purpose** Use the `tftp put` command to upload a file from the switch to the specified directory on the TFTP server and save it with a new name.

**Syntax** `tftp tftp-server put source-file [ dest-file ]`

|                   |                    |                                                                                                                          |
|-------------------|--------------------|--------------------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | <i>tftp-server</i> | IP address or host name of the TFTP server. The name of the TFTP server should be a string from 1 to 20 characters long. |
|                   | <i>source-file</i> | Specifies the file name of the source file that is saved on the switch.                                                  |
|                   | <i>dest-file</i>   | Specifies the file name of the destination file that will be saved on the TFTP server.                                   |

**Example** `<SW5500>tftp 1.1.3.214 put sw5500cfg.txt temp.txt`

**View** This command can be used in the following views:

- User view

**Related Command** `tftp get`

# tftp-server

---

## Purpose

Use the **tftp-server** command to configure the public TFTP server for cluster members on the management device.

Use the **undo tftp-server** command to cancel the public TFTP server configuration.

## Syntax

```
tftp-server ip-address
```

```
undo tftp-server
```

## Parameters

*ip-address*

IP address of TFTP server configured for the cluster.

## Default

By default, no public TFTP server is configured.

Only after you assign an IP address for TFTP server of the cluster, member devices can access it through the management device.

## Example

Configure an IP address for the TFTP server on the management device.

```
<aaa_0.S5500>system-view
System View: return to User View with Ctrl+Z.
[aaa_0.S5500]cluster
[aaa_0.S5500-cluster] tftp-server 1.0.0.9
```

## View

This command can be used in the following views:

- Cluster view

## Description

These commands can only be executed on the management device.

# tftp source-interface

---

**Purpose** Use the **tftp source-interface interface** command to specify source interface for the TFTP client. If you specify a nonexistent interface in the command, your configuration fails.

**Syntax** `tftp source-interface interface-type interface-number`

**Parameters**

|                         |                          |
|-------------------------|--------------------------|
| <i>interface-type</i>   | Source interface type.   |
| <i>interface-number</i> | Source interface number. |

**Example** Specify source interface for the TFTP client.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] tftp source-interface Vlan-interface 1
```

**View** This command can be used in the following views:

- System view

# tftp source-ip

---

## Purpose

Use the **tftp source-ip** command to specify source IP address for the TFTP client. If the **ip-addr** in the command is not an address of the device, your configuration fails.

Use the **undo tftp source-ip** command to clear the source IP address configuration. After that, the source address in the packets sent to the TFTP server is determined by the system.

## Syntax

```
tftp source-ip ip-addr
```

```
undo tftp source-ip
```

## Parameters

**ip-addr** Source IP address.

## Example

Specify source IP address for the TFTP client.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] tftp source-ip 192.168.0.1
```

## View

This command can be used in the following views:

- System view

# tftp tftp-server source-interface

---

**Purpose** Use the `tftp tftp-server source-interface` command to use a specified source interface to establish a connection with a TFTP server.

**Syntax** `tftp tftp-server source-interface interface-type interface-number`

|                   |                         |                                                                                                    |
|-------------------|-------------------------|----------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | <i>tftp-server</i>      | IP address or host name of a TFTP server.                                                          |
|                   | <i>interface-type</i>   | Source interface type. If you specify a nonexistent interface in the command, the command fails.   |
|                   | <i>interface-number</i> | Source interface number. If you specify a nonexistent interface in the command, the command fails. |

**Example** Use a specified source interface to establish a connection with a remote TFTP server.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] tftp 192.168.8.8 source-interface Vlan-interface 1
```

**View** This command can be used in the following views:

- User view

# tftp tftp-server source-ip

---

**Purpose** Use the **tftp tftp-server source-ip** command to use a specified source IP address to establish a connection with a TFTP server.

**Syntax** `tftp tftp-server source-ip ip-addr`

**Parameters**

|                          |                                         |
|--------------------------|-----------------------------------------|
| <code>tftp-server</code> | IP address or host name of TFTP server. |
| <code>ip-addr</code>     | Source IP address.                      |

**Example** Use a specified source IP address to establish a connection with a remote TFTP server.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] tftp 192.168.8.8 source-ip 192.168.0.1
```

**View** This command can be used in the following views:

- User view

# time-range

---

## Purpose

Use the `time-range` command to configure a time range.

Use the `undo time-range` command to delete a time range.

## Syntax

```
time-range time-name { start-time to end-time days-of-the-week [from
start-time start-date] [to end-time end-date] | from start-time
start-date [to end-time end-date] | to end-time end-date }
```

```
undo time-range time-name [start-time to end-time days-of-the-week [
from start-time start-date] [to end-time end-date] | from start-time
start-date [to end-time end-date] | to end-time end-date]
```

## Parameters

|                                         |                                                                                                                                                                                                                                                                                                                                                                                                     |
|-----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>time-name</code>                  | Name of a special time range to be referenced.                                                                                                                                                                                                                                                                                                                                                      |
| <code>start-time</code>                 | Start time of the special time range, format as hh:mm.                                                                                                                                                                                                                                                                                                                                              |
| <code>end-time</code>                   | End time of the special time range, format as hh:mm.                                                                                                                                                                                                                                                                                                                                                |
| <code>days-of-the-week</code>           | Means the special time is effective on a specified day every week. You can input the following parameters: <ul style="list-style-type: none"><li>■ Numbers (ranging from 0 to 6)</li><li>■ Monday, Tuesday, Wednesday, Thursday, Friday, Saturday or Sunday</li><li>■ Working-day, representing 5 working days, from Monday to Friday</li><li>■ Off-day, representing Saturday and Sunday</li></ul> |
| <code>from start-time start-date</code> | The start date of a special time-range, together with <code>end-time end-date</code> means this special time-range is effective during a certain period, notated as hh:mm MM/DD/YYYY.                                                                                                                                                                                                               |
| <code>to end-time end-date</code>       | The end date of a special time-range, together with <code>start-time start-date</code> means this special time-range is effective during a certain period, notated as hh:mm MM/DD/YYYY.                                                                                                                                                                                                             |

If the two parameters above are not configured, it means there is no restriction to time-range.

## Example

Configure a time range to take effect at 00:00 on January 1, 2000 with no end date specified.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]time-range test from 0:0 1-1-2000
```

**View**

This command can be used in the following views:

- System view

**Description**

If you input the parameter when using the **undo time-range** command, the system will cancel the corresponding content of the parameters in the time range.



# timeout

---

**Purpose** Use the **timeout** command to configure the timeout time of the test.  
Use the **undo timeout** command to restore the default timeout time.

**Syntax** `timeout time`  
`undo timeout`

**Parameters** `time` Timeout time. Valid values are 1 to 60.  
If not specified, the default is 3 (in seconds).

**Example** Set the timeout time of the test group administrator icmp to 10 seconds.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] remote-ping administrator icmp
[S5500-remote-ping-administrator-icmp] timeout 10
```

**View** This command can be used in the following views:

- Remote-Ping Test Group view

# timer

---

## Purpose

Use the **timer** command to set the interval of handshake packets.

Use the **undo timer** command to restore the default interval value.

## Syntax

```
timer interval
```

```
undo timer
```

## Parameters

*Interval*

Handshake packet interval. Valid values are 1 to 255 seconds.

If not specified, the default is 10 seconds.

## Example

Configure to send handshake packets once every 3 seconds.

```
<aaa_0.S5500>system-view
System View: return to User View with Ctrl+Z.
[aaa_0.S5500]cluster
[aaa_0.S5500-cluster] timer 3
```

## View

This command can be used in the following views:

- Cluster view

## Description

Inside a cluster, member devices communicate in real time with the management device through transmitting handshake packets. The regular handshake helps monitor the states of cluster members and links.

This command can only be executed on the management device, which will advertise the cluster timer value to member devices.

# timer loop

---

**Purpose** Use the **timer loop** command to set the detecting interval, that is, the frequency to perform auto detect.

**Syntax** `timer loop seconds`

**Parameters** *seconds* Detecting interval. Valid values are 1 to 86,400 in seconds.  
If not specified, the default is 15.

**Example** Set the detecting interval of detecting group 10 to 60 seconds.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] detect-group 10
[S5500-detect-group-10] timer loop 60
```

**View** This command can be used in the following views:

- Detecting Group view

# timer quiet

---

## Purpose

Use the **timer quiet** command to set the waiting time before the primary server resumes the active state.

Use the **undo timer quiet** command to restore the default configuration.

## Syntax

```
timer quiet minutes
```

```
undo timer quiet
```

## Parameters

*minutes*

The number of minutes the primary server must wait before it resumes the active state. Valid values are 1 to 255 minutes.  
If not specified, the default is 5.

## Example

Set the quiet timer for the primary server to ten minutes.

```
[S5500] hwtacacs scheme test1
[S5500-hwtacacs-test1] timer quiet 10
```

## View

This command can be used in the following views:

- HWTACACS view

## Description

This command is designed to inhibit the switch from processing user request packets for a time when the communication between the switch and the server is interrupted. After the switch waits for a time that is equal or greater than the time set by this command, it re-attempts to send packets to the server.

## Related Command

**display hwtacacs**

# timer realtime-accounting

---

**Purpose** Use the `timer realtime-accounting` command to set the real-time accounting interval.

Use the `undo timer realtime-accounting` command to restore the default interval.

**Syntax**

```
timer realtime-accounting minutes
undo timer realtime-accounting
```

**Parameters**

*minutes*: Real-time accounting interval. Valid values are 3 to 60 minutes and must be a multiple of 3. If not specified, the default is 12 minutes.

**Example** Set the real-time accounting interval of the HWTACACS scheme 3Com to 51 minutes.

```
[S5500-hwtacacs-3Com] timer realtime-accounting 51
```

**View** This command can be used in the following views:

- HWTACACS view

**Description** The setting of real-time accounting interval is necessary for real-time accounting. After an interval is set, the NAS transmits the accounting information of online users to the TACACS accounting server periodically.


The setting of real-time accounting interval somewhat depends on the performance of the NAS and the TACACS server: a shorter interval requires higher device performance. You are therefore recommended to adopt a longer interval when there are a large number of users (more than 1000, inclusive). The following table lists the numbers of users and the recommended intervals.

**Table 100** Number of users and recommended interval

| Number of users | Real-time accounting interval (minutes) |
|-----------------|-----------------------------------------|
| 1 – 99          | 3                                       |
| 100 – 499       | 6                                       |
| 500 – 999       | 12                                      |
| ≥1000           | ≥15                                     |

# timer response-timeout

---

|                        |                                                                                                                                                                                                                                            |
|------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>         | <p>Use the <code>timer response-timeout</code> command to set the TACACS server response timeout time.</p> <p>Use the <code>undo timer response-timeout</code> command to restore the default setting.</p>                                 |
| <b>Syntax</b>          | <pre>timer response-timeout <i>seconds</i><br/>undo timer response-timeout</pre>                                                                                                                                                           |
| <b>Parameters</b>      | <p><i>seconds</i> TACACS server response timeout time. Valid values are 1 to 300 seconds.<br/>If not specified, the default is 5 seconds.</p>                                                                                              |
| <b>Example</b>         | <p>Set the TACACS server response timeout time to 30 seconds.</p> <pre>[S5500] hwtacacs scheme test1<br/>[S5500-hwtacacs-test1] timer response-timeout 30</pre>                                                                            |
| <b>View</b>            | <p>This command can be used in the following views: S5500</p> <ul style="list-style-type: none"><li>■ HWTACACS view</li></ul>                                                                                                              |
| <b>Description</b>     | <p> <i>Since HWTACACS is implemented based on TCP, so server response timeout or TCP timeout may terminate the connection to the TACACS server.</i></p> |
| <b>Related Command</b> | <pre>display hwtacacs</pre>                                                                                                                                                                                                                |

# timer retry

---

**Purpose** Use the `timer retry` command to configure a connection request retry interval.

Use the `undo timer retry` command to restore the default value.

**Syntax** `timer retry seconds`

`undo timer retry`

**Parameters** `seconds:` Connection request retry interval in seconds. Valid values are 1 to 60. If not specified, the default is 30 seconds.

**Example** Set the connection request retry interval to 60 seconds.

```
<S5500> system-view
[S5500] msdp
[S5500-msdp] timer retry 60
```

**View** This command can be used in the following views:

- MSDP view

**Related Command** `peer`

# timer wait

---

|                   |                                                                                                                                                                                                                  |                                                                                                                     |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>    | Use the <b>timer wait</b> command to set the timeout time for detect operations.                                                                                                                                 |                                                                                                                     |
| <b>Syntax</b>     | <code>timer wait <i>seconds</i></code>                                                                                                                                                                           |                                                                                                                     |
| <b>Parameters</b> | <i>seconds</i>                                                                                                                                                                                                   | Timeout time of detect operations. Valid values are 1 to 30 seconds.<br>If not specified, the default is 2 seconds. |
| <b>Example</b>    | Set the timeout time to 3 seconds for detecting group 10.<br><br><pre>&lt;S5500&gt; system-view System View: return to User View with Ctrl+Z. [S5500] detect-group 10 [S5500-detect-group-10] timer wait 3</pre> |                                                                                                                     |
| <b>View</b>       | This command can be used in the following views: <ul style="list-style-type: none"><li>■ Detecting Group view</li></ul>                                                                                          |                                                                                                                     |



# timers

---

## Purpose

Use the **timers** command to modify the values of the three RIP timers: period update, timeout, and garbage-collection.

Use the **undo timers** command to restore the default settings.

## Syntax

```
timers { update update-timer-length | timeout timeout-timer-length } *
undo timers { update | timeout } *
```

## Parameters

|                             |                                                                                                                                           |
|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <i>update-timer-length</i>  | Specifies the value of the period update timer. Valid values are 1 to 3600 seconds.<br>If not specified, the default value is 30 seconds. |
| <i>timeout-timer-length</i> | Specifies the value of the timeout timer. Valid values are 1 to 3600 seconds.<br>If not specified, the default value is 180 seconds.      |

## Default

By default, the values of period update, timeout, and garbage-collection timers are 30 seconds, 180 seconds, and 120 seconds, respectively.

Generally, the value of the garbage-collection timer is fixed to 4 times the value of the period update timer. Adjusting the period update timer will affect the garbage-collection timer.

The modification of RIP timers takes effect immediately.

## Example

```
Set the values of the Period Update timer and the Timeout timer of RIP
to 10 seconds and 30 seconds respectively.
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]rip
[SW5500-rip]timers update 10 timeout 30
```

## View

This command can be used in the following views:

- RIP view

## Related Command

**display rip**

# tracert

---

**Purpose** Use the **tracert** command to check the reachability of network connection and troubleshoot the network.

**Syntax** `tracert [[ -a source-ip] -f first-TTL ] [ -m max-TTL ] [ -p port ] [ -q nqueries ] [ -w timeout ] string`

|                   |                            |                                                                                                                               |
|-------------------|----------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b> | <b>-a <i>source-IP</i></b> | Configures the source IP address used by tracert command.                                                                     |
|                   | <b>-f</b>                  | Configures to verify the -f switch, <i>first-TTL</i> specifies an initial TTL, ranging from 0 to the maximum TTL.             |
|                   | <b>-m</b>                  | Configures to verify the -m switch, <i>max-TTL</i> specifies a maximum TTL larger than the initial TTL.                       |
|                   | <b>-p</b>                  | Configures to verify the -p switch, <i>port</i> is an integer host port number. Generally, user need not modify this option.  |
|                   | <b>-q</b>                  | Configures to verify the -q switch, <i>nqueries</i> is an integer specifying the number of query packets sent, larger than 0. |
|                   | <b>-w</b>                  | Configures to verify the -w switch, <i>timeout</i> is an integer specifying IP packet timeout in seconds, larger than 0.      |
|                   | <b><i>string</i></b>       | IP address of the destination host or the hostname of the remote system.                                                      |

**Default** By default, when the parameters are not specified,

- *first-TTL* is 1,
- *max-TTL* is 30,
- *port* is 33434,
- *nqueries* is 3 and
- *timeout* is 5s.

**Example** Test the gateways passed by the packets to the destination host at 18.26.0.115.

```
<SW5500>tracert 18.26.0.115
tracert to allspice.lcs.mit.edu (18.26.0.115), 30 hops max
1 helios.ee.lbl.gov (128.3.112.1) 0 ms 0 ms 0 ms
2 lilac-dmc.Berkeley.EDU (128.32.216.1) 19 ms 19 ms 19 ms
3 lilac-dmc.Berkeley.EDU (128.32.216.1) 39 ms 19 ms 19 ms
4 ccngw-ner-cc.Berkeley.EDU (128.32.136.23) 19 ms 39 ms 39 ms
5 ccn-nerif22.Berkeley.EDU (128.32.168.22) 20 ms 39 ms 39 ms
6 128.32.197.4 (128.32.197.4) 59 ms 119 ms 39 ms
7 131.119.2.5 (131.119.2.5) 59 ms 59 ms 39 ms
```

```
8 129.140.70.13 (129.140.70.13) 80 ms 79 ms 99 ms
9 129.140.71.6 (129.140.71.6) 139 ms 139 ms 159 ms
10 129.140.81.7 (129.140.81.7) 199 ms 180 ms 300 ms
11 129.140.72.17 (129.140.72.17) 300 ms 239 ms 239 ms
12 * * *
13 128.121.54.72 (128.121.54.72) 259 ms 499 ms 279 ms
14 * * *
15 * * *
16 * * *
17 * * *
18 ALLSPICE.LCS.MIT.EDU (18.26.0.115) 339 ms 279 ms 279 ms
```

## View

This command can be used in the following views:

- Any view

## Description

Users can test gateways passed by the packets transmitted from the host to the destination.

The **tracert** command sends a packet with TTL 1, and the first hop will send an ICMP error message back to indicate this packet cannot be transmitted (because of TTL timeout). Then this packet will be sent again with TTL 2, and the second hop will indicate a TTL timeout error. Perform this operation repeatedly till reaching the destination. These processes are operated to record the source address of each ICMP TTL timeout so as to provide a path to the destination for an IP packet.

After the **ping** command finds some error on the network, perform **tracert** to locate the error.

The output of the **tracert** command includes IP address of all the gateways to the destination. If a certain gateway times out, output "\*\*\*".

# traffic-limit

---

## Purpose

Use the `traffic-limit` command, to activate the ACL and perform traffic limitation.

Use the `undo traffic-limit` command to remove traffic limitation.

## Syntax

```
traffic-limit inbound { user-group acl-number [rule rule] | ip-group
acl-number [rule rule [link-group acl-number rule rule]] |
link-group acl-number [rule rule] } target-rate [exceed action]
```

```
undo traffic-limit inbound { user-group { acl-number [rule rule] |
ip-group acl-number [rule rule [link-group acl-number rule rule]] |
link-group acl-number [rule rule] }
```

## Parameters

|                                           |                                                                                                                                                                                                                                                                                                                                                                                     |
|-------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>inbound</code>                      | Performs traffic limitation to the packets received by the interface.                                                                                                                                                                                                                                                                                                               |
| <code>user-group <i>acl-number</i></code> | Activates user-defined ACLs. <b><i>acl-number</i></b> : Sequence number of ACL. Valid values are 5000 to 5999.                                                                                                                                                                                                                                                                      |
| <code>ip-group <i>acl-number</i></code>   | Activates IP ACLs, including basic and advanced ACLs. <b><i>acl-number</i></b> : Sequence number of ACL. Valid values are 2000 to 3999.                                                                                                                                                                                                                                             |
| <code>link-group <i>acl-number</i></code> | Activates Layer 2 ACLs. <b><i>acl-number</i></b> : Sequence number of ACL. Valid values are 4000 to 4999.                                                                                                                                                                                                                                                                           |
| <code>rule <i>rule</i></code>             | Specifies the sub-item of an active ACL. Valid values are 0 to 65534; if not specified, all sub-items of the ACL will be activated. If only an IP ACL or a Layer 2 ACL is activated, this parameter can be omitted. If both IP and Layer 2 ACLs are activated at the same time, the <i>rule</i> parameter cannot be omitted.                                                        |
| <code><i>target-rate</i></code>           | The set normal traffic, unit in Kbps, the granularity of traffic limit is 64 kbps, if the number input is in ( N*64 <the number input<(N+1)*64), in which N is a natural number, the Switch automatically sets (N+1)*64 as the parameter value. For 100 Mbps ports, <b><i>target-rate</i></b> ranges from 64 to 99968 inclusive; for 1000 Mbps ports, from 64 to 1000000 inclusive. |
| <code>exceed <i>action</i></code>         | The action taken when the traffic exceeds the threshold. The <b><i>action</i></b> can be: <ul style="list-style-type: none"> <li>■ <b><i>drop</i></b>: Drops the packets.</li> <li>■ <b><i>remark-dscp value</i></b>: Sets new DSCP value.</li> </ul>                                                                                                                               |

## Example

Perform traffic limitation on packets that match the permit rule of ACL 2000. The target traffic rate is 128 kbps.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Ethernet 1/0/1
[SW5500-Ethernet1/0/1] traffic-limit inbound ip-group 2000 128
[SW5500-Ethernet1/0/1]
```

## View

This command can be used in the following views:

- Ethernet Port view

## Description

This command performs traffic limitation on the packets that match with a specified ACL rule, and is only effective with a permit rule.

The granularity of traffic limit is 64 kbps.



*You can only remark traffic with a DSCP value. The Switch 5500 does not permit CoS remarking with this command.*

# traffic-limit

---

## Purpose

Use the `traffic-limit` command to add traffic policing action in the QoS profile, with the granularity of 64 kbps.

Use the `undo traffic-limit` command to remove traffic policing action from the QoS profile.

## Syntax

```
traffic-limit inbound { user-group acl-number [rule rule] | ip-group
acl-number [rule rule [link-group acl-number rule rule]] |
link-group acl-number [rule rule] } target-rate [exceed action]

undo traffic-limit inbound { user-group acl-number [rule rule] |
ip-group acl-number [rule rule [link-group acl-number rule rule]] |
link-group acl-number [rule rule] }
```

## Parameters

|                                           |                                                                                                                                                                                                                                                                                                                                                                                          |
|-------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>inbound</code>                      | Sets traffic limiting for the inbound packets on the port.                                                                                                                                                                                                                                                                                                                               |
| <code>user-group <i>acl-number</i></code> | Custom ACL. Valid values are 5000 to 5999                                                                                                                                                                                                                                                                                                                                                |
| <code>ip-group <i>acl-number</i></code>   | Basic or advanced ACL. Valid values are 2000 to 3999.                                                                                                                                                                                                                                                                                                                                    |
| <code>link-group <i>acl-number</i></code> | Layer 2 ACL. Valid values are 4000 to 4999.                                                                                                                                                                                                                                                                                                                                              |
| <code>rule <i>rule</i></code>             | Specifies a match statement in the ACL. Valid values are 0 to 65534. All match statements are selected if you skip this keyword.                                                                                                                                                                                                                                                         |
| <code><i>target-rate</i></code>           | The set normal traffic, unit in Kbps, the granularity of traffic limit is 64kbps, if the number input is in ( $N*64 < \text{the number input} < (N+1)*64$ ], in which N is a natural number, the Switch automatically sets $(N+1)*64$ as the parameter value. For 100 Mbps port, <i>target-rate</i> ranges from 64 to 99968 inclusive; for 1000 Mbps port, from 64 to 1000000 inclusive. |
| <code>exceed <i>action</i></code>         | Action taken when the traffic threshold is exceeded (optional). Two actions are available: <ul style="list-style-type: none"> <li>■ <code>drop</code>: Drops packets.</li> <li>■ <code>remark-dscp <i>value</i></code>: Sets a new DSCP value.</li> </ul>                                                                                                                                |

## Example

To add to the qos-profile student this traffic policing action: Limits traffic for the packets matching ACL 2000, the target rate is 128 kbps, drop the packets at a rate exceeding this target rate, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]qos-profile student
[SW5500-qos-profilestudent]traffic-limit inbound ip-group 2000 128
exceed drop
[SW5500-qos-profilestudent]
```

## View

This command can be used in the following views:

- QoS Profile view

## Description

You cannot remove traffic policing action from the specific QoS profile that has been applied to the port.

# traffic-priority

---

## Purpose

Use the `traffic-priority` command to activate an ACL and perform priority marking.

Use the `undo traffic-priority` command to remove the priority marking.

## Syntax

```
traffic-priority { inbound | outbound } { user-group acl-number [rule rule] | ip-group acl-number [rule rule [link-group acl-number rule rule]] | link-group acl-number [rule rule] } { { dscp dscp-value | ip-precedence { pre-value | from-cos } } | cos { pre-value | from-ipprec } | local-precedence pre-value }*
```

```
undo traffic-priority { inbound | outbound } { user-group acl-number [rule rule] | ip-group acl-number [rule rule [link-group acl-number rule rule]] | link-group acl-number [rule rule] }
```

## Parameters

|                                                            |                                                                                                                                                                                                                                                                                                                                 |
|------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>inbound</code>                                       | Performs priority marking to the packets received by the interface.                                                                                                                                                                                                                                                             |
| <code>outbound</code>                                      | Performs priority marking to the packets sent by the interface.                                                                                                                                                                                                                                                                 |
| <code>user-group <b>acl-number</b></code>                  | Activates user-defined ACLs. <b>acl-number</b> : Sequence number of ACL. Valid values are 5000 to 5999.                                                                                                                                                                                                                         |
| <code>ip-group <b>acl-number</b></code>                    | Activates IP ACLs, including basic and advanced ACLs. <b>acl-number</b> : Sequence number of ACL. Valid values are 2000 to 3999.                                                                                                                                                                                                |
| <code>link-group <b>acl-number</b></code>                  | Activates Layer 2 ACLs. <b>acl-number</b> : Sequence number of ACL. Valid values are 4000 to 4999.                                                                                                                                                                                                                              |
| <code>rule <b>rule</b></code>                              | Specifies the sub-item of an active ACL. Valid values are 0 to 65534.<br>If not specified, all sub-items of the ACL will be activated. If only an IP ACL or a Layer 2 ACL is activated, this parameter can be omitted. If both IP and Layer 2 ACLs are activated at the same time, the <i>rule</i> parameter cannot be omitted. |
| <code>dscp <b>dscp-value</b></code>                        | Sets DSCP priority. Valid values are 0 to 63.                                                                                                                                                                                                                                                                                   |
| <code>ip-precedence { <b>pre-value</b>   from-cos }</code> | Sets IP precedence, pre-value. Valid values are 0 to 7. from-cos means to set the IP precedence with the corresponding 802.1p priority value.                                                                                                                                                                                   |
| <code>cos { <b>pre-value</b>   from-ipprec }</code>        | Sets 802.1p priority, pre-valu. Valid values are 0 to 7. from-ipprec means to set the 802.1p priority of the packet with the corresponding 802.1p priority value.                                                                                                                                                               |
| <code>local-precedence</code>                              | This does not actually remark the packet but gives it an internal "local-precedence" that determines which queue it is assigned to. The queue can be determined                                                                                                                                                                 |



by looking at cos-local precedence map using the display qos cos-local-precedence command.

## Example

Perform priority marking to packets that match with the permit rule of ACL 2000. Set its 802.1p priority to 0.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]interface Ethernet 1/0/1
[SW5500-Ethernet1/0/1]traffic-priority outbound ip-group 2000 cos 0
[SW5500-Ethernet1/0/1]
```

## View

This command can be used in the following views:

- Ethernet Port view

## Description

The system can mark the packets with various levels DSCP priority, IP Precedence, CoS (802.1p) priority and local Precedence.

## Related Command

`display qos-interface traffic-priority`

# traffic-priority

---

## Purpose

Use the **traffic-priority** command to enable traffic priority marking for traffic that matches the ACL.

Use the **undo traffic-priority** command to remove traffic priority marking.

## Syntax

```
traffic-priority { inbound | outbound } { user-group acl-number [rule rule] | ip-group acl-number [rule rule [link-group acl-number rule rule]] | link-group acl-number [rule rule] } { { dscp dscp-value | ip-precedence { pre-value | from-cos } } | { pre-value | from-ipprec } | local-precedence pre-value }*
```

```
undo traffic-priority { inbound | outbound } { user-group acl-number [rule rule] | ip-group acl-number [rule rule [link-group acl-number rule rule]] | link-group acl-number [rule rule] }
```

## Parameters

|                                               |                                                                                                                                     |
|-----------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| <b>inbound</b>                                | Replaces the preference value for the inbound packets on the port.                                                                  |
| <b>outbound</b>                               | Replaces the preference value for the outbound packets on the port.                                                                 |
| <b>user-group acl-number</b>                  | Custom ACL. Valid values are 5000 to 5999.                                                                                          |
| <b>ip-group acl-number</b>                    | Basic or advanced ACL. Valid values are 2000 to 3999.                                                                               |
| <b>link-group acl-number</b>                  | Layer 2 ACL. Valid values are 4000 to 4999.                                                                                         |
| <b>rule rule</b>                              | Specifies a match statement in the ACL. Valid values are 0 to 65534. All match statements are selected if you skip this keyword.    |
| <b>dscp dscp-value</b>                        | Sets DSCP preference value. Valid values are 0 to 63.                                                                               |
| <b>ip-precedence { pre-value   from-cos }</b> | Set IP precedence value, pre-value is in the range 0 to 7. from-cos sets the IP precedence value consistent with the 802.1p value.  |
| <b>cos { pre-value   from-ipprec }</b>        | Sets the 802.1p value, pre-value is in the range 0 to 7. from-ipprec sets the 802.1p value consistent with the IP precedence value. |
| <b>local-precedence pre-value</b>             | Sets local preference value. Valid values are 0 to 7.                                                                               |

## Example

To add to the student profile this preference replacing action: Sets local preference 0 to the inbound packets matching the ACL 2000, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500]qos-profile student
[SW5500-qos-profilestudent]traffic-priority inbound ip-group 2000
local-precedence 0
[SW5500-qos-profilestudent]
```

## View

This command can be used in the following views:

- QoS Profile view

## Description

You cannot remove traffic priority marking from the specific QoS profile that has been applied to the port.

# traffic-redirect

---

## Purpose

Use the `traffic-redirect` command to activate the ACL to recognize and redirect the traffic (whose action is permit).

Use the `undo traffic-redirect` command to cancel the redirection.

## Syntax

```
traffic-redirect { inbound | outbound } { user-group acl-number [rule rule] | ip-group acl-number [rule rule [link-group acl-number rule rule]] | link-group acl-number [rule rule] } { cpu | interface { interface-name / interface-type interface-num } }
```

```
undo traffic-redirect { inbound | outbound } { user-group acl-number [rule rule] | ip-group acl-number [rule rule [link-group acl-number rule rule]] | link-group acl-number [rule rule] }
```

## Parameters

|                                                                                               |                                                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>inbound</code>                                                                          | Performs traffic redirecting on the packets received by the interface.                                                                                                                                                                                                                                                                                                                      |
| <code>outbound</code>                                                                         | Performs traffic redirecting on the packets sent by the interface.                                                                                                                                                                                                                                                                                                                          |
| <code>user-group <i>acl-number</i></code>                                                     | Activates user-defined ACLs. <b><i>acl-number</i></b> : Sequence number of ACL. Valid values are 5000 to 5999.                                                                                                                                                                                                                                                                              |
| <code>ip-group <i>acl-number</i></code>                                                       | Activates IP ACLs, including basic and advanced ACLs. <b><i>acl-number</i></b> : Sequence number of ACL. Valid values are 2000 to 3999.                                                                                                                                                                                                                                                     |
| <code>link-group <i>acl-number</i></code>                                                     | Activates Layer 2 ACLs. <b><i>acl-number</i></b> : Sequence number of ACL. Valid values are 4000 to 4999.                                                                                                                                                                                                                                                                                   |
| <code>rule <i>rule</i></code>                                                                 | Specifies the sub-item of an active ACL, ranging from 0 to 65534; if not specified, all sub-items of the ACL will be activated. If only an IP ACL or a Layer 2 ACL is activated, this parameter can be omitted. If both IP and Layer 2 ACLs are activated at the same time, the <i>rule</i> parameter cannot be omitted.                                                                    |
| <code>cpu</code>                                                                              | Configures to redirect the traffic to the CPU.                                                                                                                                                                                                                                                                                                                                              |
| <code>interface { <i>interface-name</i> / <i>interface-type</i> <i>interface-num</i> }</code> | Specifies the Ethernet port to which the packets will be redirected. <b><i>interface-type</i></b> specifies the port type. <b><i>interface-num</i></b> specifies the port number. <b><i>interface-num</i></b> and <b><i>interface-type</i></b> specify a complete port name together. <b><i>interface-name</i></b> is <b><i>interface-type</i></b> added with <b><i>interface-num</i></b> . |

## Example

Redirects the packets matching the ACL 2000 rules with action permit to the port Ethernet1/0/1.

```
<SW5500>system-view
System View: return to User View with Ctrl+Z
[SW5500] interface Ethernet1/0/2
[SW5500-Ethernet1/0/2] traffic-redirect inbound ip-group 2000 interface
ethernet1/0/1
[SW5500-Ethernet1/0/2]
```

## View

This command can be used in the following views:

- Ethernet Port view

## Description



*You can only redirect traffic within the same unit. That is to say that if you receive traffic on port 2/0/1 you can only redirect it to another port in unit 2.*

# traffic-share-across-interface

---

- Purpose** Use the **traffic-share-across-interface** command to enable traffic sharing across RIP interfaces to averagely distribute the traffic to the RIP interfaces of the router through equal-cost routes.
- Use the undo **traffic-share-across-interface** command to disable traffic sharing.
- Syntax** **traffic-share-across-interface**
- undo traffic-share-across-interface**
- Parameters** None
- Default** By default, traffic sharing across RIP interfaces is disabled.
- Example** Enable traffic sharing across RIP interfaces.
- ```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] rip
[S5500-rip] traffic-share-across-interface
```
- View** This command can be used in the following views:
- RIP view

traffic-statistic

Purpose

Use the **traffic-statistic** command to activate the ACL to recognize and count the traffic (whose action is permit).

Use the **undo traffic-statistic** command to cancel the traffic statistics.

Syntax

```
traffic-statistic inbound { user-group acl-number [ rule rule ] |  
ip-group acl-number [ rule rule [ link-group acl-number rule rule ] ]  
| link-group acl-number [ rule rule ] }
```

```
undo traffic-statistic inbound { user-group acl-number [ rule rule ]  
| ip-group acl-number [ rule rule [ link-group acl-number rule rule ] ]  
| link-group acl-number [ rule rule ] }
```

Parameters

inbound	Performs traffic statistic on the packets received by the interface.
user-group acl-number	Activates user-defined ACLs. acl-number : Sequence number of ACL. Valid values are 5000 to 5999.
ip-group acl-number	Activates IP ACLs, including basic and advanced ACLs. acl-number : Sequence number of ACL. Valid values are 2000 to 3999.
link-group acl-number	Activates Layer 2 ACLs. acl-number : Sequence number of ACL. Valid values are 4000 to 4999.
rule rule	Specifies the sub-item of an active ACL. Valid values are 0 to 65534. If not specified, all sub-items of the ACL will be activated. If only an IP ACL or a Layer 2 ACL is activated, this parameter can be omitted. If both IP and Layer 2 ACLs are activated at the same time, the rule parameter cannot be omitted.

Example

Count the packets matching the ACL 2000 rules with action **permit**.

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]interface Ethernet 1/0/1  
[SW5500-Ethernet1/0/1]traffic-statistic inbound ip-group 2000  
[SW5500-Ethernet1/0/1]
```

View

This command can be used in the following views:

- System view

Description

The statistics information of **traffic-statistic** command keeps track of the number of times a packet is matched to the ACL. You can use the **display traffic-statistic** command to display the statistics information.

Related Command`display qos-interface traffic-statistic`

udp-helper enable

Purpose	<p>Use the <code>udp-helper enable</code> command to enable the UDP Helper function.</p> <p>Use the <code>undo udp-helper enable</code> command to disable the UDP Helper function.</p>
Syntax	<pre>udp-helper enable undo udp-helper enable</pre>
Parameters	None
Default	By default, UDP Helper function is disabled.
Example	<p>To enable the UDP Helper function.</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]udp-helper enable</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view

udp-helper port

Purpose

Use the `udp-helper port` command to configure the UDP port with relay function.

Use the `undo udp-helper enable` command to delete the UDP port with relay function.

Syntax

```
udp-helper port { port | dns | netbios-ds | netbios-ns | tacacs | tftp  
| time }
```

```
undo udp-helper port { port | dns | netbios-ds | netbios-ns | tacacs |  
tftp | time }
```

Parameters

<code>port</code>	Specifies the ID of the UDP port with relay function to be enabled. Valid values are 1 to 65535.
<code>dns</code>	Domain name service, corresponding to UDP port 53.
<code>netbios-ds</code>	NetBios datagram service, corresponding to UDP port 138.
<code>netbios-ns</code>	NetBios name service, corresponding to UDP port 137.
<code>tacacs</code>	TAC access control system, corresponding to UDP port 49.
<code>tftp</code>	Trivial file transfer protocol, corresponding to UDP port 69.
<code>time</code>	Time service, corresponding to UDP port 37.

Example

To configure the UDP port with relay function as the UDP port corresponding to DNS, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]udp-helper port dns
```

View

This command can be used in the following views:

- System view

udp-helper server

Purpose Use the `udp-helper server` command to configure the relay destination server.
Use the `undo udp-helper server` command to delete the relay destination server.

Syntax

```
udp-helper server ip-address  
undo udp-helper server [ ip-address ]
```

Parameters *ip-address* Specifies the IP address of the destination server.

Default By default, no relay destination server is configured.

Example To configure the relay destination server with IP address 192.1.1.2, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]interface vlan-interface 1  
[SW5500-Vlan-interface1]udp-helper server 192.1.1.2
```

View This command can be used in the following views:

- VLAN Interface view

Related Command `display udp-helper server`

undelete

Purpose Use the **undelete** command to recover the deleted file.

Syntax `undelete file-path`

Parameters `file-path` Name of the file to be recovered.

Example Display the information for all of the files in the current directory, including the deleted files.

```
<SW5500>dir /all
Directory of unit1>flash:/
  0  -rw-      595  Jul 12 2001 20:13:19  test.txt
  1  -rw-       50  Jul 12 2001 20:09:23  [sample.bak]
16125952 bytes total (13972480 bytes free)
```

Recover the deleted file `sample.bak`.

```
<SW5500>undelete sample.bak
Undelete unit1>flash:/sample.bak ?[confirm]:y
% Undeleted file unit1>flash:/sample.bak
```

Display the information for all of the files in the current directory, including the deleted files.

```
<SW5500>dir /all
Directory of unit1>flash:/
  0  -rw-       50  Jul 12 2001 20:34:19  sample.bak
  1  -rw-      595  Jul 12 2001 20:13:19  test.txt
16125952 bytes total (13972480 bytes free)
```

View This command can be used in the following views:

- User view

Description The file name to be recovered cannot be the same as an existing directory name. If the destination file name is the same as an existing file name, a prompt will be displayed asking whether to overwrite the existing file.

undo snmp-agent

Purpose	Use the <code>undo snmp-agent</code> command to disable all versions of SNMP running on the server.
Syntax	<code>undo snmp-agent</code>
Parameters	None
Example	<p>Disable the running SNMP agents of all SNMP versions.</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]undo snmp-agent [SW5500]</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view
Description	Any <code>snmp-agent</code> command will enable SNMP Agent.

unicast-suppression

Purpose	Use unicast-suppression to configure the amount of unicast traffic that will be accepted on a port.				
Syntax	<pre>unicast-suppression { <i>ratio</i> pps <i>pps</i> } undo unicast-suppression</pre>				
Parameters	<table><tr><td>ratio</td><td>Specifies the bandwidth ratio of unicast traffic allowed on an Ethernet port. Valid ratio values are 1 to 100. The incremental step is 1. If not specified, the default ratio is 100, meaning that all unicast traffic is accepted. The smaller the ratio is, the less bandwidth is allocated to unicast traffic and therefore less broadcast traffic is accepted on the Ethernet port.</td></tr><tr><td>pps pps</td><td>Specifies the maximum number of unicast packets per second accepted on an Ethernet port. Valid values are 1 to 148810 pps.</td></tr></table>	ratio	Specifies the bandwidth ratio of unicast traffic allowed on an Ethernet port. Valid ratio values are 1 to 100. The incremental step is 1. If not specified, the default ratio is 100, meaning that all unicast traffic is accepted. The smaller the ratio is, the less bandwidth is allocated to unicast traffic and therefore less broadcast traffic is accepted on the Ethernet port.	pps pps	Specifies the maximum number of unicast packets per second accepted on an Ethernet port. Valid values are 1 to 148810 pps.
ratio	Specifies the bandwidth ratio of unicast traffic allowed on an Ethernet port. Valid ratio values are 1 to 100. The incremental step is 1. If not specified, the default ratio is 100, meaning that all unicast traffic is accepted. The smaller the ratio is, the less bandwidth is allocated to unicast traffic and therefore less broadcast traffic is accepted on the Ethernet port.				
pps pps	Specifies the maximum number of unicast packets per second accepted on an Ethernet port. Valid values are 1 to 148810 pps.				
Example	<p>Enable a limit of 20% of the available bandwidth on a port to be allocated to unicast traffic. Unicast traffic exceeding 20% of the ports bandwidth will be discarded.</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]interface ethernet 1/0/1 [SW5500-Ethernet1/0/1]unicast-suppression 20 [SW5500-Ethernet1/0/1]</pre> <p>Specify the maximum packets per second of the unicast traffic on an Ethernet1/0/1 as 1000 Mpps.</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]interface ethernet 1/0/1 [SW5500-Ethernet1/0/1]unicast-suppression pps 1000 [SW5500-Ethernet1/0/1]</pre>				
View	This command can be used in the following views: <ul style="list-style-type: none">■ Ethernet Port view				
Description	Once the multicast traffic exceeds the value set by the user, the excess unicast traffic will be discarded. This feature can be used to ensure network service and prevent unicast storms.				

update fabric

Purpose Use the **update fabric** command to update all the units in the fabric by using the App, BootROM, or Web file on a unit in the fabric.

Syntax `update fabric file-name`

Parameters `file-name` Name of the file used for the update.

Example Update all other units in the fabric by using the App file Switch 5500.app on this unit.

```
<5600-EI>display xm-fabric
Fabric name is 5600-EI, system mode is L3.
Fabric authentication : no authentication, number of units in stack: 1.
Unit Name                               Unit ID
First                                    1(*)
First                                    2
First                                    8(*)
<5600-EI >update fabric Switch 5500.app
This will update the Fabric. Continue? [Y/N] y
The software is verifying ...
The result of verification is :
Unit ID  Free space(bytes)  Enough  Version comparison
1        2126848             Y       Y
2        2125824             Y       Y
8        1439744             Y       Y
warning: the verification is completed, start the file transmission
[Y/N] y
The fabric is being updated, 100%
The Switch 5500.app is stored on unit 1 successfully
The Switch 5500.app is stored on unit 2 successfully
The Switch 5500.app is stored on unit 8 successfully
Do you want to set Switch 5500.app to be running agent next time to
boot[Y/N] y
The Switch 5500.app is configured successfully
```

View This command can be used in the following views:

- User view

Description



CAUTION: You can use the **update fabric** command only after inhibiting service traffic.

Currently, the system supports the global update of App, BootROM and Web file, and can distinguish the type of update file by the suffix of the file name. For example, SWITCH 5500.app, SWITCH 5500.btm, and SWITCH 5500.web can be used to update the host software, BootROM file, and Web file respectively.

Note:



- *The suffix of the update file can be web, app, or btm.*
- *The update file must have already existed in the root directory on a unit in the fabric.*
- *After the file synchronization is completed, the file will be copied to the root directories on other units in the fabric.*
- *In the executing process of the **update fabric** command, the system first obtains information about the free space on each unit, and then reports whether the remaining available space in the flash memory on each unit is sufficient. If there is not enough available space (the available space must be one KB larger than the size of the updating file for the update to proceed), the system prompts you to clean the flash memory on the unit to continue the stack update operation.*
- *Before actually transmitting the update file, the system obtains the version information of the corresponding file type on each unit, performs compatibility comparison, and then displays the comparison results. If the update file cannot substitute for the app, web or btm file on a unit, the command execution fails and the system displays the reason of the failure.*
- *You must update the app and btm files in all units in the fabric (stack) before you can update the web file. After using **update fabric** to update the app and btm files, reboot the system and then use **update fabric** again to update the web file.*

user

Purpose Use the **user** command to register an FTP user.

Syntax `user username [password]`

Parameters

<i>username</i>	Logon username.
<i>password</i>	Logon password.

Example Log in the FTP Server with username `tom` and password `hello`.

```
<SW5500>ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in
[ftp]user tom hello
331 Password required for tom.
230 User logged in.
[ftp]
```

View This command can be used in the following views:

- FTP Client view

user-interface

Purpose Using **user-interface** command, you can enter single user interface view or multiple user interface views to configure the corresponding user interfaces.

Syntax `user-interface [type] first_number [last_number]`

Parameters	<i>type</i>	Specifies the user interface type, which can be AUX or VTY.
	<i>first_number</i>	Specifies the number of the first user interface to be configured.
	<i>last_number</i>	Specifies the number of the last user interface to be configured.

Example To configure the user interfaces with index numbers 0 to 9, enter the following:


```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]user-interface 0 9
[SW5500-ui0-9]
```

This example command selects two AUX (Console) port user interfaces and two VTY user interfaces (VTY 0, VTY 1). You can now assign access levels to these interfaces using the user privilege level command.

View This command can be used in the following views:

- System view

user-name-format

Purpose	Use the user-name-format command to set the username format acceptable to the TACACS server.	
Syntax	user-name-format { with-domain without-domain }	
Parameters	with-domain	Specifies that the domain name is taken along with the username that will be sent to the TACACS server
	without-domain	Specifies that no domain name is taken along with the username that will be sent to the TACACS server
Example	Specify that no domain name is taken along with the username that will be sent out with the HWTACACS scheme 3Com. <pre>[S5500-hwtacacs-3Com] user-name-format without-domain</pre>	
View	This command can be used in the following views: <ul style="list-style-type: none">■ HWTACACS view	
Description	<p>For a HWTACACS scheme, each username sent to a TACACS server contains a domain name by default.</p> <p>Username is usually in the "userid@isp-name" format, with the ISP domain name following "@". The switch uses domain names to group users to different ISP domains. While some earlier TACACS servers do not accept the username with domain name. In this case, you must remove the domain name before sending a username to the server.</p> <p> <i>When you specify that no ISP domain name is contained in usernames for a HWTACACS scheme, this scheme cannot be used in two or more ISP domains at the same time; otherwise, errors may occur because the TACACS server considers users in different ISP domains but with the same name as one user.</i></p>	
Related Command	hwtacacs scheme	

user privilege level

Purpose	<p>Use the user privilege level <i>level</i> command to configure the command level that a user can access from the specified user interface.</p> <p>Use the undo user privilege level command to restore the default command level.</p>		
Syntax	<pre>user privilege level <i>level</i> undo user privilege level</pre>		
Parameters	<table> <tr> <td style="vertical-align: top;"><i>level</i></td> <td>Specifies the level of command that a user can access. Valid values are 0 to 3.</td> </tr> </table>	<i>level</i>	Specifies the level of command that a user can access. Valid values are 0 to 3.
<i>level</i>	Specifies the level of command that a user can access. Valid values are 0 to 3.		
Default	By default, a user can access all commands at Level 3 after logging in through the AUX User Interface, and all commands at Level 0 after logging in through a VTY user interface.		
Example	<p>To configure a user to access command level 0 after logging in from the VTY 0 user interface, enter the following:</p> <pre><SW5500>system-view System View: return to User View with Ctrl+Z. [SW5500]user privilege level 0 When the user Telnets from the VTY 0 user interface to the switch, the terminal displays commands at level 0, as shown below: <SW5500>? User view commands: debugging Debugging functions language-mode Specify the language environment ping Ping function quit Exit from current command view super Privilege current user a specified priority level telnet Establish one TELNET connection tracert Trace route function undo Negate a command or set its default</pre>		
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none"> ■ User Interface view 		
Description	The user can use all the available commands at this command level.		

verbose

Purpose Use the **verbose** command to enable verbose.
Use the **undo verbose** command to disable verbose.

Syntax **verbose**
undo verbose

Parameters None

Default By default, verbose is disabled.

Example Enable verbose.

```
<SW5500>ftp 1.1.1.1
Trying ...
Press CTRL+K to abort
Connected.
220 FTP service ready.
User(none):hello
331 Password required for hello.
Password:
230 User logged in
[ftp]verbose
% Verbose is on
[ftp]
```

View This command can be used in the following views:

- FTP Client view

virtual-cable-test

Purpose

Use the **virtual-cable-test** command to start the virtual cable test (VCT) to make the system test the cable connected to the current electrical Ethernet port and display the test results.

The test items include:

- Cable status: the result may be normal, abnormal, abnormal-open, abnormal-short, or failure (the test fails).
- Cable length

Syntax

virtual-cable-test

Parameters

None

Default

By default, the test of the connection cable of the Ethernet port is closed.

Example

Enter system view.

```
<S5500> system-view
```

Enter Ethernet1/0/1 port view.

```
[S5500] interface Ethernet 1/0/1
```

Start the VCT test of connection cable.

```
[S5500-Ethernet1/0/1] virtual-cable-test  
Cable status: abnormal(open), 7 metres  
Pair Impedance mismatch: yes  
Pair skew: 4294967294 ns  
Pair swap: swap  
Pair polarity: normal  
Insertion loss: 7 db  
Return loss: 7 db  
Near-end crosstalk: 7 db
```

View

This command can be used in the following views:

- Ethernet Port view

Description



Note:

When the cable is in normal status, this command displays the total length of the cable.

When the cable is in abnormal status, this command displays the length from the current port to the abnormal position of the cable.

- Pair Impedance mismatch
- Pair skew
- Pair swap
- Pair polarity
- Insertion loss
- Return loss
- Near-end crosstalk

vlan

Purpose Use the **vlan** command to enter the VLAN view, and use the related configuration commands.

Use the **undo vlan** command to exit from the specified VLAN.

Syntax

```
vlan vlan_id
```

```
undo vlan vlan_id { [to vlan_id ] / all }
```

Parameters

vlan_id Specifies the ID of the VLAN you want to configure. Valid values are 1 to 4094.

all Delete all VLANs.

Default

VLAN 1 is default VLAN and cannot be deleted.

Example

To enter VLAN 1 view, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]vlan 1
```

View

This command can be used in the following views:

- System view

Related Command

```
display vlan
```


vlan-assignment-mode

Purpose Use the `vlan-assignment-mode` command to configure the VLAN assignment mode.

Syntax `vlan-assignment-mode { integer | string }`

Parameters

<code>integer</code>	Sets the VLAN assignment mode to integer.
<code>string</code>	Sets the VLAN assignment mode to string.

Default By default, the VLAN assignment mode is integer. That is, the switch supports the integer type of VLAN IDs assigned by RADIUS authentication server.

Example Set the VLAN assignment mode to string.

```
[S5500-isp-3Com163.net] vlan-assignment-mode string
```

View This command can be used in the following views:

- ISP Domain view

Description Through dynamic VLAN assignment, the Ethernet switch dynamically adds the ports of the successfully authenticated users to different VLANs depending on the attribute values assigned by RADIUS server, so as to control the network resources the users can access.

In actual application, to cooperate with Guest VLAN, port control is usually set to the port-based mode. If it is set to the MAC address–based mode, each port can have only one user end connected.

Currently, the switch supports the following two data types of VLAN ID assigned by RADIUS authentication server:

- Integer: The switch adds the port to a VLAN depending on the integer type of VLAN ID assigned by the RADIUS authentication server. If the VLAN does not exist, the switch creates the VLAN, and then adds the port to the new VLAN.
- String: The switch compares the character string type of VLAN ID assigned by the RADIUS authentication server with the existing VLAN names on it. If the switch finds a match, it adds the port to the corresponding VLAN; otherwise the VLAN assignment fails and the user fails to pass the authentication.



Note: In string mode, the switch processes an assigned VLAN ID in this way: If the VLAN name assigned by the RADIUS server is a string that contains only digital characters (for example, 1024) and the string can be transformed to an integer number in the valid VLAN range, the switch transforms this string to an integer

number and adds the authenticated port to the VLAN whose ID is this number (VLAN 1024, for example).

Related Commands

- **dot1x guest-vlan**
- **name**

vlan-mapping modulo

Purpose Use the **vlan-mapping modulo** command to map VLANs to specific spanning tree instances.

Syntax `vlan-mapping modulo modulo`

Parameters `modulo` Specifies modulo value. Valid values are 1 to 16.

Default By default, all VLANs in a network are mapped to the CIST (spanning tree instance 0).

Example Map VLANs to spanning tree instances using the modulo of 16.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] stp region-configuration
[S5500-mst-region] vlan-mapping modulo 16
```

View This command can be used in the following views:

- MST Region view

Description MSTP uses VLAN mapping tables to describe VLAN-to-spanning tree instance mappings. You can use this command to establish VLAN mapping tables and to map VLANs to specific spanning tree instances.



Note: A VLAN cannot be mapped to multiple spanning tree instances at a time. A VLAN-to-spanning tree instance mapping becomes invalid when you map the VLAN to another spanning tree instance.

*You can map large amounts of VLANs to specific spanning tree instances quickly by using the **vlan-mapping modulo modulo** command. The ID of the spanning tree instance to which a VLAN is mapped can be figured out by using the following expression:*

$(\text{VLAN ID}-1) \% \text{modulo} + 1$

*where $(\text{VLAN ID}-1) \% \text{modulo}$ yields the module of $(\text{VLAN ID}-1)$ with regards to **modulo**. For example, if you set the **modulo** argument to 16, VLAN 1 is mapped to spanning tree instance 1, VLAN 2 is mapped to spanning tree instance 2, ..., VLAN 16 is mapped to spanning tree instance 16, VLAN 17 is mapped to spanning tree instance 1, and so on.*

Related Commands

- **active region-configuration**
- **check region-configuration**

- **region-name**
- **revision-level**

vlan to

Purpose

Use the **vlan to** command to create multiple VLANs simultaneously.

Use the **undo vlan to** command to remove multiple VLANs simultaneously.

Syntax

```
vlan { vlan-id1 to vlan-id2 | all }
```

```
undo vlan { vlan-id1 to vlan-id2 | all }
```

Parameters

vlan-id1	Starts VLAN ID of the VLAN ID range. Valid values for this argument are from 1 to 4094.
to	Identifies a VLAN ID range.
vlan-id2	Ends VLAN ID of the VLAN ID range. Valid values for this argument are from 1 to 4,094 and cannot be smaller than the vlan-id1 argument.
all	Specifies to create all VLANs.

Example

Create multiple VLANs with their VLAN IDs ranging from 4 through 100.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] vlan 4 to 100  
Please wait..... Done.
```

View

This command can be used in the following views:

- System view

Description

Use the **vlan to** command to create multiple VLANs simultaneously.

Use the **undo vlan to** command to remove multiple VLANs simultaneously.



VLAN 1 is the default VLAN and cannot be removed.

vlan-vpn enable

Purpose Use the `vlan-vpn enable` command to enable the VLAN-VPN function for a port.
Use the `undo vlan-vpn` command to disable the VLAN-VPN function for a port.

Syntax

```
vlan-vpn enable  
undo vlan-vpn
```

Parameters None

Default By default, the VLAN-VPN function is disabled.

Example Enable the VLAN-VPN function for Ethernet1/0/1 port.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] interface Ethernet 1/0/1  
[S5500-Ethernet1/0/1] vlan-vpn enable
```

View This command can be used in the following views:

- Ethernet Port view

Description With the VLAN VPN function enabled, a received packet is tagged with the default VLAN tag of the receiving port no matter whether or not the packet already carries a VLAN tag. If the packet already carries a VLAN tag, the inserted VLAN tag becomes a nested VLAN tag in the packet. Otherwise, the packet is transmitted with the default VLAN tag of the port carried.



CAUTION: The VLAN-VPN function is unavailable if the port has any of the protocols among GVRP, GMRP, STP, IRF, NTDP and 802.1x enabled.

vlan-vpn inner-cos-trust

Purpose

Use the **vlan-vpn inner-cos-trust enable** command to enable the inner VLAN tag priority replication function.

Use the **undo vlan-vpn inner-cos-trust** command to disable the inner VLAN tag priority replication function.

Syntax

```
vlan-vpn inner-cos-trust enable
```

```
undo vlan-vpn inner-cos-trust
```

Parameters

None

Example

Enable the inner VLAN tag priority replication function for Ethernet 1/0/2 port.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface Ethernet 1/0/2
[S5500-Ethernet1/0/2] vlan-vpn inner-cos-trust enable
```

View

This command can be used in the following views:

- Ethernet Port view

vlan-vpn tpid

Purpose

Use the **vlan-vpn tpid** command to set a TPID value for a port. The setting takes effect only when the VLAN-VPN or VLAN-VPN uplink function is enabled.

Use the **undo vlan-vpn tpid** command to restore the default TPID value.

Syntax

```
vlan-vpn tpid value
```

```
undo vlan-vpn tpid
```

Parameters

value TPID value (in hexadecimal format) to be set. Valid values for this argument are from 1 to 0xFFFF.

Default

The default TPID value is 0x8100.

Example

Set the TPID value to 0x12 for Ethernet1/0/2 port.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface Ethernet 1/0/2
[S5500-Ethernet1/0/2] vlan-vpn tpid 12
```

View

This command can be used in the following views:

- Ethernet Port view

Description

Do not set the TPID value to a value that conflicts with the known protocol type values (such as 0x0806, which is that of ARP packets). Otherwise, the packet may be discarded.

Table 101 Common Ethernet frame protocol type values

Protocol type	Value
ARP	0x0806
IP	0x0800
MPLS	0x8847/0x8848
IPX	0x8137
IS-IS	0x8000
LACP	0x8809
802.1x	0x888E

vlan-vpn tunnel

Purpose Use the `vlan-vpn tunnel` command to enable the BPDU tunnel function.
Use the `undo vlan-vpn tunnel` command to disable the BPDU tunnel function.

Syntax

```
vlan-vpn tunnel  
undo vlan-vpn tunnel
```

Parameters None

Default By default, the BPDU tunnel function is disabled.

Example Enable the BPDU tunnel function for the switch.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] vlan-vpn tunnel
```



- *Note:*
- *You must enable STP on a device before enabling the BPDU tunnel function on it.*
- *The BPDU tunnel function is only available to access ports.*
- *To implement the BPDU tunnel function, the links between operator networks must be trunk links.*
- *As the VLAN VPN function is unavailable to the ports with 802.1x, GVRP, GMRP, STP, or NTDP employed, the BPDU tunnel function is unavailable to these ports.*

View This command can be used in the following views:

- System view

Description The BPDU tunnel function enables BPDUs to be transparently transmitted between geographically dispersed user networks through specified VLAN VPNs in operator's networks, allowing spanning trees to be generated across these user networks and keep independent of those of the operator's networks.

vlan-vpn uplink enable

Purpose Use the **vlan-vpn uplink enable** command to configure a port to be a VLAN-VPN uplink port.

Use the **undo vlan-vpn uplink** command to remove the configuration.

Syntax

```
vlan-vpn uplink enable  
undo vlan-vpn uplink
```

Parameters None

Example Configure Ethernet1/0/2 port to be a VLAN-VPN uplink port.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500]interface Ethernet 1/0/2  
[S5500-Ethernet1/0/2] vlan-vpn uplink enable  
VLAN-VPN uplink status: enabled
```

View This command can be used in the following views:

- Ethernet Port view

Description When sending a VLAN-VPN packet, a VLAN-VPN uplink port replaces the TPID value in the outer VLAN tag of the packet with the customized TPID value. You can use the **vlan-vpn tpid** command to set the TPID value used by the VLAN-VPN uplink port.



CAUTION: *The **vlan-vpn uplink enable** command and the **vlan-vpn enable** command are mutually exclusive. That is, if you execute the **vlan-vpn enable** command on a port, you will fail to execute the **vlan-vpn uplink enable** command on the same port. Similarly, if you execute the **vlan-vpn uplink enable** command on a port, you will fail to execute the **vlan-vpn enable** command on the same port*

vlink-peer

Purpose

Use the **vlink-peer** command to create and configure a virtual link.

Use the **undo vlink-peer** command to cancel an existing virtual link.

Use the **authentication-mode** command, when configuring virtual link authentication, to set the authentication type to MD5 cipher text or plain text on the backbone network.

Syntax

```
vlink-peer router_id [ hello seconds | retransmit seconds | trans-delay seconds | dead seconds | simple password | md5 keyid key ]*
```

```
undo vlink-peer router-id
```

Parameters

<i>router_id</i>	Specifies the Router ID of a virtual link neighbor.
<i>hello seconds</i>	Specifies the interval for the transmission of hello packets, in the range 1 to 8192 seconds. This must equal the hello seconds value of the router virtually linked to the interface. The default value is 10 seconds.
<i>retransmit seconds</i>	Specifies the interval for the retransmission of LSA packets on an interface, in the range 1 to 8192 seconds. The default value is 5 seconds.
<i>trans-delay seconds</i>	Specifies the delay interval for transmitting LSA packets on an interface, in the range 1 to 8192 seconds. The default value is 1 second.
<i>dead seconds</i>	Specifies the dead time interval, in the range 1 to 8192 seconds. This value must equal the dead time of the virtually linked router, and must be at least four times that of the hello interval. The default value is 40 seconds.
<i>simple password</i>	Specifies the simple text authentication key of the interface, in eight characters or less. This must equal the authentication key of the virtually linked neighbor.
<i>md5 keyid</i>	Specifies the MD5 authentication key ID, in the range 1 to 255. This must be equal to the authentication key ID of the virtually linked peer.
<i>key</i>	Specifies the MD5 authentication key. If it is input in a plain text form, the key is a character string not exceeding 16 characters. It will be displayed in a cipher text form in a length of 24 characters when display current-configuration command is executed. Inputting the MD5 key in a cipher text form with 24 characters is also supported.

Example

To create a virtual link to 10.110.0.3, and use the MD5 cipher authentication mode, enter the following:

```
<SW5500>system-view
System View: return to User View with Ctrl+Z.
[SW5500]router id 1.1.1.1
[SW5500]ospf
[SW5500-ospf-1]area 10.0.0.0
[SW5500-ospf-1-area-10.0.0.0]vlink-peer 10.110.0.3 md5 3 345
```

View

This command can be used in the following views:

- OSPF Area view

Description

RFC2328 states that an OSPF area must be connected to the backbone network. You can use **vlink-peer** command to set up this connectivity if an area does not have a direct connection to the backbone area. A virtual link can also be used to connect a discontinuous backbone. Virtual link can be regarded as a common interface that uses OSPF so that you can easily understand how to configure parameters such as **hello**, **retransmit**, and **trans-delay**.

Related Commands

- **authentication-mode**

voice-config

Purpose

Use the **voice-config** command to configure option 184 and its sub-options, which will be sent to DHCP clients by a DHCP server as well when the DHCP server assigns IP addresses of a global address pool to DHCP clients.

Use the **undo voice-config** command to disable a DHCP server from sending option 184 and the specified sub-option to DHCP clients when the DHCP server assigns IP addresses to DHCP clients.

Syntax

```
voice-config { ncp-ip ip-address | as-ip ip-address | voice-vlan  
vlan-id { disable | enable } | fail-over ip-address dialer-string }  
undo voice-config [ ncp-ip | as-ip | voice-vlan | fail-over ]
```

Parameters

ncp-ip	Specifies the IP address of the NCP.
as-ip	Specifies the IP address of the AS.
voice-vlan	Specifies the voice VLAN.
fail-over	Specifies the Fail-over call routing.
ip-address	IP address of the NCP, alternate server, or Fail-over.
vlan-id	ID of the voice VLAN. This argument ranges from 1 to 4094.
enable	Enables the voice VLAN.
disable	Disables the voice VLAN.
dialer-string	Dial number string. This argument comprises of number 0 through 9 and the * character (acting as the wildcard).

Default

By default, option 184 and its sub-options are not supported by a DHCP server.

Example

Enter system view.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.
```

Configure the DHCP server to support option 184 when the DHCP server assigns the IP addresses of address pool 123 (a global DHCP address pool) to DHCP clients, with the sub-options being set as follows:

```
NCP-IP: 1.1.1.1  
AS-IP: 2.2.2.2  
Voice VLAN: Enabled  
Voice VLAN ID: 1  
IP address of Fail-over: 3.3.3.3  
Dialer-string: 99*  
[S5500] dhcp select global all
```

```
[S5500] dhcp server ip-pool 123
[S5500-dhcp-pool-123] voice-config ncp-ip 1.1.1.1
[S5500-dhcp-pool-123] voice-config as-ip 2.2.2.2
[S5500-dhcp-pool-123] voice-config voice-vlan 1 enable
[S5500-dhcp-pool-123] voice-config fail-over 3.3.3.3 99*
```

View

This command can be used in the following views:

- DHCP Address Pool view

Description

A DHCP server sends Option 184 and the corresponding sub-options to a DHCP client only when the latter requests for option 184.

The NCP-IP sub-option is necessary for all other sub-options. You need to configure the NCP-IP sub-option first to enable other sub-options.



This command applies only to the S5500-EI series among Switch 5500-Series Switches.

Related Command

dhcp server voice-config

voice vlan

Purpose

Use the **voice vlan** command to enable the voice VLAN function globally.

Use the **undo voice vlan enable** command to disable the voice VLAN function globally.

Syntax

```
voice vlan vlan-id enable
```

```
undo voice vlan enable
```

Parameters

vlan-id

ID of the VLAN for which the voice VLAN function is to be enabled. Valid values for this argument are from 2 to 4,094.

Example

Enable the voice VLAN function for VLAN 2.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] vlan 2
[S5500-vlan2] quit
[S5500] voice vlan 2 enable
```

With the voice VLAN function enabled for VLAN 2, the following message appears if you enable the voice VLAN function for another VLAN, for example, VLAN 4.

```
[S5500] voice vlan 4 enable
Can't change voice vlan configuration when other voice vlan is running
```

View

This command can be used in the following views:

- System view

Description

Use the **voice vlan** command to enable the voice VLAN function globally.

Use the **undo voice vlan enable** command to disable the voice VLAN function globally.



CAUTION:

- Before enabling the voice VLAN function, make sure the VLAN for which the voice VLAN function is to be enabled exists. Otherwise, you will fail to perform the operation.
- To remove a VLAN with the voice VLAN function enabled, you need to disable the voice VLAN function first.
- Only one VLAN can have the voice VLAN function enabled at a time.

Related Command

```
display voice vlan status
```

voice vlan aging

Purpose	<p>Use the voice vlan aging command to set the aging time for a voice VLAN.</p> <p>Use the undo voice vlan aging command to restore the default aging time for a voice VLAN.</p>
Syntax	<pre>voice vlan aging minutes undo voice vlan aging</pre>
Parameters	<p><i>minutes</i> Aging time (in minutes) to be set for a voice VLAN. Valid values for this argument are from 5 to 43,200. If not specified, the default is 1,440.</p>
Example	<p>Set the aging time of the voice VLAN to 100 minutes.</p> <pre><S5500> system-view System View: return to User View with Ctrl+Z. [S5500] voice vlan aging 100</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view
Related Command	<pre>display voice vlan status</pre>

voice vlan enable

Purpose

Use the **voice vlan enable** command to enable the voice VLAN function for a port.

Use the **undo voice vlan enable** command to disable the voice VLAN function for a port.

Syntax

```
voice vlan enable
```

```
undo voice vlan enable
```

Parameters

None

Example

Enable the voice VLAN function for Ethernet1/0/2 port.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] interface ethernet1/0/2  
[S5500-Ethernet1/0/2] voice vlan enable
```

View

This command can be used in the following views:

- Ethernet Port view

Description

The voice VLAN function takes effect on a port only when it is enabled in both system view and port view. Note that the operation to enable the voice VLAN function for a port is independent of that to enable the function globally.

Related Command

```
display voice vlan status
```

voice vlan mode

Purpose

Use the **voice vlan mode auto** command to configure an Ethernet port to operate in the automatic voice VLAN mode.

Use the **undo voice vlan mode auto** command to configure an Ethernet port to operate in the manual voice VLAN mode.

Syntax

```
voice vlan mode auto  
  
undo voice vlan mode auto
```

Parameters

None

Default

By default, an Ethernet port operates in the automatic voice VLAN mode.

Example

Configure Ethernet 1/0/2 port to operate in the manual voice VLAN mode.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] interface ethernet 1/0/2  
[S5500-Ethernet1/0/2] undo voice vlan mode auto
```

View

This command can be used in the following views:

- Ethernet Port view

Description

Use the **voice vlan mode auto** command to configure an Ethernet port to operate in the automatic voice VLAN mode.

Use the **undo voice vlan mode auto** command to configure an Ethernet port to operate in the manual voice VLAN mode.



These two commands are valid only before you enable the voice VLAN function globally.

Related Command

```
display voice vlan status
```

voice vlan mac-address

Purpose

Use the **voice vlan mac-address** command to set a MAC address used for a voice VLAN to identify voice devices.

Use the **undo voice vlan mac-address** command to remove a MAC address used to identify voice devices.

Syntax

```
voice vlan mac-address oui mask oui-mask [ description string ]
```

```
undo voice vlan mac-address oui
```

Parameters

<i>oui</i>	MAC address to be set. You need to provide this argument in the format of H-H-H.
<i>oui-mask</i>	MAC address mask in the format of H-H-H. This argument specifies the valid bits of the MAC address.
<i>string</i>	Description of the MAC address, consisting of a string from 1 to 30 characters long.

Example

Set 00aa-bb00-0000 as an OUI address, with a description of "ABC".

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] voice vlan mac-address 00aa-bb00-0000 mask ffff-ff00-0000
description ABC
```

View

This command can be used in the following views:

- System view

Description

A switch can use up to 16 MAC addresses to identify voice devices, including the four default MAC addresses shown below. When the number of MAC addresses reaches 16, you will be unable to add new MAC addresses.


Table 102 Default OUI address

Number	OUI	Description
1	00e0-bb00-0000	3com phone
2	0003-6b00-0000	Cisco phone
3	00e0-7500-0000	Polycom phone
4	00d0-1e00-0000	Pingtel phone

Related Command

```
display voice vlan oui
```

voice vlan security enable

Purpose	<p>Use the voice vlan security enable command to enable the voice VLAN security mode.</p> <p>Use the undo voice vlan security enable command to disable the voice VLAN security mode.</p>
Syntax	<pre>voice vlan security enable undo voice vlan security enable</pre>
Parameters	None
Default	By default, the voice VLAN security mode is enabled.
Example	<p>Disable the voice VLAN security mode.</p> <pre><S5500> system-view System View: return to User View with Ctrl+Z. [S5500] undo voice vlan security enable</pre>
View	<p>This command can be used in the following views:</p> <ul style="list-style-type: none">■ System view
Description	<p>In the voice VLAN security mode, the ports in a voice VLAN and with voice devices attached to can only forward voice data. Data packets with their MAC addresses not among the OUI addresses that can be identified by the system will be dropped. This mode has no effects on other VLANs.</p> <p> <i>These two commands are valid only before you enable the voice VLAN function globally.</i></p>
Related Command	<pre>display voice vlan status</pre>

vrrp authentication-mode

Purpose

Use the **vrrp method** command to map the MAC address of a backup group to the virtual router IP addresses.

You can map the real or virtual MAC address of a Layer 3 switch routing interface to virtual router IP addresses.

Use the **undo vrrp method** command to restore the default map settings.

Syntax

```
vrrp authentication-mode authentication-type authentication-key
```

```
undo vrrp authentication-mode
```

Parameters

authentication-type

Authentication type, which can be:

- simple; indicates to perform simple character authentication.
- md5; indicates to perform the AH authentication with MD5 algorithm.

authentication-key

Authentication key. When you specify **authentication-type** to be simple, you need to provide a string comprising up to eight characters. When you specify **authentication-type** to be md5, you need to provide a string comprising up to eight characters or a 24-character encrypted string.

Example

Specify the authentication type and authentication key for a VRRP backup group.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface vlan-interface 2
[S5500-vlan-interface2] vrrp authentication-mode simple aabbcc
```

View

This command can be used in the following views:

- VLAN Interface view

Description

If the simple or md5 authentication is configured, the authentication key is required.

This command sets the authentication type and authentication key for all the VRRP backup groups on an interface. As defined in the protocol, all the backup groups on an interface share the same authentication type and authentication key. And all the members joining the same backup group share the same authentication type and authentication key too.

The authentication key is case-sensitive.



The VRRP feature is supported by Switch 5500-EI series switches but is not supported by Switch 5500-SI series switches.

vrrp method

Purpose

Use the **vrrp method** command to map the MAC address of a backup group to the virtual router IP addresses.

You can map the real or virtual MAC address of a Layer 3 switch routing interface to virtual router IP addresses.

Use the **undo vrrp method** command to restore the default map settings.

Syntax

```
vrrp method { real-mac | virtual-mac }
```

```
undo vrrp method
```

Parameters

real-mac	Maps the real MAC address of a Layer 3 switch routing interface to virtual router IP addresses.
virtual-mac	Maps the virtual MAC address of a Layer 3 switch routing interface to virtual router IP addresses.

Default

By default, the virtual MAC address of a backup group is mapped to the IP address of the virtual router.

If you map the virtual MAC address of a Layer 3 switch routing interface to virtual router IP addresses, you can create up to 14 backup groups on the VLAN interface.

Example

Map the real MAC address of a routing interface to a virtual router IP address.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] vrrp method real-mac
```

View

This command can be used in the following views:

- System view

Description



Notes:

- *As the relationship between the MAC addresses of a backup group and a virtual router IP address cannot be configured after the backup group is created, configure the relationship before you create a backup group.*
- *The VRRP feature is supported by Switch 5500-EI series switches but is not supported by Switch 5500-SI series switches.*

vrrp ping-enable

Purpose Use the **vrrp ping-enable** command to enable a backup group to respond to ping operations destined for its virtual router IP address.

Use the **undo vrrp ping-enable** command to revert to the default.

Syntax

```
vrrp ping-enable  
undo vrrp ping-enable
```

Parameters None

Default By default, a backup group does not respond to ping operations destined for its virtual router IP address.


As these two commands are invalid to switches in backup groups, use them before you create a backup group.

Example Enable a backup group to respond to ping operations destined for its virtual router IP address.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] vrrp ping-enable
```

View This command can be used in the following views:

- System view

Description  *Note: The VRRP feature is supported by Switch 5500-EI series switches but is not supported by Switch 5500-SI series switches.*

vrrp vlan-interface vrid track

Purpose

Use the **vrrp vlan-Interface vrid track** command to enable the port tracking function on the physical ports of a backup group.

Use the **undo vrrp vlan-Interface vrid track** command to disable the port tracking function.

Syntax

```
vrrp vlan-interface vlan-id vrid virtual-router-ID track [ reduced value-reduced ]
```

```
undo vrrp vlan-interface vlan-id vrid virtual-router-ID track
```

Parameters

virtual-router-ID	VRRP backup group ID. Valid values are 1 to 255.
vlan-id	VLAN ID.
value-reduced	Value by which the priority of a switch is to decrease. Valid values for this argument are from 1 to 255. If not specified, the default is 10.

Example

Configure that the priority of the switch decreases by 50 if its Ethernet1/0/1 port fails.

```
<S5500> system-view
[S5500] vlan 2
[S5500-vlan2] port Ethernet1/0/1
[S5500-vlan2] quit
[S5500] interface vlan-interface2
[S5500-Vlan-interface2] vrrp vlan-interface 2 vrid 1 track reduced 50
```

View

This command can be used in the following views:

- VLAN Interface view

Description

With the VRRP backup group port tracking function enabled, you can specify to track a specified port and decrease the priority of the switch when the port fails.

Using this function, you can enable the priority of a master switch to decrease by specific value when the uplink port of the master switch fails. This in turn triggers the new master to be determined in the backup group.



Notes:

- The port to be tracked can be in the VLAN which the backup group belongs to.
- Up to eight ports can be tracked simultaneously.

vrrp vrid preempt-mode

Purpose

Use the **vrrp vrid preempt-mode** command to configure a switch to operate in the preemptive mode and set the delay period.

Use the **undo vrrp vrid preempt-mode** command to cancel the configuration.

Syntax

```
vrrp vrid virtual-router-ID preempt-mode [ timer delay delay-value ]
undo vrrp vrid virtual-router-ID preempt-mode
```

Parameters

<i>virtual-router-ID</i>	VRRP backup group ID. Valid values are 1 to 255.
<i>delay-value</i>	Delay period (in seconds). Valid values are 0 to 255.

Default

By default, switches in a backup group operate in the preemptive mode, with the delay period set to 0 second.

Example

Configure the switches to operate in the preemptive mode.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface vlan-interface 2
[S5500-vlan-interface2] vrrp vrid 1 preempt-mode
# Set the delay period.
[S5500-vlan-interface2] vrrp vrid 1 preempt-mode timer delay 5
# Configure the switches to operate in non-preemptive mode.
[S5500-vlan-interface2] undo vrrp vrid 1 preempt-mode
```

View

This command can be used in the following views:

- VLAN Interface view

Description

If you want backup switches to preempt the master switch, configure them to operate in the preemptive mode. You can also set the delay period as needed.



*The **undo vrrp vrid preempt-mode** command causes switches in a backup group to operate in non-preemptive mode.*

The VRRP feature is supported by Switch 5500-EI series switches but is not supported by Switch 5500-SI series switches.

vrrp vrid priority

Purpose

Use the **vrrp vrid priority** command to set the priority of a switch in a backup group.

Use the **undo vrrp vrid priority** command to revert to the default priority.

Syntax

```
vrrp vrid virtual-router-ID priority priority
```

```
undo vrrp vrid virtual-router-ID priority
```

Parameters

virtual-router-ID	VRRP backup group ID. Valid values are 1 to 255.
priority	Switch priority to be set. Valid values for this argument are 1 to 254. If not specified, the default is 100.

Example

Set the priority to 120 for the switch in the backup group in VLAN 2 interface view.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface vlan-interface 2
[S5500-vlan-interface2] vrrp vrid 1 priority 120
```

View

This command can be used in the following views:

- VLAN Interface view

Description

Switch priority determines the possibility for the switch to become a master switch. A switch with larger priority is more likely to become a master switch. Note that the priority of 0 is reserved for special use, and the priority of 255 is for IP address owners. That is, the priority of a switch that owns a virtual router IP address is fixed to 255 and cannot be modified.



The VRRP feature is supported by Switch 5500-EI series switches but is not supported by Switch 5500-SI series switches.

vrrp vrid timer advertise

Purpose

Use the **vrrp vrid timer advertise** command to set the interval for the master switch of a backup group to send VRRP packets.

Use the **undo vrrp vrid timer advertise** command to revert to the default interval.

Syntax

```
vrrp vrid virtual-router-ID timer advertise adver-interval
undo vrrp vrid virtual-router-ID timer advertise
```

Parameters

virtual-router-ID	VRRP backup group ID. Valid values are 1 to 255.
adver-interval	Interval (in seconds) for the master switch of a backup group to send VRRP packets. Valid values for this argument are 1 to 255. If not specified, the default is 1.

Example

Set the interval for the master switch to send VRRP packets to 15 seconds.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface vlan-interface 2
[S5500-vlan-interface2] vrrp vrid 1 timer advertise 15
```

View

This command can be used in the following views:

- VLAN Interface view

Description



Note: Configuration error occurs if switches of the same backup group are configured with different adver-interval values.

As long as a switch in the backup group becomes the master switch, other switches, even if they are configured with a higher priority later, do not preempt the master switch unless they operate in the preemptive mode. The switch operating in preemptive mode will become the master switch when it finds its priority is higher than that of the current master switch, and the former master switch becomes a backup switch accordingly.

You can also set the delay period when configuring switches in a backup group to operate in the preemptive mode to enable a backup switch to undergo a specified period before it becomes the master switch. In an unstable network, backup switches may not receive packets from master switches in time because of network congestions. This causes master switches being determined frequently if the delay period is not configured or is too short. You can avoid this problem by setting the delay period to a proper value.



The VRRP feature is supported by Switch 5500-EI series switches but is not supported by Switch 5500-SI series switches.

vrrp vrid track

Purpose

Use the **vrrp vrid track** command to set a VLAN interface to be tracked.

Use the **undo vrrp vrid track** command to disable a VLAN interface from being tracked.

Syntax

```
vrrp vrid virtual-router-ID track vlan-interface vlan-id [ reduced  
value-reduced ]
```

```
undo vrrp vrid virtual-router-ID track vlan-interface vlan-id [ reduced  
value-reduced ]
```

Parameters

<i>virtual-router-ID</i>	VRRP backup group ID. Valid values are 1 to 255.
<i>vlan-interface vlan-id</i>	Specifies a VLAN interface ID.
<i>value-reduced</i>	Value by which the priority is to decrease. Valid values for this argument are 1 to 255. If not specified, the default is 10.

Example

Configure VLAN 2 interface to track VLAN 1 interface and specify the priority of the master switch of backup group 1 (on VLAN 2 interface) decreases by 50 when VLAN 1 interface goes down.

```
<S5500> system-view  
System View: return to User View with Ctrl+Z.  
[S5500] interface vlan-interface 2  
[S5500-vlan-interface2] vrrp vrid 1 track vlan-interface 1 reduced 50
```

View

This command can be used in the following views:

- VLAN Interface view

Description

The VLAN interface tracking function extends the use of the backup function. With this function enabled, the backup function is applicable to the VLAN interface that belongs to a backup group and those that do not belong to a backup group. You can utilize the VLAN interface tracking function by specifying monitored VLAN interfaces.

With the VLAN interface tracking function enabled, the priority of a master switch decreases by the value set by the *value-reduced* argument when a tracked VLAN interface on the switch goes down. And other switches in the backup group, whose priorities are higher than the decreased priority of the master switch, may become the master switch.



Note:

- Switches that own IP addresses do not support the VLAN interface tracking function.
- A backup group can track up to eight VLAN interfaces simultaneously.

- *The VRRP feature is supported by Switch 5500-EI series switches but is not supported by Switch 5500-SI series switches.*

vrrp vrid track detect-group

Purpose

Use the **vrrp vrid** command to enable the auto detect function when employing VRRP.

Use the **undo vrrp vrid** command to disable the auto detect function when employing VRRP.

Syntax

```
vrrp vrid virtual-router-id track detect-group group-number [ reduced value-reduced ]
```

```
undo vrrp vrid virtual-router-id track detect-group group-number
```

Parameters

<i>virtual-router-id</i>	Virtual router ID. Valid values are 1 to 255.
<i>group-number</i>	Detecting group number. Valid values are 1 to 50.
<i>value-reduced</i>	Value by which the preference value is to be reduced. Valid values for this argument are from 1 to 255. If not specified, the default is 10.

Example

Create detecting group 10 and specify to detect the IP address of 202.13.1.55.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] detect-group 10
[S5500-detect-group-10] detect-list 1 ip 202.13.1.55
```

Specify to decrease the preference value of backup group 1 by 20 when the result of detecting group 10 is unreachable.

```
[S5500] interface vlan-interface 2
[S5500-vlan-interface2] vrrp vrid 1 track detect-group 10 reduced 20
```

View

This command can be used in the following views:

- VLAN Interface view

Description

You can control the preference value of a VRRP backup group according to the result of a detecting group to enable automatic switch between the primary switch and the secondary switch. That is,

- Decrease the preference value of a VRRP backup group when the result of the detecting group is **unreachable**.
- Restore the preference value of a VRRP backup group when the result of the detecting group is **reachable**.

vrrp vrid virtual-ip

Purpose

Use the **vrrp vrid virtual-ip** command to add a virtual router IP address to an existing backup group.

Use the **undo vrrp vrid virtual-ip** command to remove a virtual router IP address from an existing backup group.

Syntax

```
vrrp vrid virtual-router-ID virtual-ip virtual-address
```

```
undo vrrp vrid virtual-router-ID virtual-ip virtual-address
```

Parameters

virtual-router-ID VRRP backup group ID. Valid values are 1 to 255.

virtual-address Virtual router IP address to be configured.

Example

Create a backup group.

```
<S5500> system-view
System View: return to User View with Ctrl+Z.
[S5500] interface vlan-interface 2
[S5500-vlan-interface2] vrrp vrid 1 virtual-ip 10.10.10.10
# Add a virtual router IP address to an existing backup group.
[S5500-vlan-interface2] vrrp vrid 1 virtual-ip 10.10.10.11
# Remove a virtual router IP address from a backup group.
[S5500-vlan-interface2] undo vrrp vrid 1 virtual-ip 10.10.10.10
# Remove a backup group.
[S5500-vlan-interface2] undo vrrp vrid 1
```

View

This command can be used in the following views:

- VLAN Interface view

Description

The **vrrp vrid virtual-ip** command can also be used to create a backup group. You can add up to 16 virtual router IP addresses to a backup group. The **undo vrrp vrid virtual-ip** command can also be used to remove an existing backup group. A backup group is removed if all the virtual router IP addresses configured for it are removed.



The VRRP feature is supported by Switch 5500-EI series switches but is not supported by Switch 5500-SI series switches.

wred

Purpose

Use the **wred** command to configure WRED parameters. WRED (Weighted Random Early Detection) is a queuing feature used in a network to mitigate the effects of queue congestion.

Use the **undo wred** command to restore the default settings.

Syntax

```
wred queue-index qstart probability
```

```
undo wred queue-index
```

Parameters

<i>queue-index</i>	Index of output queue. Valid values are 0 to 7.
<i>qstart</i>	Start random discarding queue length, if the queue is shorter than the value, no packet will be dropped. Valid values are 1 to 128. The value must be a multiple of 16 KBytes.
<i>probability</i>	Discarding probability.

Default

By default, the wred function is disabled.

Example

To configure 'start random discarding queue length' of queue 0 is 32kbytes, discarding probability is 50%, enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z  
[SW5500]interface Ethernet 1/0/1  
[SW5500-Ethernet1/0/1]wred 0 32 50  
[SW5500-Ethernet1/0/1]
```

View

This command can be used in the following views:

- Ethernet Port view

xmodem

Purpose Use the **xmodem** command to establish an xmodem connection.

Syntax `xmodem get filename`

Parameters	get	Obtain remote data file.
	<i>filename</i>	Specifies the filename to retrieve.

Example `<5500-EI>xmodem`

View This command can be used in the following views:

- User view

Description Xmodem is a protocol for transferring files during direct dial-up communications. Xmodem has basic error checking to ensure that information isn't lost or corrupted during transfer; it sends data in 128-byte blocks.

xrn-fabric authentication-mode

Purpose Use the `xrn-fabric authentication-mode` command to configure or delete the authentication mode of the fabric.

Syntax

```
xrn-fabric authentication-mode { simple password | md5 key }  
undo xrn-fabric authentication-mode
```

Parameters

<i>password</i>	Password, consisting of a character string from 1 to 16 characters long.
<i>key</i>	Key word, consisting of a character string from 1 to 16 characters long.

Default By default, no authentication mode is configured on the Fabric.

Example To set the authentication mode of the Fabric to simple, with the password "hello", enter the following:

```
<SW5500>system-view  
System View: return to User View with Ctrl+Z.  
[SW5500]xrn-fabric authentication-mode simple hello
```

View This command can be used in the following views:

- System view

Description



CAUTION: All units must have the same Fabric authentication settings in order to form a stack of units.

COMMANDS BY FUNCTION

802.1x

dot1x guest-vlan	504
dot1x retry-version-max	513
dot1x supp-proxy-check	514
dot1x timer ver-period	518
dot1x version-check	519

AAA and Radius

access-limit	29
accounting	30
accounting optional	35
accounting-on enable	33
attribute	63
authentication	65
authorization	69
cut connection	113
display connection	226
display domain	259
display dot1x	260
display local-server statistics	321
display local-user	322
display radius	415
display radius statistics	416
domain	496
dot1x	499
dot1x authentication-method	501, 502
dot1x dhcp-launch	503
dot1x max-user	506
dot1x port-control	507
dot1x port-method	509
dot1x quiet-period	511
dot1x retry	512
dot1x timer	516
level	650
local-server	654
messenger	684
name	705
radius nas-ip	842
radius scheme	844
radius-scheme	843
reset dot1x statistics	864
reset radius statistics	886
retry realtime-accounting	902
retry stop-accounting	903
scheme	940
self-service-url	946
server-type	948
service-type	951
state	1010, 1011

stop-accounting-buffer enable	1022
vlan-assignment-mode	1141

Address Management

am enable	43
am ip-pool	44
am user-bind	47
display am	208
display am user-bind	209

Auto-detect

detect-group	166
detect-list	167
display detect-group	237
ip route-static	642
option	737
retry	901
standby detect-group	1009
timer loop	1103
timer wait	1108

Centralized MAC

debugging mac-authentication event	135
display mac-authentication	331
mac-authentication	671
mac-authentication authpassword	674
mac-authentication authusername	675
mac-authentication domain	676
mac-authentication mode	673
mac-authentication timer	677

Cluster Configuration

add-member	40
administrator-address	42
auto-build	70
build	84
cluster	101
cluster enable	102
cluster switch-to	105
cluster-mac	103
cluster-mac syn-interval	104
delete-member	161
display cluster	219
display cluster candidates	221
display cluster members	223
ftp cluster	547
ftp-server	552
holdtime	572
ip-pool	641
logging-host	658
management-vlan	678
nm-interface vlan-interface	714
port-tagged	816
reboot member	847
snmp-host	988

tftp cluster get	1090
tftp cluster put	1091
tftp-server	1094
timer	1102

Device Management

display device	238
----------------	-----

DHCP

accounting domain	32
address-check	41
debugging dhcp server	124
debugging dhcp-relay	122
dhcp enable	168
dhcp relay information enable	169
dhcp relay information strategy	170
dhcp select global	171
dhcp server detect	176
dhcp server dns-list	177
dhcp server domain-name	179
dhcp server expired	181
dhcp server forbidden-ip	183
dhcp server ip-pool	186
dhcp server nbns-list	187
dhcp server netbios-type	189
dhcp server option	191
dhcp server ping	193
dhcp server static-bind	194
dhcp server voice-config	195
dhcp server voice-config interface	197
dhcp-security static	199
dhcp-security tracker	200
dhcp-server	175
dhcp-server ip	185
dhcp-snooping	201
dhcp-snooping trust	202
display dhcp server conflict	243
display dhcp server expired	244
display dhcp server free-ip	246
display dhcp server ip-in-use	248
display dhcp server statistics	250
display dhcp server tree	252
display dhcp-security	240
display dhcp-server	241
display dhcp-server interface vlan-interface	247
display dhcp-snooping	254
display dhcp-snooping trust	255
dns-list	495
domain-name	498
expired	525
gateway-list	562
hcp select interface	173
nbns-list	707
netbios-type	711
network	712
reset dhcp server conflict	861
reset dhcp server ip-in-use	862

reset dhcp server statistics	863
static-bind ip-address	1013
static-bind mac-address	1015
voice-config	1153
DLDP	
debugging DLDP	128
display dldp	257
dldp	488
dldp authentication-mode	490
dldp interval	491
dldp reset	492
dldp unidirectional-shutdown	493
dldp work-mode	494
EAD	
security-policy-server	945
Fabric	
change self-unit	91
change unit-id	92
display xrn-fabric	487
ftm stacking-vlan	545
set unit name	955
sysname	1073
xrn-fabric authentication-mode	1175
File Management System	
backup current-configuration to	72
boot attribute-switch	75
update fabric	1131
File System Management	
boot boot-loader	76
boot boot-loader backup-attribute	77
boot web-packege	79
display boot-loader	213
display current-configuration	229
display saved-configuration	436
display startup	456
display this	468
ftp	546
ftp server enable	553
get	563
local-user	655
local-user password-display mode	656
reset recycle-bin	887
reset saved-configuration	888
restore startup-configuration from	900
save	934
startup bootrom-access enable	1019
startup saved-configuration	1020

Gratuitous ARP	
gratuitous-arp learning enable	564
GVRP	
display garp statistics	275
display garp timer	276
display gvrp statistics	277
display gvrp status	278
garp timer	559
garp timer leaveall	561
gvrp	565
gvrp registration	566
reset garp statistics	865
HWTACACS	
data-flow-format	115
debugging hwtacacs	129
display hwtacacs	280
display stop-accounting buffer	457
hwtacacs nas-ip	574
hwtacacs scheme	575
key	644
nas-ip	706
primary accounting	821
primary authentication	822
primary authorization	823
reset hwtacacs statistics	866
reset stop-accounting-buffer	890
secondary accounting	942
secondary authentication	943
secondary authorization	944
timer quiet	1104
timer realtime-accounting	1105
timer response-timeout	1106
user-name-format	1135
IGMP	
display mac-address multicast static	330
display multicast-souce-deny	349
mac-address multicast interface vlan	668
mac-address multicast vlan	669
Information Center	
display logbuffer	324
display trapbuffer	471
info-center synchronous	625
info-center timestamp loghost	627
IRF	
display ftm	270
display rmon history unit	428

display rmon statistics unit	432
fabric port enable	526
Loopback Detection	
display-loopback-detection	326
Management VLAN	
display bootp client	214
Miscellaneous	
display bootp client	214
display drv	262
display mpm	339
fixdisk	538
free web-users	543
icmp	576
pki	786
xmodem	1174
MSDP	
cache-sa-enable	86
debugging msdp	136
display msdp brief	340
display msdp peer-status	341
display msdp sa-cache	342
display msdp sa-count	344
import-source	609
msdp	697
msdp-tracert	698
originating-rp	738
peer connect-interface	767
peer description	768
peer mesh-group	769
peer minimum-ttl	770
peer request-sa-enable	772
peer sa-cache-maximum	773
peer sa-policy	774
peer sa-request-policy	775
reset msdp peer	872
reset msdp sa-cache	873
reset msdp statistics	874
shutdown	963
timer retry	1107
MSTP	
active region-configuration	39
check region-configuration	93
display stp	458
display stp region-configuration	461
instance	629
region-name	848
reset stp	891
revision-level	905
stp	1024

stp bpdu-protection	1025
stp bridge-diameter	1026
stp cost	1027
stp edged-port	1028
stp interface	1031
stp interface cost	1032
stp interface edged-port	1034
stp interface loop protection	1036
stp interface mcheck	1037
stp interface point-to-point	1038
stp interface port priority	1040
stp interface root-protection	1041
stp interface transmit-limit	1043
stp loop-protection	1044
stp max-hops	1045
stp mcheck	1046
stp mode	1047
stp pathcost-standard	1048
stp point-to-point	1050
stp port priority	1052
stp priority	1053
stp region-configuration	1054
stp root primary	1055
stp root secondary	1058
stp root-protection	1057
stp tc-protection	1060
stp timer forward-delay	1063
stp timer hello	1065
stp timer max-age	1066
stp timer-factor	1062
stp transmit-limit	1067
vlan-mapping modulo	1143
vlan-vpn tunnel	1149

Multicast Protocol

bsr-policy	82
c-bsr	87
c-rp	88
crp-policy	111
debugging igmp	130
debugging multicast forwarding	137
debugging multicast kernel-routing	138
debugging multicast status-forwarding	139
debugging pim common	141
debugging pim dm	142
debugging pim sm	143
display igmp group	283
display igmp interface	284
display igmp-snooping configuration	285
display igmp-snooping group	286
display igmp-snooping statistics	287
display mac-address multicast static	330
display multicast forwarding-table	345
display multicast routing-table	347
display multicast-source-deny	349
display pim bsr-info	385
display pim interface	386
display pim neighbor	387
display pim routing-table	388

display pim rp-info	390
igmp enable	584
igmp group-limit	585
igmp group-policy	586
igmp host-join	588
igmp lastmember-queryinterval	589
igmp max-response-time	591
igmp proxy	592
igmp robust-count	593
igmp timer other-querier-present	603
igmp timer query	604
igmp version	605
igmp-snooping	595
igmp-snooping fast-leave	596
igmp-snooping group-limit	597
igmp-snooping group-policy	598
igmp-snooping host-aging-time	600
igmp-snooping max-response-time	601
igmp-snooping router-aging-time	602
mac-address multicast interface vlan	668
mac-address multicast vlan	669
multicast route-limit	700
multicast routing-enable	701
multicast-source-deny	702
pim sm	781
pim timer hello	782
register-policy	849
reset igmp group	867
reset igmp-snooping statistics	868
reset multicast forwarding-table	875
reset multicast routing-table	877
reset pim neighbor	883
reset pim routing-table	884
service-type multicast	953
source-policy	989
static-rp	1016
NDP	
display ndp	350
ndp enable	708
ndp timer aging	709
ndp timer hello	710
reset ndp statistics	878
Network Protocol	
am trap enable	46
arp check enable	56
arp static	57, 58
arp timer	60
debugging arp packet	119
debugging dhcp client	121
debugging dhcp xrn xha	126, 127
debugging resilient-arp	144
debugging udp-helper	146
display arp	210
display arp timer aging	212
display dhcp client	239

display fib	264, 265
display fib acl	266
display fib ip_address	267
display fib ip-prefix	268
display fib statistics	269
display icmp statistics	281
display ip host	293
display ip interface vlan-interface	294
display ip socket	311
display ip statistics	313
display isolate port	315
display resilient-arp	420
display tcp statistics	463
display tcp status	465
display udp statistics	473
display udp-helper server	472
ip address	633
ip address bootp-alloc	635
ip address dhcp-alloc	636
ip host	637
pim	776
pim bsr-boundary	777
pim dm	778
pim neighbor-limit	779
pim neighbor-policy	780
port isolate	800
reset arp	859
reset ip statistics	869
reset tcp statistics	892
reset udp statistics	896
resilient-arp enable	898
resilient-arp interface vlan-interface	899
tcp timer fin-timeout	1076
tcp timer syn-timeout	1077
tcp window	1078
udp-helper enable	1125
udp-helper port	1126
udp-helper server	1127

NTDP

display ntdp	352
display ntdp device-list	353
ntdp enable	716
ntdp explore	717
ntdp hop	718
ntdp timer	719
ntdp timer hop-delay	720
ntdp timer port-delay	721

Password Control

display password-control	382
display password-control blacklist	383
display password-control super	384
password	758
password-control	759
password-control enable	762
password-control super	764

reset password-control blacklist	880
reset password-control history-record	881
reset password-control history-record super	882

PoE

apply poe-profile	50
display poe interface	391
display poe power	393
display poe power supply	395
display poe-profile	396
poe enable	787
poe legacy enable	788
poe max power	789
poe mode	790
poe power-management	791
poe priority	792
poe update	794
poe-profile	793

Port

broadcast-suppression	80, 81
copy configuration	109
debugging lacp packet	131
debugging lacp state	132
debugging link-aggregation error	133
debugging link-aggregation event	134
description	163
display brief interface	215
display interface	289
display lacp system-id	316
display link-aggregation interface	317
display link-aggregation summary	319
display link-aggregation verbose	320
display port	397
display port-security	398
display transceiver-information interface	470
display unit	474
duplex	520
flow-control	540
interface	631
jumboframe enable	643
lacp enable	645
lacp port-priority	646
lacp system-priority	647
link-aggregation group agg-id description	652
link-aggregation group agg-id mode	653
loopback	659
loopback-detection control enable	660
loopback-detection enable	661
loopback-detection interval-time	663
loopback-detection per-vlan enable	664
mdi	679
multicast-suppression	704
port access vlan	796
port hybrid pvid vlan	798
port hybrid vlan	799
port link-aggregation group	801
port link-type	802

port trunk permit vlan	817
port trunk pvid vlan	818
port-security enable	803
port-security intrusion-mode	804
port-security max-mac-count	806
port-security ntk-mode	807
port-security OUI	809
port-security port-mode	810
port-security timer disableport	813
port-security trap	814
reset counters interface	860
reset lacp statistics	870
speed	991
unicast-suppression	1130
virtual-cable-test	1138

QoS

display mirroring-group	337
display protocol-priority	402
mirroring group	687
mirroring-group mirroring-port	688
mirroring-group monitor-port	689
mirroring-group reflector-port	690
mirroring-group remote-probe vlan	691
protocol-priority protocol-type	827
remote-probe vlan	853

QoS/ACL

acl	36, 37
apply qos-profile	52
apply qos-profile interface	53
debugging webcache	148
display acl	207
display mirror	336
display packet-filter	381
display qos cos-local-precedence-map	405
display qos-interface all	406
display qos-interface line-rate	408
display qos-interface mirrored-to	409
display qos-interface traffic-limit	410
display qos-interface traffic-priority	411
display qos-interface traffic-statistic	412
display qos-profile	413
display queue-scheduler	414
display time-range	469
display webcache	486
ip http acl	638
line-rate	651
mirrored-to	685
mirroring-port	692
monitor-port	694
packet-filter	753, 754
priority	824
priority trust	825
qos cos-local-precedence-map	839
qos-profile	841
queue-scheduler	835

reset acl counter	858
reset traffic-statistic	893
rule	930
snmp-agent community	965
snmp-agent group	966
snmp-agent usm-user	984
time-range	1099
traffic-limit	1112, 1114
traffic-priority	1116, 1118
traffic-redirect	1120
traffic-statistic	1123
wred	1173
Reliability	
debugging vrrp	147
display vrrp	484
reset vrrp statistics	897
vrrp authentication-mode	1161
vrrp method	1163
vrrp ping-enable	1164
vrrp vlan-interface vrid track	1165
vrrp vrid preempt-mode	1166
vrrp vrid priority	1167
vrrp vrid timer advertise	1168
vrrp vrid track	1169
vrrp vrid track detect-group	1171
vrrp vrid virtual-ip	1172
Remote-ping	
count	110
destination-ip	165
display remote-ping	417
frequency	544
remote-ping	850
remote-ping-agent-enable	852
test-enable	1088
test-type	1089
timeout	1101
Routing	
display ospf peer brief	374
display ospf peer statistics	375
display rip interface	422
traffic-share-across-interface	1122
Routing Protocol	
abr-summary	28
apply cost	49
apply tag	54
area	55
asbr-summary	61
authentication-mode	68
checkzero	95
default cost	149, 151
default interval	152

default limit	153
default tag	156
default type	157
default-cost	150
default-route-advertise	154
delete static-routes all	162
display debugging ospf	236
display ip ip-prefix	295
display ip routing-table	296
display ip routing-table acl	297
display ip routing-table ip_address	300
display ip routing-table ip_address1 ip_address2	302
display ip routing-table ip-prefix	303
display ip routing-table protocol	305
display ip routing-table radix	307
display ip routing-table statistics	308
display ip routing-table verbose	309
display memory	333
display memory limit	335
display ospf abr-asbr	358
display ospf asbr-summary	359
display ospf brief	361
display ospf cumulative	363
display ospf error	365
display ospf interface	367
display ospf lsdb	369
display ospf nexthop	371
display ospf peer	372
display ospf request-queue	377
display ospf retrans-queue	378
display ospf routing	379
display ospf vlink	380
display rip	421
display route-policy	433
filter-policy export	528, 529, 531
filter-policy import	532, 534, 536
if-match { acl ip-prefix }	579
if-match cost	580
if-match interface	581
if-match ip next-hop	582
if-match tag	583
import-route	606, 607
ip ip-prefix	639
ip route-static	642
memory auto-establish disable	680
memory auto-establish enable	681
memory safety limit	682
nssa	715
ospf	739
ospf authentication-mode	740
ospf cost	742
ospf dr-priority	743
ospf mib-binding	744
ospf mtu-enable	745
ospf network-type	746
ospf timer dead	748
ospf timer hello	749
ospf timer poll	750
ospf timer retransmit	751
ospf trans-delay	752

peer	765, 766
preference	819, 820
reset	857
reset ospf all	879
rip	906
rip input	909
rip metricin	910
rip metricout	911
rip output	912
rip split-horizon	913
rip version	914
rip work	915
route-policy	923
router id	925
silent-interface	964
snmp-agent trap enable	977
snmp-agent trap enable ospf	979
spf-schedule-interval	992
stub	1068
summary	1069
timers	1109
vlink-peer	1151
RSTP	
display stp ignored-vlan	460
display stp tc	462
stp ignored vlan	1030
stp timeout-factor	1061
SNMP	
display snmp-agent trap-list	448
snmp-agent log	971
Specification Source IP Address	
display ftp source-ip	273
display ftp-server source-ip	272
display sftp source-ip	440
display ssh2 source-ip	455
display ssh-server source-ip	453
display telnet-server source-ip	466
display tftp source-ip	467
ftp cluster remote-server source-interface	548
ftp cluster remote-server source-ip	549
ftp source-interface	556
ftp source-ip	557
ftp-server source-interface	554
ftp-server source-ip	555
sftp source-interface	959
sftp source-ip	960
ssh2 source-interface	1007
ssh2 source-ip	1008
ssh-server source-interface	996
ssh-server source-ip	998
telnet source-interface	1082
telnet source-ip	1083
telnet-server source-interface	1080

telnet-server source-ip	1081
tftp source-interface	1095
tftp source-ip	1096
tftp tftp-server source-interface	1097
tftp tftp-server source-ip	1098

SSH

bye	85
cd	89
cdup	90
delete	160
dir	205
display rsa peer-public-key	435
display ssh server	451
display ssh server-info	452
display ssh user-information	454
exit	524
help	570
ls	665
mkdir	693
peer-public-key end	771
protocol inbound	826
public-key-code begin	830, 831
public-key-code end	832
put	833
pwd	834
quit	837, 838
remove	855
rename	856
rmdir	916
rsa local-key-pair create	926
rsa local-key-pair destroy	928
sftp	956
sftp server enable	958
sftp time-out	961
ssh client assign rsa-key	993
ssh client first-time enable	994
ssh server authentication-retries	995
ssh server timeout	999
ssh user assign rsa-key	1000
ssh user service-type	1003
ssh2	1005

System Access

authentication-mode	67
auto-execute command	71
command-privilege level	106
databits	116
display history-command	279
display user-interface	475
display users	477
flow-control	539
free user-interface	542
header	567
idle-timeout	578
language-mode	648
lock	657
parity	755

return	904
screen-length	941
send	947
service-type	949
set authentication password	954
shell	962
speed	990
stopbits	1023
super	1070
super password	1071
sysname	1072
system-view	1075
telnet	1079
user privilege level	1136
user-interface	1134
System Maintenance and Debugging	
display debugging	234
display debugging fabric by-module	235
display diagnostic-information	256
ftp disconnect	551
reboot	846
System Management	
ascii	62
binary	74
boot bootrom	78
clock datetime	96
clock summer-time	97
clock timezone	99
close	100
copy	108
debugging	117
debugging ntp-service	140
debugging ssh server	145
disconnect	206
display channel	217
display clock	218
display config-agent	225
display cpu	228
display debugging	233
display fan	263
display ftp-server	271
display ftp-user	274
display info-center	288
display mac-address	327, 666
display mac-address aging-time	329
display memory	334
display ntp-service sessions	355
display ntp-service status	356
display ntp-service trace	357
display power	401
display rmon alarm	423
display rmon event	424
display rmon eventlog	425
display rmon history	426
display rmon prialarm	429
display rmon statistics	430

display rsa local-key-pair public	434
display schedule reboot	439
display snmp-agent	441
display snmp-agent community	442
display snmp-agent group	443
display snmp-agent mib-view	444
display snmp-agent statistics	445
display snmp-agent sys-info	447
display snmp-agent usm-user	449
display snmp-proxy unit	450
display version	478
enable snmp trap updown	521
end-station polling ip-address	522
execute	523
file prompt	527
format	541
ftp dir	550
ftp timeout	558
info-center channel name	610
info-center console channel	611
info-center enable	612
info-center logbuffer	613
info-center loghost	614
info-center loghost source	616
info-center monitor channel	617
info-center snmp channel	618
info-center source	619
info-center switch-on	623
info-center timestamp	626
info-center trapbuffer	628
lcd	649
mac-address max-mac-count	667
mac-address timer	670
more	695
move	696
ntp-service access	722
ntp-service authentication enable	723
ntp-service authentication-keyid	724
ntp-service broadcast-client	725
ntp-service broadcast-server	726
ntp-service in-interface disable	727
ntp-service max-dynamic sessions	728
ntp-service multicast-client	729
ntp-service multicast-server	730
ntp-service reliable authentication-keyid	731
ntp-service source-interface	732
ntp-service unicast-peer	733
ntp-service unicast-server	735
passive	756
ping	783
remotehelp	854
reset logbuffer	871
reset trapbuffer	895
rmon alarm	917
rmon event	918
rmon history	919
rmon prialarm	920
rmon statistics	922
schedule reboot at	936
schedule reboot delay	938

snmp-agent group	968
snmp-agent local-engineid	970
snmp-agent mib-view	972
snmp-agent packet max-size	973
snmp-agent sys-info	974
snmp-agent target-host	975
snmp-agent trap life	981
snmp-agent trap queue-size	982
snmp-agent trap source	983
snmp-agent usm-user	986
ssh server rekey-interval	997
ssh user authentication-type	1001
ssh user username authentication-type	1004
sysname	1074
terminal debugging	1084
terminal logging	1085
terminal monitor	1086
terminal trapping	1087
tftp get	1092
tftp put	1093
tracert	1110
undelese	1128
undo snmp-agent	1129
user	1133
verbose	1137

VLAN

description	164
display interface VLAN-interface	292
display protocol-vlan interface	403
display protocol-vlan vlan	404
display vlan	479, 480
display voice vlan oui	482
display voice vlan status	483
interface VLAN-interface	632
port	795
port hybrid protocol-vlan vlan	797
protocol-vlan	828
vlan	1140
vlan to	1145
voice vlan	1155
voice vlan aging	1156
voice vlan enable	1157
voice vlan mac-address	1159
voice vlan mode	1158
voice vlan security enable	1160

VLAN-VPN

display port vlan-vpn	400
vlan-vpn enable	1146
vlan-vpn inner-cos-trust	1147
vlan-vpn tpid	1148
vlan-vpn uplink enable	1150